

DIAGRAM #1




DIAGRAM #2




DIAGRAM #3




DIAGRAM #4




DIAGRAM #5




DIAGRAM #6




DIAGRAM #7

BATTERY INSTALLATION

(For maximum performance, use alkaline batteries)

Remember to take out all batteries from vehicle and transmitter after playing.

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable batteries.

ATTENTION PARENTS

It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

HOW TO INSTALL BATTERY IN VEHICLE

1. Make sure the "ON/OFF" switch at the underside of the vehicle is at the "OFF" position. (See Diagram 1)
2. Unscrew to open the battery cover. (See Diagram 1)
3. Insert 5 "AA" batteries by matching the (+) and (-) signs as indicated in the battery compartment.
4. Replace the battery lid.

HOW TO INSTALL BATTERY IN TRANSMITTER

1. Slide open the battery cover at the back of the transmitter and put the 9V battery inside following the engraved sign. (See Diagram 3)
2. Replace the battery cover.

Note: Remove battery after you have finished using your vehicle.

HOW TO PLAY

START TO PLAY

1. Build up antenna by passing the cable through the antenna tube provided and plug into the vehicle tightly. Otherwise, the vehicle will not work. (See Diagram #4)
2. Push the ON/OFF switch to the "ON" position of the vehicle. (See Diagram #5)
3. Operate the vehicle with the transmitter (See Diagram #7).
4. Turn OFF the vehicle and the transmitter after playing and remove all batteries from the transmitter and the car.

FRONT WHEELS STEERING ADJUSTMENT

1. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle. (See Diagram #6)
2. If the vehicle runs towards left, turn "Steering Alignment Lever" towards "R".
3. If the vehicle runs towards right, turn "Steering Alignment Lever" towards "L".

CAUTIONS

1. Do not charge battery pack that is hot, wet or shows leakage or corrosion.
2. May explode if disposed of in fire!
3. Do not disassemble the battery pack.
4. Non-rechargeable batteries are not to be recharged.
5. Rechargeable batteries are to be removed from the toy before being charged.
6. Rechargeable battery pack is only to be charged by adult or by children at least 8 year old.
7. Different types of batteries or new and used batteries are not to be mixed.
8. Only batteries of the same or equivalent type as recommended are to be used.
9. Batteries are to be inserted with the correct polarity.
10. Exhausted batteries are to be removed from the toy.
11. The supply terminals are not to be short-circuited.
12. The antenna wires are not to be inserted into socket outlet.

WARNING: CHOKING HAZARD - SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult your local retailer store or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your product. Changes or modifications not expressly approved by the Responsible Party may cause interference and void the user's authority to operate the equipment.

FCC Note: The antenna installed on the equipment is a unique one. Installation of an unauthorized antenna on this equipment could void the user's authority to operate the equipment.

- "Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

- "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.



EZTEC
www.eztec.hk

EZ-TEC® IS A REGISTERED TRADEMARK OWNED BY SCIENTIFIC TOYS, LTD.

© 2016 SCIENTIFIC TOYS LTD. 1108, TOWER B,
14 SCIENCE MUSEUM ROAD, TSIMSHATSUI, HONG KONG.
PRINTED IN CHINA
O.I. NO.6020

SIZE: 210MM X 297MM PN#65-6020-000-0100