



MINI FLIP BUGGY

OPERATING INSTRUCTIONS:

MINI FLIP BUGGY

The Mini Flip Buggy is powered by a built-in non-replaceable rechargeable battery. The included rechargeable battery is not charged prior to shipment and must be charged before the first use.

INSTALL BATTERIES IN THE CONTROLLER

- Unscrew the battery compartment cover to open. (See Diagram #1)
- Insert four AAA/LR3 batteries by matching (+) and (-) signs indicated in the battery compartment. (See Diagram #2)
- Replace the battery compartment cover, and screw it closed.

CHARGING THE MINI FLIP BUGGY

- Make sure the Mini Flip Buggy's ON/OFF switch is in the OFF position.
- Open the controller's top. Push the button to CHARGE/ON. (See Diagram #3)
- Align the car's metal contact point (on the bottom) with the controller and snap the car in place. (See Diagram #4)
- The RED light will stay ON to show it is charging.
- Once the light turns from RED to GREEN, the Mini Flip Buggy is fully charged. It takes about 30 minutes.
- Press the RELEASE button on the top of the left hand corner of the controller to release your car from the controller.

Caution: After charging the Mini Flip Buggy, take it out from the controller. Overcharging could damage the car and the controller.

CAUTION: BUILT-IN BATTERY SAFETY INFORMATION

- The Mini Flip Buggy includes a non-replaceable battery. Do not open, disassemble or alter the Mini Flip Buggy in any way.
- Adult supervision is required when charging the Mini Flip Buggy.
- Charge battery in an isolated area. Keep away from flammable materials.
- Do not expose to direct sunlight.
- Do not recharge the toy if it is hot. Allow it to cool before recharging.
- Do not allow the batteries to get wet.
- Carefully read the instruction guide and charge the batteries correctly.
- Rechargeable batteries are only to be charged under adult supervision.
- Routinely examine for damage to the plug, enclosure and other parts. In the event of any damage, the toy must not be used with a USB port until the damage has been repaired.

HOW TO PLAY TO BEGIN

- Turn "ON" the controller.
- Turn "ON" the vehicle.

RUNNING FORWARD

- Press both control buttons forward at the same time for forward running. (See Diagram #5)

RUNNING REVERSE

- Press both control buttons backward at the same time for reverse running. (See Diagram #6)

TURNING

- Press the right button forward while pressing the left button backward at the same time to turn left. (See Diagram #7)
- Press the left button forward while pressing the right button backward at the same time to turn right. (See Diagram #8)

STOP OPERATION

To stop the vehicle, release both control buttons. (See Diagram #9)

PERFORMANCE TIPS FOR VEHICLE

- For maximum performance, drive vehicle on smooth ground.
- Avoid driving on uneven surfaces- this could cause damage to vehicle.
- Do not drive car on grass, sand or carpet.
- Do not drive car through water.
- Be sure to rest your vehicle for at least 30 minutes after every 15 minutes of operation.
- Make sure ON/OFF switch on your vehicle is in the "OFF" position when it is not in use.
- Do not bend the antenna.
- Electrical, CB interference, mobile phones, air conditioning, elevators and steel girders in buildings will affect the operation of your vehicle.
- Do not leave the vehicle or transmitter near sources of heat or in direct sunlight for long periods of time.
- Remove the batteries from the vehicle and transmitter when they are not in use.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ATTENTION PARENTS:
IT IS RECOMMENDED THAT THIS TOY AND ALL ACCESSORIES BE PERIODICALLY EXAMINED FOR POTENTIAL HAZARDS AND THAT ANY POTENTIALLY HAZARDOUS PARTS BE REPAIRED OR REPLACED.

www.toysrus.com

Toys R Us®

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

6+

**A
A
X
4
NOT INCLUDED**

Contents and colors may vary.
Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

FAST LANE IS A MARK OF (EST UNE MARQUE DE/ES UNA MARCA DE) GEOFFREY, LLC, A SUBSIDIARY OF (UNE FILIALE DE/UNA SUBSIDIARIA DE) TOYS'R'US, INC. © 2017 GEOFFREY, LLC
MADE IN CHINA (FABRIQUÉE EN CHINE/FABRICADO EN CHINA)
DISTRIBUTED IN THE UNITED STATES BY (DISTRIBUÉE AUX ÉTATS-UNIS PAR/DISTRIBUIDO EN LOS ESTADOS UNIDOS POR)
TOYS'R'US, INC., WAYNE, NJ 07470
IMPORTED BY (IMPORTÉ PAR/IMPORTADO EM)
TOYS'R'US (CANADA) LTD. (LTEE),
2777 LANGSTAFF ROAD, CONCORD, ON L4K 4M5
DISTRIBUTED IN AUSTRALIA BY (DISTRIBUÉE EN AUSTRALIE PAR/
DISTRIBUIDO EN AUSTRALIA POR) TOYS'R'US (AUSTRALIA (AUSTRALIE)) PTY LTD.(LTEE), REGENTS PARK NSW 2143
www.toysrus.com www.toysrus.ca




DIAGRAM 1





DIAGRAM 2

DIAGRAM 3




DIAGRAM 4




DIAGRAM 5




DIAGRAM 6




DIAGRAM 7




DIAGRAM 8




DIAGRAM 9