


Controls



Button Functions

Phone button

- When playing music, press and release to pause music; press and release again to play music.
- When receiving an incoming call, press and release to answer; press and release to end the call.
- Press twice quickly to call the last number dialed.

Note: When playing music and a call comes in, the music will pause and you will hear a ringtone. The music will resume when the call is ended.

Volume up/track forward

- Press to play next track
- Press and hold to raise volume

Volume down/track back

- Press to play previous track
- Press and hold to lower volume

Note: The button functions may vary per device.

Charging

Note: Make sure your BT100 is fully charged before using it for the first time.

- Gently plug the Micro-USB end of the included charging cable into the charge port of the control box.
- Plug the USB end of the cable into a powered USB port, such as a computer, laptop, or a USB AC adapter (not included).
- The LED indicator located on the control box will glow red. Once the headset is fully charged, the LED power indicator will turn off.

Note

- The LED indicator will light up red while charging even if the BTE01 is off.
- You cannot charge your BT100 while listening to music.

Connect via Bluetooth®

(first time set-up)

Note: Adjust the volume of your device and the BT100 to a comfortable volume before use.

- Move the power switch on the side of the BT100 to the "ON" position. The LED indicator light on the control box will flash blue.
- Open the settings on your Bluetooth device (Bluetooth must be enabled).
- Select "SCOSCHE BT100" from the list of Bluetooth devices.
- Once paired, the LED indicator light will flash blue slowly.
- To turn off the BT100, move the power switch on the side to the "OFF" position.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: BT100