


Bluetooth FM Transmitter



1. **LED SCREEN**
ÉCRAN DEL
PANTALLA LED
- *2. **PLAY/PAUSE**
LECTURE/PAUSE
REPRODUCCIÓN/PAUSA
- *3. **CHANNEL BUTTON**
BOUON CANAL
BOTÓN SELECTOR DE CANAL
- *4. **MULTIFUNCTION BUTTON**
BOUON MULTIFONCTION
BOTÓN MULTIFUNCIÓN
- *5. **BACK/VOLUME -**
RECULER/VOLUME -
RETROCEDER/VOLUMEN -
- *6. **FORWARD/VOLUME +**
AVANCER/VOLUME +
AVANZAR/VOLUMEN +
7. **3.5MM AUX IN/OUT**
ENTRÉE/SORTIE AUX 3,5 MM
ENTRADA/SALIDA AUXILIAR DE 3,5 MM
8. **2.4A USB CHARGING PORT**
PORT DE CHARGE USB 2,4A
PUERTO DE CARGA USB DE 2,4A
9. **12V PLUG**
PRISE 12 V
ENCHUFE DE 12 V
10. **REMOTE**
TÉLÉCOMMANDE
CONTROL REMOTO

FEATURES


- Bluetooth hands free calling and music streaming
- USB charging port for charging mobile phones and other devices.
- Auxiliary Input for use with other devices
- Wireless remote control
- Includes audio cable

SPECIFICATIONS:

A2DP Bluetooth calling and audio streaming
FM transmitter frequency range: 88.1-107.9MHZ
Input power: 12VDC
USB output: 5V at up to 2.4 amps

POWER UP AND BLUETOOTH PAIRING

Follow these steps to power up and pair your BTMFREQ to your mobile phone.

1. Plug the BTMFREQ into your cars 12V power socket.
2. Wait for the Bluetooth indicator  to flash.
3. Access the Bluetooth menu on your mobile device, and enable the Bluetooth function. From the list of available accessories find and select "Scosche BTFM3".
4. Your phone will confirm once it is connected, and the Bluetooth indicator will stop flashing.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

CONNECTING TO YOUR CAR'S STEREO

There are two options for connecting the BTMFREQ to your car stereo.

FM RADIO (option 1)

The BTMFREQ has a small FM radio transmitter that can broadcast to your car's stereo.

1. Find a weak station on your FM radio that has no active broadcast signal.
2. Use the CH, then the Forward and Back buttons to tune the BTMFREQ to match the frequency of your FM radio.
3. If you experience interference you may have entered an area where there is an active broadcast signal on the station you are tuned to. Repeat the above steps to find a different clear station.

AUX OUT (option 2)

If your car stereo includes an AUX port you can use the BTMFREQ's AUX out feature.

1. Connect the included audio cable from the AUX IN/OUT port on the BTMFREQ to the AUX port in your stereo.
2. Set your car stereo source to AUX. Consult your vehicle owners manual if you are not sure how.

USING THE BTMFREQ

Once you have paired the BTMFREQ to your phone (see Power up and pairing section) and have connected the BTMFREQ to your stereo (see Connecting to your cars stereo) you can begin using your BTMFREQ.

STREAMING MUSIC

1. Stream music by using the music player on your phone.
2. You can use the controls on the BTMFREQ to play, pause and change tracks.

MAKING AND RECEIVING PHONE CALLS

Making a call

1. Use your mobile phone to make a call as you normally would. Phone call audio will automatically stream through the BTMFREQ.
2. When you are finished talking, press the Multifunction button to hang up.
3. To call the last number dialed you can press the Multifunction button.

Receiving a call

1. Press the Multifunction button once to receive a call.
2. Press the Multifunction button once to end the call.

Voice Assistant activation

Press and hold the Multifunction button for 3 seconds to activate your smart phone's voice assistant.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications.

Le présent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement