



# USER MANUAL

## **1** Precautions

- Liquids - Do not expose your device to liquids or extreme humidity. Liquids can get into the product's circuits, leading to damage and corrosion. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the device.
- Extreme heat/cold – Avoid placing your device near a heat source or in direct sunlight. Extreme temperatures can cause the battery to swell, leak or malfunction.
- Cleaning – Use a clean cotton cloth. Don't use alcohol or other cleaning solutions.
- Never place the device over other electronic devices.
- Do not attempt to repair or take apart the device by yourself.

## **2** Included Accesories

- A. US AC to USB Power Charger Adapter Plug
- B. Micro USB to USB Cable



A



B

*Pictures are for illustration purposes only. Actual items may slightly vary in appearance and design.*

### 3 Device Overview

USB Charging output Jack & Light

Red indicator light – Power indicator


Green Indicator Light – Charger indicator

Blue Indicator Light

Bluetooth Indicator

Device Power on/off switch


Push  key 3 seconds



## 4 Battery Management

1. Connect the Micro USB cable (included) to the Micro USB port on the Powerplay 2 and connect the USB Cable to the Power Charger Adapter Plug.
2. Plug the Adapter Plug into an electrical wall outlet to fully charge the battery (approx. 8 hours).
3. Red indicator light is on while charging and will turn off when fully charged.

***Do not charge additional devices while charging the Powerplay 2, this will damage the device.***



4. The number indicate % of battery life on Powerplay 2.




## 5 Pairing your Bluetooth enabled device to your Powerplay 2

*Powerplay 2 doesn't work with all apps.*


1. Go to your mobile device's Network Settings.
2. Set your Bluetooth device to discover. Follow your device's instruction guide. This usually involves going into a "setup", "connect" or "Bluetooth" menu.

### Step 1 iPhone



Step 1  
Android

**Settings**>Wireless & network settings>  
Bluetooth Settings>Bluetooth devices



Step 2

iPhone

Settings > Bluetooth > Devices



Step 2  
Android

Settings>**Wireless & network settings**>

Bluetooth Settings>Bluetooth devices

**Wireless & network settings**

**Airplane mode**   
Disable all wireless connections

**Wi-Fi**   
Turn on Wi-Fi

**Wi-Fi settings**  
Set up & manage wireless access points

**Bluetooth**

**Bluetooth settings**  
Manage connections, set device name & discoverability

**VPN settings**  
Set up & manage Virtual Private Networks (VPNs)



3. Push **▶||◀** key 3 seconds to turn on Bluetooth.
4. Locate the Powerplay 2 on your Bluetooth device & select "Powerplay2" from the list. Keyin password "0000".
5. Your Powerplay 2 will beep when pairing is complete.
6. Using **▶||◀** key to play and pause music playing.

### Step 3


#### iPhone


Settings>**Bluetooth**>Devices



Step 3  
Android

Settings>Wireless & network settings>  
Bluetooth Settings>Bluetooth devices









*In case of unsuccessful pairing, repeat the steps on previous pages.*



## 6 Charging Devices

1. Connect the USB end of the charging cable that came with your mobile device to the OUT port on the Powerplay 2.
2. Connect the micro USB end to your mobile device.
3. During charging, the red indicator light will stay on.



## 7 Hands-free calling

1. Make, receive and end call by push  bottom.
2. Control volume by using Powerplay 2 .
3. When not using the Powerplay 2 bluetooth, press  bottom 3 seconds to turn off to save power.



## 8 Specs

- Weight < 7.4 ounces
- Size: 4.65 inches (L)\*1.54 inches (W)\*1.54 inches (H)
- Rechargeable Battery: Lithium - polymer 3.7V 5200 mAh
- Power Consumption: DC5V/500mA ~1A
- Super High Capacity Rechargeable Battery 5200mAh, about 300% of iPhone 4 battery life
- Speaker Frequency: 100Hz ~ 20KHZ
- Frequency Range: 2.4000Ghz-2.480 GHz
- Input/Output voltage: 5V
- Signal and noise ratio:  $\geq 75$ dB
- Power of loudspeaker: 2W\*2
- Charging time – Approximately 8 hours
- Playing time – Approximately 32 hours (volume at 60%)
- Hands-free calling – Bluetooth connector
- LED indicator Light for Bluetooth
- Effective Distance – up to 33 feet

## 9 Troubleshooting

### No Sound

- Make sure the mobile device is not on mute and your volume is turned up.

### Bluetooth Connection

- Ensure that the speaker and mobile device are within 33 feet of each other.
- Ensure mobile device is still paired with your Powerplay 2.

### No Power

- Device needs to be charged. Connect the device to a USB port and the power adaptor.

## FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

