

RF Perpheral



**FUJIKAM**

## Wireless Door Sensor

RF Perpheral



**FUJIKAM**

### Introduction

Working with Vimtag cloud IP camera, RFC1 is a wireless door sensor which could detect the opening and closing of the doors and windows. It sends an alarm signal to the camera when it detects over 3 cm position offset between the signal transmission module and the magnetic box. Users could receive the alarm message on Vimtag application, and take immediate action to stop the intruders.

### Installation Guide

Step 1: Stick the Transmission module and the Magnetic box on the door or the window, keeping them at a distance of 2 cm or less.

Step 2: Close and open the door or window to see if the red light on the transmission module is on. If the light is on, installation succeeded.

### Add Device

Please make sure you have added cameras to your account before adding the accessories.

#### Adding Procedure:

1. Log in to your account
2. Enter the 'Settings' interface of the camera
3. Select 'Accessory'
4. Select 'Door Sensor'
5. Follow the APP instruction to complete adding.

### Specifications

Battery model: CR2032  
Service life: 2 years  
Power: 12dBm  
Voltage: 2.7V-3.3V  
Working Distance: 80M  
Temperature: -10°C~55°C

### CAUTION

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.