

1 Protection Switich

ON ← → OFF

Note: To keep the battery in good condition, OFF when the product is not in use over 72 hours.

2 AUX

AUX Cable


3 USB phone charging

USB POWER 5V 1A

The phone must be charged properly by USB ports: 5V 1A

4 POWER INPUT

AC110~240V 50/60HZ



5 Volume

Last item ← short press → Next item

volume down ← long press → volume up

8 NFC

Place your phone or PAD on the speaker's NFC detection area.

Click 'Yes' from your device in the first time.

7 Bluetooth button

ON → OFF

Long press to disconnect with the device
Short press to play or pause music


6 Power On/Off

ON → OFF

Long press for Power On/off
Short press for Bluetooth/Line-in mode

Bluetooth Speaker Stylebox P3

Specification



Thank you for using this product of our company. Before using this product, please read the manual carefully.

IMPORTANT

Thank you for using this product of our company. Before using this product, please read the manual carefully.

CAUTION

To maintain the aesthetic quality of the loudspeakers for the long term, placing such in very warm, very cold, or very humid environments should be avoided. Please avoid direct sunlight or excessive brightness. Please don't use it under the high humidity and temperature environment.

Do not charge the speaker with other unsuitable AC/DC power adaptor, it may cause damage to the speaker. The sharp peaks of the spikes may cause injuries and damage sensitive some surfaces may be made by glass. If you do not use the speaker for long periods, be sure to store it in a dry place, free from extreme temperature, humidity and dust.

Do not use abrasive cleaning solvents to clean the speaker. Battery shall not be exposed to excessive heat such as sunshine, fire or the like.

ACCESSORIES

- main body User's Manual
- USB cable AUX Cable

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Trouble shooting guide

Trouble	Trouble shooting guide
No sound	Please check whether the volume set is too low. Please check whether the product connect with the adapter correctly. Please check the battery.
Noise	Please check whether the cable connect with the adapter correctly. Please change another cable. Please check whether the external device make the noise.
No charging	Please check whether the USB power adaptor connect with the product correctly. Please check the whether the power suit for the charging power.
Bluetooth Pairing	Please check whether the USB power adaptor connect with the product correctly. Please check the whether the power suit for the charging power.

Trouble	Trouble shooting guide
Bluetooth mode sound intermittent	Please make sure the product connecting with the device in 10m and without obstacle, or you can change to another device to connect.
AUX-In mode doesn't work	Please check the AUX line whether connecting correctly or not. Bluetooth mode sound intermittent

SPECIFICATIONS

Model	Stylebox P3
Drive	40mm4Ω 5W+ 3in 4Ω 15W speaker diaphragm*2
Frequency Response	55Hz-20KHz±3dB
Amplifier	Class D Audio Power Amplifier@10W+5W*2
VRMS	THD<1%
SNR	>75dB(A)
Maximum SPL	92dB+3dB(500mV@1M)
Play Mode	bluetooth/External audio input
Charging Power	DC15V,1.2A
Power Supply	6600mAh-11.1V Li Bttery
Dimensions (W*H*D)	235mmx140mmx75mm
Special Feature:	DSP to improve the sound quality
Bluetooth	NFC Bluetooth4.0V Match Function