

Bluetooth Headset Quick Guide

SX-986

Brand: SUICEN
FCC ID: UHB-SX986

SAFETY PRECAUTIONS

- Please read, follow and keep these instructions
- Heed all warnings on the product and in the operation instructions.
- Stop using this product immediately if it causes discomfort or pain. When using this product, it is recommended that you limit volume to help avoid harm to your ears and danger resulting from being unable to hear what is going on around you.
- Keep the device out of extreme heat and humidity.
- Do not use the device near water, such as sinks, bathtubs, swimming pools, washing machines, tubs of water, etc.
- Using a headphones while driving can distract you and increase the likelihood of an accident.
- Power time may differ depending on personal habits.

WARNINGS!

- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- Prolonged listening at high volume could lead to hearing damage.

PACKAGE CONTENTS

- Bluetooth Headset SX-986.
- USB charging cable.
- Instruction manual.
- 3.5MM Audio cable.

Features

- Bluetooth 4.0.
- Supports two mobile phones.
- Voice prompt
- Earphone battery display on iPhone.
- Foldable Headset.

OVERVIEW OF SX-986

Charging SX-986

- To charge SX-986, plug the included USB charging cable into SX-986 and computer (or an optional USB charger). When SX-986 battery is very low, the red LED will continually flash and a full charge can take up to two hours with solid red LED light. The red LED will turn off when charging has been finished.

CHARGING LI-POLYMER BATTERY SAFELY

- ❖ The headphones has a non-removable lithium-polymer battery.
- ❖ Do not try to remove the battery. Do not dispose of the headphones in a fire, the battery may explode.
- ❖ Dispose of the headphones in accordance with the applicable laws and regulations in your area for the disposal of lithium-polymer batteries.
- ❖ Non-compliance with the conditions of use of the lithium-polymer battery may cause a fire, explosion or chemical burn.
- ❖ Do not allow battery leakage to come into contact with eyes or skin. In case of contact, flush eyes or skin with plenty of water and seek medical advice.
- ❖ Do not expose the lithium-polymer battery to a temperature higher than 60°C.
- ❖ Do not disassemble, crush, short-circuit or incinerate your battery as it may cause fire, injury, burns, or other hazards.
- ❖ Before your first time use, please recharge your headphones.
- ❖ Do not overcharge your player, or it may shorten the battery's life.
- ❖ The times of charge/discharge are no less than 300 cycles.

Connecting SX-986

(Supports two mobile phones)

Product picture in this manual is for demonstration purpose. Actual product may be different.

- Take SX-986 out of package, adjust the length of headband for your comfort.

Have 1st mobile phone paired with SX-986.

a : Long press 'MFB' button for 7 seconds till red/blue indicator lights blink alternately.

b : Turn on Bluetooth in 1st mobile phone, search headset "SX-986" and have devices paired.

Have the 2nd mobile phone connected with SX-986 again.

a: Long press 'MFB' button till indicator light is off ("SX-986" is off) and turn off Bluetooth of 1st mobile phone.

b : Turn on Bluetooth headset "SX-986" again.

c: Turn on 'Bluetooth' in the 2nd mobile phone and it will search Bluetooth headset "SX-986" automatically.

d : Meantime, turn on 'Bluetooth' in your 1st mobile phone. Click previous pairing record and connect.

Using SX-986

Listen to music or make a call.

Play/ Pause.

- Select an audio track or video clip.
- Tap (press less than one second) the Multi-function button to play / pause the audio track or video clip.

- Short press the button " - / + " to have volume up / down function.
- Long press the volume " + / - " button to adjust volume to your favourite.
- Power off the headphone, and plug the provided audio cable for portable music player.

Answer an incoming call

- Connect the headphone to a smart phone. Short press (less than one second) the Multi-function button to answer an incoming call.

End a call.

- Short press (less than one second) the Multi-function button to end the call.

Reject an incoming call.

- Press the Multi-function button for two seconds.

voice dial

- under the headset standby mode, double press the volume down key until you heard "du" prompted to let go.

Voice prompt

"Power On" , "Power Off" , "Pairing" , " Pairing Complete" , "connected" , "Pairing not Complete" , "incoming call" , "disconnected" , "Battery is low" .

A. Long press Multifunctional button until the blue and red LED indicator light flash, SX-986 will prompt "Power On" when turn it on, and prompt "Pairing" under the pairing mode;

B. SX-986 will prompt " Pairing Complete" once it connected with Bluetooth device. It prompts "connected" when successfully connected with Bluetooth device, and it prompts "disconnected" when disconnected. SX-986 will have voice prompt "Pairing not Complete" if not successfully connect with your Bluetooth devices within 10 minutes.

C. SX-986 will prompt "Incoming call" when there is an incoming call.

D. SX-986 will prompt "battery is low" When it is low battery.

E. Long press Multifunctional Button will turn off SX-986, it will prompt "Power Off" .

F. Chinese / English voice prompt switch method : long press both previous and forward button, release when hearing long beep prompts, and then it will switch to Chinese voice prompt. The default setting is English voice prompt.

LED indications

Flashing Blue.	Bluetooth: A connection is made; your headphones is ready to use.
Slow Flashing Red.	The battery is in low power; Headset disconnected.
Short Flashing Red.	When you turn off the headphones successfully, the red LED will short flash and go off.
Solid Red.	Charging, and the red LED will turn off if charging finished.
No light.	Your headphones is power off.

TECHNICAL SPECIFICATION

Correspond with : V4.0
Support : HSP, HFP, A2DP, AVRCP
Transmittig Power : Class2
Working Distance Range : ≤10m
Frequency Range : 2.402GHz-2.480GHz
Charge Time : ≤ 2.5 hours
Talk Time : ≥13.5 hours
Music Time : ≥11 hours
Standby Time : ≥120 hours

TROUBLE SHOOTING

See below for solutions to common problems.

Symptom	Solution
LEDs are not light	Use the provided USB charging cable to charge the battery by referring to the "charging the wireless headphone" in this guide. Check if the headphone is receiving power from your computer's USB port; If the headset is not in charge, please check whether charging connection is connected and make sure the power supply to the headphone is working. Try re-pressing the multi-function button.

Bluetooth not connecting?	Try powering off the headphones, and then power it back on by pressing the Multi-function button. If failed to pair within 3 minutes, re-establish pairing between the headphones and your Bluetooth device by referring to "connecting the wireless headphones" in this guide.
	Try using the headphones with a different Bluetooth device.
	Make sure the Bluetooth feature is activated of your device.
	The light of state will flash slowly when Bluetooth headset connected to your bluetooth device. Bluetooth headset connection standard distance is within 10m.
Distorted sound? No sound at all? Microphone not working?	Make sure the headphones is selected as the active output audio device on your Bluetooth device. Adjust the volume settings to an audible level on both your headphones and Bluetooth devices. Please turn off the headset and charge it when red light flashing and prompt with blue.

Compliance statement

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

(5)

(6)

(7)

(8)

(9)

(10)