


## User manual (1)

### Installation Guide of SiPARK Ground Sensor

- Find and mark the center of the desired location for installation of the SiPARK Ground Sensor
- Core a hole in the parking place. Check the depth as you drill
- Vacuum or brush the hole clear of dust and debris
- Ensure that the hole is dry, if not, please try the hole
- Add part of the epoxy on the bottom of the hole
- Place the SiPARK Ground Sensor in the center of the hole
- Fill the hole with epoxy, and completely covering the SiPARK Ground Sensor, as seen the figure below
- Update the installation records with the sensor ID and physical location.



Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

## User manual (2)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.