

Product protected by Mercedes-Benz and other trademarks. Mercedes-Benz, Mercedes-Benz, SLS AMG are trademarks of Mercedes-Benz Group AG.

**silverlit** Developed by Silverlit Team for Mercedes-Benz Group

Mercedes-Benz logo

www.silverlit.com

Facebook icon: www.facebook.com/silverlit

**Baniville**

Product protected by Mercedes-Benz and other trademarks. Mercedes-Benz, Mercedes-Benz, SLS AMG are trademarks of Mercedes-Benz Group AG.

**silverlit** Interactive Bluetooth (S-C) remote control system

**Mercedes-Benz SLS AMG**

Introduction Manual

QR Code

Apple App Store icon | Google Play Store icon

**silverlit** Interactive Bluetooth (S-C) remote control system

**Mercedes-Benz SLS AMG**

Introduction Manual

**WARNING:** **CHOKING HAZARD - Small Parts. Not for children under 3 years.**

CE mark

**4. Battery Installation**

4 x AA Batteries

Vehicle

**Safety instructions:**

- Do not touch the battery terminals with your fingers.
- Do not use tools to insert or remove the batteries.
- Do not short-circuit the battery terminals.
- Do not use the remote control if the battery is completely discharged.

**PC** **IP67** **Shock Resistant and Waterproof Equipment**

**FCC Statements**

The FCC has granted a certificate of FCC Part 15C Class B digital device for this device. This device complies with Part 15 of the FCC Rules, which limits the radio frequency energy that this device can emit to protect against interference with other radio devices. This device must not be used near a health care facility, such as a hospital, doctor's office, or clinic, and must not be used near an aircraft.

**Radio Frequency Interference**

This device is designed to operate in the 2.4 GHz ISM band, which is a shared band. It may interfere with other radio frequency devices. The user should be notified of such interference by the device.

**Class and Measurement**

Class: Class B

Measurement: Conducted Emissions

**Radio Frequency Interference**

This device is designed to operate in the 2.4 GHz ISM band, which is a shared band. It may interfere with other radio frequency devices. The user should be notified of such interference by the device.

**Class and Measurement**

Class: Class B

Measurement: Conducted Emissions

**2. Part Identification**

2.1 Parts included

Vehicle

**3. Getting Started**

3.1 Connect the remote

**4. Operation Steps**

4.1 Turn on the remote control

4.2 Turn on the car power

4.3 Press the power button

**5. Interface Control Function Description Gesture Mode**

5.1 Control Area Overview

**5.2 Operation Steps: Close the Door and Play Music in Gesture Mode**

When you are sitting in the vehicle and play the music.

Press **OK** button. The vehicle will play the music. The music will play until you press the **OK** button.

To close the door, press **OK** button.

Also, the music will stop when the door is closed.

**6. Interface Control Function Description: Joystick Mode**

6.1 Joystick Mode Overview

**6.2 Operation Steps: Close the Door and Play Music in Joystick Mode**

When you are sitting in the vehicle and play the music.

Press **OK** button. The vehicle will play the music. The music will play until you press the **OK** button.

To close the door, press **OK** button.

Also, the music will stop when the door is closed.

**7. Control Your Vehicle**

7.1 Control Your Vehicle

Control Area Overview

7.2 Gesture Mode 1

7.3 Gesture Mode 2

7.4 Joystick Mode

**8. Interface Indicator Description**

8.1 Gesture Mode

8.2 Joystick Mode

**9. Interface Option Screen Setting**

9.1 Secondary Setting

9.2 Acceleration Count Setting

9.3 To the vehicle

9.4 To the vehicle

**10. Interface Music Player**

10.1 Music Player Overview

10.2 Music Player Overview

10.3 Music Player Overview

**11. Music Player Overview**

11.1 Music Player Overview

11.2 Music Player Overview

11.3 Music Player Overview

**11. Interface Interaction Edit**

11.1 Interface Interaction Edit

11.2 Interface Interaction Edit

11.3 Interface Interaction Edit

**12. Interface Trigger Condition & Sensitivity**

12.1 Interface Trigger Condition & Sensitivity

12.2 Interface Trigger Condition & Sensitivity

12.3 Interface Trigger Condition & Sensitivity

**13. Driving Time**

13.1 Driving Time

13.2 Driving Time

13.3 Driving Time

**14. Environmental Protection**

14.1 Environmental Protection

14.2 Environmental Protection

14.3 Environmental Protection