

Instructions for SBox_K_0024

This system is mainly used for locking or unlocking the doors of the vehicle.

The transmitter sends a radio wave signal while the button is pushed.

The receiver becomes active in response to the signal from the transmitter.

Button Functions



Using the Remote

Ensure you are within range of the vehicle before performing remote functions.

- Press "Lock" button to Lock all doors (horn will honk)
- Press "Unlock" button one (1) time to Unlock driver's door. Press "Unlock" button a second time within 5 seconds to unlock all doors.
- Press and hold "Panic" button to sound alarm
 - Press "Unlock" button to disable alarm

Note: Specific vehicle responses to remote interaction vary from vehicle to vehicle. Please check the vehicle manual for more information.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or and experienced radio/TV technician for help.

RF Warning Statement: This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.