

## 1 Basics

### 1.1 Introduction

To make the best use of your phone, please read this manual carefully. The company launched the phone is user-friendly design and craftsmanship . Powerful file management functions (support T-Flash card). The stylish camera functions、MP3 Player、MP4 Player、Handsfree、More convenient to your work and to bring your amateur fun.

## 2 Preparation before Use

### 2.1 Installing the SIM card, T-Flash memory card and battery

SIM card contains your private information, Where Stores your phone number, PIN, PIN2, PUK, PUK2, and IMEI、Phonebook data and message data, etc.

T-Flash memory card can store mobile audio, video, photos, audio files, etc.

#### Note:

- . When inserted SIM card can be inserted in parallel.
- . When T-Flash memory card is inserted, push down the deck and lift it up and put it into a memory card, and then press the push to make the deck locked.
- . Turn off the phone and then remove or insert the SIM card after a few seconds.

### 2.2 Key Functions

Left softkey	Enter the menu interface.
Right softkey	Enter the contacts; Return.
SND key	Dial or answer a call
END key	When finished, hang up call. Non-standby screen, press to exit the program to the standby screen. Power on / off function when long press.
Up / Down navigation key	Switching the date and time, operator display.

Left navigation keys	Profiles
Right navigation keys	Message
Numeric Keypad	For dialing, SMS and other editing. Key 1^6: Press and call an emergency number in the standby screen Key 0: Open / Close the LED Flashlight Key #: Long press to enter FM player in the standby screen

### 3 Menu Features

#### 3.1 Phonebook

The phone number can be stored for 100 phonebook entries.

#### 3.2 Message

Message Services is a network feature that allows you to send, receive and edit information. For more details, please contact your network operator companies.

#### 3.3 Call center

In the call history screen, you can view detail records of missed calls, received calls, dialed call. Press Options to view, call, send a message, delete, and save it to the phone book, you can also make a call setup.

#### 3.4 Settings

##### 3.4.1 Phone settings

You can set the time and date, language, input method, the standby menu display, dedicated keys, flight mode and LCD backlight.

##### 3.4.2 Profiles

Select the desired mode: general, and silent mode. Here you can set the tone, volume, etc.

##### 3.4.3 Security Settings

Security settings refers to certain features of the phone encryption settings.

To prevent your mobile phone and SIM card against unauthorized use. You can change the phone lock password.

#### **3.4.4 Network Settings**

This function is used to set the phone to find a network.

#### **3.4.5 Restore settings**

In this menu, Enter the phone lock code (default 1122), After determining the phone will automatically restart, Phone settings and parameters returned to the initial settings.

### **3.5 Multimedia**

#### **3.5.1 Camera**

Enter [camera] function, the camera begins to work, Press the middle button it can take pictures while viewfinder status appears on the screen. You can shoot after photo quality, photo size, storage location settings.

#### **3.5.2 Image viewer**

Select [Image viewer] submenu. You can easily view the photos saved in the phone and memory card, Press [Options] button on the selected photo to view, rename, delete and other operations.

#### **3.5.3 FM radio**

You can listen to the radio. Press the option to view the channel list, manual input, and automatic search. Press key \* to switch the Fine tuning / Auto Mode; Press the Up / Down navigation keys to adjust the volume.

#### **3.5.4 Audio player**

**Warning:** Please adjust the volume to an appropriate size when use headphone, in order to avoid hearing damage.

Audio player provides playback or pause, stop, rewind, forward, loop mode, playback order, etc. Press key \*, key # to adjust the volume.

#### **3.5.5 Video recorder**

This function is used to record movies. The phone will automatically named .AVI file format.

#### **3.5.6 Video player**

Video player interface provides playback or pause, full-screen, back, forward, stop, etc. Press key \*, key # to adjust the volume.

#### **3.5.7 Sound recorder**

In the recording screen, press the option to record a new record, see the list of recordings and sound quality settings.

### **3.5.8 File manager**

The phone supports T-flash card. You can use this feature to easily manage the files stored in the phone memory, and the T-Flash card.

## **3.6 Organizer**

### **3.6.1 First Aid Settings**

Setting designated emergency number. After opening mode, long press the number key 1 to 6 in the standby interface, it can automatically dial the emergency number

### **3.6.2 Magnify**

Press the Up or Down navigation keys to zoom in or out. Press the right soft key to exit.

### **3.6.3 Calendar**

To view the date and other relevant information.

### **3.6.4 Alarm**

This function is used to make the phone sounding the alarm tone at a specified time.

### **3.6.5 Calculator**

This phone provides users with computing capabilities, including addition, subtraction, multiplication, and division operations.

### **3.6.6 Led flashlight**

Open or close a LED flashlight function.

## **3.7 Input Method Description**

The phone offers a variety of input methods for you to edit the message, edit contacts, etc.

# FCC Caution.

## **§ 15.19 Labelling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **§ 15.21 Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **§ 15.105 Information to the user.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

(This PHONE meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types:FB305(FCC ID:

2ACLMFB305) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.15W/kg and when properly worn on the body is 0.75W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.