





Wi-Fi智能开关模块 (四通道)



产品参数:
 型号: 4CHR3
 输入: 100-240V AC 16A Max
 输出: 100-240V AC 10A/Gang 16A/Total
 Wi-Fi: IEEE 802.11 b/g/n 2.4GHz
 产品材料: PC V0
 产品规格: 145x90x34mm

使用该设备前请检查以下事项:

- 您的智能手机或平板已连接上一个能上网的2.4G WiFi.
- 使用安卓系统的手机或平板, 系统必须是4.0以上版本.
- 使用苹果手机或iPad时必须能够访问APP商店并下载APP.
- 如果您的无线路由器设置了MAC地址过滤, 请先进入路由器后台关闭MAC过滤功能.



产品使用说明

- 1 在各大应用市场搜索“易微联”或扫码下载安装。




下载免费“易微联”APP

- 2 安装过程如有提示权限请求请选择允许。
- 3 注册账号并登录易微联。


- 4 按照设备外壳指示正确接线。

警告: 接线前请断电


注: 本设备的开关原理是通过控制电路火线的通断, 从而实现电器工作和停止。
 本设备必须零火线供电, 设备才能正常工作。



4.1 控制4路电器或插座示例



4.2 控制单火线开关接线方法 (比如灯具开关)



确保零火线接入无误。

- 5 上电
通电后, 设备首次使用, 默认进入快速模式(Touch), Wi-Fi指示灯呈两短一长闪烁状态。

注意: 三分钟内没有进行配网, 设备将退出快速模式。如需再次进入, 长按触摸开关键5秒直到Wi-Fi指示灯呈两短一长闪烁即可。

- 6 进入易微联, 点击APP上的添加按钮 +



- 8 输入手机当前连接的WiFi密码, 下一步。
- 9 待APP自动添加完成, 给设备命名, 完成添加。
- 10 当设备的WiFi指示灯亮, 即可进行远程控制。




产品安装时, 请确保产品输入线已断开, 以免发生点击。

制造商: 深圳松诺技术有限公司
 进口商: xxxxx
 地址: xxxxx




4-gang Wi-Fi Smart Switch



Specifications:
 Model: 4CHR3
 Input: 100-240V AC 16A Max
 Output: 100-240V AC 10A/Gang 16A/Total
 Wi-Fi: IEEE 802.11 b/g/n 2.4GHz Material: PC V0
 Dimension: 145x90x34mm
 WIFI Frequency Range: 2412-2472MHz for CE
 2412-2462MHz for FCC
 Max Transmit Power: <20dBm

Checklist before using the device

- Your smart phone or tablet has connected to a 2.4G WiFi with internet.
- You have the correct WiFi password.
- Your smart phone or tablet must have access to APP Store, Google Play.
- Make sure your router is MAC-open.



User Guide

- 1 Start with “eWeLink” APP.




- 2 Register an eWeLink account.
- 3 If you have eWeLink account, just log in.


4 Wiring instructions:

Warning: please cut off the power before wiring.


ON/OFF operating principle:
 The connected appliances work/stop through live wire power on/off. The device must be powered by L and N.



4.1 Appliances Wiring Instruction.



4.2 One wire output instruction (Eg: light).



Make sure the neutral wire and live wire connection is correct.

- 5 Power on
After powering on, the device will enter the quick pairing mode (Touch) during the first use. The Wi-Fi LED indicator changes in a cycle of two short and one long flash.

Note: The device will exit the quick pairing mode (Touch) if not paired within 3mins. If you want to enter this mode, please long press the Touch switch for about 5s until the Wi-Fi LED indicator changes in a cycle of two short and one long flash and release.

- 6 Tap + on eWeLink app.



- 8 Input your WiFi SSID & password.
- 9 Name your device to complete.
- 10 When the WiFi LED is on, the device is online. Start to control now!

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 —Reorient or relocate the receiving antenna.
 —Increase the separation between the equipment and receiver.
 —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 —Consult the dealer or an experienced radio/TV technician for help.



To avoid electric shocks, be sure to disconnect the power supply cord when installing the product.

Manufacturer: Shenzhen Sonoff Technologies Co., Ltd.
 Importer: xxx
 Address: xxx
 Statement
 The The 4-gang Wi-Fi Smart Switch shall be so constructed that it can be operated in Eu member states (including Germany, France, Belgium, etc.) shall be so constructed that it can be operated in Eu member states (including Germany, France, Belgium, etc.) without infringing applicable requirements on the use of radio spectrum.