SONOFF®

Waterproof Wi-Fi socket

Model：S55TPB

Parameter:
Input: 100-240V AC 50/60Hz
Wi-Fi: 2.4GHz 802.11 b/g/n
Max. Load: S55TPI: 10A (Interational)
S55TPG: 13A (Britain)
S55TPB: 15A (U.S.A)
S55TPE: 16A (France)
S55TPF: 16A (Germany)
S55TPD: 16A (South Africa)

Checklist before using the device

- Your smart phone or tablet has connected to a 2.4G WiFi with internet.
- You have the correct WiFi password.
- Your smart phone or tablet must have access to APP Store, Google Play.
- Make sure your router is MAC-open.

WiFi — S55
Router
Internet
Server
WiFi/GPRS
APP
Android/IOS

User Guide

1 Start with "EWelink" APP.

EWelink

Download on the App Store
GET IT ON Google Play

2 Register an EWelink account.

3 If you have EWelink account, just log in.

---

4 Installation. Open the waterproof cover, take out the 4 screws. Drill 2 holes to install the box with 2 screws. Connect your L/N/E lines to the PCB connector. Recover the plug on the box. Power up.

WiFi LED/ON-OFF LED
Waterproof Cover
Setting Button/Manual Switch
Power Input

Input: AC 100-240V
N E L

5 Press and hold the button for 7 seconds until the WiFi LED blinks like this: blinks 3 times and on repeatedly.

6 Tap + on EWelink app.

7 Select the "Touch". Click next.

Touch

8 Input your WiFi SSID & password.

9 Name your device to complete.

10 When the WiFi LED is on , the device is online. Start to control now!

Troubleshooting

Q: My device on the app stays "Offline"？

A: The new added device needs 1-2min to connect to WiFi and the Internet. If it stays offline for a long time, please judge the problem by the WiFi LED status:

WiFi led quickly blinks one time every second: The device failed to connect to WiFi:

①Maybe you have entered wrong WiFi password.
②The device is too far away from the router, which causes a weak WiFi signal. Please take it closer. If still failed, try to delete and add again.

WiFi led quickly blinks twice every second:

S55 has connected to WiFi but failed to connect to server. Please check your network connectivity.

Scan the right QR code to read the pairing instructions for Amazon Echo and Google Nest.

Scan to download EWelink free APP

Scan to read the detailed user guide

SONOFF®

防水WiFi智能插座

型号：S55TPB

产品参数:
输入电压: 100-240V AC 50/60Hz
WiFi标准: 2.4GHz 802.11 b/g/n
最大负载: S55TPI: 10A
S55TPG: 13A
S55TPB: 15A
S55TPE/F/D: 16A

使用该设备前请检查以下事项：

- 您的智能手机或平板已连接上一个能上网的2.4G WiFi。
- 使用安卓系统的手机或平板，系统必须是4.0以上版本。
- 使用苹果手机或iPad必须能够访问APP商店并下载APP。
- 如果您的无线路由器设置了MAC地址过滤，请先进入路由器后台关闭MAC过滤功能。

WiFi — S55
无线路由器
互联网
云服务器
WiFi/手机流量
APP
苹果/安卓手机

产品使用说明

1 在各大应用市场搜索"易微联"或扫码下载安装。

下载免费"易微联"APP

2 安装过程如有提示权限请求请选择允许。

3 注册账号并登录易微联。

---

4 安装操作：打开防水面罩，卸下插座面板上的4颗螺丝。使用螺丝和胶塞将底盒固定在开孔位置。将进线的零火地三根线正确接到电路板的接线端上。重新用螺丝将插座面板安装回去，完成后即可接通电源。

WiFi 指示灯/开-关指示灯
防水面盖
配对按钮/手动开关
防水进线口

可输入 100V至240V 交流电
零 地 火

5 APP添加设备：长按插座上的配对按钮7秒左右，直到插座上的WiFi指示灯快闪（闪两下亮一秒）松开。

6 进入易微联，点击APP上的添加按钮 +

7 选择"Touch"快速配对模式，下一步。

Touch

8 输入您的WiFi名和密码，下一步。

9 待APP自动添加完成，给设备命名，完成添加。

10 当设备的WiFi指示灯长亮，即可进行远程遥控。

常见问题：设备添加成功后，显示离线，无法控制？

答：设备刚添加成功后，需要一两分钟时间连接您的路由器并联网。如果长时间还是显示不在线，请根据设备WiFi指示灯的状态来判断：

一秒快闪一下：说明设备没有连上您的WiFi。

①可能是WiFi密码输入不正确。
②可能是设备离您的路由器太远，信号太弱，或环境有干扰。请先将设备靠近路由器，如无改善，请重新添加一遍。
③设备不能识别5G的WiFi，请选择2.4G的WiFi重新添加。
④检查您的路由器后台是否开启MAC地址过滤。如有，请关闭。

一秒快闪2下：说明设备已连接到了WiFi但没有连上外网。

请确认您的WiFi当前连接外网是否稳定、正常。如时好时坏，频繁出现这种双闪情况，说明您的网络不稳定，并非产品原因。

*扫码阅读使用NEST、ALEXA语音关联控制的教程。

ewelink.coolkit.cc
扫码阅读最新的使用说明和帮助