

Contents

Getting started	4	Connectivity	63
Assembling the phone, SIM card, battery, making a call.		Internet and email settings, synchronizing, Bluetooth™ wireless technology, infrared.	
Getting to know your phone	8	More features	72
Phone overview, using the menus, entering letters, file manager.		Time and date, alarm clock, calendar, tasks, SIM card lock, etc.	
Calling	17	Troubleshooting	81
Calls, phonebook, voice control, call options.		Why doesn't the phone work the way I want?	
Messaging	36	Additional information	84
Text messaging, picture messaging, email, My Friends, messaging glossary.		Sony Ericsson Web site, safe and efficient use, warranty, declaration of conformity.	
Imaging	51	Icons	91
Camera, video recorder, pictures, screen saver.		Icon descriptions.	
Entertainment	57	Index	93
Media player, sounds, themes, games.			

Sony Ericsson

GSM 900/1800/1900

First edition (March 2004)

This manual is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this manual.

All rights reserved.

© Sony Ericsson Mobile Communications AB, 2004

Publication number: AE/LZT 108 6824 R1A

Please note:

Some of the services in this manual are not supported by all networks. *This also applies to the GSM International Emergency Number 112.*

Please contact your service provider if you are in doubt whether you can use a particular service or not.

Please read the *Guidelines for safe and efficient use* and the *Limited warranty* chapters before you use your mobile phone.

The *Bluetooth* word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license.

T9™ Text Input is a trademark or a registered trademark of Tegic Communications.

T9™ Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, and 6,011,554; Canadian Pat. No. 1,331,057; United Kingdom Pat. No. 2238414B; Hong Kong Standard Pat. No. HK0940329; Republic of Singapore Pat. No. 51383; Euro. Pat. No. 0 842 463 (96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; and additional patents are pending worldwide.

Java and all Java based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

End-user license agreement for Sun™ Java™ J2ME™.

- 1 Restrictions: Software is confidential copyrighted information of Sun and title to all copies is retained by Sun and/or its licensors. Customer shall not modify, decompile, disassemble, decrypt, extract, or otherwise reverse engineer Software. Software may not be leased, assigned, or sublicensed, in whole or in part.

2 Export Regulations: Software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software. Software may not be downloaded, or otherwise exported or re-exported (i) into, or to a national or resident of, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (as such listing may be revised from time to time) or any country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nations or the U.S. Commerce Department's Table of Denial Orders.

3 Restricted Rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 252.227-7013(c) (1) (ii) and FAR 52.227-19(c) (2) as applicable.

Part of the software in this product is copyright © SyncML initiative Ltd. (1999-2002). All rights reserved.

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

Getting started

Getting started

Assembling the phone, SIM card, battery, making a call.

More information and downloads are available at www.SonyEricsson.com.

Instruction icons

The following instruction icons appear in this user guide:

- ▶ Use the selection keys or the navigation key to scroll and select. ➤ *10 Navigating the menus.*
- See also page ...
- ! Important
- Note
- Contact your service provider for details. ➤ *6 Available services.*

Assembly

Before you can use your phone you need to:

- Insert the SIM card.
- Attach and charge the battery.

SIM card

When you register as a subscriber with a service provider, you get a SIM (Subscriber Identity Module) card. The SIM card contains a computer chip that keeps track of your phone number, the services included in your subscription, and your phonebook information, among other things.


- ! *If you have been using a SIM card in another phone, make sure that your information is saved to the SIM card before you remove it from the other phone. For example, contacts may have been saved in the phone memory ➤ 19 Phonebook.*


SIM card and battery information

Always turn off the phone and detach the charger before you insert or remove a SIM card.

- ! *It may take up to 30 minutes before the battery icon appears when charging.*

To insert the SIM card and charge the battery



- 1 Insert the SIM card. Make sure the SIM card is placed under the silvery holders.
- 2 Place the battery on the back of the phone with the label side up and the connectors facing each other.
- 3 Place the back cover as shown in the picture and slide it into place.
- 4 Open the connector cover and connect the charger to the phone at the flash symbol. The flash symbol on the charger plug must face upwards.
- 5 It may take up to 30 minutes before the battery icon appears on the screen.
- 6 Wait approximately 4 hours or until the battery icon indicates that the battery is fully charged. If you do not see the battery icon after this time, press any key or  to activate the screen.
- 7 Remove the charger by tilting the plug upwards.


PIN (Personal Identity Number)


You may need a PIN (Personal Identity Number) to activate the services in your phone. Your PIN is provided by your service provider. When you enter your PIN, the digits are hidden with an *, unless your PIN starts with the same digits as an emergency number, for example 112.

Getting started

This is so that you can see and call an emergency number without entering a PIN


► *19 Emergency calls.*

If you make a mistake while entering your PIN, delete the number by pressing .

 *If you enter the wrong PIN three times in a row, the SIM card is blocked and the message PIN blocked appears. To unblock it, you need to enter your PUK (Personal Unblocking Key), ► 78 SIM card lock.*

Available services

Some services and functions described in this user guide are network- or subscription-dependent. Because of this, all menus may not be available in your phone.

 This symbol indicates that a service or function is network- or subscription-dependent.

Please consult your service provider for more information about your subscription.

Turning on the phone and making calls

Make sure that the phone is charged before you turn it on. When you have turned the phone on, you can use a setup wizard to quickly and easily prepare your phone for use.

Setup wizard

You can use the setup wizard to help you get started with the basic settings in your phone. If you do not want help the first time you turn on your phone, you can select to use the wizard later. You can also select to start the wizard from the menu system at any time. The wizard gives you tips on how to use the keypad and guides you through the following settings:


- Time and time format.
- Date and date format.
- Copying names and numbers from your SIM card to Contacts in the phonebook.


To start the setup wizard from the menu system

- 1 ► Settings ► the General tab ► Setup Wizard.
- 2 Select language for your phone.
- 3 To use the wizard ► Yes and follow the instructions that appear.

Getting started

To turn on the phone



- 1 Press and hold .
- 2 Enter your PIN if you have one for your SIM card.
- 3 At first start-up, select the language you want for your phone, that is, the language for the menus.
- 4 **► Yes** if you want the setup wizard to help you get started, and follow the instructions that appear.

To make and receive calls


- Enter the area code and phone number **► Call** to make the call. **► End Call** to end the call.
- When the phone rings **► Yes**.

Getting to know your phone

Getting to know your phone

Phone overview, using the menus, entering letters, file manager.

Phone overview



- 1 Infrared port.
- 2 Press and hold to activate the camera and video recorder.
- 3 Volume buttons.
- 4 Screen.
- 5, 11 Selection keys.
- 6 Press once to go back one level in the menus. Press and hold to return to standby.
- 7 Stereo headset and charger connector. Connector cover.
- 8 Press and hold to turn the phone on/off.
- 9 Speaker.
- 10 Internet button.
- 12 Navigation key. Press to enter the desktop menu. Move through menus, lists and texts.
- 13 Delete numbers, letters or an item from a list.
- 14 Microphone.

Getting to know your phone

Overview, menu

- | | | | | | |
|--|---|--|--|---|---|
| <p>1. Sony Ericsson*</p> | <p>2. Internet Services*</p> | <p>3. Entertainment
Games
MusicDJ™
Record Sound</p> | <p>4. Camera</p> | <p>5. Messages
Write New
Inbox
My Friends
Call Voicemail
Email
Drafts
Templates
Outbox
Sent Items
Saved Items
Settings</p> | <p>6. Radio</p> |
| <p>7. File Manager
Pictures
Sounds
Videos
Themes
Games
Applications
Other</p> | <p>8. Phonebook**
Contacts
Options:
Speed Dial
My Business Card
Groups
SIM Numbers
Special Numbers
Advanced</p> | | <p>8. Phonebook**
SIM Numbers
Options:
Speed Dial
My Business Card
Contacts
Special Numbers
Advanced</p> | <p>9. Media Player</p> | |
| <p>10. Connect
Online Services
Bluetooth
Infrared Port
Synchronization
Mobile Networks
Data Comm.
Internet Settings
Streaming Setting
Accessories</p> | <p>11. Organizer
Calendar
Tasks
Notes
Applications
Alarm Signal
Timer
Stopwatch
Calculator
Code Memo</p> | <p>12. Settings
General
Profiles
Time & Date
Language
Voice Control
Phone Status
Shortcuts
Locks
Setup Wizard
Master Reset</p> | <p>Sounds & Alerts
Ring Volume
Ringtone
Silent Mode
Vibrating Alert
Message Alert
Key Sound</p> | <p>Display
Wallpaper
Themes
Startup Screen
Screen Saver
Light</p> | <p>Calls
Forward Calls
Manage Calls
Time & Cost
Show or Hide No.
Handsfree</p> |


**Please note that some menus are provider- network- and subscription-dependent.*

***The menu depends on which phonebook is selected as default.*

Getting to know your phone

Navigating the menus

The main menus are shown as icons on the desktop. Some submenus include tabs that appear on the screen. Scroll to a tab with the navigation key and select an option.



- 1 Press to go to the desktop.
Press to select highlighted items.
Move , , , through menus and tabs.
- 2 Press to go back one level in the menus.
Press and hold to return to standby.
- 3 Press to select the options shown immediately above these keys on the screen.

Phone language

Most SIM cards automatically set the language used in the menu to the language of the country where you bought your SIM card. If this is not the case, the predefined language is English. If you use the setup wizard to help you get started with your phone, you will be asked to select phone language, 6 *Setup wizard*.

- You can always choose *Automatic language* by pressing 8888 in standby.
You can always choose *English* by pressing 0000 in standby.

To change the phone language

- 1 Settings the General tab Language Phone Language.
- 2 Select a language.

Help texts

More information, explanations or tips about selected features, menus or functions are available in your phone.

To get help

Scroll to the menu item Info.

Shortcuts

A quicker way to move through the menus is to use shortcuts. You can use keypad shortcuts or you can create your own shortcuts from standby.

Using keypad shortcuts

Enter the menus by pressing **Ⓞ** and then enter the number of the menu to which you want to go. For example, to reach the fifth menu item, press **(5)**. To reach the tenth, eleventh and twelfth menu items, press **(*)B/A**, **(D+)** and **(#↵)** respectively. To get back to standby, press and hold **(←)**.

Creating standby shortcuts

You can create your own shortcuts and use **Ⓞ** to go directly to that function.

To create a standby shortcut

- 1 Press **Ⓞ** in a direction for which there is no predefined shortcut. ► **Yes** when you are asked if you want to create a shortcut.
- 2 Scroll to a function that you want to create a shortcut to ► **Shortcut**.

Getting to know your phone

To edit a standby shortcut

- 1 ► **Settings** ► the **General** tab ► **Shortcuts** and select which shortcut you want to edit ► **Edit**.
- 2 Scroll to a function that you want to create a new shortcut to ► **Shortcut**.

More options

► **More** to enter a list of options. There are different alternatives in the list of options depending on where you are in the menus.

Entering letters

There are two ways of entering letters, for example, when writing a message or writing a name in the phonebook:

- Multitap text input

You press each key as many times as needed to show the letter you want.

- T9™ Text Input

The T9 Text Input method uses a built-in dictionary to recognize the most commonly used word for each sequence of key presses. This way you press each key only once, even if the letter you want is not the first letter on the key.

Getting to know your phone

Writing languages

Before you start entering letters, you need to select the languages that you want to use when writing.

When writing, you can switch to one of your selected languages by pressing and holding **(#)**.

To select writing language

- ▶ Settings ▶ the General tab ▶ Language
▶ Writing Language.
- Scroll to the language that you want to use for entering letters and mark each language you want. ▶ OK to exit the menu.

To enter letters using multitap text input

- To enter text, you have to be in a function where text input is possible, for example
▶ Messages ▶ Write New ▶ Text Message.
- Press the appropriate key, **(1)** – **(9)**, **(0)** or **(#)**, repeatedly until the character you want appears on the screen.

Press... to get...

(1)	., - ? ! ' @ : ; / () 1
(2)	A B C Ä Å Æ à ç 2 Γ
(3)	D E F è é 3 Δ Φ
(4)	G H I i 4
(5)	J K L 5 Λ
(6)	M N O Ñ Ö Ø ò 6
(7)	P Q R S B 7 Π Σ
(8)	T U V Ü ü 8
(9)	W X Y Z 9
(0)	+ 0 @ # Ξ Ψ Ω
(#)	space ↵ ¶
(C)	to delete letters and numbers
(*)	to shift between upper- and lower-case letters
(0) – (9)	press and hold to enter numbers

Example:

- To enter an 'A', press **(2)** once.
- To enter a 'B', quickly press **(2)** twice.
- To shift between upper- and lower-case letters, press **(*)**, then enter the letter.
- You can use the volume buttons as a shortcut to certain letters: To enter a 'B', press and hold **(+)** and press **(2)**. To enter a 'C', press and hold **(-)** and press **(2)**.

To enter letters using T9 Text Input

- 1 **► Messages ► Write New ► Text Message.**
- 2 For example, if you want to write the word "Jane", press **(5)**, **(2)**, **(6)**, **(3)**.
- 3 If the word shown is the one you want, press **(#)** to accept and add a space. To accept a word without adding a space, press **(*)**. If the word shown is not the one you want: press **(*)** or **(*)** repeatedly to view alternative words. Accept a word and add a space by pressing **(#)**.
- 4 Continue writing your message. To enter a period or other punctuation marks, press **(1)** and then **(*)** or **(*)** repeatedly. Accept by pressing **(#)**.

Getting to know your phone**To add words to the T9 dictionary**

- 1 While entering letters **► More ► Spell Word.**
- 2 Edit the word by using multitap input. Navigate between the letters with **(*)** and **(*)**. To delete a character, press **(C)**. To delete the entire word, press and hold **(C)**.
- 3 When you have edited the word **► Insert.** The word is added to the T9 dictionary. Next time you enter this word using T9, it will appear as one of the alternative words.

To select another writing method

Before, or while entering letters, press and hold **(*)** to select another writing method.

Options when entering letters

- More** to view a list of options. The list may contain some or all of the following:
- **Add Symbol** – symbols and punctuation marks such as ? and , are shown. Move between the symbols by using **(*)**, **(*)**, **(*)** and **(*)**.
 - **Add Item** – pictures, melodies and sounds.
 - **Spell Word** – for T9 Text Input only. Edit the suggested word by using multitap text input.
 - **Text Format** – change style, size and alignment.

Getting to know your phone

- **Writing Language** – a list of available languages is shown.
- **Writing Method** – a list of methods available for the current language is shown.
- **Dictionary (T9)** – turn T9 text input on or off.
- **Word Suggestions** – select to view, or not, word suggestions when writing a word.
- **My Words** – manage the words that you have added to the dictionary.
- **National Chars.** – turn off language-specific characters to save space. This option appears only for some writing languages.

File manager

Items such as pictures, videos, sounds, themes and games are saved as files in folders. All files that the phone cannot recognize are saved in the **Other** folder. The phone has several predefined folders. You can create your own subfolders in the predefined folders to which you can move your saved files.

When handling files, you can select several files at the same time to delete, send or move to a folder.

To move a file to a folder

- 1 ▶ **File Manager** and select a folder.
- 2 Scroll to a file, for example, a picture that you want to move ▶ **More** ▶ **Manage Files** ▶ **Move to Folder**.
- 3 Select the folder you want to move the file to, or select **New folder** and name the folder ▶ **OK**.

To create a subfolder

- 1 ▶ **File Manager** and select a folder.
- 2 ▶ **More** ▶ **Manage Files** ▶ **New Folder** and enter a name for the folder.
- 3 ▶ **OK** to save the folder.

To select several files

- 1 ▶ **File Manager** and select a file ▶ **More** ▶ **Mark Several**.
- 2 Scroll and select more files by pressing **Mark** or **Unmark**.

File information













Items that are downloaded or received using Bluetooth wireless technology, the infrared port, text or picture messages may be copyright-protected. If a file is protected, you may not be able to copy or send that file – a message will appear to inform you about this. You can also select to view information for the file.

Getting to know your phone







Quick keys

Useful key combinations are described below.

Navigating menus

- Enter the main menu and select menu items 
- Navigate in the menu and lists    
- Delete an item press  when in lists
- Enter a list of options  **More**
- Enter the status menu to see, for example, date, profile, free memory and model name press a volume button once
- Change the language to **Automatic**  8888 
- Change the language to **English**  0000 
- Go back to standby press and hold 

Making and receiving calls

- Make an emergency call enter the international emergency number
▶ **Call**
- Set the phone to silent press and hold 
- Call your voicemail press and hold 
- Enter call list ▶ **Calls**
- Voice dial press and hold a volume button or say your magic word
- Reach a contact beginning with a specific letter press and hold any of the keys  - 
- Speed dial press any of the number keys  -  and ▶ **Call**
- Reject a call quickly press a volume button twice when receiving a call or ▶ **No**

Getting to know your phone

Turn off the ringtone when receiving a call

Put a call on hold

Retrieve a call

Turn off the microphone

Enter a list of options

Entering letters

Shift between upper- and lower-case letters

Delete letters and numbers

Shift between multitap or T9 Text input methods

Shift between writing languages

Enter numbers

Enter the + sign

press a volume button once or press **C**

▶ Hold

▶ Retrieve

press and hold **C**

▶ More

press *****, then the letter

press **C**

press and hold *****

press and hold **#**

press and hold any of the number keys

press and hold **D**

Enter a *p* (pause)

press and hold ***** when entering numbers or saving codes

Using multitap text input

Reach the second letter or character of a key

press and hold **+** and press any of the number keys

Reach the third letter or character of a key

press and hold **-** and press any of the number keys

Enter a space

press **#**

Using T9 Text Input

View alternative words

⊙ or **⊙**

Accept a word and add a space

press **#**

Enter a full stop

press **1**

View alternative punctuation marks

press **1**, then **⊙** or **⊙** repeatedly

Calling

Calls, phonebook, voice control, call options.

Making calls


Before you can make or receive any calls, you must turn on the phone and be within range of a network.

➔ 6 *Turning on the phone and making calls.*

Networks

When you turn on the phone, it automatically selects your home network if this is within range. If it is not within range, you may use another network, provided your service provider has an agreement that allows you to do so. This is called roaming.

You can select the network you want to use, or you can add a network to your list of preferred networks. You can also change the order in which networks are selected during an automatic search. For all such options ▶ **Connect** ▶ **Mobile Networks**.

 *You can call numbers from the call list and the phonebook, ➔ 23 Call list, and ➔ 19 Phonebook. You can also use your voice to make calls, ➔ 24 Voice control.*




To make a call

- 1 Enter the area code and the phone number.
- 2 ▶ **Call** to make the call.
- 3 ▶ **End Call** to end the call.

To change the speaker volume during a call

Use the volume buttons on the side of the phone to increase or decrease the speaker volume during a call.

To turn off the microphone during a call

- 1 Press  ▶ **Mute Microphone**, or press and hold  until the icon for muted microphone is displayed.
- 2 ▶ **Replace?**, or press and hold  again to resume the conversation.

Receiving calls

When you receive a call, the phone rings and **Answer?** is displayed.

If your subscription includes the Caller ID service and the caller's number is identified, the number is displayed.

Calling

If you have saved the number in the phonebook, the name and number are displayed. If you have assigned a picture to a contact, the picture is also displayed. If the number is a restricted number, Withheld is displayed.

To answer a call

► Yes.

To reject a call





► No or quickly press a volume button twice.

Missed calls

If you have missed a call, **Missed Calls:** appears in standby indicating the number of missed calls.

► Yes to view the missed calls in the call list.

If you want to view the missed calls later ► No.

Use , ,  and  to scroll between the tabs.

To check your missed calls


- 1 From standby ► **Calls** and scroll to the missed calls tab.
- 2 To call a number from the list, scroll to the number ► **Call**.

Automatic redialing

The phone redials the number up to ten times or until:

- The call is connected
- You press **Cancel**
- You receive a call

Automatic redialing is not available for data calls.

 *Do not hold the phone to your ear while waiting. When the call is connected, the phone gives a loud signal.*


To redial a number

If the connection of the call failed and **Retry?** is displayed ► **Yes**.

Making international calls


When you make an international call, the + replaces the international prefix number of the country from which you are calling.

To make international calls

- 1 Press and hold  until a + sign appears on the screen.
- 2 Enter the country code, area code (without the leading zero) and phone number ► **Call**.

Emergency calls

Your phone supports the international emergency numbers 112, 911 and 08. This means that these numbers can normally be used to make an emergency call in any country, with or without a SIM card inserted if a GSM network is within range.

 *In some countries, other emergency numbers may also be promoted. Your service provider may therefore have saved additional local emergency numbers on the SIM card.*

To make an emergency call

Enter, for example, 112 (the international emergency number) ► Call.

To view your local emergency numbers

► Phonebook ► Options ► Special Numbers
► Emergency Nos.





Phonebook

You can save your phonebook information in the phone memory as contacts or on the SIM card as names and numbers. You can choose which phonebook – contacts or SIM numbers – is shown as default.

For useful information and settings in either of these phonebooks ► Options.


Contacts

You can save up to 510 numbers in your contacts. You can also add pictures, ringtones and personal information, such as email, Web and street addresses, to the contacts.

When you add information to a contact, the information is organized under five tabs. Use , ,  and  to scroll between the tabs and their information fields.

SIM numbers

On your SIM card, you can save entries as a name with a single number. The number of entries you can save depends on the amount of memory available on the SIM card, see **Phonebook** ► Options ► Advanced ► Memory Status.

 Contact your service provider for more information.

Contacts or SIM numbers as default phonebook

If you select to use contacts as default, your phonebook will show all information saved in contacts. If you select SIM numbers as default, the phonebook will only show names and numbers saved on the SIM card.

Calling

To select contacts or SIM numbers as your phonebook

- 1 ▶ Phonebook ▶ Options ▶ Advanced
▶ My Phonebook.
- 2 Select Contacts or SIM Numbers.

To add a contact

- 1 ▶ Phonebook ▶ New Contact ▶ Add.
- 2 Enter the name directly or press Add and enter the name ▶ OK.
- 3 Enter the number directly or press Add and enter the number ▶ OK.
- 4 Select a number type.
- 5 Scroll between the tabs and select fields to enter more information. To enter symbols, for example, @ in an email address ▶ Symbols and select a symbol ▶ Insert.
- 6 When you have entered the information you want for your contact ▶ Save.

To add a SIM number

If SIM numbers is your default phonebook, follow the same steps as for adding a contact. You can add only name and number to the SIM numbers phonebook.

Pictures and personal ringtones

You can add a picture and a personal ringtone to a phonebook contact. When that person calls, the picture is displayed (provided your subscription supports the Caller ID service) and the ringtone is played.

To add a picture or a personal ringtone to a contact

- 1 ▶ Phonebook and select the contact you want to add a picture or ringtone to ▶ More ▶ View & Edit.
- 2 Scroll to the relevant tab and select **Picture:** or **Ringtone:** ▶ Edit. This takes you to **Pictures** or **Sounds** in the **File Manager** menu.
- 3 Select a picture or sound. ▶ Save to save the picture or sound.



Calling from the phonebook

You can call one of the numbers saved for one of your contacts, or a number on your SIM card.

If contacts is the default phonebook, you can choose to call from contacts or from the SIM card.

If SIM numbers is the default phonebook, you can only call the numbers on the SIM card.

To call a contact

- 1 ▶ **Phonebook**. Scroll to or enter the first letters of the contact you want to call.
- 2 When the contact you want to call is highlighted, press  or  to select a number ▶ **Call**.

To call a SIM number

- 1 ▶ **Phonebook**. If SIM numbers is the default phonebook, select the name and number you want to call from the list ▶ **Call**.
- 2 If Contacts is the default phonebook
▶ **Phonebook** ▶ **Options** ▶ **SIM Numbers** and select the name and number you want to call from the list ▶ **Call**.

Ask to save

When you end a call, the phone can prompt you to add a phone number or email address to your contacts.

To activate ask to save in contacts

- ▶ **Phonebook** ▶ **Options** ▶ **Advanced**
▶ **Ask To Save** ▶ **On**.

Updating the phonebook

When needed, you can easily update and edit any information in your phonebook.


To edit a contact

- 1 ▶ **Phonebook** and select a contact ▶ **More**
▶ **View & Edit**.
- 2 Scroll to the relevant tab and edit the information you want to edit ▶ **Save**.

To edit SIM numbers

- 1 If SIM numbers is your default phonebook
▶ **Phonebook** and the number you want to edit. If contacts is your default phonebook
▶ **Phonebook** ▶ **Options** ▶ **SIM Numbers**.
Select the name and number you want to edit.
- 2 ▶ **More** ▶ **Edit** and edit the name and number.

To delete a contact or a SIM number

▶ **Phonebook** and scroll to the contact or SIM number you want to delete, press .

Calling

To delete all contacts

- 1 ▶ Phonebook ▶ Options ▶ Advanced
▶ Delete All Contacts.
- 2 ▶ Yes and enter the phone lock code ▶ OK.
The default phone lock code is 0000.
Names and numbers that are saved on the SIM card are not deleted.

Default items for contacts

You can choose which item – a phone number, email address or a Web address – that is displayed first for each contact.

To set the default item for a contact

- 1 ▶ Phonebook and scroll to a contact ▶ More
▶ Default.
- 2 Select the phone number, email address or Web address that you want as default item.

Copying contacts

You can copy SIM numbers to and from your contacts and the SIM card. Choose if you want to copy all SIM numbers, or a SIM number.

! *When you copy from the phone, all existing information on the SIM card will be replaced.*

To copy names and numbers to the SIM card

- 1 ▶ Phonebook ▶ Options ▶ Advanced
▶ Copy to SIM.
- 2 Select Copy All or Copy a Number.

To copy SIM numbers to contacts

- 1 ▶ Phonebook ▶ Options ▶ Advanced
▶ Copy from SIM.
- 2 Select Copy All or Copy a Number.

Sending contacts

You can send contacts using Bluetooth wireless technology, the infrared port or a text or picture message.

To send a contact

- 1 ▶ Phonebook and select a contact ▶ More
▶ Send Contact.
- 2 Select a transfer method.

To send all contacts

- ▶ Phonebook ▶ Options ▶ Advanced
▶ Send All Contacts and select a transfer method.

Checking the memory

With the memory status function in your phonebook, you can check how many positions you have left in the phone memory and SIM memory.

To check the memory

- ▶ Phonebook ▶ Options ▶ Advanced
- ▶ Memory Status.

Synchronizing contacts

You can back up and synchronize your contacts with a phonebook on the Web. For more information about a phonebook on the web, please contact your service provider.

- 1 ▶ Phonebook ▶ Options ▶ Sync. Contacts
▶ Select.
- 2 If you have more than one account, select which account to use ▶ Select. If you do not have an account in the phone, ➔ 67 To enter the remote synchronization settings.

Call list

The numbers of the last 30 calls that you have made are saved in the call list. If your subscription includes the Caller ID service and the caller's number is identified, the call list also shows the numbers of answered and missed calls.

In addition to the call list with all numbers, there are also separate lists for dialed, answered and missed calls, organized under tabs.

To call a number from the call list

- 1 ▶ Calls from standby and select a tab.
- 2 Scroll to the name or number you want to call
▶ Call.

To clear the call list

- ▶ Calls and scroll to the tab with all calls ▶ More
- ▶ Delete all.

Speed dialing

You can save the phone numbers that you want to reach easily in positions 1-9 in your phone and on your SIM card. To speed dial with contacts as default phonebook, numbers have to be saved as contacts, and to speed dial with SIM numbers as default phonebook, numbers have to be saved on your SIM card.

Calling

To speed dial

From standby, enter the position number and ► **Call**.

To set the position number for speed dialing

- 1 ► **Phonebook** ► **Options** ► **Speed Dial** and scroll to the position to which you want to add a phone number ► **Add**.
- 2 Select a number.

To replace a number in the speed dial list

- 1 ► **Phonebook** ► **Options** ► **Speed Dial**.
- 2 Scroll to the number ► **Replace**. Select a new number for the position.

Voice mail

If your subscription includes an answering service, callers can leave a voicemail message when you cannot answer a call.

Receiving a voicemail message

Depending on your service provider, you are informed that someone has left a message by a text message or by a voicemail icon. Press **Yes** to read the text message and call the voicemail service to listen to the message.

Calling your voicemail service

You can easily call your voicemail service by pressing and holding **(1)**. If you have not set your voicemail number, you will be asked if you want to enter the number. ► **Yes** to enter the number. You get the number from your service provider.

To enter the number to your voicemail service

► **Messages** ► **Settings** ► **Voice mail Number**.

Voice control

With your phone, you can use your voice to:

- Voice dial – call someone by saying the name.
- Activate voice control by saying a “magic word”.
- Answer and reject calls when using a handsfree kit.

You can save approximately 30 recorded words as voice commands in the phone. Voice commands cannot be saved on the SIM card. There are 25 seconds available for voice commands.



When recording, make sure that you are in a quiet environment and try to use names that are distinct from each other ► *27 Tips when recording and using voice commands*.

Calling

Before voice dialing

You must first activate the voice dialing function and record your voice commands. An icon appears next to a phone number that has a voice command.

To activate voice dialing and record names

- ▶ Settings ▶ the General tab ▶ Voice Control ▶ Voice Dialing ▶ Activate ▶ New Voice Cmd. and select a contact.
- If the contact has more than one number, use  and  to view the numbers. Select the phone number to which you want to add the voice command. Now you are going to record a voice command such as “John mobile” for the phone number you selected.
- Instructions appear. Lift the phone to your ear, wait for the tone and say the command that you want to record. The voice command is played back to you.
- If the recording sounds ok ▶ Yes. If not ▶ No and repeat step 3.
- To record another voice command for a contact ▶ New Voice Cmd. again and repeat steps 2-5 above.

Caller name

You can choose whether you want to hear the recorded contact name when you receive a call from that contact.

To turn the caller name On or Off

- ▶ Settings ▶ the General tab ▶ Voice Control ▶ Play Caller Name.

Voice dialing

You can voice dial by saying a prerecorded voice command. Start voice dialing from standby using the phone, a portable handsfree, a Bluetooth headset or by saying your magic word.

To make a call from the phone

- From standby, press and hold one of the volume buttons.
- Lift the phone to your ear, wait for the tone and say the name you recorded earlier, for example “John mobile”. The name is played back to you and the call is connected.

To make a call with a handsfree


From standby, press the handsfree button, or Bluetooth headset button.

Calling

The magic word

You can record a magic word and use it as a voice command to allow totally handsfree access to voice dialing. Instead of pressing and holding a volume button to voice dial, you say the magic word and then one of your recorded voice commands.

The magic word is especially suitable when using a car handsfree kit.


 Choose a long, unusual word or phrase that can easily be distinguished from ordinary background speech.

To activate and record the magic word

- 1 ▶ Settings ▶ the General tab ▶ Voice Control ▶ Magic Word ▶ Activate.
- 2 Instructions appear. ▶ Continue and lift the phone to your ear. Wait for the tone and say the magic word.
- 3 Instructions appear. ▶ Continue and select the environments in which you want your magic word to be activated. You can select several alternatives.

Voice answering

You can answer or reject incoming calls by using your voice when using a portable handsfree or a car handsfree kit.

 You cannot use voice answering if you have selected an MP3 file as ringtone.

To activate voice answering and record voice answer commands

- 1 ▶ Settings ▶ the General tab ▶ Voice Control ▶ Voice Answer ▶ Activate.
- 2 Instructions appear. ▶ Continue and lift the phone to your ear. Wait for the tone and say “Answer”, or another word. If the recording sounds ok ▶ Yes. If not ▶ No and repeat step 2.
- 3 Say “Busy”, or another word ▶ Yes.
- 4 Instructions appear. ▶ Continue and select the environments in which you want voice answering to be activated. You can select several alternatives.

To answer a call using voice commands

When the phone rings, say “Answer” and the call is connected.

Calling

To reject a call using voice commands

When the phone rings, say “Busy”. The call is rejected. The caller is forwarded to voicemail, if activated, or hears a busy tone.

Editing your voice commands

You can keep all your voice commands up to date by rerecording them or deleting the ones you do not use. You can also edit a voice command for a phone number in the phonebook. Select the contact you want to edit a voice command for ► **More** ► **View & Edit**. Scroll to the relevant tab and edit your voice command.

To rerecord a voice command

- 1 ► **Settings** ► the **General** tab ► **Voice control** ► **Voice Dialing** ► **Edit Names**.
- 2 Select a voice command ► **More** ► **Replace Voice**.
- 3 Lift the phone to your ear, wait for the tone and say the command.

Tips when recording and using voice commands


If your phone cannot detect speech, one of the following might have happened:

- You spoke too softly – try speaking louder.
- You held the phone too far away – hold it as you do during a call.
- The voice command was too short – it should be around one second long and more than one syllable.
- You spoke too late or too soon – speak immediately after the tone.
- You did not record the voice command when the handsfree was attached – for voice control with a handsfree kit, record when the handsfree is attached.
- You used another intonation – use the same intonation as you did when recording the voice command.

Calling

Forwarding calls

If you cannot answer incoming calls, you can forward them to another number, for example, your answering service.

 *When the Restrict calls function is activated, some Forward calls options are not available.*

You can choose between the following forward options:

- **Always Forward** – forward all calls.
- **When Busy** – forward calls if you are already on the phone.
- **Not Reachable** – forward calls if your phone is turned off or if you are unreachable.
- **No Reply** – forward calls that you do not answer within a specified time limit (service provider-dependent).

To activate call forwarding

- 1 ▶ Settings ▶ the Calls tab ▶ Forward Calls.
- 2 Select a call type and then one of the forward options ▶ Activate.
- 3 Enter the phone number to which you want your calls to be forwarded, or ▶ Lookup to find the contact in your phonebook ▶ OK.

To deactivate call forwarding

Scroll to the forward option ▶ Deactivate.

To check all forwarding options

- ▶ Settings ▶ the Calls tab ▶ Forward Calls
- ▶ Check All.

More than one call

You can handle more than one call simultaneously. For example, you can put an ongoing call on hold, while you make or answer a second call, and then switch between the two calls.

Call waiting service

If the call waiting service is activated, you hear a beep if you receive a second call during an ongoing call.

To activate or deactivate the call waiting service

- ▶ Settings ▶ the Calls tab ▶ Manage Calls
- ▶ Call Waiting.

To make a second call

- 1 ▶ Hold to put the ongoing call on hold.
- 2 Enter the number you want to call ▶ Call.

Receiving a second call

When you receive a second call, you can do the following:

- ▶ **Answer** to answer the second call and put the ongoing call on hold.
- ▶ **Busy** to reject the second call and continue the ongoing call.
- ▶ **Replace Active Call** to answer the second call and to end the ongoing call.

Handling two calls

When you have one ongoing call and one call on hold, you can do the following:

- ▶ **Switch** to switch between the two calls.
- Press **Ⓞ** ▶ **Join Calls** to join the two calls into a conference call.
- Press **Ⓞ** ▶ **Transfer Call** to connect the two calls. You are disconnected from both calls.
- ▶ **End Call** to end the ongoing call, then press **Yes** to retrieve the held call.
- ▶ **End Call** twice to end both calls.
- You cannot answer a third call without ending one of the first two calls or joining them into a conference call.

Conference calls

In a conference call, you can have a joint conversation with up to five other people. You can also put a conference call on hold and make another call.

- There may be additional charges for calls involving multiple parties. Contact your service provider for more information.

Creating a conference call

To create a conference call, you must first have one ongoing call and one call on hold. In a conference call you can have a private conversation with one of the participants or release a participant.

To join the two calls into a conference call


Press **Ⓞ** ▶ **Join Calls**.

To add a new participant


- ▶ **Hold** to put the joined calls on hold.
- Press **Ⓞ** ▶ **Add Call** and call the next person you want to include in the conference call.
- Press **Ⓞ** ▶ **Join Calls**.
- Repeat steps 1-3 to include more participants.

Calling


To release a participant

Press  ► **Release Part.** and select the participant that you want to release from the conference call.

To have a private conversation

- 1 Press  ► **Talk To** and select the participant that you want to talk to.
- 2 ► **Join Calls** to resume the conference call.

Two voice lines

-  If you have a subscription that supports alternate line service, your phone may have two voice lines with different phone numbers.

This may be useful if, for example, you want to keep business calls and private calls on separate lines. You select which line you want to use for outgoing calls. All outgoing calls are made on this line until you change it. Incoming calls can still be received on either line.

You can change the names of the lines, and have different settings for each line, for example, different ringtones.

To select a line

► **Settings** ► the **Calls** tab and select line 1 or 2.

To change the name of a line

► **Settings** ► the **Display** tab ► **Edit Line Names** and select one of the lines to edit the name.

My numbers

You can view, add and edit your own phone numbers.

To check your phone numbers

► **Phonebook** ► **Options** ► **Special Numbers** ► **My Numbers** and select one of the options.

Accept calls

With the accept calls service, you can choose to receive calls only from certain phone numbers. Other calls are automatically rejected by a busy tone. If the call forward option **When Busy** is activated, calls are forwarded instead of rejected by a busy tone. The phone numbers of calls you have rejected are saved in the call list.


To add numbers to the accepted callers list


- 1 ▶ Settings ▶ the Calls tab ▶ Manage Calls
▶ Accept Calls ▶ Only From List.
- 2 ▶ Edit ▶ New ▶ Add. This takes you to phonebook look up. Select numbers from your phonebook.

To accept all calls

- ▶ Settings ▶ the Calls tab ▶ Manage Calls
- ▶ Accept Calls ▶ From All.

Restricted dialing

 You can use the restrict calls service to restrict outgoing and incoming calls. This may be useful, for example, when you are abroad. To use this service, you need a password which you get from your service provider

 *If you forward incoming calls, you cannot activate some Restrict calls options.*

The following calls can be restricted:


- All outgoing calls – **All Outgoing**.
- All outgoing international calls – **Outgoing Intl.**


- All outgoing international calls except to your home country – **Outgoing Intl Roam**.
- All incoming calls – **All Incoming**.
- All incoming calls when you are abroad (when roaming) – **Inc. When Roaming**.

To activate or deactivate a call restriction

- 1 ▶ Settings ▶ the Calls tab ▶ Manage Calls
▶ Restrict Calls and select an option.
- 2 Select **Activate** or **Deactivate**.
- 3 Enter your password ▶ **OK**.

Fixed dialing

 The fixed dialing function allows calls to be made only to certain numbers saved on the SIM card. Fixed dialing requires a SIM card that allows fixed numbers to be saved. The fixed numbers are protected by your PIN2.

 *Calls to the international emergency number 112 can still be made even when the fixed dialing function is activated.*

Partial numbers can be saved. For example, saving 0123456 allows calls to be made to all numbers starting with 0123456.

Calling


To activate or deactivate fixed dialing


- 1 ▶ Phonebook ▶ Options ▶ Special Numbers ▶ Fixed Dialing and select **Activate** or **Deactivate**.
- 2 Enter your PIN2 ▶ **OK** and then ▶ **OK** again to confirm.

To save a fixed number

- ▶ Phonebook ▶ Options ▶ Special Numbers ▶ Fixed Dialing ▶ Fixed Numbers ▶ New Number and enter the information.

Call time and cost

-  During a call, the duration of the call is shown on the screen. If you subscribe to cost information, you can check the duration of your last call, outgoing calls and the total time. You can also check the cost of your last call and the total cost of your calls.

-  *If you subscribe to cost information, you must enter your PIN2 to reset the cost or time counter.*

To check the call time

- ▶ Settings ▶ the Calls tab ▶ Time & Cost ▶ Call Timers.

To reset the call time meter

- ▶ Settings ▶ the Calls tab ▶ Time & Cost ▶ Call Timers ▶ More and select **Reset total** or **Reset Outgoing**.

To check the call cost

- ▶ Settings ▶ the Calls tab ▶ Time & Cost ▶ Call Costs.

To reset the call cost meter

- ▶ Settings ▶ the Calls tab ▶ Time & Cost ▶ Call Costs ▶ More ▶ **Clear Total Cost**.

Setting the call cost

You can use the tariff function to specify the price per call unit. If you do not specify a price per call unit, the number of call units appears.

To enter the price per call unit

- 1 ▶ Settings ▶ the Calls tab ▶ Time & Cost
▶ Call Costs ▶ More ▶ Set Rate.
- 2 Enter your PIN2 ▶ OK.
- 3 ▶ Currency and enter the code for the currency you want (for example USD for US Dollars)
▶ OK.
- 4 ▶ Units and enter the price per call unit ▶ OK.
To enter a decimal point, press .

Credit limit for calls


You can enter a total amount of money that can be used for making calls. When the amount reaches zero, no more calls can be made. Please note that the credit limit is only an estimated value.

To set a credit limit

- 1 ▶ Settings ▶ the Calls tab ▶ Time & Cost
▶ Call Costs ▶ More ▶ Set Credit and enter your PIN2 ▶ OK.
- 2 Select Limited or Unlimited. If you select Limited, enter an amount ▶ OK.

Call priority service

You can request a certain priority when you make a call, if your subscription supports the call priority service.

-  The priority levels are defined by your service provider and are normally within the range of 0-4, where 0 is the highest priority.

To check or change your standard priority level

- 1 ▶ Settings ▶ the Calls tab ▶ Manage Calls
▶ Default Priority.
- 2 The network sends available priority levels.
Select a priority level.

To change the priority for one call

- 1 Enter the phone number you want to call.
- 2 ▶ More ▶ Call Priority and select a priority.
The number is called.

Calling

Closed user groups

- 📞 The closed user group function is a way of lowering call costs. If you subscribe to closed user groups it is cheaper on some networks to make calls within a call group. You can save ten groups.

To add a group

- 1 ▶ Settings ▶ the Calls tab ▶ Manage Calls ▶ Closed Groups ▶ Edit List ▶ New Group ▶ Add.
- 2 Enter the name of the user group ▶ Continue.
- 3 Enter the index number ▶ Save. You get the index number from your service provider.

To call outside a closed user group

- ▶ Settings ▶ the Calls tab ▶ Manage Calls ▶ Closed Groups ▶ Open Calls ▶ On. When Off is selected, it is only possible to call within the group.

Additional calling functions

Tone signals

You can use telephone banking services or control an answering machine by sending tone signals (also known as DTMF tones or touch tones) during a call.

- To send the tones, press the keys **1** – **9**, ***** or **#**.
- To clear the screen after the call is finished, press **C**.
- To turn the tones on or off during a call
 - ▶ More in standby and select Turn Off Tones or Turn On Tones.

Notepad

You can use the phone to make a note of a phone number during a call. When you end the call, the number remains on the screen. ▶ Call to call the number. ▶ More ▶ Save Number and select a contact to save the number. If you want to create a new contact and save the number ▶ New Contact.

Showing or hiding your number

If your subscription supports the Caller ID Restriction service, you can hide your phone number when making a call. You can do this per call, or select this as a default setting. ▶ More in standby to quickly change this default setting.

To show or hide your phone number

- 1 Enter the phone number you want to call.
- 2 ▶ More and select Hide Number or Show Number.

To always show or hide your phone number

- 1 ▶ Settings ▶ the Calls tab ▶ Show or Hide No.
- 2 Select Show Number, Hide Number or Network Default.

Groups

You can create a group of numbers. By doing so, you can send text messages and picture messages to several recipients at the same time

➤ *36 Messaging.*

To create a group of numbers

- 1 ▶ Phonebook ▶ Options ▶ Groups
▶ Send DTMF Tones ▶ Add.
- 2 Enter a name for the group ▶ Continue.
- 3 ▶ New Number ▶ Add to find the contact in your phonebook.
- 4 Select a number from the contact.
- 5 Repeat steps 3-4 to add more numbers to the group. ▶ Done to save the group.

Business cards

You can add your own business card to the phonebook. You can exchange business cards between your phone and another similar phone, a PDA or a PC using Bluetooth wireless technology, the infrared port, cable or a text or picture message.

To add your own business card

- ▶ Phonebook ▶ Options ▶ My Business Card and enter the information for your business card
- ▶ Save.

To send your business card

- ▶ Phonebook ▶ Options ▶ My Business Card
- ▶ Send My Card and select a transfer method.


To receive a business card

When you receive the business card ▶ Yes ▶ Save to save the business card in the phonebook.

Messaging


Messaging


Text messaging, picture messaging, email, My Friends, messaging glossary.

-  Your phone supports various messaging services – text messaging, picture messaging, email and My Friends. Please contact your service provider for details on which services you can use.

Text messaging

Text messages are sent via SMS (Short Message Service). Text messages can contain pictures, animations, melodies and sound effects.







Text messages can be sent to one person, several recipients or to a group of recipients that you have saved in the phonebook  *35 Groups*.

-  *If you send a text message to a group, you are charged for each member of that group.*

Before you start


First make sure that the number of your service center is set. The number is supplied by your service provider and is usually saved on the SIM card.



To set the service center number

- 1  **Messages**  **Settings**  **Text Message**  **Service Center**. If the service center number is saved on the SIM card, it is shown in the list.
- 2 If there is no number in the list  **Add** and enter the number, including the international “+” sign and country code  **Save**.











Sending text messages

For information about entering letters

 *11 Entering letters.*

-  *Some language-specific characters use more space. For some languages you can deactivate National Chars. to save space.  13 Options when entering letters.*

To write and send a text message

- 1  **Messages**  **Write New**  **Text Message**.
- 2 Write your message  **Continue**. If you want to save the message for later, press   **Yes** to save it in **Drafts**.
- 3  **Phone Number** and enter the recipient's phone number, or  **Phonebook LookUp** to retrieve a number or a group from the phonebook. To enter an email address  **Enter Email Addr**. A list below the send options shows the last 10 recipients. You can also select a recipient from this list.  **Send**.

Messaging

To insert an item in a text message

- 1 ► Messages ► Write New ► Text Message.
- 2 While writing your message ► More ► Add Item.
- 3 Select Picture, Sound Effect, Melody, Animation, Templates or Picture (other).
- 4 Select an item.

Formatting text

You can change the style, size and alignment of the text, and create new paragraphs.

To format the text in a text message

- 1 ► Messages ► Write New ► Text Message.
- 2 While writing your message ► More ► Text Format. Then select Text Size, Text Style, Alignment or New Paragraph.
- 3 Select a text format.

Receiving text messages

When you receive a text message, a message alert sounds and a text is displayed that informs you that a text message has been received.

► Yes to read the text message or ► No if you want to read the message later.

While reading the text message you can, for example, go to a Web address found in the text message, save a picture found in the text message or listen to a sound inserted in the text message.

When you have read the text message ► More to view a list of options. Press (↵) to close the text message.

Calling a number in a text message

You can call a phone number that appears in a text message.

To call a number in a text message

Select the phone number ► Call.

Saving received text messages

Received text messages are saved in the phone memory. When the phone memory is full, you must delete messages or move them to the SIM card to be able to receive new messages. Messages that you have saved on the SIM card remain there until you delete them.

To save a message to the SIM card

► Messages ► Inbox ► More ► Save Message ► SIM.


Messaging

To save an item from a text message

- 1 Select the phone number, Web address, picture or sound that you want to save in the message
▶ **More**.
- 2 If you have selected to save a phone number
▶ **Use** ▶ **Save Number**. If you have selected a Web address ▶ **Save Bookmark**, a picture
▶ **Save Picture**, a sound ▶ **Save Sound**.

Long messages

The number of characters that a text message can contain depends on the language you are writing in. You can send a longer message by linking two or more messages. Please note that you are charged for each of the messages linked in a long message. You may not receive all parts of a long message at the same time.

-  Check with your service provider for the maximum number of messages that can be linked.

To turn long messages on

- ▶ **Messages** ▶ **Settings** ▶ **Text Message**
▶ **Max. Msg Length** ▶ **Max. Available**.

Templates

If you have one or more messages that you send often, you can save these as templates. There are predefined templates in your phone, but you can also create your own templates.

To create a template

- 1 ▶ **Messages** ▶ **Templates** ▶ **New Template**
▶ **Add** ▶ **Text**.
- 2 Write the message ▶ **OK**.
- 3 Enter a title for the message ▶ **OK**.

Message options

You can set a default value for several message options or choose the settings each time you send a message. You can, for example, select to request a reply to a sent message, select what type of text message you want to send or set how long a message should be valid. For details about the message options ➡ *49 Messaging glossary*.

To set a default text message option

- ▶ **Messages** ▶ **Settings** ▶ **Text Message** and select an option.

Messaging

To set a message option for a specific message

- 1 When you have selected a recipient to send your text message to ► **More** ► **Advanced**.
- 2 Select the option that you want to change ► **Edit** and select a new setting.
- 3 ► **Done** when you have changed the options.

To check the status of a sent message

- **Messages** ► **Sent Items** and select a text message
- **View** ► **More** ► **View Status**.

Picture messages

Picture messages can contain text, pictures, video clips, camera pictures, and sound recordings and are sent via MMS (Multimedia Messaging Service). You must have a subscription that supports MMS, and the receiver of the picture message must also have support for MMS. Picture messages can be sent to a mobile phone and an email account. You can send your business card as an attachment in a picture message.

Before you start

Before sending a picture message, make sure that:

- 1 The address to your message server is set
 - **Messages** ► **Settings** ► **Picture Msg.**
 - **Message Server**.
- 2 You have entered the correct settings
 - **Messages** ► **Settings** ► **Picture Msg.**
 - **Internet Profile**. Select a profile or **New Profile**. To create an Internet profile, ► **63 Setting up Internet and email**. You can also download all the settings you need automatically from your service provider.

Writing and sending picture messages

When composing a picture message, you select from different items to format your message. The different items are: **Picture**, **Text**, **Sound**, **Video**, **Camera Picture**, **Video Clip** and **Sound Recording**.

Before sending a picture message, you can select from different options to adjust and enhance your message. You can, for example, preview the entire message or a single page in the message, change the timing for items in the message and add or replace items to be sent in the message. For details about options ► **49 Messaging glossary**.

Messaging

To write and send a picture message

- 1 ▶ **Messages** ▶ **Write New** ▶ **Picture Msg.** ▶ Add to view a list of items to add to your message. Select an item.
- 2 ▶ Add to add more items to the message. You can view and select options to enhance the message by highlighting items in the message and pressing the left selection key.
- 3 When you have finished writing your message ▶ **More** ▶ **Send**.
- 4 ▶ **Phone Number** and enter the recipient's phone number, or ▶ **Phonebook LookUp** to retrieve a number or a group from the phonebook. To enter an email address ▶ **Enter Email Addr.** A list below the send options shows the last 10 recipients. You can also select a recipient from this list. ▶ **Send**.

To make a call while writing a picture message

- 1 While writing your message ▶ **More**.
- 2 ▶ **Make a Call** and enter or retrieve a phone number ▶ **Call**. You return to the message.
- 3 To end the call ▶ **More** ▶ **End Call**.

To set a default message option

- ▶ **Messages** ▶ **Settings** ▶ **Picture Msg.** and select one of the options.

Additional send options

You can request a read receipt, a delivery report and set a priority for a specific message. You can also add more recipients to the message. For details about the additional send options ➔ *49 Messaging glossary*.


To select additional send options



- 1 When you have entered the recipient's phone number ▶ **More**.
- 2 Select **Add Recipient** or **Recipients** to add more recipients, or **Advanced** to select an additional send option.

Receiving picture messages

When you receive a picture message, a message alert sounds and a text is displayed that informs you that a message has been received.

Messaging

▶ **Yes** to read or play the message. Press any key to stop. When you have read the message ▶ **Reply** to reply immediately or ▶ **More** to view a list of options. Press  to close the message.

 You can select a message from the list of messages and press  to delete the entire message.

Save items from a picture message

When you have viewed a picture message, you can save items from the message. ▶ **More** ▶ **Save Items** and select an item from the list that appears.

Templates

You can base your message on one of the predefined templates. You can also add new templates.

To use a predefined template for a picture message

- ▶ **Messages** ▶ **Templates** and select a template.
- ▶ **Use** ▶ **Picture Msg.** ▶ **Add** to make changes or add new items.
- ▶ **More** ▶ **Send** to send the message.

Automatic download

You can select how you want your picture messages to be downloaded.

▶ **Messages** ▶ **Settings** ▶ **Picture Msg.**


▶ **Auto Download** to view the following:

- **Always** – your phone automatically downloads messages to your phone as soon as they come to your service provider's server. This is default.
- **Ask in Roaming** – you will be asked if you want to download messages when you are using another network than your service provider's.
- **Never in Roam** – the messages are never downloaded when you are using a network other than your service provider's.
- **Always Ask** – you will always be asked if you want to download messages regardless of the network being used.
- **Off** – new messages appear in the inbox as icons. Select the message ▶ **View** ▶ **Yes** to download.

Messaging

Postcard

You can have a message with picture and text delivered as a postcard to a street address.

-  *This service is not available in all countries. Another way of sending a postcard is to use the phonebook by selecting a contact, More ► Send Message ► Postcard. You can also create a postcard by selecting File Manager ► Pictures. Select a picture ► More ► Send ► As Postcard.*

To send a postcard

- 1 ► Messages ► Write New ► Postcard ► Add.
- 2 Select **Picture** or **Camera Picture** to add a picture to your message.
- 3 ► Add ► Text to add a message to accompany the picture.
- 4 Write your message ► OK.
- 5 ► Send ► **Street Address** to enter name and address, or you can either select **Phonebook LookUp** to retrieve a contact, or select a recipient from the list of previous recipients.
- 6 When you have entered name and address ► OK ► Send. The picture and message will be printed on a postcard and sent to the address you choose.

To view a sent postcard

- Messages ► Sent Items and highlight the message
- View.

Email

You can use your phone to send and receive email messages. Please note that you need a subscription that supports data transmission. For more information, contact your service provider.

Before you start

First make sure that:

- You have set up a data account, ► 63 *Entering Internet and email settings.*
- You have set up and selected an email account.

Email account settings

An email account specifies, for example, the server that is used for your email messages. There are three ways to create an email account:

- Download settings from Internet
- Send a request in a text message
- Create an email account manually

Receiving settings

At www.SonyEricsson.com you can get support on how to enter your email settings. Some service providers provide a service with which you can request settings in a text message. Contact your service provider for information about your settings.

To request settings in a text message

► Messages ► Email ► Settings ► Auto Configure.

To create an email account manually

- 1 ► Messages ► Email ► Settings ► New Account.
- 2 Enter a name for the account, for example “Home” or “Office” ► **Connect Using**.
- 3 Select the data account that you want to use with this email account.
- 4 Enter the rest of the settings, some of which are optional. To enter the settings, scroll to the setting ► **Select**. Enter the information ► **OK** to confirm. Repeat this for each required setting. You use the same email settings in your phone as in your PC email program. If you do not have an email service, contact your service provider to get all the necessary settings. For details about the settings ► *49 Messaging glossary*.


Default email account

If you have both an office and a home email account, you can set one of them as default: ► Messages ► Email ► Settings and select an account.

Writing and sending email messages

When writing and sending your email message, you can select from several options to accompany your message. For details about the options ► *49 Messaging glossary*.

- Messages ► Email ► Inbox ► More
- Send & Receive offers the fastest way to check for new email messages.

 *The number of email messages that can be saved depends on memory left in the phone. All email messages are also saved on your email server, and you can view both older and newer messages on the server.*

To write and send an email message

- 1 ► Messages ► Email ► Write New.
- 2 Write the subject for your message ► **OK** and then the text ► **OK**.
- 3 ► Enter Email Addr. to enter an email address or ► Phonebook LookUp to retrieve an address from your phonebook.
- 4 ► Send to send your email message or ► More to view a list of options for your message.

Messaging

To receive and read email messages

- 1 ▶ Messages ▶ Email ▶ Inbox ▶ More
▶ Send & Receive to download new messages.
- 2 Select a message to read it.

To reply to an email message

- 1 Open the email message ▶ Reply.
- 2 Write your message. ▶ More to view options for the message.
- 3 ▶ Send to send the message.

To save an email address or a phone number in an email message

- 1 Select the email address or phone number that you want to save ▶ More.
- 2 If you have selected to save an email address ▶ Use ▶ Save Email. If you have selected to save a phone number ▶ Save Number.

To save an email message

- 1 Open the email message ▶ More
▶ Save Message.
- 2 The message is saved in Saved Items in the Email menu.


To delete an email message (POP3 users)

- 1 ▶ Messages ▶ Email ▶ Inbox and select the message ▶ More.
- 2 Select Mark for Deletion. The message is deleted the next time you connect to your email server.

To delete an email message (IMAP4 users)

- 1 ▶ Messages ▶ Email ▶ Inbox and select the message ▶ More.
- 2 ▶ Mark for Deletion. The message is marked for deletion on the server.
- 3 ▶ More ▶ Clear Inbox. The message is deleted the next time you connect to your email server.

My Friends

 The My Friends function gives you more options when messaging. You can create a list of favorite contacts either from the phonebook or from the My Friends server. You can see which of your contacts are online and what mood they are in. To see contacts online, they have to be connected to the My Friends server. You can also send and receive instant messages and join community chats. Please contact your service provider for information about your subscription and My Friends settings.

My Friends contacts

You can add contacts from the phonebook to a list of contacts in My Friends, even if you do not have a My Friends account and are not connected to the My Friends server. You can then quickly access your favorite contacts and choose how you want to communicate with them.

Log in to the My Friends server

You can select to log in to your My Friends server each time you want to send or receive instant messages, or you can be logged in automatically when you turn on your phone. You can edit the settings for your My Friends account. To set automatic log in and edit your account settings you have to be logged out from the My Friends server.

To log in to your My Friends server

► Messages ► My Friends ► Myself ► Log In.

To set automatic log in

► Messages ► Myself ► More ► Accounts ► Edit
► Auto-Login ► On.

To edit the My Friends account

► Messages ► Myself ► More ► Accounts ► Edit
and edit your settings.

List of contacts

You can create a list of contacts – people you want to send messages to on a regular basis. You can add contacts from your phonebook or from your My Friends server.

Messaging

To add a contact from the phonebook

- 1 ▶ Messages ▶ My Friends ▶ More
▶ Add Contact ▶ From Contacts.
- 2 Enter the first letters of the contact and then select a contact.
- 3 When you have selected a contact, you can choose to subscribe to status information for that contact. To subscribe ▶ Yes and follow the instructions that appear. ▶ No if you do not want to subscribe.

To add a contact from a network server

- ▶ Messages ▶ My Friends ▶ More ▶ Add Contact
▶ From Server and follow the instructions that appear.

Status

You can view the status of your contacts and choose to show your own status to others. You can also change your own status with the help of the following options:

- **Picture** – select a picture from Pictures or take a picture with the camera. You can change, update or remove pictures.
- **About Me** – write a short text about yourself.

- **Availability** – select what to show others when you are online, Available, Busy, Away, or Invisible. If you select Invisible, you will appear as offline to others.
- **Mood** – select a mood from the list.
- **Show My Status** – ▶ To All if you want to show full status to friends but limited status to others, and ▶ Only To contacts if you want to show full status to friends but nothing to others.
- **Username:** – view your username.

To view the status of a contact

- ▶ Messages ▶ My Friends and select a contact
▶ More ▶ View Status.

To change your own status

- ▶ Messages ▶ My Friends ▶ Myself ▶ Change Status and edit your status according to the options.

To send a message from My Friends

- 1 ▶ Messages ▶ My Friends and select a contact.
- 2 If the contact is linked to your phonebook
▶ More ▶ Send Instant Msg. ▶ Send. If not,
select the contact ▶ Send IM.