

Get to Know Your Phone

Setting Up Your Phone


Welcome to Verizon Wireless. You're now part of a growing movement that's about speed, signal and strength. This guide will show you how to set up and use your phone, access special features, and find help.

Insert the SIM Card

NOTE: If not already inserted, follow the instructions below to insert your 4G LTE SIM card.

To insert the SIM card:

- 1. Open the SIM card slot cover.
- 2. Using a fingernail, pull out the SIM card
- Carefully insert the 4G LTE SIM card into the SIM card holder with the Verizon logo facing down.
- 4. Push the SIM card holder back into place.
- 5. Close the SIM card slot cover.




Charge the Phone

Before turning on your phone, charge it fully

- 1. Connect the USB cable to the charger.
- 2. Insert the other end of the USB cable into the charger port on the left side of the phone.
- 3. Plug the charger into a compatible electrical outlet.

WARNING! Please use only an approved charging accessory to charge your phone. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.



Optional: Insert the microSD Card If you have a microSD card, slide the


To insert the microSD card-

- 1. Open the microSD card slot cover.
- Carefully slide the microSD card into the microSD slot with the gold contacts facing up.
- 3. Close the microSD slot cover.


(To remove the microSD card, carefully push the card inward to release it from the slot.)

NOTE: The microSD card is sold separately.





NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.



Using Your Phone

Turning Your Phone On/Off

It's important to fully charge the battery before turning on your phone.

To turn on your phone:

• Press and hold the **Power/Lock** button on the right side of your phone.

To turn off your phone:

- 1. Press and hold the **Power/Lock** button until the Device options screen appears.
- 2. Tap Power off → OK.

Home Screen



Setup Wizard 🌋

Follow the onscreen instructions to quickly set up your phone and email accounts.

Locking and Unlocking Your Phone

Prevent accidental key presses by locking your phone.

To lock your phone:

• Press the Power/Lock button.

To unlock your phone:

 Press the Power/Lock button to wake the display and then drag your finger across the screen in any direction.

Using the Touch Screen

Use touch gestures to move around the screen, open menus, select items, zoom in or out on web pages, and more.

Swipe—Swipe by quickly sliding your finger in any direction.

Drag—Drag by touching an item and sliding it to a new position.

Double-Tap—Tap two times rapidly to zoom in or out on a web page or picture.

Multi Touch—Pinch or spread your thumb and index finger to zoom in or out.

Making a Call

- 1. Tap the phone icon on the Home
- 2. Enter the number you want to call.
- 3. Tap Send to place the call.

Receiving a Call

Tap Answer and slide to the right to answer an incoming call.

Setting Up Voice Mail

- 1. Tap the phone icon on the Home screen.
- 2. Dial*86 and tap Send.
- When you hear a greeting, tap # to interrupt.
- 4. Follow the setup tutorial.

Checking Voice Mail

From your phone, dial *86 and press Send. From other phones, enter your wireless number

- When you hear a greeting, tap # to interrupt.
- 2. Follow the prompts.

NOTE: Voice mailboxes not set up within 45 days will be canceled. Your voice mailbox is not password protected until you create a password by following the setup tutorial.

Sending a Text

- From the Home screen, tap Apps → Messaging.
- Tap the Add icon to create a new conversation.
- 3. Enter the contact information and your message text.
- 4. **②** You can also tap onscreen icon to add an attachment.
- 5. Tap Send.

Taking Photos

- From the Home screen, tap Apps → Camera.
- 2. Use the phone's screen as a viewfinder to set up your shot.
- 3. Pinch the screen to zoom out or pinch open to zoom in.
- You can tap onscreen icons to choose various camera options and settings.
- You can also tap the screen to move the focus to a desired area of interest.
- Tap the Camera icon (the shutter will sound). The picture is automatically stored in your selected storage location.

Setting Up Email

- 1. \longrightarrow From the Home screen, tap Apps -> Email.
- 2. Enter your email address in the "Email address" field
- 3. Enter your password in the Password field and tap Next.
- At the "Account setup" screen, name the account and enter a screen name to identify yourself on this account.
- Tap **Next** to save the new account.

Play Store

From the Home screen.



Tap the Google Play Store icon.

Viewing Apps

To view your apps, from the Home screen, tap the **Apps** icon.

Installing Apps

Thousands of apps are available to download from the Google Play™ Store.

From the Home screen, tap the Play Store icon

Uninstalling Apps

- From the Home screen, tap the Apps icon.
- 2. Swipe in from the left edge of the screen and choose **Uninstall**.
- Tap the red X of the app you want to uninstall.

Isis Mobile Wallet™

Now you can pay with your phone. Isis* lets you pay for purchases and often save on them too. Learn more at verizonwireless.com/isis.

Improving Accessibility

Adjust accessibility settings to assist users who have impaired vision or hearing, or reduced dexterity.

- 2. Tap a category and set the desired options to improve accessibility.

Using TalkBack

TalkBack provides screen reading to assist people with impaired vision.

- Tap TalkBack. Then tap the TalkBack switch to turn it on.
- Tap Settings at the top of the screen to adjust the TalkBack settings.

NOTE: When TalkBack is on, double-tap when you hear the item you want. (You can change to single-tap in Settings.)

Support & More

My Verizon App



Manage your account, track your usage, edit account information. pay your bill and more.

Get Help Using Your Phone



Use your Help app to get assistance at your fingertips, right from your phone.



From your computer, visit verizonwireless.com/support.

Customer Service



Call 1-800-922-0204. Follow us @VZWSupport.



More Information



To download a User Guide, go to VerizonWireless.com/support and find your device.

Customer Information

Your Wireless Device and Third Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features of fered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products including any personal information you choose to use, submit or share with others. Specific third party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.