

**SONY**<sup>®</sup>

# User guide

Stereo Bluetooth<sup>®</sup> Headset  
SBH70

# Contents


<b>Introduction</b> .....	<b>3</b>
Function overview.....	3
Hardware overview.....	3
<b>Basics</b> .....	<b>5</b>
Charging the battery.....	5
Battery and power management.....	5
Turning the headset on and off.....	5
Adjusting the volume.....	5
Reconnecting the headset.....	5
Restarting and resetting the headset.....	6
Wearing instruction.....	6
<b>Getting started</b> .....	<b>7</b>
Preparing to use your headset with a Bluetooth® device.....	7
<b>Settings for your Stereo Bluetooth® Headset SBH70</b> .....	<b>8</b>
Using the Stereo Bluetooth® Headset application.....	8
<b>Using your headset</b> .....	<b>9</b>
Using your headset to handle phone calls.....	9
Using your headset to listen to music.....	9
Using your headset with two devices simultaneously.....	9
Using your headset to record a sound memo.....	10
<b>Troubleshooting</b> .....	<b>12</b>
I cannot answer a second call.....	12
Music from another device does not play in the headset.....	12
The headset turns off automatically.....	12
No connection between headset and other device.....	12
Unexpected behaviour.....	12
<b>Legal information</b> .....	<b>13</b>
Declaration of Conformity .....	14





# Introduction

## Function overview

Your Stereo Bluetooth® Headset SBH70 is designed to make life more convenient when you're on the go. You can use it together with an Android™ powered device such as a phone or tablet, or with a Bluetooth® compatible device such as a non-Android phone, a computer or a music player. When paired with a compatible device, you can use your headset to control incoming and outgoing phone calls or to listen to music.

## Hardware overview



1 Notification light	Red light: 5%-15% battery level Orange light: 15%-50% battery level Green light: 50%-100% battery level Flashing blue light: headset is in pairing mode. Flashing purple light: a call is coming in.
2 Power key 	Press and hold down to turn the headset on or off. When the headset is on, briefly press to show a notification light indicating battery level.
3 NFC detection area	Touch other devices to this area during NFC pairing.
4 Call key/Music key 	Press to answer incoming calls. Press and hold down to reject incoming calls. Press to play or pause the current track.
5 Microphone	
6 Volume up key 	Press to turn up the volume.
7 Volume down key 	Press to turn down the volume.

8 Micro USB port


Insert the cable for charging the battery.

# Basics

## Charging the battery

Before using the Stereo Bluetooth® Headset SBH70 for the first time, you need to charge the headset for approximately 2.5 hours. Sony chargers are recommended.

### To charge your headset



- 1 Plug one end of the USB cable into the charger or into the USB port of a computer.
- 2 Plug the other end of the cable into the Micro USB port of your Stereo Bluetooth® Headset SBH70 device.

## Battery and power management


You can check the battery status of your headset before the remaining power reaches a critical level.

### To check the battery status from your headset

- Press the power key. The notification light colour indicates the amount of battery power remaining.

## Turning the headset on and off

### To turn on the headset

- Press and hold down  until the headset vibrates and the notification light turns green.

### To turn off the headset

- Press and hold down  until the headset vibrates.

## Adjusting the volume

### To change the call or music volume

- During a call, or when listening to music, press **+** or **-**.

## Reconnecting the headset

In cases where a connection gets lost, for example, when the connected Android™ device goes out of range, your headset automatically performs a series of

reconnection attempts. When this happens, you can use any key to force the accessory to try reconnecting, or you can use NFC to reconnect the two devices.

#### To force the headset to try reconnecting

- 1 Android™ device: Make sure that the Bluetooth® function is turned on.
- 2 Press any key on the headset.

#### To reconnect your headset using NFC

- 1 Android™ device: Make sure that the NFC function is turned on and that the screen is active and unlocked.
- 2 Place the Android™ device over your headset so that the NFC detection area of each device touches the other.

## Restarting and resetting the headset

You can force your headset to shut down in situations where it stops responding or won't restart normally. No information about paired devices gets deleted. You can also reset your headset to its original factory settings, which deletes all information about paired devices.


#### To force the headset to shut down

- Press and hold down the power key for at least 6 seconds.

#### To reset the headset

- 1 Turn off the headset, then connect the charger so that the headset starts to charge.
- 2 Press and hold down ►||/⏻ until the headset vibrates briefly.

## Wearing instruction



To get the best performance from your headset when using it outdoors, carry the device paired with your headset in front of your body.

# Getting started

## Preparing to use your headset with a Bluetooth® device


Before you can start using your headset with a Bluetooth® device, you need to pair the headset with the Bluetooth® device manually using Bluetooth® or automatically using NFC.

- 💡 A setup wizard in the Stereo Bluetooth® Headset application guides you through the process of setting up your headset for the first time.

### To manually pair your headset with a Bluetooth® device

- 1 Bluetooth® device: Make sure the Bluetooth® function is turned on.
- 2 Turn off your headset.
- 3 Headset: Press and hold down the Power key until a blue notification light starts flashing rapidly.
- 4 Bluetooth® device: Scan for Bluetooth® devices, then select **SBH70** in the list of available devices.
- 5 Bluetooth® device: Follow the pairing instructions that appear on the screen.

### To automatically pair your headset with a Bluetooth® device



- 1 Bluetooth® device: Make sure that the NFC function is turned on and that the screen is active and unlocked.
  - 2 Place the Bluetooth® device over your headset so that the NFC detection area of each device touches the other.
  - 3 Bluetooth® device: Follow the pairing instructions that appear.
- ! The illustration is for reference purposes only. The location of the NFC detection area varies between devices.

# Settings for your Stereo Bluetooth® Headset SBH70

## Using the Stereo Bluetooth® Headset application

You can view and change settings for your headset by using the Stereo Bluetooth® Headset application on your Android™ device. A setup wizard in the Stereo Bluetooth® Headset application guides you through the process of setting up your headset for the first time.


### To install the Stereo Bluetooth® Headset application

- 1 From the main application screen of your Android™ device, find and tap **Play Store**.
- 2 Tap the search icon, then search for **SBH70**.


### To set a headset ringtone

- 1 From the main application screen of your Android™ device, find and tap **SBH70 > SETTINGS**.
- 2 Tap **Headset Ringtone**.
- 3 Select a ringtone.
- 4 Tap **Done**.

### To set your headset to vibrate when ringing

- 1 From the main application screen of your Android™ device, find and tap **SBH70 > SETTINGS**.
  - 2 Mark the **Vibrate on incoming call** checkbox.
-  This function is enabled by default.

### To set an Out of Range alert

- 1 From the main application screen of your Android™ device, find and tap **SBH70 > SETTINGS**.
  - 2 Mark the **Out-of-range alert** checkbox. Your headset vibrates when the connection is lost.
-  This function is enabled by default.



# Using your headset

## Using your headset to handle phone calls

Use the headset to handle incoming calls, for example, to answer or reject a call.

### To answer a call with the headset

- When you hear an incoming call signal, press ►||/☎.

### To end a call

- During an ongoing call, press ►||/☎.

### To reject a call

- When you hear an incoming call signal, press and hold down ►||/☎.

### To answer a second call

- When you hear an incoming call signal during an ongoing call, press ►||/☎. The ongoing call is put on hold.

- 💡 You can also double press ►||/☎ to switch to another call and put the current call on hold.

### To reject a second call

- When you hear an incoming call signal during an ongoing call, press and hold down ►||/☎.

### To mute and unmute the microphone during a call

- Press and hold down ►||/☎ to mute the microphone. To unmute the microphone, press and hold down ►||/☎ again.

### To make a call using voice dialler

- 1 Headset: Press and hold down ►||/☎ until you hear a beep.
  - 2 Bluetooth® device: Follow the instructions that appear on your screen. Speak clearly so your device accepts the contact name or phone number.
- 💡 When paired your headset with an iOS device, you can also use your voice to get weather information and read out text messages.

## Using your headset to listen to music

You can listen to music from your phone or another Bluetooth® compatible device using your headset.

### To listen to music

- 1 Open the music player application in your Bluetooth® device and select a track that you want to listen to.
- 2 To play the track, press ►||/☎.
- 3 To pause the track, press ►||/☎ again.

### To move between tracks

- 1 To skip forward to the next track, press and hold down the volume up key.
- 2 To play the current track from the beginning, press and hold down the volume down key. To play the previous track, press and hold down the volume down key a second time.

## Using your headset with two devices simultaneously

Your headset has two different connection modes: Multipoint mode and Singlepoint mode. Multipoint mode helps you manage two connections at the same time. For

example, if you connect your headset with two phones, you can receive calls from both phones without having to disconnect and reconnect.

Singlepoint mode is enabled by default. If you want to use your headset with two devices at the same time, you should switch to Multipoint mode manually.

- ! You can only connect to a maximum of two devices in Multipoint mode. If you pair the headset with a third device, the first paired device gets disconnected.

#### To switch between Multipoint mode and Singlepoint mode

- 1 Make sure that the headset is turned off.
  - 2 Place the headphones over your ears.
  - 3 To enter Multipoint mode, press and hold down the volume up key while turning on the headset. After Multipoint mode is activated, you will hear two beeps.
  - 4 To enter Singlepoint mode, press and hold down the volume down key while turning on the headset. After Singlepoint mode is activated, you will hear one beep.
- 💡 In order to connect to both paired devices in Multipoint mode, you need to restart the headset.

#### To manually pair your headset with two Bluetooth® devices

- 1 Make sure that the headset is in Multipoint mode and is paired successfully with the first Bluetooth® device.
- 2 Turn off the headset.
- 3 Headset: Press and hold down the Power key until a blue notification light starts flashing rapidly.
- 4 Second Bluetooth® device: Scan for Bluetooth® devices, then select **SBH70** in the list of available devices. Follow the pairing instructions that appear on the screen.
- 5 First Bluetooth® device: To reconnect to the headset, select **SBH70** in the list of paired devices on the Bluetooth® settings screen.

#### To automatically pair your headset with two Bluetooth® devices

- 1 Make sure that the headset is in Multipoint mode and is paired successfully with the first Bluetooth® device.
- 2 Turn off the headset.
- 3 Second Bluetooth® device: Make sure that the NFC function is turned on and that the screen is active and unlocked.
- 4 Place the second Bluetooth® device over your headset so that the NFC detection area of each device touches the other, then follow the pairing instructions that appear on the screen.
- 5 First Bluetooth® device: To reconnect to the headset, select **SBH70** in the list of paired devices on the Bluetooth® settings screen.

## Using your headset to record a sound memo

You can use your Stereo Bluetooth® Headset SBH70 to record a sound memo. A sound memo is a Life bookmark stored in the Lifelog application to help you remember special occasions. It can save the time, location, conversation and music being played during a particular moment, along with a 10 seconds audio clip.

To use the sound memo feature, you must install the latest version of the Stereo Bluetooth® Headset application and the Lifelog application on your Android™ device.

- ! For location data to be gathered, you must have an active Internet connection on your Android™ device.

### To record a sound memo using your headset

- 1 Make sure that you have installed or updated the Stereo Bluetooth® Headset application and the Lifelog application to the latest version.
  - 2 Make sure that your headset is turned on and connected to your Android™ device.
  - 3 Press the volume up and down keys simultaneously on the headset and speak into the microphone. You can record 10 seconds of audio.
- 💡 You can view your audio clips in the Lifelog application. When your headset is connected to your Android™ device, data gets synchronised automatically to the Lifelog application.

# Troubleshooting

## **I cannot answer a second call**

- Make sure that your calling device supports the Bluetooth® headset profile.
- Make sure that the correct calling device is selected.

## **Music from another device does not play in the headset**

- Make sure that the music-playing device is paired with the headset.
- Restart the music player application on the music-playing device.
- Make sure that the correct music source is selected.

## **The headset turns off automatically**

- If the headset beeps several times shortly before turning off, the battery level is low. Charge the battery.

## **No connection between headset and other device**

- Make sure that the headset is charged and within range of the device that you want to connect to. A maximum distance of 10 metres (33 feet), with no solid objects in between, is recommended.
- Disable the Bluetooth® function in the other device so that all connections are closed, then re-enable the Bluetooth® function and pair the headset with the device again.

## **Unexpected behaviour**

- Reset the headset.

# Legal information

## Sony SBH70



Prior to use, please read the *Important information* leaflet separately provided.

This User guide is published by Sony Mobile Communications Inc. or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications Inc. at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

©2015 Sony Mobile Communications Inc.

Interoperability and compatibility among Bluetooth® devices varies. Device generally supports products utilizing Bluetooth spec. 1.2 or higher, and Headset or Handsfree profile.

Sony is the trademark or registered trademark of Sony Corporation. Bluetooth is the trademark of the Bluetooth (SIG) Inc. and is used under license. All other marks are the property of their respective owners. All rights reserved.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

Visit [www.sonymobile.com](http://www.sonymobile.com) for more information.

All illustrations are for illustration only and may not accurately depict the actual accessory.

## Declaration of Conformity

We, Sony Mobile Communications AB of

Nya Vattentorget

SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony type **RD-0200**

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards **EN 300 328:V1.8.1, EN 301 489-3:V1.6.1, EN 301 489-7:V1.3.1, EN 301 489-17:V2.2.1 and EN 60 950-1:2006 +A11:2009+A1:2010+A12:2011** following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive 1999/5/EC.

Lund, November 2014

CE 0682



Pär Thuresson,  
*Quality Officer, SVP, Quality & Customer Services*

## FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Any change or modification not expressly approved by Sony may void the user's authority to operate the equipment.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Industry Canada Statement

This device complies with RSS-210 of Industry Canada.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Avis d'industrie Canada

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et, (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.