

Halala ngokuthenga kwakho i-Sony Ericsson K850i. Thola ushiyelane ngemizuzu eyikhwalithi. Ukuze uthole okunye okuqukethwe kwefoni, iya ku www.sonyericsson.com/fun.

Bhalisa manje uthole isixhobo samathuluzi, ukulondoloza mahhala kulayini, izipesheli, izindaba nemincintiswano ku www.sonyericsson.com/myphone.

Ngesaphothi yemikhiqizo, yiya ku
www.sonyericsson.com/support.

Izesekeli – Okwengeziwe kwefoni yakho

I-Camera Phone Kit IPK-100

Ukuvikeleka okwedlulele kwefoni yakho.



I-Bluetooth™ Headset HBH-IV835

Ukuzikhethela okusesitayeleni
okunomsindo ovelele.



I-Desk Stand CDS-65

Umsizi ongcono kakhulu wefoni yakho:
xhuma ikhebulu le-USB, ishaja nehendisfri
ephatjwayo.

Lezi sekeli zingathengwa zodwa kodwa kungenzeka zingatholakali kuzo zonke izimakethe. Ukuhlola uhla oluphelele yiya ku www.sonyericsson.com/accessories.



This is the Internet version of the User's guide. © Print only for private use.

Okuqukethwe

Ukuqalisa	5	Ukudayela okuhleliwe	30
Ukuhlanganisa	5	Isikhathi sokufona nezindleko	30
Ukuvula ifoni	5		
Usizo efonini yakho	6		
Ukushaja ibhethri	7	Ukuthumela imibiko	31
Uhlolojikelele lwefoni	8	Imibiko yombhalo	31
Uhlolojikelele lwemenyu	10	Imibiko yesithombe	32
Ukuhamba	12	Okukhethwa kukho imibiko	33
Imenenja yefayela	14	Izibonisi	34
Ulimi lwefoni	15	Imibiko yezwi	34
Ukufaka umbhalo	15	I-imeyili	35
Kushaywa ucingo	17	Abangani bami	37
Ukushaya nokwamukela izingcingo	17	Ulwazi lwendawo nolweselula	39
Oxhumene nabo	19		
Uhla lwezingingo	23		
Ukudayela okusheshayo	24	Ukufanekisa	40
Imeyili yezwi	24	Ikhamera nevidyo rekhoda	40
Ukulawula izwi	24	Isitholi sokubonayo namakhi ekhamera	40
Ukudluliselwa phambili izingcingo ...	26	Ukusebenzisa ikhamera	41
Ngaphezu kocingo olulodwa	27	Ukuthola okuthe xaxa kwikhamera	41
Izinombolo zami	28	Izimpawu namasethingi kwekhamera	42
Yamukela izingcingo	29	Amashothikhathi ekhamera	43
Ukudayela okukalelwwe	29	Kudluliswa izithombe	43
		Ukuphrinta kwekhamera	44
		Izithombe	45

I-PhotoDJ™ ne-VideoDJ™	46	Ezinye izimpawu	66
Izingqikithi	46	Ama-alamu	66
Ezokuzithokozisa	47	Ikhalenda	67
Ihendisfri ephathekayo yestiryo	47	Imisebenzi	68
Umculo nezidlali mavidyo	47	Amanothi	69
Ukudlulisa umculo usuka kwikhompyutha	48	I-timer, istophuwoshu nomshini wokubala	69
I-TrackID™	51	Ikhodi memo	70
Umsakazo	51	Amaphrofayli	71
I-PlayNow™	52	Isikhathi nosuku	71
Amaringithoni kanye nemiculo	53	Amalokhi	72
I-MusicDJ™	53	Ukuxazulula	74
Isirekhodi somsindo	54	Imibuzo evamile	74
Imidlalo	54	Imibiko enephutha	76
Izinhlelo	55	Ulwazi olubalulekile	78
Ukuxhumana	56	Imihlahlandlela yezokuphepha futhi esizayo ekusebenziseni ucingo	80
Amasethingi	56	Isivumelwano Selayisense Yomsebenzisi Wokugcina	85
Igama lefoni	56	Iwaranti Enomkhawuko	85
Kusetshenziswa i-Inthanethi	56	FCC Statement	88
Ama-feed e-Web	58	Declaration of Conformity	88
I-Bluetooth™ wireless technology	59	Uhla Iwamagama	89
Ukusebenzisa ikhebula le-USB	61		
Kuyavumelaniswa	62		
I-Update service	65		

Sony Ericsson K850i

UMTS 2100 GSM 900/1800/1900

Le Gaydi yokusebenzisa ifoni ishiclelwé ngabakwa-Sony Ericsson Mobile Communications AB noma inkampani yangakini esebeenzisana nabo, ngaphandle kwewaranti ethile. Ubungcono nezinguuko kule ncwadi yokusebenzisa ucingo okwenzive amaphutha okuthaypha, ukungalungi kolwazi lwamanje, noma ubungcono ezinhlelwé kanye/noma amathuluzi, kungenziva ngu-Sony Ericsson Mobile Communications AB noma ingasiphi isikhathi ngaphandle kwesaziso. Izinguuko ezinjalo, ngakho, ziyongeniswa kwizilhumusho ezintsha zale Gaydi yokusebenzisa ifoni.

Wonke amalungelo agodliwe.

©Sony Ericsson Mobile Communications AB, 2007

Inamba yesishicilelo: 1200-7437.1

Sicela wazi:

Amanye amasevisi akule Gaydi yokusebenzisa ifoni awasekelwe yiwo wonke amanethiwethi. *Lokhu futhi kuyenza kwiNamba Ephuthumayo Yomhlaba ye-GSM u 112.*

Sicela uxhumane no-opharetha wenethiwekhi yakho noma umnikezel i wakho wesevisi uma ungabaza noma ungasebenzisa isevihi ethile noma qha. Sicela ufunde *Imihlahlandlela yokuphepha nokusebenza okuyiko* kanye namakhasi *Ewaranti yomkhawuko ngaphambi kokusebenzisa ifoni yakho ephathekayo.*

Ifoni yakho inamandla okulanda, kulonda nokudulisa okuqukethwe okwengeziwe, isb. amaringithoni. Ukuusethenzisa kokuqukethwe okufana nalokho kungavinjelwa noma knqatshelwe ngamalungelo abantu besithathu, okubandakanja kodwa kungakalelwé kwizivimbello ezingaphansi kwemithetho yamalungelo okushicilela afanele. Wena, hhayi u-Sony Ericsson, unamandla aphelele kokuqukethwe okwengeziwe okulanda noma okudulisa kuvela efonini yakho. Ngaphambi kokusebenzisa okuqukethwe okwengeziwe,

sicela uqinisekise ukuthi ukusebenzisa okuhilosile kulayisensiwe noma kugunyaziwe. U-Sony Ericsson akaqinisekisi ngokungabi naphutha, ubuqotho noma ikhwalithi yokuqukethwe okwengeziwe noma okunye okuqukethwe kwabantu besithathu. U-Sony Ericsson ngeke abekwe icala ngokusebenzisa kwakho okungalungile kokuqukethwe okwengézive noma okunye okuqukethwe kwabantu besithathu.

I-Bluetooth™ inguphawu lokuthengisa noma inguphawu lokuthengisa olubhalisiwe lakwa-Bluetooth SIG Inc.

I-logo yemabuli, i-BestPic, i-PlayNow, i-TrackID, i-MusicDJ, i-PhotoDJ ne-VideoDJ yizimpawu zokuthengisa noma izimpawu zokuthengisa ezibhalisiwe ze-Sony Ericsson Mobile Communications AB.

I-Sony ne-Cyber-shot yizimpawu zokuhweba zika-Sony Corporation.

I-Memory Stick Micro™ ne-M2™ yizimpawu zokuthengisa zakwa-Sony Corporation.

I-Ericsson wuphawu lokuhweba noma wuphawu lokuhweba noma wuphawu lokuhweba olubhalisiwe Iwaka- Telefonaktiebolaget LM Ericsson.

I-Adobe® Photoshop® Album Starter Edition iwuphawu lokuhweba noma wuphawu lokuhweba olubhalisiwe Iwe-Adobe Systems Incorporated e-United States kanye /noma kwamanye amazwe.

I-Microsoft, i-Windows, i-Outlook i-Vista ne-PowerPoint yizimpawu zokuthengisa ezibhalisiwe noma izimpawu zokuthengisa ze-Microsoft Corporation e-U.S nakwamanye amazwe.

I-MicroSD wuphawu lokuthengisa noma uphawu lokuthengisa olubhalisiwe Iwe-SanDisk Corporation.

I-T9™ Text Input inguphawu lokuthengisa noma uphawu lokuthengisa olubhalisiwe Iwe-Tegic Communications. I-T9™ Text Input ilayisenswe ngaphansi kokukodwa noma okungaphezezulu kwalokhu okulandelayo: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, no 6,011,554; Canadian Pat. No. 1,331,057, United Kingdom Pat. No. 2238414B; Hong Kong Standard

Pat. No. HK0940329; Republic of Singapore
Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260.8)
DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; kanye
namaphathenti engeziwe asazofika emhlabeni
jikelele.

I-Java kanye nazo zonke izimpawu zokuthengisa
ezixigile kwi-Java namalogo kuyizimpawu
zokuthengisa noma izimpawu zokuthengisa
ezibhalisiwe ze-Sun Microsystems, Inc. e-U.S.
nakwamanye amazwe.

Isivumelwano selayisense yomsebenzisi wokugcina
we-Sun™ Java™ J2ME™.

Izivimbilo: I-Software ingulwazi lwamalungelo
agodliwe oluyimfilho lakwa-Sun futhi isihloko kuwo
wonke amakhophi agcinwe ngu-Sun no/noma
abantu bakhe bamalyisense. Umthengi ngeke
aguqule, ahlakaze, ahlukanise, acacise, akhiphe
noma ahlelhise i-Software kanjinriyela. I-Software
ngeke yaqashiswa, yanikezelwa, noma yalayisenswa
ngaphansi kwelaiyisense, iphelele noma ingxenye
yayo.

Imithetho Yokuthekelisa: I-Software, kubandakanya
idatha yomsebenzi osizayo, ingaphansi kwemithetho
elawula ukuthekelisa yase-U.S., kubandakanya
Umthetho Owengamele Ukuthekelisa wase-U.S.
kanye nemigomo yawo ehlobene nawo, futhi
kungaba ngaphansi kwemigomo yokuthekelisa
noma yokungenisa kwamanye amazwe. Umthengi
uvuma ukuzibophezela kuyo yonke imigomo enjalo
futhi uyavuma ukuthi unesibopho sokuthola
amalyisense okuthekelisa, ukuthekelisa kabusha,
noma ukungenisa i-Software. I-Software ngeke
yalandwa, noma ithekeliswe noma ithekeliswe
kabusha (i) ku, noma ezweni noma kumhlali wase,
Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria
(njengoba lolu hlu lungabuyekezwaza ngezikhathi
ezithile) noma kunoma iliphi izwe i-U.S. evimbele
izimpahla kulo; noma (ii) kunoma ubani oshlwini
Iwe-U.S. Treasury Department ye-Specially
Designated Nations noma i-U.S. Commerce
Department's Table of Denial Orders.

Amalungelo Avinjelwe: Ukuveshenzisa, ukuphindwa
noma ukuvezwa nguhulumeni wase-United
States kungaphansi kwezivimbelo njengoba
zibekiwe ngaphambili kwi-Rights in Technical
Data and Computer Software Clauses
kwi-DFARS 252.227-7013(c) (1) (ii)
ne FAR 52.227-19(c) (2) (njengoba kufanele.
Amanye amagama omkhiquzo nezinkampani
abawle lapha kungaba izimpawu zokuthengisa
zabanikazi abafanele.

Noma imaphi amalungelo angabaliwe lapha
agodliwe.

Yonke imifanekiso iyimifanekiso kuphela futhi
ayibonisi ifoni yangempela.

Izimpawu zemiyalelo

Lezi mpawu zivela kwigaydi
yoMsebenzisi.



Yazi



Ithiphu



Isexwayiso



Isevisi noma umsebenzi
uncike kwinethiwekhi noma
kokuthengiwe. Xhumana no-
opharetha wakho wenethiwekhi
ngemininingwane ethe thuthu.



Sebenzisa okukhethwa kukho
okuthintwayo noma ikhi
lokuhambisa ukupheqa bese
ukhetha. Bheka *Ukuhamba*
ekhasini 12.

Ukuqalisa

Ukuhlanganisa

Ngaphambi kokuqala ukusebenzisa ifoni yakho, udinga ukufaka iSIM khadi nebhethri

Faka iSIM khadi



- 1 Khipha ikhava yebhethri.
- 2 Shelelezisa iSIM khadi kwisibambi sayo izixhumi ezsagolide zibheke phansi.

Ukufaka ibhethri



- 1 Faka ibhethri isayidi lelebuli libheke phansi nezixhumi zibhekane.
- 2 Vala bese ushelelezisa ikhava yebhethri endaweni.

Ukuvula ifoni

Ukuvula ifoni



- 1 Cindezela bese ubamba ①
- 2 Khetha izinga:
 - **Imodi ejwayne.** – ukusebenza okugcwele.
 - **I-Flight mode** – okunomkhawuko.
- 3 Faka iPIN yeSIM khadi yakho, uma iceliwe bese ukhetha **Kulungile**.
- 4 Khetha ulimi.
- 5 Khetha **Qhubek > Yebo** ukusebenzisa isethaphu wizadi ngesikhathi kulandwa amasethingi.

 Uma ufuna ukulungisa iphutha khathi ukufaka i-PIN, cindezela ②.

I-SIM khadi

I-SIM (Subscriber Identity Module) khadi, oyithola ku-opharetha wenethiwekhi yakho, inolwazi lokuthenga kwakho. Njalo ubovala ifoni yakho bese ukhipha ishaja ngaphambi kokufaka noma kokukhipha i-SIM khadi.

-  *Ungagcina oxhumana nabo ku-SIM khadi ngaphambi kokuyikhipha efonini yakho. Bheka Ukukopishela amagama nezinombolo kwiSIM khadi ekhasini 20.*

I-PIN

Ungahle udinge i-PIN (Personal Identification Number) ukwenza kusebenze amasevisi efonini yakho. I-PIN yakho ilinzechwa wu-opharetha wenethiwekhi yakho. Idjithi ngayinye ye-PIN ivela njenge *, ngaphandle uma iqala ngamadijithi enamba yezimo eziphuthumayo, isibonelo, 112 noma 911. Ungabona futhi ushayele inamba yezimo eziphuthumayo ngaphandle kokufaka i-PIN.

-  *Uma ufaka iPIN yakho ngokungeyikho izikhathi ezintathu zilandelana, iSIM khadi iyavimbeka. Bheka llokhi yeSIM khadi ekhasini 72.*

I-Flight mode

Ku **I-Flight mode** ama-transceivers enethiwekhi nawomsakazo ayavalwa ukunqanda ukuphazamiseka empahleni ebucayi.

-  *Ungasebenzisa umsebenzi we-Bluetooth™ kwi-Flight mode.*

Isibuko sokuqalisa

Isibuko sokuqalisa sivela uma uvula ifoni yakho. Bheka **Ukusebenzisa izithombe** ekhasini 45.

Okubekwe eceleni

Emva kokuba usuyivilile ifoni yakho wakafa ne-PIN yakho, igama lika-opharetha wenethiwekhi liyavela. Lokhu kuthiwa okubekwe eceleni.

Usizo efonini yakho

Usizo nolwazi kuyatholakala efonini yakho. Bheka **Ukuhamba** ekhasini 12.

Ukusebenzisa isethaphu wizadi

- 1 Kokubekwe eceleni khetha **lmenu** > **Izinhlelo** > eye **Okujwayelekile** ithebu > **Isetaphu wizadi**.
- 2 Khetha ongakhetha kukho.

Ukuhlola ulwazi ngemisebenzi

- Pheqela kumsebenzi bese ukhetha **Ulwazi**, uma luhkona. Kokunye, i **Ulwazi** ivela ngaphansi kwe Izinketho.

Ukuhlola ukuboniswa kwefoni

- Kokubekwe eceleni khetha **Imenu** > **Imidlalo** > **I-Demo tour**.

Ukuhlola ulwazi lezinga

- Kokubekwe eceleni cinddezela ukhuphule ikhi yevolume.

Ukushaja ibhethri

Ibhethri yefoni ishajeke kancane uma uyithenga.

Ukushaja ibhethri

①



②




1 Xhuma ishaja kwifoni. Kuthatha cishe 2.5 amahora ukushaja ibhethri ngokugcwle. Cinddezela ikhi ukuhlola isibuko.

2 Khipha ishaja ngokugobisela ipulaki phezulu.


-💡 *Ungayisebenza ifoni yakho ngesikhathi isashaja. Ungashaja ibhethri noma nini isikhathi esingaphezu noma esingaphansi kuka 2.5 amahora. Ungakumisa ukushaja ngaphandle kokulimaza ibhethri.*

Uhlolojikelele Iwefoni

- 1 Ispikha sasendlebeni
- 2 Isibuko
- 3 Okukhethwa kukho okuthintwayo
- 4 Ikhi lemenyu yomsebenzi
- 5 Ikhi yokushaya ucingo
- 6 Ikhi yokuhamba
- 7 Ikhamera yocingo Iwevidyo
- 8 Ivolumu, amakhi e-zoom edijithali
- 9 Ikhi ye-C (Sula)
- 10 Ikhi yokuqedo
- 11 Ikhi yokushintsha izinga lekhamera
- 12 Ikhi yekhamera
- 13 Ikhi yokuvula/ukuvala ikhamera
- 14 Ikhi lokuthulisa
- 15 Isixumi seshaja, ihendisfri nekhebulu le-USB



- 16 Ikhi yokuvula/ukuvala
- 17 Ikhava yelensi yekhamera
- 18 Ifleshi



Uhlolojikelele Iwemenyu



I-PlayNow™*



I-inthanethi*



Imidlalo

Amasevisi akulayi.*
Imidlalo
TrackID™
VideoDJ™
PhotoDJ™
I-MusicDJ™
Isiqhebeza buqama
Qopho umsindo
I-Demo tour



Cyber-shot™



Imibiko ethunyel.



Imidiya

Bhala okusha
Ibhokisi lokunge
I-meiyili
Ama-feed eWeb
Izinhlaka
Ibhokisi lokuphu
Thumela izinhla
Izinhlamvu ezigc
Abangani bami*
Foneta isiqopha.
Izibonisi
Lawula imiyalezo
Izinhlelo



Ama-alamu



Ifonibhuku

Mina qobo
Oxhumene naye



Umsakazo



Lizingingo**



Konke



Luphenduliwe



Ludayeliwe



Aluphendulwanga



Umhleli

Imenenja yefayela**
Izicelo
Ucingo Iwevidyo
Ikhalenda
Imisebenzi
Amanothi
Ukw. kuhambi.
Isikhathi
Isimisa washi
Umshi. wokubala
Isiqophi sekhozi



Izinhlelo**



Okujwayelekile

Amaphrofayli

Isikhathi nosuku

Ulimi

I-Update service

Lawula izwi

Izigamek. ezintsha

Oshothikhathi

I-Flight mode

Ezokuphepha

Isethaphu wizadi

Ukungeneka

Izinga lefoni

Isihleli esikhulu



Imisindo nezibonis
Ivolumu yeringith.

Iringithoni

Imodi ethule

Nyusa umsindo

Isixwa. sokudlikiza

Osungafundwa

Ikhi lomsindo



Khombisa
Iphepha lodonga

Izingqikithi

Isibuko sokuqualisa

Londa isibuko

Usayizi wewashi

Ukugqama

Hlela ulayini*



Izingingo
Dayela ngokushesh

Ukucinga Iwe-Smart

Phambula

Phendulela ku-2*

Singatha izin.

Ukuhlanganyela

ivid*

Isikhathi nezindlek*

Kho./fihla ina.yami

Ihndisifri



Ukuxhumana*

I-Bluetooth

I-USB

Igama lefoni

Ukuhlan ngenethwek

Ukw. kuhambi.

Ukusingathwa kwedi.

Amanethiwekhi a

Izinhlelo ze-inthan

Izinhlelo zokuham

Izinhlelo zombiko*

Izesekeli


* Amanyae amamenyu ancike ku-opharetha, kwinethiwekhi nasekuthengeni.

** Ungasebeniza ikhi lokuhamba ukupheqa kumathethu kumamenyu amancane. Ngolunye ulwazi,
bhaka Ukuhamba ekhasini 12.

Ukuhamba

Amamenyu amakhulu akhonjiswa njengezimpawu. Amanye amamenyu amancane abandakanya amathebhu.

Ukuhamba kumamenyu efonи




- 1 Kokubekwe eceleni khetha **Imenu**
- 2 Sebenzisa ikhi yokuhamba ukuhamba kumamenyu.

Ukupheqa kumathebhu

- Pheqelal kwithebhu ngokucindezela ikhi lokuhamba esinxeleni noma kesokudla.

Ukusebenzisa okukhethwa kukho kokuthinta

Okukhethwa kukho okuthintwayo



- Khetha isenzo esikhonjiswe phansi esibukweni ngokucindezela okukhethwa kukho okuthintwayo esinxeleni, phakathi noma kwesokudla.

Ukuhlola okukhethwa kukho kwento

- Khetha **Izkinketho** ukuze, isibonelo, uhlele.

Ukubuyela kokubekwe eceleni

- Cindezela **▲**.

Ukuqedu umsebenzi

- Cindezela **▼**.

Tukuhamba kwimidya yakho

- 1 Kokubekwe eceleni khetha **I'midiya**
- 2 Sebenzisa ikhi yokuhamba ukuya phezulu, phansi, esinxeleni nakwesokudla kumamenyu.

Ukususa izinto

- Cindezela  ukususa izinto ezifana nezinamba, izinhlamvu, izithombe nemisindo.

Amashothikhathi

Ungasebenzisa amashothikhathi ekhiphedi ukuya ngqo kwimenu. Ukufakwa kwezinamba kumamenyu kuqala kuphawu oluphezulu esinxeleni kunqamule kuye kolunye uhlangothi bese kwehla umugqa ngomugqa.

Ukuya ngqo kwimenu enkulu

- Kokubekwe eceleni khetha **I'menu** bese ucindezela  – , ,  noma .

Ukusebenzisa amashothikhathi ekhi lokuhamba

- Kokubekwe ecele cindezela , ,  noma  ukuya ngqo kumsebenzi.

Ukuhlela ishothikhathi yekhi lokuhamba

- 1 Kokubekwe eceleni khetha **I'menu** > **Izinhlelo** > eye **Okujwayelekile** ithebhу > **Oshothikhathi**.
- 2 Pheqela kokukhethwa kukho bese ukhetha **Hlela**.
- 3 Pheqela kokukhethwa kukho kwemenyu bese ukhetha **Shotkh**.

I'menu yomsebenzi

I'menu yomsebenzi yenza ufinyelele ngokushesha kwimisebenzi ethile.

Ukuvula imenu yomsebenzi

- Cindezela .

Amathebhу emenu yomsebenzi

- **Izig. ezintsha** – izingcingo ezingabanjwanga nemibiko emisha.
- **Izinhlelo eziha.** – izinhlelo ezihambayo ngemuva kwisendlalelo.
- **Amashothikh. ami** – ngeza imisebenzi oyikhonzile ukuze ufinyelele kuyo ngokushesha.
- **I-inthanethi** – ukufinyelela ngokushesha kwi-Inthanethi.

Imenenja yefayela


Ungasebenzisa imenenja yefayela ukusingatha amafayela agcinwe kwimemori yefoni noma kwimemori khadi.

- ! Kungadingeka uthenge imemori khadi eceleni.

Imemori khadi


Ifony yakho isekela i-Memory Stick Micro™ (M2™) noma i-MicroSD™ memori khadi okwengeza esinye isikhala sokulondoloza efonini yakho. Ingasetshenziswa futhi njengememori khadi ephathekayo namanye amadivaysi afanelene.

Ukufaka imemori khadi



- Vula ikhava yebhethri. Faka imemori khadi ye-Memory Stick Micro™ (M2™) okokuthintana okusagolide kubheke phezulu noma faka imemori khadi ye-MicroSD™ okokuthintana okusagolide kubheke phansi.

Ukukhipha imemori khadi



- Vula ikhava yebhethri bese ucindezela ekugcineni kwememori khadi ukulikhulula bese uyalikhipha.

Ukuhlola okukhethwa kukho imemori khadi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umhleli](#) > [Imenenja yefayela](#) > [eye Kwimemori khadi](#) ithebhу.
- 2 Khetha [Izinketho](#).

Ukusingatha amafayela

Ungahambisa futhi ukopishe amafayela phakathi kwefoni yakho, ikhompyutha nememori khadi. Amafayela agcinwa kwimemori khadi kuqala bese kuba yikwimemori yefoni. Amafayela angaziwa agcinwa [Okunye](#) kwifolda.

Ungakha amafolda amancane ukuhambisa noma ukukopishela amafayela ku. Ungakhetha ngaphezu kweyodwa noma wonke amafayela

kwifolda ngesikhathi awowonke amafolda ngaphandle kwe [Imidlalo](#) ne [Izelolo](#).

Uma imemori igcwele, susa okunye okuqukethwe ukwakha isikhala.

Amathebhу emenenja yamafayela
Imenenja yefayela ihlukaniswe ngamathebhу amathathu, nezimpawu zikubonisa lapho amafayela agcinwe khona.

- [Wonke amafayela](#) – konke okuqukethwe kwimemori yefoni nakwimemori khadi
- [Efonini](#) – konke okuqukethwe kwimemori yefoni.
- [Kwimemori khadi](#) – konke okuqukethwe kwimemori khadi

Ukuhlola ulwazi ngamafayela

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Thola ifayela bese ukhetha [Izinketho](#) > [Ulwazi](#).

Ukusebenzisa ifayela kwimennenja yefayela

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Thola ifayela bese ukhetha [Izinketho](#) > [Singatha ifayela](#) > [Hambisa](#).
- 3 Khetha ongakhetha kukho.

Ukukhetha ngaphezu kwefayela elilodwa kwifolda

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Pheqela kwifolda bese ukhetha [Vula](#).
- 3 Khetha [Izinketho](#) > [Maka](#) > [Maka okuningi](#).
- 4 Kwifayela ngalinye ofuna ukulimaka, pheqela kulona bese uyalikhetha [Maka](#).

Ukususa ifayela kwimennenja yefayela

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Thola ifayela bese ucindezela [c](#).

Ulimi Iwefoni

Ungakhetha ulwimi ozolusebenzisa efonini yakho.

Ukushintsha ulimi Iwefoni

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Izinhlelo](#) > eye [Okujwayelekile](#) ithebhу > [Ulimi](#) > [Ulimi Iwefoni](#).
- 2 Khetha ongakhetha kukho.

Ukufaka umbhalo

Ungasebenzisa i-multitap text input noma i-T9™ Text Input  ukufaka umbhalo. Indlela ye-T9 Text Input isebeenzisa isichazamazwi esakhelwe ngaphakathi.

Ukushintsha indlela ye-text input

- Uma ufaka umbhalo, cindezela bese ubamba 

Ukushintsha phakathi kosonhlamvukazi abakhulu nabancane.

- Uma ufaka umbhalo, cindezela 

Ukfaka izinamba

- Uma ufaka umbhalo, cindezela bese ubamba  - 

Ukfaka amafulstophu namakhoma

- Uma ufaka umbhalo, cindezela 

Ukfaka umbhalo usebenzisa i-T9™ Text Input

- 1 Kokubekwe eceleni khetha, isibonelo, Imenu > Imibiko ethunyel. > Bhala okusha > Umbiko womb.
- 2 Uma  kungakhonjiswa, cindezela bese ubamba  ukushintshela ku-T9 Text Input.
- 3 Cindezela ikhi ngayinye kanye kuphela, noma ngabe lolohlamvu olufunayo akulona olukuqala kwikhi. Isibonelo, ukubhala igama elithi "Jane", cindezela , , ,  noma  ukuhlola imibono.
- 5 Cindezela  ukwamukela umbono.

Ukufaka umbhalo ngokusebenzisa i-multitap

- 1 Kokubekwe eceleni khetha, isibonelo, Imenu > Imibiko ethunyel. > Bhala okusha > Umbiko womb.
- 2 Uma  ukhonjiswa, cindezela bese ubamba  ukushintshela ku-multitap text input.
- 3 Cindezela  -  ngokuphindelala kuze kuvele uhlamvu olufunayo.
- 4 Uma igama libhalwa, cindezela  ukwengeza isikhala.

Ukwengeza amagama kwisichazamazwi esakhelwe ngaphakathi

- 1 Uma ufaka umbhalo usebenzisa i-T9 Text Input, khetha [Izinketho](#) > Pela igama.
- 2 Bhala igama usebenzisa i-multitap input bese ukhetha [Faka](#).

Kushaywa ucingo

Ukushaya nokwamukela izingcingo

Udinga ukuvula ifoni yakho bese uba sendaweni eyamukela inethiwekhi.

Ukushaya ucingo

- 1 Kokubekwe eceleni faka inamba yefoni (nekhodi lamazwe omhlaba jikelele nekhodi lendawo, uma kudingeka).
- 2 Cindezela ↗.
Bheka Ucingo Iwevidyo ekhasini 18.

 **Ungashayela izinamba ezikoxhumene nabo nasohlwini Iwezingingo.** Bheka Oxhumene nabo ekhsini 19, ne Uhla Iwezingingo ekhasini 23.
Ungasebeniza futhi izwi lakkhu ukushaya izingcingo. Bheka Ukulawula izwi ekhasini 24.

Ukushaya izingcingo zomhlaba jikelele

- 1 Kokubekwe eceleni cindezela +
kuze kuvele uphawu “+”.
- 2 Fakaikhodi yezwe, ikhodi yendawo (ngaphandle kuka-zero wokuqala) nenamba yefoni.
- 3 Cindezela ↗.

Ukudayela kabusha inombolo

- Uma Phinda uzame? kuvela khetha Yebo.

 **Ungayibeki ifoni yakho endlebeni ngenkathi usalindile.** Uma ucingo luxhuma, ifoni inika isignalii enomsindo.

Ukuphendula ucingo

- Cindezela ↗.

Ukudikila ucingo

- Cindezela ↘.

Ukushintsha ivolumu yespikha sasendlebeni ngesikhathi socingo

- Cindezela ikhi yevolumu iye phezulu noma ezansi.

Ukuthulisa imakhrofoni ngesikhathi socingo

- 1 Cindezela bese ubamba .
- 2 Cindezela bese ubamba
futhi ukuqhubeka.

Ukuvula ilawudispikha ngesikhathi socingo

- Khetha Ispikha.

 **Ungayibeki endlebeni ifoni yakho ngenkathi usebenzisa ilawudispikha.** Lokhu kungalimaza izindlebe zakho.

Ukuhlola izingcingo

ezingabanjwanga kokubekwe eceleni

- Cindezela bese upheqela kweye **Izigamek.** ezintsha ithebhu bese ukhetra inamba.
- Cinezela ukuvula uhlu lwezingingo.

Amanethiwekhi

Iponi yakho izishintsha ngokwayo phakathi kwamanethiwekhi e-GSM nave-3G (UMTS) kuncike ekutholakaleni. O-opharetha abathile bamanethiwekhi bakuvumela ukuba ushintshanise amanethiwekhi ngesandla.

Ukushintsha amanethiwekhi ngesandla

- 1 Kokubekwe eceleni khetha **Imenu** > **Izhinlelo** > eye **Ukuxhumana** ithebhu > **Amanethiwekhi a** > **Amanet. e-GSM/3G.**
- 2 Khetha ongakhetha kukho.

Izingingo eziphuthumayo

Iponi yakho isekela izinombolo zamazwe omhlaba jikelele eziphuthumayo, isibonelo, u-112 no-911. Lezi zinombolo zingasetshenziswa ngendlela ejwayelekile ukushayela inombolo ephuthumayo kunoma yiliphi izwe,

kufakwe noma ingafakiwe i-SIM khadi, uma nje inethiwekhi ye-3G (UMTS) noma ye-GSM isohlelwini lokwemukela izingcingo.

! **Kwamanye amazwe, ezinye izinombolo eziphuthumayo zingakhangiswa.**

U-opharetha wakho kungenza kuka uvele usezicinile kwi-SIM khadi yakho izinombolo ezengenziwe eziphuthumayo zasekhaya.

Ukushaya ucingo oluphuthumayo

- Kokubekwe eceleni faka 112 (inamba yezimo eziphuthumayo yomhlal awonke) bese ucindezela .

Ukuhlola izinombolo eziphuthumayo zakho zasekhaya

- 1 Kokubekwe eceleni khetha **Imenu** > **Ifonibuku.**
- 2 Pheqela ku **Oxhumene naye** bese ukhetra **Izinketho** > **Izinombolo ezithile** > **Izinamba eziphuth.**

Ucingo Iwevidyo

Bona umuntu esibukweni ngesikhathi sezingingo. Womabilo amaqwmbu adinga ukuthenga okwesekela isevisi ye-3G (UMTS), futhi udinga ukuba ukwazi ukwamukela inethiwekhi ye-3G (UMTS). Inethiwekhi ye-3G (UMTS) iyatholakala uma kuvela.

Ukushaya ucingo lwevidyo

- 1 Kokubekwe eceleni faka inamba yefoni (nekhodi lamazwe omhlaba jikelele nekhodi lendawo, uma kudingeka).
- 2 Khetha [Izinketho](#) > [Shaya ucingo lwe.](#)

Ukusebenzisa i-zoom nocingo oluphumayo lwevidyo

- Cindezela noma .

Ukuhlola okukhethwa kukho kwezingcingo zevidyo

- Ngesikhathi socingo, khetha [Izinketho](#).

Oxhumene nabo

Ungagcina amagama, izinamba zefoni nolwazi oluqondene nawe ku [Ifonibhuku](#). Ulwazi lungagcinwa kwimemori yefoni noma kwi-SIM khadi.

Oxhumene naye wedifolthi

Ungakhethwa ukuthi yiluphi ulwazi loxhumene nabo olukhonjiswa njengedifolthi. Uma [Abangani](#) ekhethwe njengedifolthi, oxhumana nabo bakhombisa lonke ulwazi olugcinwe ku [Ifonibhuku](#). Uma ukhetha [Izinombolo zeSIM](#) njengedifolthi, oxhumana nabo bakhombisa amagama nezinamba okugcinwe kwiSIM khadi.

Ukukhetha oxhumene nabo bedifolthi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Okukhethwa](#) > [Kuthuthukile](#) > [Oxhumene nabo a.](#)
- 3 Khetha ongakhetha kukho.

Oxhumene nabo befoni

Oxhumana nabo befoni bangaba namagama, izinamba zefoni nolwazi oluqondene nabo. Igcinwa kwimemori yefoni.

Ukwengeza oxhumana naye efonini

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Engeza](#).
- 3 Faka igama bese ukhetha [Kulungile](#).
- 4 Faka igama bese ukhetha [Kulungile](#).
- 5 Khetha okukhethwa kukho inamba.
- 6 Pheqa phakathi kwamathebhу bese ukhetha izindima ukwengeza ulwazi.
- 7 Khetha [Gcina](#).

Ukufonela oxhumana nabo

Ukushayela oxhumana naye efonini

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibhuku](#).
- 2 Pheqela koxhumana naye bese ucindezela .

 **Ukuya nggo koxhumene naye, kokubekwe eceleni cinddezela bese ubamba** (2) – (9).

Ukufonela oxhumana naye we-SIM ophuma koxhumana nabo befon

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Oku.kukho** > **Izinombolo zeSIM**.
- 3 Pheqela koxhumana naye bese ucinddezela ↵.

Ukufona nge-Smart search

- 1 Kokubekwe eceleni cinddezela (1) – (9) ukufaka igama noma inamba yefoni koxhumana naye. Konke okufakwayo okuhambisana nokulandelana kwamadjithi noma izinhlamvu kukhonjiswa ohlwini.
- 2 Pheqela koxhumana naye noma inamba yocingo bese ucinddezela ↵.

Ukuvula noma ukuvala i-Smart search

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Izingingo** ithebhу > **Ukcinga lwe-Smart**.
- 2 Khetha ongakhetha kukho.

Ukuhlela oxhumana nabo

Ukwengeza ulwazi koxhumene naye efonini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela koxhumana naye bese ukhetha **Izinketho** > **Hlela oxhumene n.**
- 3 Pheqa phakathi kwamathebhu bese ukhetha **Engeza**.
- 4 Khetha okukhethwa kukho nento ozokufaka.
- 5 Khetha **Gcina**.

 **Uma okuthengwayo kwakho kusekela isevisi Ukwaziswa Kolayini Oforonayo (CLI), unganikezela iringithoni eqondene nawe koxhumene nabo.**

Ukukopishela amagama nezinombolo kwiSIM khadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Kopisha kwiSIM**.
- 3 Khetha ongakhetha kukho.

Ukugcina nge-othomathikhi amagama nezinamba zefoni kwiSIM khadi

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Izinketho](#) > [Kuthuthukile](#)
> [Ukulonda nge-Otho](#).
- 3 Khetha ongakhetha kukho.

Ukugcina oxhumana nabo kumemori khadi

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Izinketho](#) > [Kuthuthukile](#)
> [Saphotha i-M.C.](#).

oxhumene nabo be-SIM

Oxhumana nabo be-SIM bangaba namagama nezinamba kuphela.
Bagcinwa kwi-SIM khadi.

Ukwengeza oxhumene naye we-SIM

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Engeza](#).
- 3 Faka igama bese ukhetha [Kulungile](#).
- 4 Faka igama bese ukhetha [Kulungile](#).
- 5 Khetha okukhethwa kukho kwenamba bese wengeza olunye ulwazi, uma lukhona.
- 6 Khetha [Gcina](#).

! *Uma ukopisha bonke oxhumene nabo basuke efonini baye kwiSIM khadi, lonke ulwazi olukwiSIM khadi luyasuswa kufakwe olusha.*

Ukushayela ucingo oxhumene naye kwi-SIM

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela koxhumana naye bese ucindezela .

Ukukopisha amagama nezinamba koxhumana nabo efonini

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Izinketho](#) > [Kuthuthukile](#)
> [Kopisha kwi-SIM](#).
- 3 Khetha ongakhetha kukho.

Ukususa oxhumana nabo

Ukususa oxhumene naye

- 1 Kokubekwe eceleni khetha [Imenuy](#)
> [Ifonibhuku](#).
- 2 Pheqela koxhumana naye bese ucindezela .

Ukususa bonke oxhumene nabo befoni

- 1 Kokubekwe eceleni khetha [Imenuy > Ifonibhuku.](#)
- 2 Pheqela ku [Oxhumene naye bese ukhetha Izinketho > Kuthuthukile > Susa bonke oxhum.](#)

Ukuthumela oxhumana nabo

Ukuthumela oxhumene naye

- 1 Kokubekwe eceleni khetha [Imenuy > Ifonibhuku.](#)
 - 2 Pheqela koxhumana naye bese ukhetha [Izinketho > Thumela umngani.](#)
 - 3 Khetha indlela yokudlulisa.
- ! [Qinisekisa ukuthi idvaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.](#)

Izinga lememori

Isibalo soxhumene nabo ongabagcina kwifoni yakho noma kwiSIM khadi sincike kwimemori etholakalayo.

Ukuhlola izinga lememori

- 1 Kokubekwe eceleni khetha [Imenuy > Ifonibhuku.](#)
- 2 Pheqela ku [Oxhumene naye bese ukhetha Izinketho > Kuthuthukile > Izinga lesiqophi.](#)

Ukuvumelanisa oxhumene nabo
Oxhumana nabo bangavumeniswa nge-Microsoft Exchange Server (Microsoft® Outlook®). Ngolunye ulwazi bheka [Kuyavumelaniswa ekhasini 62.](#)

Mina

Ungafaka ulwazi olumayelana nawe bese, isibonelo, uthumela ibhizinesi khadi yakho.

Ukufaka ulwazi Lwami

- 1 Kokubekwe eceleni khetha [Imenuy > Ifonibhuku.](#)
- 2 Pheqela ku [Mina qobo bese ukhetha Vula.](#)
- 3 Pheqela kokukhethwa kukho bese uhlela ulwazi.
- 4 Khetha [Gcina.](#)

Ukufaka ibhizinesi khadi yakho

- 1 Kokubekwe eceleni khetha [Imenuy > Ifonibhuku.](#)
- 2 Pheqela ku [Mina qobo bese ukhetha Vula.](#)
- 3 Pheqela ku [Iminin yokux nami bese ukhetha Engeza > Qamba okusha.](#)
- 4 Pheqa phakathi kwamathebhу bese ukhetha izindima ukwengeza ulwazi.
- 5 Faka ulwazi bese ukhetha [Gcina.](#)

- [Ukufaka uphawu khetha Izinketho > Faka uphawu > Faka.](#)

Ukuthumela ibhizinesi khadi yakho

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibhuku](#).
 - 2 Pheqela ku [Mina qobo](#) bese ukhetha [Vula](#).
 - 3 Pheqela ku [Iminin yokux nami](#) bese ukhetha [Thumel](#).
 - 4 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Amaqembu

Ungakha iqoqo lezinamba zefoni namakheli e-imelyi nge [Abangani](#) ukuthumela imibiko ku. Bheka *Ukuthumela imibiko* ekhasini 31. Ungasebenzisa futhi amaqembu (nezinamba zezingcingo) uma wakha uhlu lwabafonayo abamu kelekile. Bheka *Yamukela izingcingo* ekhasini 29.

Ukwakha iqoqo lezinamba namakheli e-imelyi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Okukukho](#) > [Amaqembu](#).
- 3 Pheqela ku [Iqembu elisha](#) bese ukhetha [Engeza](#).
- 4 Faka igama leqembu bese ukhetha [Qhubek](#).

5 Pheqela ku [Okusha](#) bese ukhetha [Engeza](#).

6 Kuleyo naleyo namba yoxhumana naye noma ikheli le-imelyi ofuna ukukumaka, pheqela kukona bese ukhetha [Maka](#).

7 Khetha [Qhubek](#) > [Kwenziw](#).

Uhla Iwezingcingo

Ungahlola ulwazi mayelana nezingcingo zakamuva.

Ukushayela inombolo ohlwini Iwezingcingo

- 1 Kokubekwe eceleni cindezela ↗ bese upheqela kwithebhу.
- 2 Pheqela kwigama noma inamba yocingo bese ucindezela ↗.

Ukwengeza inombolo yohlu Iwezingcingo koxhumene nabo

- 1 Kokubekwe eceleni cindezela ↗ bese upheqela kwithebhу.
- 2 Pheqa enambeni bese ukhetha [Gcina](#).
- 3 Khetha [Oxhumene naye](#) ukwakha oxhumene naye omusha noma khetha oxhumene naye ovele okhona ukwengeza inamba kuye.

Ukusula uhla Iwezingcingo

- 1 Kokubekwe eceleni cindezela ↗
- 2 Pheqela kweye [Konke](#) ithebhу bese ukhetha [Izinketho](#) > [Susa konke](#).

Ukudayela okusheshayo

Ukudayela okusheshayo kukuvumela ukhethe oxhumananababo abayisishiyagalolunye ongabashayela ngokushesha. Oxhumana nayo bangagcinwa ezindaweni 1-9.

Ukweneza oxhumana nabo kwizinamba zokudayela ngokushesha

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ifoniibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Okukukho](#) > [Dayela ngokushesh](#).
- 3 Pheqela kwinamba yesikhala bese ukhetha [Engeza](#).
- 4 Khetha oxhumana naye.

Ukudayela ngokushesha

- Kokubekwe eceleni faka inamba yendawo bese ucinezela ↗.

Imeyili yezwi

Uma ukuthenga kwakho kubandakanya isevisi yokuphendula, umshayilucingo angashiya umbiko kwisiqophambiko uma ungeke ukwazi ukuphendula ucingo.

Ukuhlela inamba yemeyili yezwi yakho

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel](#). > [Izhinlelo](#) > [Inombolo yesiqoph](#).
 - 2 Faka igama bese ukhetha [Kulungile](#).
- Ukushayela isevisi yemeyili yezwi yakho*
- Kokubekwe eceleni cindezela bese ubamba [\(1\)](#).

Ukulawula izwi

Ngokwakha imiyalo yezwi unga:

- Dayela ngezwi – fonela umuntu ngokuthi usho igama lakhe.
- Vula ukudayela ngezwi ngokuthi usho “igama eliwumlingo”.
- Phendula noma udkile izingcingo ngenkathi usebenzisa ihendisifri

Ukurekhoda umyalo wezwi ngokusebenzisa ukudayela ngezwi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Izhinlelo](#) > eye [Okujwayelekile](#) ithebu > [Lawula izwi](#) > [Ukudayela ngezwi](#) > [Cupha](#).
- 2 Khetha [Yebo](#) > [Izwi elisha lomyalelo](#) bese ukhetha oxhumana naye. Uma oxhumana naye enezinamba ezingaphezu kweyodwa, khetha inamba ozofaka kuyo umyalo wezwi.

- Rekhoda umyalelo wezwi njengokuthi "John mobile".
- Landela imiyalelo evelayo. Lindela ithoni bese usho umyalelo ozowurekhoda. Umyalelo wezwi ubuye udlalelwona.
- Uma imisindo yokurekhoda ikahle, khetha **Yebo**. Uma kungenjalo, khetha **Cha** bese uphinda izinyathelo 3 no 4.
- ! Imiyalo yezwi igcinwa kwimemori yefoni kuphela. Ayikwazi ukusetshenziswa kwenye ifoni.**

Ukuze urekhode kabusha umyalelo wezwi

- Kokubekwe eceleni khetha **Imenu** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **Lawula izwi** > **Ukudayela ngezwi** > **Hlela amagama**.
- Pheqela kumyalelo bese ukhetha **Izinketho** > **Faka okunye esi**.
- Lindela ithoni bese usho umyalelo.

Ukudayela ngezwi

Ungalalela igama loxhumene naye omrekhodile uma wamukela ucingo oluvela kuyena.

Ukudayela ngezwi

- Kokubekwe eceleni cindezela bese ubamba ikhi yevolumu.
- Lindela ithoni bese usho igama elirekhodiwe, isibonelo "John mobile". Igama ubuye udlalelwona kanti nocingo luxhumekile.

Igama eliwumlingo

Ungarekhoda bese usebenzisa umyalelo wezwi njengegama eliwumlingo ukucupha ukudayela kwezwi ngaphandle kokucindezela amakhi. Ihendisfri yakho kufanele ixhumeke kwifoni yakho uma usebenzisa igama eliwumlingo.

- ! Kumele ukhethe igama elide nelingajwayelekile noma umushwana ongahlukaniswa kalula enkulumeni eyjwayelelike neyisendlalelo. Ihendisfri ye-Bluetooth ayisesekeli le sici.**

Ukuvula nokuqophaa igama eliwumlingo

- Kokubekwe eceleni khetha **Imenu** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **Lawula izwi** > **Igama eliwumlingo** > **Cupha**.
- Landela imiyalelo evelayo bese ukhetha **Qhubek**. Lindela izwi bese usho igama eliwumlingo.

- 3 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.
- 4 Landela imiyalelo evelayo bese ukhetha **Qhubek**.
- 5 Khetha ukuthi lizocushwa kuphi igama lakho eliwumlingo.

***Ukushaya ucingo ngokusebenzisa
igama eliwumlingo***

- 1 Kokubekwe eceleni qinisekisa ukuthi i iyabonakala.
- 2 Yisho igama eliwumlingo.
- 3 Lindela ithoni bese usho umyalelo wezwi.

Ukuphendula ngezwi

Uma usebenzisa ihendisfri, ungaphendula noma udikile izingcingo ezingenayo ngezwi lakho.

***Ukuvula uhlelo lokuphendula ngezwi
bese uqopha imiyalelo yokuphendula
ngezwi***

- 1 Kokubekwe eceleni khetha **Imenu** > **Izhinlelo** > eye **Okujwayelekile** ithebhу > **Lawula izwi** > **Ukuphendula ngez.** > **Cupha**.
- 2 Landela imiyalelo evelayo bese ukhetha **Qhubek**. Lindela ithoni uthi "Phendula", noma elinye igama.
- 3 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.

- 4 Landela imiyalelo evelayo bese ukhetha **Qhubek**. Lindela izwi bese usho igama eliwumlingo "Bhizi", noma elinye igama.

- 5 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.

- 6 Landela imiyalelo evelayo bese ukhetha **Qhubek**.

- 7 Khetha ukuthi kuzocushwa kuphi ukuphendula ngezwi kwakho.

***Ukuphendula ucingo usebenzisa
imiyalelo yezwi***

- Yithi "Phendula".

***Ukudlulisela phambili
imiyalelo yezwi***

- Yithi "Bhizi".

***Ukudlulisela phambili
izingcingo***

Ungadlulisela phambili izingcingo, isibonelo, ziye kwisevisi yokuphendula.

- !
Uma Kholi alawuliwe isetshenziswa, okunye okukhethwa kukho kokushaya izingcingo akutholakali. Bheka **Ukudayela** okukalelwе ekhasinи 29.

Okukhethwa kukho kokudlulisela phambili izingcingo
Okukhethwa kukho okujwayelekile yilokhu:

- **Onke amakholi** – dlulisela phambili zonke izingcingo zakho
- **Uma kubhizi** – uma ucingo luqhubeaka
- **Awutholakali** – uma ifoni yakho ivaliwe noma ingafinyeleleki.
- **Nampendulo** – uma ucingo lungaphendulwanga ngesikhathi esithile.

Ukudlulisela phambili izingcingo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Izingcin**. ithebhу > **Phambula**.
- 2 Khetha uhlollo locingo nokukhethwa kukho kokudlulisela phambili.
- 3 Khetha **Vuselela**.
- 4 Faka inamba ozodlulisela phambili kuyona izingcingo bese ukhetha **Kulungile**.

Ngaphezu kocingo olulodwa

Ungasingatha ngaphezu kocingo olulodwa ngesikhathi. Isibonelo, ungalindisa ucingo oluqhubebakayo, khathi ushaya noma uphendula ucingo lvesibili. Ungashintshanisa futhi phakathi kwezingcingo ezimbili.

Awukwazi ukuphendula ucingo lwsithathu ngaphandle kokuqeda olunye Iwezingcingo ezimbili zokuqala.

Ucingo lulindile

Uma ucingo olulindile kucushiwe, uzwa ibhiphu uma wamukela ucingo lwsibili.

Ukucupha ucingo olulindile

- Kokubekwe eceleni khetha **Imenyu**
> **Izinhlelo** > eye **Izingcin**. ithebhу
> **Singatha izin**. > **Azophendulwu**
> **Vuselela**.

Ukushaya ucingo lwsibili

- 1 Ngesikhathi socingo, khetha **Izinketho** > **Bamba**. Lokhu kumisa ucingo olusaqhubeaka.
- 2 Khetha **Izinketho** > **Engeza ucingo**.
- 3 Faka inamba ozoyifonela bese ucindezelā ↗.

Ukushaya ucingo lwsibili

- Ngesikhathi socingo, cindezelā ↗. Lokhu kumisa ucingo olusaqhubeaka.

Ukudikila ucingo lwsibili

- Ngesikhathi socingo, cindezelā ↗ bese uqhubeaka nocingo oluqhubebakayo.

Ukuqedo ucingo oluqhubekeyo bese uphendula olwesibili

- Ngesikhathi socingo, khetha [Faka ucingo oluse](#).

Ukuphatha izingcingo zezwi ezimbili
Ungaba nezingcingo eziqhubekeyo nezimile kanyekanye.

Ukushintsha phakathi kwezingcingo ezimbili

- Ngesikhathi socingo, cindezela ↗.

Ukuhlanganisa izingcingo ezimbili

- Ngesikhathi socingo, khetha [Izinketho > Hllanganisa izingc.](#)

Ukuxhuma izingcingo ezimbili

- Ngesikhathi socingo, khetha [Izinketho > Dlulisa ucingo](#). Unqanyuliwe kulezi zingcingo ezimbili.

Ukuqedo ucingo oluqhubekeyo bese ubuyela ocengweni olulindile

- Qala ucindezele ↘ bese kuba ↗.

Kwemukelwa ucingo lwezw iwsithathu

Awukwazi ukuphendula ucingo lweithathu ngaphandle kokuqedo olunye lwezingcingo ezimbili zokuqala noma ukuzihlanganisa.

 *Izingcingo zenkomfa*

Ngocingo lwsigungu, ungaba nengxoxo ebanjiswene nabantu abafinyelela kwabahlanu.

Ukwengeza omusha umhlanganyeli

- 1 Ngesikhathi socingo, khetha [Izinketho > Bamba](#). Lokhu kumisa izingcingo ezihlangananisiwe.
- 2 Khetha [Izinketho > Engeza ucingo](#).
- 3 Faka inamba ozoyifonela bese ucindezela ↗.
- 4 Khetha [Izinketho > Hllanganisa izingc.](#) ukwengeza umhlanganyeli omusha.
- 5 Phinda lo msebenzi ukwengeza abanye abahlanganyeli.

Ukudedela umhlanganyeli

- 1 Khetha [Izinketho > Khulula ingxeny.](#)
- 2 Khetha umhlanganyeli ozomkhulula.

Ukuba nengxoxo yangasese

- 1 Ngesikhathi socingo, khetha [Izinketho > Khuluma no](#) bese ukhetha umhlanganyeli ozokhuluma naye.
- 2 Ukuquhubeka nocingo lwenkomfa, khetha [Izinketho > Hllanganisa izingc.](#)

Izinombolo zami

Ungahlola, wengeze bese uhlela izinombolo zakho zefoni.

Ukuhlola izinombolo zefoni yakho

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye](#) bese ukhetha [Okukukho](#) > [Izinombolo ezithile](#) > [Izinombolo zami](#).
- 3 Khetha ongakhetha kukho.

Yamukela izingcingo

Ungakhetha ukwamukela izingcingo ezivela kuzinamba zefoni ezithile kuphela.

Ukfaka ezinye izinombolo ohlwini l'wabashayizingingo abemukeleleka

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Izinhlelo](#) > eye [Izingcin](#). ithebhу > [Singatha izin.](#) > [Mkela izingcingo](#) > [Ezisolhwini kup](#).
- 2 Pheqela ku [Okusha](#) bese ukhetha [Engeza](#).
- 3 Pheqela koxhumana naye noma khetha [Amaqembu](#).

 Bheka [Amaqembu](#) ekhasini 23.

Ukwamukela zonke izingcingo

- Kokubekwe eceleni khetha [Imenuy](#) > [Izinhlelo](#) > eye [Izingcin](#). ithebhу > [Singatha izin.](#) > [Mkela izingcingo](#) > [Bonke abafonile](#).



Ukudayela okukalelwe

Ungakalela izingcingo eziphumayo nezingenayo. Iphasiwedi elivelа kumniikezelі wakho wesevisi liyadingeka.



Uma udlulisela phambili izingcingo ezingenayo, ngeke ukwazi ukusebenzisa okunye okukhethwa kukho kokukalela izingcingo.

Okukhethwa kukho kokukalela izingcingo

Okukhethwa kukho okujwayelekile yilokhu:

- [Eziphumayo](#) – zonke izingcingo eziphumayo.
- [Eziya emazweni](#) – zonke izingcingo zomhlaba jikelele eziphumayo.
- [Oluphumay uma uzul](#) – zonke izingcingo zomhlaba jikelele eziphumayo, ngaphandle kwalezo eziya ezweni lakini.
- [Ezingenayo](#) – zonke izingcingo ezingenayo.
- [Olungenayo uma uzu](#) – zonke izingcingo ezingenayo uma uphesheyaw kwezilwandle

Ukukalela izingcingo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Izinhlelo](#) > eye [Izingcin](#). ithebhu > [Singatha izin](#). > [Kholi alawuliwe](#).
- 2 Khetha ongakhetha kukho.
- 3 Khetha [Vuselela](#).
- 4 Faka iphasiwedi yakho bese ukhetha [Kulungile](#).

Ukudayela okuheliwe

Ukudayela oluhleliwe kukuvumela ukuthi ushayele izingcingo ezinambeni ezithile kuhphela ezigcinwe kwiSIM khadi. Izinamba eziheliwe zivikelwe yiPIN2 yakho.

Izinombolo ezingaphelele zingalondwa. Isibonelo, ukugcina u-0123456 kuvumela izingcingo ukuba zishayelwe kuzo zonke izinombolo eziqala ngo-0123456.

- ! *Uma kusetshenzisa ukudayela okuheliwe, awukwazi ukuhlolola noma ukuphatha zoma yiziphi izinamba zefoni ezigcinwe kwi-SIM khadi kodwa usengakwazi ukushayela inamba yomhlaba yezimo eziphuthumayo, u-112.*

Ukusebenzisa ukudayela okuheliwe

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye bese](#) ukhetha [Izinketho](#) > [Izinombolo ezithile](#) > [Ukudayela okuheli](#) > [Cupha](#).
- 3 Faka i-PIN2 yakho bese ukhetha [Kulungile](#).
- 4 Khetha [Kulungile](#) futhi ukuqjinisekisa.

Ukulonda inombolo ehleliwe

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ifonibhuku](#).
- 2 Pheqela ku [Oxhumene naye bese](#) ukhetha [Izinketho](#) > [Izinombolo ezithile](#) > [Ukudayela okuheli](#) > [Izinombolo eziheli](#) > [Inombolo entsha](#).
- 3 Faka ulwazi bese ukhetha [Gcina](#).

Isikhathi sokufona nezindleko

Ngesikhathi usocingweni, isikhathi socingo siyakhonjiswa. Ungahlola isikhathi socingo Iwakho lokugcina, izingcingo eziphumayo nesikhathi esiphelele sezingcingo zakho.

Ukuhlola isikhathi socingo

- Kokubekwe eceleni khetha [Imenuy](#) > [Izinhlelo](#) > eye [Izingcingo](#) ithebhu > [Isikhathi nezindlek](#) > [Isilinganiso](#).

Ukuthumela imibiko

Ukwamukela nokugcina imibiko
Uyaziswa uma wamukela umbiko.
Imibiko igcinwa nge-othomathikhi
kwimemori yefoni. Uam imemori
yefoni isigcwеле, ungasusa imibiko
noma uyigcune kwimemori khadi
noma kwi-SIM khadi.

Ukugcina umbiko kumemori khadi

- Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Izinhlelo](#) > [Okujwayelekile](#) > [Gcina ku](#) > [Imemori khadi](#).

Ukugcina umbiko kwi-SIM khadi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) bese ukhetha ifolda.
- 2 Pheqela kumbiko bese ukhetha [Izinketho](#) > [Gcina umbiko](#).

Ukuhlola umbiko ovela ebhokisini lengenayo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Ibhokisi lokunge](#).
- 2 Pheqa kumbiko bese ukhetha [Hlola](#)

Ukususa umbiko

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) bese ukhetha ifolda.
- 2 Pheqa kumbiko bese ukhetha [C](#).

Imibiko yombhalo

Imibiko ebhaliwe ingaqukatha izithombe, imiphumela yomsindo, izithombe zezilwane, nemiculo.

Ngaphambi kokusebenzisa

Kufanele ube nenamba yesikhungo sesevisi. Inamba ihlinzekwa wumnikezelu wesevisi yakho futhi ngokuvamile igcinwa kwi-SIM khadi. Uma inamba yesikhungo sesevisi yakho ingagciniwe kwi-SIM khadi yakho, kufanele uyifake wena inamba.

Ukfufaka inamba yesikhungo sesevisi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Izinhlelo](#) > [Umbiko obhaliwe bese upheqela ku Isikhungo sokuse](#). Uma inamba yesikhungo sesevisi igcinwe kwi-SIM khadi iyakhonjiswa.
- 2 Uma ingekho inamba ekhonjisiwe, khetha [Hlola](#).
- 3 Pheqela ku [Isikhungo esisha s](#) bese ukhetha [Engeza](#).
- 4 Faka inamba, kubandakanya olwamazwe omhlaba uphawu oluthi “+” nekhodi yezwe.
- 5 Khetha [Gcina](#).

Ukubhala nokuthumela umbiko obhalive

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Bhala okusha](#) > [Umbiko obhalive.](#)
 - 2 Bhala umbiko bese ukhetha [Qhubek](#) > [Bheka ifonibhuku.](#)
 - 3 Khetha umamukeli bese ukhetha [Thumela.](#)
- ! *Uma uthumela umbiko obhalive egenjini, uyakhokhiswa ngelungu ngalinye. Bheka Amaqembu ekhasini 23.*

Ukufaka into embikweni obhalive

- 1 Uma ubhala umbiko, khetha [Izinketho](#) > [Engeza uhlamu.](#)
- 2 Khetha okukhethwa kukho kanye nento.

Ukufonela inombolo embikweni obhalive

- Uma uhlola umbiko, pheqela kwinamba yefoni bese ucindezela ↗.

Imibiko yesithombe

Imibiko yesithombe ingaqukatha umbhalo, izithombe, izilaydi, umsindo orekhodiwe, amavidiyo kliphu, izisayindo nezinamathisel. Ungathumela imibiko yesithombe efonini ehambayo noma kwikheli le-imeyli.

Ngaphambi kokusebenzisa imibiko yezithombe

Kufanele usethe iphrofayili ye-Inthanethi kanye nekheli leseva yemibiko yakho. Uma lingekho iphrofayili le-inthanethi noma isevo yombiko ekhona, ungamukela wonke amasethingi nge-othomathikhi avela ku-opharetha wakho wenethiwekhi noma ku www.sonyericsson.com.

Ukukhetha iphroayli ye-MMS

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Izinhlelo](#) > [Umbiko wesitho.](#) > [Iphrofayli le-MMS.](#)
- 2 Khetha iphrofayli.

Ukusetha ikheli leseya yemibiko

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Izinhlelo](#) > [Umbiko wesitho.](#)
- 2 Pheqela ku [Iphrofayli le-MMS](#) bese ukhetha [Hlela.](#)
- 3 Khetha [Izinketho](#) > [Hlela.](#)
- 4 Pheqela ku [Unolwazi wombiko](#) bese ukhetha [Hlela.](#)
- 5 Faka ikheli bese ukhetha [Kulungle](#) > [Gcina.](#)

Ukwakha nokuthumela umbiko wesithombe

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Bhala okusha** > **Umbiko wesith.**
- 2 Faka umbhalo. Ukwengeza izinto kumbiko, cindezela , pheqa bese ukhetha into.
- 3 Khetha **Qhubek** > **Bheka ifonibhku.**
- 4 Khetha umamukeli bese ukhetha Thumela.

Ukwemukela imibiko yezithombe

Ungakhetha indlela yokulanda imibiko yakho yezithombe. Okukhethwa kukho okujwayelekile uma ulanda imibiko yesithombe yilena:

- **Njalo** – ukulanda nge-othomathikhi.
- **Buza ekuzulen** – cela ukulanda uma ungekho kwinethiwekhi yasekhaya.
- **Ayizuli** – ungalandi uma ungekho kwinethiwekhi yasekhaya.
- **Cela njalo** – cela ukulanda.
- **Valiwe** – imibiko emisha ivela ku lhhokisi lokunge.

Ukusetha ukulanda nge-othomathikhi

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Izinhlelo** > **Umbiko wesitho.** > **Ukukhipha i-otho.**
- 2 Khetha ongakhetha kukho.

Ukugcina into ethile embikweni wesithombe

- Uma uhlola umbiko wesithimbe khetha **Izinketho** > **Gcina izinhlamvu** bese ukhetha into.

Ukususa umbiko

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** bese ukhetha ifolda.
- 2 Khetha umbiko bese ucindzelza .

Okukhethwa kukho imibiko

Ungasetha okukhethwa kukho okujwayelekile kwayo yonke imibiko noma ukhetha amasethingi abaluliwe njalo uma uthumela umbiko.

Ukusetha okukhethwa kukho umbiko wombhalo

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Izinhlelo** > **Umbiko obhalive.**
- 2 Pheqela kokukhethwa kukho bese ukhetha **Hlela.**

Ukusetha okukhethwa kukho kombiko wesithombe

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Izinhlelo** > **Umbiko wesitho.**
- 2 Pheqela kokukhethwa kukho bese ukhetha **Hlela.**

Ukusetha okukhethwa kukho umbiko ngombiko othile

- 1 Uma umbiko usuwakhwiwe nomemukeli esekhethiwe, khetha [Izinketho](#) > [Kuthuthukile](#).
- 2 Pheqela kokukhethwa kukho bese ukhetha [Hlela](#).

Izibonisi

Uma usebenzisa njalo imishwana nezithombe okufanayo kumbiko, ungagcina lowo mbiko njengesibonisi.

Ukwengeza isibonisi sombiko wombhalo

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Izibonisi](#) > [Isibonisi esisha](#) > [Umbhalo](#).
- 2 Faka umbhalo noma khetha [Izinketho](#) ukwengeza izinto. Khetha [Kulungile](#).
- 3 Faka isihloko bese ukhetha [Kulungile](#).

Ukusebenzisa isibonisi sombiko wesithombe

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Izibonisi](#).
- 2 Pheqela kwisibonisi bese ukhetha [Sebenzisa](#).
- 3 Uma umbiko usulungile, khetha [Qhubek](#) > [Bheka ifonibhku](#).
- 4 Khetha umamukeli bese ukhetha [Thumela](#).

Ukwengeza isibonisi sombiko wesithombe

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Izibonisi](#) > [Isibonisi esisha](#) > [Umbiko wesithombe](#).
- 2 Faka umbhalo. Ukwengeza izinto kumbiko, cindezela , pheqa  bese ukhetha into.
- 3 Khetha [Yebo](#), faka isihloko bese ukhetha [Kulungile](#).

Ukugcina umbiko njengesibonisi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Ibhokisi lokunge](#).
- 2 Pheqa kumbiko bese ukhetha [Izinketho](#) > [Gcina njengesibo](#).

Imibiko yezwi

Ungathumela futhi wamukele umsindo orekhodiwe njengombiko wezwi.

- ! *Umrhumeli nomemukeli kufanele bathenge okusekela ukuthunyelwa kwemibiko yezithombe.*

Ukurekhoda nokuthumela umbiko wezwi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Bhala okusha](#) > [Umbiko wezwi](#).
- 2 Rekhoda umbiko bese ukhetha [Misa](#) > [Thumela](#) > [Bheka ifonibhku](#).
- 3 Khetha umamukeli bese ukhetha [Thumela](#).



I-imeyli

Ungasebenzisa imisebenzi ejwayelekile ye-imeyli nekheli le-imeyli lekhompyutha yakho efonni yakho.

Ngaphambi kokusebenzisa i-imeyli
Ungasebenzisa isethaphu wizadi ukhulola nom a masethingi ayatholakala e-akhawunti yakho ye-imeyli nom a ungawafaka ngesandla. Ungamukela futhi amasethingi ku www.sonyericsson.com/support.

Ukwakha i-akhawunti ye-imeyli

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ama-akhawunti](#).
- 2 Pheqela ku [I-akhawunti entsha](#) bese ukhetha [Engeza](#).

Uma ufaka amasethingi ngesandla, ungaxhumana nomnkezeli we-imeyli yakho ngeminye imininingwane. Umnikezeli we-imeyli kungaba yinkampani eyakunika ikheli lakho le-imeyli.

Ukubhala nokuthumela umbiko we-imeyli

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Bhala okusha](#).
- 2 Khetha [Engeza](#) > [Faka ikheli le-imeyli](#). Faka ikheli le-imeyli bese ukhetha [Kulungile](#).

3 Ukufaka abanye abemukeli, khetha [Hlela](#). Pheqela kokukhethwa kukho bese ukhetha [Engeza](#) > [Faka ikheli le-imeyli](#). Faka ikheli le-imeyli bese ukhetha [Kulungile](#). Uma usulungile, khetha [Kwensiwi](#).

- 4 Pheqela ku [Ishiloko](#): Khetha [Kulungile](#) bese ufaka ishiloko.
- 5 Pheqela ku [Umbhalo](#): Khetha [Kulungile](#) bese ufaka umbhalo.
- 6 Pheqela ku [Izinamatheiso](#): Khetha [Engeza](#) bese ukhetha ifayela ozolinamathisela.
- 7 Khetha [Qhubek](#) > [Thumela](#).

Ukwamukela nokufunda umbiko we-imeyli

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ibhokisi lokunge](#) > [Izinketho](#) > [Thumela](#).
- 2 Pheqa kumbiko bese ukhetha [Hlola](#)

Ukugcina umbiko we-imeyli

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ibhokisi lokunge](#).
- 2 Pheqa kumbiko bese ukhetha [Izinketho](#) > [Gcina umbiko](#).

Ukuphendula umbiko we-imeyli

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ibhokisi lokunge.](#)
- 2 Pheqa kumbiko bese ukhetha [Izinketho](#) > [Phendula.](#)
- 3 Bhala impendulo bese ukhetha [Kulungile.](#)
- 4 Khetha [Qhubek](#) > [Thumela.](#)

Ukuhlola isinamathiselo embikweni we-imeyli

- Uma uhlola umbiko, khetha [Izinketho](#) > [Izinamathiseli](#) > [Hlola.](#)

Ukugcina isinamathiselo embikweni we-imeyli

- Uma uhlola umbiko, khetha [Izinketho](#) > [Izinamathiseli](#) > [Hlola](#) > [Gcina.](#)

Ukuvumelanisa i-imeyli

I-imeyli ingavumeniswa nge-Microsoft Exchange Server (Microsoft® Outlook®). Ngolunye ulwazi bheka *Kuyavumelaniswa ekhasini 62.*

I-akhawunti ye-imeyli esebenzayo

Uma ukhethe ama-akhawunti ambalwa e-imeyli, ungashintsha ukuthi yiliphi elisebenzayo.

Ukushintsha i-akhawunti ye-imeyli esebenzayo

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ama-akhawunti.](#)
- 2 Khetha i-akhawunti.

Ukususa i-imeyli (POP3)

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ibhokisi lokunge.](#)
- 2 Pheqa kumbiko bese ukhetha [Izinketho](#) > [Maka ukuze kucis.](#)

! *Imibiko emakiwe iyosuswa ngesikhathi esizayo uma uxhuma kwiseva yakho.*

Ukususa i-imeyli (IMAP4)

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [I-imeyli](#) > [Ibhokisi lokunge.](#)
- 2 Pheqa kumbiko bese ukhetha [Izinketho](#) > [Maka ukuze kucis.](#)
- 3 Khetha [Izinketho](#) > [Sula ibhokisi lemi.](#)

! *Imibiko ye-imeyli emakiwe izosuswa efonini nakwiseva.*

I-Push imeyli

Ungamukela isaziso efonini yakho esiphuma kwiseva ye-imeyli yakho esithi unemibiko emisha ye-imeyli.

Ukuvula isaziso se-push email

- Kokubekwe eceleni khetha [Imenuy](#)
 > [Imibiko ethunyel.](#) > [I-meyli](#) > [Izinhlelo](#)
 > [I-Push imeyli.](#)

Abangani bami

Ungakhuma bese ungena kwiseva ya Abangani bami ukuxhumana kulayini nemibiko yokuxoxa.

Ngaphambi kokusebenzisa Abangani bami

Uma amasethingi achazwe ngaphambilini engekho efonini yakho, ngeke uwadinge amanye amasethingi. Umnikeyzeli wakho wesevisi angakunika ulwazi lwamasetingi oluvamile njenge:

- Igama lomsebenzisi
- Iphasiwedi
- Ikheli leseva
- Iphrofayli ye-Inthanethi

Ukfaka amasethingi eseva ka Abangani bami

- 1 Kokubekwe eceleni khetha [Imenuy](#)
 > [Imibiko ethunyel.](#) > [Abangani bami](#)
 > [Hlela.](#)
- 2 Pheqela kwisethingi bese ukhetha [Engeza.](#)

Ukungena kwiseva y Abangani bami

- Kokubekwe eceleni khetha [Imenuy](#)
 > [Imibiko ethunyel.](#) > [Abangani bami](#)
 > [Qalisa.](#)

Ukuphuma kwiseva ya Abangani bami

- Khetha [Izinketho](#) > [Qeda.](#)

Ukwengeza oxhumene naye wokuxoxa

- 1 Kokubekwe eceleni khetha [Imenuy](#)
 > [Imibiko ethunyel.](#) > [Abangani bami](#)
 > [eye OXhumene nabo ithebhу.](#)
- 2 Khetha [Izinketho](#) > [Engeza oxhumana.](#)

Ukwengeza umbiko wengxoxo

- 1 Kokubekwe eceleni khetha [Imenuy](#)
 > [Imibiko ethunyel.](#) > [Abangani bami](#)
 > [eye Ifonibhuku ithebhу.](#)
- 2 Pheqela koxhumana naye bese ukhetha [Ingxoxo.](#)
- 3 Bhala umbiko bese ukhetha [Thumela.](#)

Izinga

Ungakhombisa izinga lakho, isibonelo, [Thokozile](#) noma [Bhizi](#), koxhumana nabo kuphela. Ungakhombisa futhi izinga lakho kubo bonke abasebenzisi kwiseva ya Abangani bami.

Ukukhombisa izinga lami

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Abangani bami** > **Izinketho** > **Izinhlelo** > **Khombisa izinga la.**
- 2 Khetha ongakhetha kukho.

Ukubuyekeza izinga lakho

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Abangani bami** > **eye Izinga lami** **ithebh**u.
- 2 Hlela ulwazi.

Iqembu lengxoxo

Iqembu lengxoxo lingaqaaliswa umniikezeli wakho wesevisi, ngumuntu ongumsebenzisi waBangani bami noma nguwe. Ungalonda amaqembu engxoxo ngokugcina isimemo sezingxoxo noma ngokucinga iqembu elithile lengxoxo.

Ukwakha iqembu lengxoxo

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Abangani bami** > **eye Amaqembu engxo.** **ithebh**u.
- 2 Khetha **Izinketho** > **Engeza iqe. lengx.** > **Iqe. lengxo. elisha.**
- 3 Khetha ozobamema ohlwini loxhumana nabo bese ukhetha **Qhubek.**
- 4 Faka umbhalo wesimemo omfishane bese ukhetha **Qhubek** > **Thumela.**

Ukwengeza iqembu lengxoxo

- 1 Kokubekwe eceleni khetha **Imenuy** > **Imibiko ethunyel.** > **Abangani bami** > **eye Amaqembu engxo.** **ithebh**u > **Izinketho** > **Engeza iqe. lengx.**
 - 2 Khetha ongakhetha kukho.
- ! *Umlando wengxoxo ulondwa phakathi kokuphuma nesikhathi sokungena futhi ukuvumela ukuthi ubuyele emibikweni yengxoxo eseizingxoxweni ezidlule.*

Ukugcina ingxoxo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Abangani bami](#) > eye [Izingxoxo](#) ithebhу.
- 2 Pheqela kwingxoxo bese ukhetha [Izinketho](#) > [Okuthuthukile](#) > [Gcina](#) [ingxoxo](#).

Ukuhlola ingxoxo egciniwe

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Abangani bami](#) > eye [Izingxoxo](#) ithebhу.
- 2 Khetha [Izinketho](#) > [Izingxo](#). [ezigciniwe](#).

Ulwazi lwendawo nolweselula

 Ulwazi lwendawo neselula yimbiko yombhalо, isibonelo, imibiko yethrafikhi yendawo ethunyelwa kubathengi ngaphakathi endaweni ethile yenethiwekhi.

Ukuvula ulwazi lwendawo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imibiko ethunyel.](#) > [Izinhlelo](#) > [Ulwazi](#) [lwendaw](#).
- 2 Pheqela ku [Ukwamukela](#) bese ukhetha [Hlela](#) > [Vuliwe](#).


Ukufanekisa

Ikhamera nevidyo rekhhoda

Ungathatha izithombe futhi urekhode amavidyo kliphu ozowahlola, uwagcine noma uwathumele.

Isitholi sokubonayo namakhi ekhamera

- 1 Sondeza noma hlehlisa
- 2 Shintshanisa ikhamera/ividyo/ukuhlola
- 3 Thatha izithombe/Rekhoda ividyo
- 4 Vula noma vala ikhamera



Ukusebenzisa ikhamera

Ukucupha ikhamera

- Uma ifoni ivuliwe, cinddezela 

Ukuthatha isithombe

- 1 Cupha ikhamera bese usebenzisa  ukukhetha ikhamera.
- 2 Cinddezela  wehle ugcine kuhhafu ukuze usebenzise i-otho focus.
- 3 Uma ichashaza nefremu ye-focus kuluhlaza, cinddezela ngokugcwale ukuthatha isithombe.
- 4 Isithombe sigcineka nge-othomathiki kwimemori khadi.

⚠ Ungabheki ngqo kwikhamera Xe flash efonini usebenzisa idivaysi yokukhulisa. Ukuhluleka ukuthobela lesixwayiso kungalimaza amehlo akho.

💡 Ungarekhodi uma kukhona umthombo wokukhanya onamandla ngemuva. Qondanisa okuthathwayo nengaphakathi lefremu. Sebenzisa isaphothi noma i-timer ukugwema isithombe esilufifi.

Ukurekhoda ividyo kliphu

- 1 Cupha ikhamera bese usebenzisa  ukukhetha ividyo rekhoda.
- 2 Cinddezela  kuye phansi ngokugcwale ukuqala ukurekhoda.

Ukuyeka ukugopha

- 1 Cinddezela .
- 2 Ividyo kliphu isigcineka nge-othomathiki kwimemori khadi.

Ukusebenzisa i-zoom

- Cinddezela amakhi evolumu aye phezulu noma ezansi.

Ukuhlela ukuggama

- Cinddezela  noma .

Ukuthola okuthe xaxa kwikhamera

I-BestPic™ ikusiza ukuba uthole umzuzu ongungqo. Ungenza ngcono isithombe esingacacile nge-Photo fix.

Ukusebenzisa i-BestPic™

- 1 Cupha ikhamera bese usebenzisa  ukukhetha ikhamera.
- 2 Khetha  > Imodi yokushutha > I-BestPic™.
- 3 Cinddezela  wehle ugcine kuhhafu ukuze usebenzise i-otho focus.
- 4 Uma ichashaza nefremu ye-focus kuluhlaza, cinddezela kuye phansi ngokugcwale ukuqedela ukuthatha.
- 5 Khetha Gci kon noma cinddezela  noma  ukukhetha isithombe esingcono kunazo zonke bese ukhetha Gcina.

Ukwenza ngcono isithombe nge-Photo fix

- 1 Cupha ikamera bese usebenzisa ukukhetha ikamera.
- 2 Khetha > *Amasethingi*.
- 3 Cinisekisa ukuthi i *Hola* isethwe ku *Vuliwe*.
- 4 Thatha isithombe.
- 5 Ngesikhathi sobuyekezo, khetha *Izinketho* > *Lungisa isithombe*.

Ukuhlola izithombe namavidyo kliphu

- 1 Cupha ikamera bese usebenzisa ukukhetha ukuhlola.
- 2 Pheqela entweni.
- 3 Cindezela ukuhlola ividyo kliphu.



Izimpawu namasethingi kwekhamera

Izimpawu ezisesibukweni zazisa ngesethingi ekhona ngaleso sikhathi. Amanye amasethingi ekhamera ayatholakala ku *Amasethingi*.

- Sebenzisa i-Photo mate ukufunda ngemisebenzi yekhamera. I-Photo mate okokufundisa okuhambisanayo, okufakiwe efonini yakho.*

Uphawu



Incazelo

Imodi yokushutha



Izithombe zezwe.

Amasethingi asehleliwe ezimo ezivamile zezithombe



Usayiz westhom



I-Focus



Ukuphayiza



Isibali sikhathi



ISO. Ukuzwela ukukhanya kwekhamera



I-Metering mode



Ibhalans emhloph.

Ukuvumelanisa amathoni emibala nezimo zokukhanya

	Usayizi wevidyo.
Kumibiko yezithombe, usayizi unomkhawuko	
	Ividyo: kuyarekhodwa
	I-zoom
	I-otho focus
	Ifremu ye-focus
300+	Ikhamera: Izithombe ezisele
	Ifleshi iyashaja

Ukushintsha amasethingi

- Cupha ikhamera bese uyakhetha .

Ukuhlola ulwazi ngamasethingi

- Pheqela kwisethingi bese ukhetha .

Amashothikhathi ekhamera

Ikhi	Ishothikhathi
	Ikhamera: Imodi yokushutha Ividyo: Usayizi wevidyo
	Ikhamera: Izithombe zezwe Ividyo: Imodi yasebsuku
	Isibali sikhathi
	Igaydi yekhi lekhamera
	Ikhamera: Ukuphayiza Ividyo: Ukukhany AF

Kudluliswa izithombe

Dlulisa uyise noma ususe
kwikhompyutha yakho

Ungasebenzisa i-Bluetooth™ wireless
technology nekhebula le-USB
ukudlulisa izithombe namavidyo kliphu
phakathi kwekhompyutha nefobi
yakho. Bheka I-Bluetooth™ wireless
technology ekhasini 59 ne
Ukusebenzisa ikhebula le-USB
ekhasini 61 ngolunye ulwazi.

Ungahlola, wenze ngcono futhi uhlele izithombe namavidyo kliphu kwakho kwikhompyutha yakho ngokufaka i *Adobe™ Photoshop™ Album Starter Edition* noma i *Sony Ericsson Media Manager*. Lokhu kufakiwe kwi-CD efika nefoni yakho futhi kuyatholakala uma kulandwa ku www.sonyericsson.com/support.

I-blog yesithombe

I-blog yesithombe yikhasi lakho siqu le-Web. Uma ukuthenga kwakho kuyisekela le sevisi, ungathumela izithombe kwi-blog.

! Amasevisi eWeb angadina isivumelwano selayisense esihlukile phakathi kwakho nomnikezeli wesevisi. Kungasebenza izilungiso namashaji engeziwe. Xhumana nomnikezeli wesevisi yakho.

Ukuthumela izithombe zekhamera kwi-blog

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifoto](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Khetha [Izinketho](#) > [Thumela](#) > [Ukubloga](#).
- 4 Engeza isihloko nombhalo.
- 5 Khetha [Kulungile](#) > [Shicilela](#).

Ukuya ekhelini le-blog eliphuma koxhumana nabo

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ifonibuku](#).
- 2 Pheqela koxhumana naye bese ukhetha ikheli le-Web
- 3 Khetha [Yiya ku](#).

Ukuthumela isithombe noma ividylo kliphu

- 1 Kokubekwe eceleni khetha [Imidiya](#).
- 2 Pheqela entweni bese ukhetha [Izinketho](#) > [Thumela](#).
- 3 Khetha indlela yokudulisa.

! Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudulisa oyikhethayo.

Ukwamukela isithombe noma ividylo kliphu

- Landela imiyalelo evelayo.

Ukuphrinta kwekhamera

Ungaphrinta izithombe zekhamera ngokusebenzisa ikhebula le-USB elixhunywe kwiphrinta evumelana nayo.

- Ungaphrinta futhi ngephrinta efanelene ne-Bluetooth.

Ukuphrinta izithombe zekhamera ngokusebenzisa ikhebula le-USB

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifotho](#) > [I-albhamu yekhamera](#).
 - 2 Pheqela kwinyanga nesithombe.
 - 3 Khetha [Izinketho](#) > [Phrinta](#).
 - 4 Khetha ongakhetha kukho.
 - 5 Xhuma ikhebula le-USB efonini.
 - 6 Xhuma ikhebula le-USB kwiphrinta.
 - 7 Lindela ifidbhekhi efonini bese ukhetha [Kulungile](#).
 - 8 Faka amasethingi ephrinta, uma edingeke bese ukhetha [Phrinta](#).
-  **Kufanele unqamule ukuxhumana bese uxhuma kabusha ikhebula le-USB uma kuneephutha lephrinta.**

Izithombe

Ungahlola, wengeze, uhlele noma ususe izithombe ku [Imidiya](#).

Ukusebenzisa izithombe

Ungongeza isithombe koxhumana naye, sisebenzise ngesikhathi uqalisa ifoni, njengephepha lodonga kokubekwe eceleni noma njengesivikeli sibuko.

Ukusebenzisa izithombe

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifotho](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Khetha [Izinketho](#) > [Sebenzisa njenge](#).
- 4 Khetha ongakhetha kukho.

Ukuhlola izithombe nge-slide show

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifotho](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Khetha [Izinketho](#) > [Veza isikhashana](#).
- 4 Khetha isimo-ngqondo.

Amathegi ezithombe

Ungafaka amathegi ezithombeni ukuehlukanisa ngononina.

Ukufaka amathegi ezithombeni

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifotho](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Cindezela  bese upheqela kwithegi.
- 4 Cindezela okukhethwa kukho kokuthinta okuphakathi.

- 5 Ngesithombe ngasinye ofuna ukusifaka ithegi, sebenzisa noma ukupheqela kuleso sithombe bese ucindezela okukhethwa kukho okuthintwayo okuphakathi.

Ukwakha ithegi yesithombe entsha

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifoto](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Cindezela bese ukhetha [Izinketho](#) > [Ithegi entsha](#).
- 4 Faka igama bese ukhetha [Kulungile](#).
- 5 Khetha uphawu.
- 6 Cindezela okukhethwa kukho okuthintwayo okuphakathi ukufaka ithegi esithombeni.

I-PhotoDJ™ ne-VideoDJ™

Ungahlela izithombe namavidyo kliphu.

Ukuhlela nokugcina isithombe

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Ifoto](#) > [I-albhamu yekhamera](#).
- 2 Pheqela kwinyanga nesithombe. Khetha [Hlola](#).
- 3 Khetha [Izinketho](#) > [Hl. ku-PhotoDJ™](#).
- 4 Hlela isithombe.
- 5 Khetha [Izinketho](#) > [Gcina](#).

Ukuhlela nokugcina ividyo kliphu

- 1 Kokubekwe eceleni khetha [Imenyu](#) > [Umhleli](#) > [Imenenja yefayela](#) > [Amavidyo](#).
- 2 Pheqela kwividyo kliphu bese ukhetha [Vula](#) > [Izinketho](#) > [VideoDJ™](#).
- 3 Hlela ividyo kliphu.
- 4 Khetha [Izinketho](#) > [Gcina](#).

Ukunquma ividyo kliphu

- 1 Kokubekwe eceleni khetha [Imenyu](#) > [Umhleli](#) > [Imenenja yefayela](#) > [Amavidyo](#).
- 2 Pheqela kwividyo kliphu bese ukhetha [Vula](#) > [Izinketho](#) > [VideoDJ™](#) > [Hlela](#) > [Nquma](#).
- 3 Khetha [Setha](#) ukusetha indawo yokuqualisa bese ukhetha [Qala](#).
- 4 Khetha [Setha](#) ukusetha indawo yokuqedza bese ukhetha [Vala](#).
- 5 Khetha [Nquma](#) > [Gcina](#).

Izingqikithi

Ungashintsha ukubukeka kwesibuko ngezinto ezifana nemibala nephepha lodonga. Ungakha futhi izingqikithi ezintsha bese uyazilanda. Ukuze uthole ulwazi oluthe xaxa, yiya ku www.sonyericsson.com/support.

Ukusetha ingqikithi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Pheqela ku [Izingqikithi](#) bese ukhetha [Vula](#).
- 3 Pheqela kwingqikithi bese ukhetha [Hlela](#).

Ezokuzithokozisa

- [Ukuhamba kwimidiya yakho bheka](#)
[Ukuhamba ekhasini 12.](#)

Ihendisfri ephathekayo yestiryo



Ukusebenzisa ihendisfri

- Xhuma ihendisfri ephathwayo. Umculo uyama uma wamukela ucingo bese uqhubeka uma seluvaliwe ucingo.

Umculo nezidlali mavidyo

Ukudlala umculo

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Umculo](#).
- 2 Pheqela kwisihloko bese ukhetha [Dlala](#).

Ukudlala amavidyo

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Ividyo**.
- 2 Pheqela kwisihloko bese ukhetha **Dlala**.

Umculo nezilawuli mavidyo

Ukumisa ukudlala umculo

- Cindezela okukhethwa kukho kokuthinta okuphakathi.

Ukuqhubeke ukudlala umculo

- Cindezela okukhethwa kukho kokuthinta okuphakathi.

Ukushintsha ivolumu

- Uma ulalela umculo, cindezela amakhi evolumu aye phezulu noma phansi.

Ukuhamba phakathi kwamathrekhi

- Uma ulalela umculo, cindezela  noma .

Ukusheshisa phambili nokusheshisa emuva

- Uma ulalela umculo, cindezela bese ubamba  noma .

Ukubuyela kumamenyu esidlali

- Khetha **Emuva**.

Ukubuyela kwizidlali

- Khetha **Izinketho** > **Qhubeka**.

Ukuphuma kumamenyu esidlali

- Cindezela bese ubamba .

Ukuthumela umculo

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Umculo**.
- 2 Pheqela kwisihloko bese ukhetha **Izinketho** > **Thumela**.
- 3 Khetha indlela yokudlulisa.

! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Ukwamukela umculo

- Landela imiyalelo evelayo.

Ukudlulisa umculo usuka kwikhompyutha

Nge Sony Ericsson Media Manager, efakiwe kwí-CD yefoni yakho, ungadlulisa umculo usuke kuma-CD, kwikhompyutha yakho noma owuthengile uye kwimemori yefoni noma kwimemori khadi.



Isoftiwe ye-Sony Ericsson Media Manager iyatholakala futhi uma ilandwa ku www.sonyericsson.com/support.

Ngaphambili kokusebenzisa iMedia Manager

Udinga olunye lwalezi nhlelo zokusebenzisa ukuze usebenzise iMedia Manager kwikhompyutha yakho:

- I-Windows Vista™ (32 bhithi no 64 bhithi izihumusho ze: I-Ultimate, Enterprise, Business, Home Premium, Home Basic)
- I-Windows XP (i-Pro ne-Home)

UkuFaka i-Media Manager

- 1 Vula ikhompyutha yakho bese ufaka i-CD. I-CD iqala nge-othomathikhi ne-installation window liyavuleka.
- 2 Khetha ulimi bese uqhebeza OK.
- 3 Qhebeza *Install Sony Ericsson Media Manager* bese ulandela imiyalo.

Ukusebenzisa i-Media Manager

- 1 Xhuma ifoni kwikhompyutha ngekhebuli le-USB elize nefoni.
- 2 **Ikhompyutha:** Qala/lzinhlelo/
Sony Ericsson/Media Manager.
- 3 **Ifoni:** Khetha [Londoloz okuningi](#)
> [Imenuy > Izinhlelo > eye](#) [Ukuxhumana ithebhу](#) > [I-USB > Imodi ye-USB](#)
> [Londoloz okuningi](#). Ifoni izozivala kule modi kodwa izoqala kabusha futhi uma inqanyulwa kwikhebuli le-USB.

! *Ungalikhipi ikebuli le-USB efonini noma kwikhompyutha ngesikhathi sokudlulisa, njengoba lokhu kungonakalisa imemori khadi noma imemori yefoni.*

- 4 Uukhiphila okuphephile ikhebuli le-USB kwimodi yokulondoloza okuningi, qhebeza isidla ophawini Iwedishki ekhiphekayo kwi-*Windows Explorer* bese ukhetha *Khipha*. Bheka *Ukusebenzisa ikhebuli le-USB* ekhasini 61.

Ngemininingwane yokudlulisa umculo, bheka ku *Media Manager Help*. Qhebeza (?) ekhoneni lesidla phezulu lefasitela *le-Media Manager*.

Kupheeqwa amafayela

Amafayela omculo namavidyo ayagcinwa futhi abekwa ngononina.

- **Abaculi** – kuklelisa amathrekhi osuwadlulisile usebenzisa i-Media Manager.
- **Ama-albham** – aklelisa amathrekhi omculo nge-albhamu efonini yakho nakwimemori khadi.
- **Amathrekhi** – aklelisa wonke amathrekhi omculo efonini yakho nakwimemori khadi.
- **Amab audio** – kuklelisa amabhuku alalelwayo owadlulise esuka kwikhompyutha yakho.

- [Ama-podcast](#) – kuklelisa wonke ama-podcast owdalulise esuka kwikhompyutha yakho.
- [Izinhla zokudlala](#) – yakha izinhla zakho zamathrekhi.
- [Ividyo](#) – iveza wonke amavidyo kliphu efonini yakho noma kwimemori khadi.

Izinhla zokudlala

Ungakha izinhla zokudlala ukuhlela amafayela. Ungasotha amafayela ngomculi noma ngesihloko. Amafayela angongezwa ohlwini lokudlala olungapezu kolulodwa.

Ukususa uhlulokudlala, noma ifayela esohlwini lokudlala, akulisusi ifayela kwimemori, kuphela irefarensi yefayela.

Ukwakha uhlulokudlala

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Umculo](#) > [Izinhla zokudlala](#).
- 2 Pheqela ku [Uhlulokudlala olus](#). bese ukhetha [Engeza](#).
- 3 Faka igama bese ukhetha [Kulungle](#).
- 4 Pheqela kwithrekhi bese ukhetha [Maka](#).
- 5 Khetha [Engeza](#) ukwengeza ithrekhi ohlwini lokudlala.

Ukwengeza amafayela ohlwini lokudlala

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Umculo](#) > [Izinhla zokudlala](#).
- 2 Pheqa ohlwini lokudlala bese ukhetha [Vula](#).
- 3 Khetha [Izinketho](#) > [Engeza imidya](#).
- 4 Pheqela kwithrekhi bese ukhetha [Maka](#).
- 5 Khetha [Engeza](#) ukwengeza ithrekhi ohlwini lokudlala.

Ukukhipha amathrekhi ohlwini lokudlala

- 1 Kokubekwe eceleni khetha [Imidiya](#) bbese upheqela ku [Umculo](#) > [Uhlulokudlala](#).
- 2 Pheqa ohlwini lokudlala bese ukhetha [Vula](#).
- 3 Pheqa kwithrekhi bese ucinddezela c.

Ukususa uhlulokudlala

- 1 Kokubekwe eceleni khetha [Imidiya](#) bese upheqela ku [Umculo](#) > [Uhlulokudlala](#).
- 2 Pheqela ohlwini lokudlala bese ucinddezela c.

Ukuhlola ulwazi ngethrekhi

- Pheqela kwithrekhi bese ukhetha [Izinketho](#) > [Ulwazi](#).

Umculo wakulayini namavidyo kliphu
Ungahlola amavidyo kliphu bese
ulalela umculo ngokuwathuthela
efonini yakho evela kwi-Inthanethi.
Uma amasethingi engekho efonini
yakho, bheka *Amasethingi* ekhasini
56. Ngolwazi oluthe xaxa, xhumana
no-opharetha wakho wenethiwekhi
noma vakashela ku
www.sonyericsson.com/support.

Ukukhetha i-akhawunti yedatha yokuthuthela

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebhу > [Izinhlelo zokuham](#).
- 2 Khetha i-akhawunti yedatha ozoyisebenzisa.

Ukuthutha umculo namavidyo kliphu

- 1 Kokubekwe eceleni khetha [Imenu](#) > [I-inthanethi](#).
- 2 Khetha [Izinketho](#) > [Yiya ku](#) > [Mabhukumaka](#).
- 3 Khetha ukuxhumana ozothutha ususa kukho.

I-TrackID™

I-TrackID™ iyisevisi ekhumbula
umculo yamahhala. Cinga izihloko
zamaculi, abaculi namagama ama-
albhamu.

Ukucinga ulwazi Iweculo

- Uma uzwa iculo ngelawudispikha,
kokubekwe eceleni khetha [Imenu](#) > [Imidlalo](#) > [TrackID™](#).
- Uma umsakazo udlala khetha [Izinketho](#) > [TrackID™](#).

Umsakazo

- ! *Ungayisebenzisi ifoni njengomsakazo ezindaweni lapho zivinjelwe khona.*

Ukulalela umsakazo

- 1 X huma ihendisfri kwifoni.
- 2 Kokubekwe eceleni khetha [Imenu](#) > [Umsakazo](#).

Ukushintsha ivolumu

- Uma umsakazo udlala, cindezela
amakhi evolumu aye phezulu noma
phansi.

Ukucinga amashaneli nge-othomathikhī

- Uma umsakazo udlala, khetha [Cinga](#).

Ukucinga amashaneli ngesandla

- Uma umsakazo udlala, cindezela noma .

Ukushintsha phakathi kwamashaneli asehleliwe

- Uma umsakazo udlala, cindezela noma .

Ukugcina amashaneli

Ungagcina kuze kufike kumashaneli
angu 20 asethwe phambilini.

Ukugcina amashaneli

- Uma usuthole ishaneli yomsakazo khetha [Izinketho](#) > [Gcina](#).

Ukukhetha amashaneli agciniwe

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umsakazo](#) > [Izinketho](#) > [Amashaneli](#).
- 2 Khetha ishaneli yomsakazo.

Ukugcina amashaneli kwizindawo 1 kuyaku 10

- Uma usuthole ishaneli yomsakazo, cindezela ubambe (0 +) – (9).

Ukukhetha amashaneli agciwe kwizindawo 1 kuyaku 10

- Uma umsakazo udlala, cindezela (0 +) – (9).

I-PlayNow™

Ungalalela umculo ngaphambi kokuwuthenga bese uwulandela efonini yakho.

- !
- Le sevisi ayitholakali kuwo wonke amazwe. Kwananye amazwe ungakwazi ukuthenga umculo kubanikazi bomculo abavelele emhlabeni.

Ngaphambi kokusebenzisa

i-PlayNow™

Kufanele ube namasethingi adingekayo efonini yakho. Bheka *Amasethingi* e khasini 56.

Ukulalela umculo we-PlayNow™

- 1 Kokubekwe eceleni khetha [Imenu](#) > [I-PlayNow™](#).
- 2 Khetha umculo ohlwini.

Kulandwa kwi-PlayNow™

Inani lentengo eliphelele livela uma ukhetha ukulanda nokugcina ifayela lomculo. Ibhili yakho yefoni noma ikhadi lokuqala ngokukhokha iba isikweletu uma okuthengile sekwamukelwe.

Ukulanda ifayela lomculo

Uma usukulalele ukudlalwa kwangaphambili kwefayela lomculo, ungavuma ukwamukela imigomo.

- 1 Khetha [Yebo](#) ukulanda.
- 2 Umbiko wombhalo uyathunyelwa ukuqinisekisa inkokhelo nefayela liyatholakala ukulandwa.

Amaringithoni kanye nemiculo

Ukusetha iringithoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhelelo** > eye **Imisindo nezibonis ithebhu** > **Iringithoni**.
- 2 Thola bese ukhetha iringithoni.

Ukusetha ivolumu yeringithoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhelelo** > eye **Imisindo nezibonis ithebhu** > **Ivolumu yeringithi**.
- 2 Cindezela noma ukushintsha ivolumu.
- 3 Khetha **Gcina**.

Ukucisha iringithoni

- Kokubekwe eceleni cindezela bese ubamba .
- ! **Wonke amasignalni ngaphandle kwasiganali ye-alamu ayaphazamiseka.**

Ukusetha isixwayisi sokudlikiza

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhelelo** > eye **Imisindo nezibonis ithebhu** > **Isixa. sokudlikiza**.
- 2 Khetha ongakhetha kukho.

Ukuthumela iringithoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umheleli** > **Imenenja yefayela**.
- 2 Pheqela ku **Umcuco** bese ukhetha **Vula**.
- 3 Pheqela kwiringithoni bese ukhetha **Izinketho** > **Thumela**.
- 4 Khetha indlela yokudlulisa.

! **Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.**

Ukwamukela iringithoni

- Landela imiyalelo evelayo.
- ! **Awuvumelekile ukushintshanisa enye impahla enamalungelo avikelwe. Ifayela elivikelwe linolwe uphawu.**

I-MusicDJ™

Ungaqamba bese uhlala imiculu yakho ukuvisebenzisa njengamarigithoni. Umcuco uqukethe izinhlobo ezine zamathrekhi – **Izigubhu, Amabhesi, Amanothi, ne iziphimiso**. Ithrekhi iqukethe amabhulokhi omculo amanangi. Amabhulokhi aqukethe imisindo ehlelwe ngaphambilini nezakhi ezihlukene. Amabhulokhi aqoqelwe aba **Isingeniso, Ivesi, Ikhoras, ne Isikhala**. Ungakha umculo ngkwengeza amabhulokhi omculo ezingomeni.

Ukuqamba umculo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imidlalo](#) > [I-MusicDJ™](#).
- 2 Khetha uku [Faka](#), [Kopisha](#) noma [Namek](#) amabhułoki.
- 3 Sebenzisa , ,  noma  ukuhamba phakathi namabhułokhi.
- 4 Khetha [Izinketho](#) > [Gcina umculo](#).

Ukuthumela umculo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Pheqela ku [Umculo](#) bese ukhetha [Vula](#).
- 3 Thola umculo bese ukhetha [Izinketho](#) > [Thumela](#).
- 4 Khetha indlela yokudlulisa.

! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Ukwamukela umculo

- Landela imiyalelo evelayo.
- ! *Awukwazi ukuthumela umculo onemisindo eminingi noma ifayela le-MP3 embikweni obhaliwe.*

Isirekhodi somsindo

Ungarekhoda imemo yezwi noma ucingo. Imsindo erekhodiwe ingasethwa njengamarangithoni.

! *Kwamanye amazwe noma kumasteythi umthetho wakhona udingga ukuthi umazise omunye umuntu ngaphambili kokurekhoda ucingo.*

Ukurekhoda umsindo

- Kokubekwe eceleni khetha [Imenuy](#) > [Imidlalo](#) > [Qopho umsindo](#).

Ukulalela okurekhodiwe

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imenenja yefayela](#).
- 2 Pheqela ku [Umculo](#) bese ukhetha [Vula](#).
- 3 Pheqela kokurekhodiwe bese ukhetha [Dlala](#).

Imidlalo

Ifoni yakho iqukethe imidlalo emibalwa. Ungalanda futhi imidlalo. Imbihalo yosizo iyatholakala emidlalweni eminingi.

Ukuqala umdlalo

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Imidlalo](#) > [Imidlalo](#).
- 2 Khetha umdlalo.

Ukuqededa umdlalo

- Cindezela .

Ukulawula imidlalo

Amakhi asefonini yakho angasetshenziselwa imisebenzi ehlukele yemidlalo. Kweminye imidlalo ungatshekisela yonke ifoni kwesobunxele, kwsokudla, phezulu noma phansi ukulawula umdlalo.

Izhinlelo

Ungalanda bese usebenzisa izinhlelo ze-Java. Ungahlola futhi ulwazi noma usethe amazinga emvume ahlukene.

Ngaphambi kokusebenzisa izinhlelo ze-Java™

Uma amasethingi engakafakwa efonini yakho, bheka *Amasethingi* ekhasini 56.

Ukukhetha uhlelo Iwe-Java

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Izicelo](#).
- 2 Khetha uhlelo.

Ukuhlola ulwazi ngohlelo Iwe-Java

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Izicelo](#).
- 2 Pheqela ohlelweni bese ukhetha [Izinketho](#) > [Ulwazi](#).

Ukusetha izimvume zohlelo Iwe-Java

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Izicelo](#).
- 2 Pheqela ohlelweni bese ukhetha [Izinketho](#) > [Izimvume](#).
- 3 Setha izimvume.

Usayizi wesibuko sohlelo Iwe-Java

Ezinye izinhlelo ze-Java zenzelwe osayizi abathile besibuko. Ngolwazi oluthe xaxa, xhumana nomthengisi wohlelo.

Ukusetha usayizi wesibuko sohlelo Iwe-Java

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Izicelo](#).
- 2 Pheqela ohlelweni bese ukhetha [Izinketho](#) > [Isibuko](#).
- 3 Khetha ongakhetha kukho.

Amaphrofayli e-Inthanethi ezinhlelo ze-Java

Ezinye izinhlelo ze-Java zidinga ukux huma kwi-Inthanethi ukwamukela ulwazi. Iningi lezinhlelo ze-Java zisebenzisa amasethingi e-Inthanethi njengesipheqi sakho se-Web.

Ukuxhumana

Amasethingi

Ngaphambi kokuvumelanisa nesevisi ye-Inthanethi, sebenzisa i-Inthanethi, i-PlayNow™, Amangani bami, i-Java, imiyalezo yezithombe, i-imeyli ne-blog yezithombe okudingayo ukuba namasethingi efonini yakho.

Uma amasethingi engakafakwa, ungalanda amasethingi ngokusebenzisa isethaphu wizadi noma ngokuya ku www.sonyericsson.com/support.

Ukulanda amasethingi ngokusebenzisa iwizadi ye Sethaphu

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Okujwayelekile](#) ithebhу > [Isetaphu wizadi](#) > [Landa izinhlelo](#).
- 2 Landela imiyalelo evelayo.

 *Xhumana no-opharetha wenethiwekhi yakho noma umnikezelu wakho wesevisi ngolwazi oluthe xaxa.*

Ukulanda amasethingi ngekhompyutha

- 1 Yiya ku www.sonyericsson.com/support.
- 2 Landela imiyalelo esesibukweni.

Igama lefoni

Ungafaka igama lefoni yakho elizokhonjiswa kwamanye amadivaysi.

Ukfufaka igama lefoni

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebhу > [Igama lefoni](#).
- 2 Faka igama lefoni bese ukhetha [Kulungile](#).

Kusetshenziswa i-Inthanethi

Ungasebenzisa i-Inthanethi ukuthola amasevisi akulayini.

Ukuqala ukupheqa

- 1 Kokubekwe eceleni khetha [Imenu](#) > [I-inthanethi](#).
- 2 Khetha [Izinketho](#) > [Yiya ku](#).
- 3 Khetha ongakhetha kukho.

Ukuphuma kwisipheqi

- Uma upheqa kwi-Inthanethi, khetha Izinketho > Isipheqi sokuph.

Ukushaya ucingo ngesikhathi upheqa

- Uma upheqa kwi-Inthanethi cindezela ↗.

Ukugcina into ephuma kwikhasi le-Web

- 1 Uma upheqa kwi-Inthanethi, khetha into.
- 2 Khetha Izinketho > Amathuluzi bese ukhetha into.

Ukuthola umbhalo ekhasini le-Web

- 1 Uma upheqa kwi-Inthanethi, khetha Izinketho > Amathuluzi > Thola ekhasini.
- 2 Faka umbhalo bese ucindezela Thola.

Ukuthumela ukuxhumana

- 1 Uma upheqa kwi-Inthanethi, khetha Izinketho > Amathuluzi > Thumela ukuxh.
- 2 Khetha ongakhetha kukho.

Usebenzisa amabhukumaka

Ungakha bese uhlela amabhukumaka njengokuxhumana okusheshayo okuya kumakhasi akho athandwayo e-Web.

Ukwakha ibhukhumaka

- 1 Uma upheqa kwi-Inthanethi, khetha Izinketho > Amathuluzi > Engeza ibhukuma. > Mabhukumaka.
- 2 Faka isihloko nekheli. Khetha Gcina.

Ukukhetha ibhukhumaka

- 1 Kokubekwe eceleni khetha Imenu > I-inthanethi.
- 2 Khetha Izinketho > Yiya ku > Mabhukumaka.
- 3 Pheqela kwibhukhumaka bese ukhetha Yiya ku.

Amashothikhathi ekhiphedi e-Inthanethi

Ungasebenzisa ikhiphedi ukuya ngqo emsebenzini wesipheqi se-Inthanethi.

Ukukhetha amashothikhathi ekhiphedi ye-Inthanethi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [I-inthanethi](#).
- 2 Khetha [Izinketho](#) > [Kuthuthukile](#) > [Imodi yekhiphedi](#) > [Amashothikhathi](#).

Ikhi	Ishothikhathi
	Mabhukumaka
	Faka umbhalo ku Faka ikheli , Cinga i-inthanethi noma cinga kwi Mabhukumaka .
	Isibuko esigcwеле noma Isithom. sendawo noma Isibuko esijwayel .
	Zoom
	Yendlala ucacise (uma i I-Smart-Fit icishiwe).

Ukuphepha kwe-inthanethi nezitifiketi

Ifoni yakho isaphotha ukupheqa okuphephile. Amanye amasevisi e-Inthanethi, njengokubhenka, adinga izitifiketi efonini yakho. Ifoni yakho kungenzeka ibe nezitifiketi ngenkathi uyithenga noma ungazilanda izitifiketi ezintsha.

Ukuhlola izitifiketi efonini

- Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Okujwayelekile](#) ithebhу > [Ezokuphepha](#) > [Izitifiketi](#).

Ama-feed e-Web

Ungamukela okuqukhethwe okubuyekezwa njalo, njengama-podcast noma izihloko zezindaba, njengama-feed e-Web. Ungongeza ama-feed ekhasi, uma linalolu phawu.

Ukwengeza ama-feed amasha ekhasi le-Web

- Uma upheqa ikhasi kwi-Inthanethi elinama-feed e-Web, khetha [Izinketho](#) > [Ama-feed eWeb](#).

Ukwakha i-feed entsha ye-Web

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Ama-feed eWeb](#) > [Izinketho](#) > [I-feed entsha](#).
- 2 Faka ikheli bese ukhetha [Yiya ku](#).

Ukusetha okukhethwa kukho kwama-feed e-Web

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Imibiko ethunyel.](#) > [Ama-feed eWeb](#).
- 2 Pheqela kwi-feed ye-Web bese ukhetha [Izinketho](#).
- 3 Khetha ongakhetha kukho.

I-Bluetooth™ wireless technology

Uhlelo Iwe-Bluetooth lwenza ukuxhumana okungenawaya kwamanye amadivaysi e-Bluetooth enzeke. Isibonelo, unga:

- Xhuma kumadivaysi ehendisfri.
- Xhuma kumadivaysi amaningi ngesikhathi esisodwa.
- Xhuma kumakhompyutha bese ungena kwi-Inthanethi.
- Shintshanisa izinto bese udlala imidlalo edlalwa abadlali abaningi.

 *Sincoma izinga eliphakathi kwamamitha ayi-10, kungabi nezinto phakathi kwalo, ngokuxhumana kwe-Buetooth.*

Ngaphambi kokuba usebenzise ubuchwepheshe obungenawaya be-Bluetooth

Kufanele uvule umsebenzi we-Bluetooth ukuxhumana namanye amadivaysi. Kufanele futhi ubhangqe ifoni yakho namanye amadivaysi e-Bluetooth.

Ukuvula uhlelo Iwe-Bluetooth

- Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Ukuxhumana** ithebhу > **I-Bluetooth** > **Vula**.

! *Qinisekisa ukuthi idivaysi ofuna ukuyibhangqa nefoni yakho inomsebenzi we-Bluetooth ocushiwe futhi obonakalayo.*

Ukubhangqa ifoni nedivaysi

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Ukuxhumana** ithebhу > **I-Bluetooth** > **Imishini yami**.
- 2 Pheqa ku **Umshini omusha bese** ukhetha **Engeza** ukucinga amadivaysi atholakalayo.
- 3 Khetha idivaysi.
- 4 Faka iphasikhodi, uma kudingeka.

Ukuvumela ukuxhumana nefoni

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Ukuxhumana** ithebhу > **I-Bluetooth** > **Imishini yami**.
- 2 Khetha idivaysi ohlwini.
- 3 Khetha **Izinketho** > **Vumela ukuxhu**.

Ukubhangqa ifoni nehendisfri ye-Bluetooth ngokokuqala

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Ukuxhumana** ithebhу > **I-Bluetooth** > **Ihendisfri**.
- 2 Khetha **Yebo**.
- 3 Faka iphasikhodi, uma kudingeka.

Ukubhangqa ifoni namahendisfri e-Bluetooth angaphezu kweyodwa

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebu > [I-Bluetooth](#) > [Ihendisifri](#) > [Ihendisifri yami](#) > [Ihendisifri entsha](#).
- 2 Pheqela kwidivaysi bese ukhetha [Engeza](#).

Ukonga amandla

Ungonga amandla ebhethri ngomsebenzi wokonga Amandla. Ungaxhuma kuhela ngedivaysi eyodwa ye-Bluetooth. Kufanele ucishe lo msebenzi uma ufunu ukuxhumana namadivaysi e-Bluetooth angaphezu kweyodwa.

Ukuvula ukonga amandla

- Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebu > [I-Bluetooth](#) > [Ukonga amandla](#) > [Vuliwe](#).

Ukubonakala

Uma ufunu amanye amadivaysi e-Bluetooth akwazi ukuthola ifoni yakho, ungakhetha ukwenza ifoni yakho ibonakale.

Ukwamukela into

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebu > [I-Bluetooth](#) > [Kuyabonakala](#) > [Bonisa ifoni](#).
- 2 Uma wamukela into ethile, landela imiyalelo evelayo.

Ukudlulisa umsindo oya noma ovela kwihiendisfri ye-Bluetooth

Ungadlulisa umsindo uye noma ovela kwihiendisfri ye-Bluetooth ngokusebenzisa ikhi yefoni noma yehendisfri.

Ukudlulisa umsindo

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Izinhlelo](#) > eye [Ukuxhumana](#) ithebu > [I-Bluetooth](#) > [Ihendisifri](#) > [Ucingo olungenayo](#).
- 2 Khetha okukhethwa kukho. I [Efonini](#) idlulisela umsindo efonini yakho. I [Kwihiendisfri](#) idlulisela umsindo kwihiendisfri.

Ukudlulisa ifayela

Ungavumelanisa ubuye udlulise amafayela ngokusebenzisa ubuchwepheshe obungenawayawa be-Bluetooth. Bheka [Ukuvumelanisa usebenzisa ikhompyutha](#) ekhasini 63.

Ukusebenzisa ikhebula le-USB

Ungax huma ifoni yakho kwikhompyutha ngekhebula le-USB ukudlulisa amafayela ngokusebenzisa **Londoloz okuningi** noma **Ukudlulisa imidiya**. Futhi ungavumelanisa, udlulise amafayela bese usebenzisa ifoni yakho njengemodemu ngokusebenzisa **Imodi yefoni**. Ngolunye ulwazi yiya engxenyeni ethi Ukuqalisa ku www.sonyericsson.com/support.

Ngaphambi kokusebenzisa ikhebula le-USB

Udinga olunye lwalezi nhlelo zokusebenza ukuze udlulise amafayela ngokusebenzisa ikhebula le-USB:

- I-Windows® 2000
- I-Windows XP (i-Pro ne-Home)
- I-Windows Vista (32 bhithi no 64 bhithi izihumusho ze: I-Ultimate, Enterprise, Business, Home Premium, Home Basic)

Ukudlulisa imidiya nokulondoloza umthamo

Ungahudula bese uphonsa amafayela phakathi kwefonu yakho noma imemori khadi nekhompyutha ku *Microsoft Windows Explorer*.

! Sebenzisa kuphela ikhebula le-USB elisekelwe yifoni yakho. Ungalikhipi ikhebula le-USB efonini noma kwikhompyutha yakho ngesikhathi sokudlulisa amafayela njengoba lokhu kungonakalisa imemori yefoni noma imemori khadi.

Ukusebenzisa imodi yokudlulisa imidya nokulondoloza umthamo



! Ngaphambi kokudlulisa amafayela kufanele ufa ke isothiye ye-Sony Ericsson PC Suite kwikhompyutha yakho. Bheka Uku faka i-Sony Ericsson PC Suite ekhasini 63.

- 1 Xhuma ikhebula le-USB kwifoni nakwikhompyutha.
- 2 Ifoni: Khetha **Londoloz okuningi** > **Imenu** > **Izhinlelo** > eye **Ukuxhumana ithebhу** > **I-USB** > **Imodi ye-USB** > **Londoloz okuningi**. Ifoni izovivala kule modi bese iqala kabusha uma inqanyulwa kwikhebula le-USB.

- Ifony:** Khetha [Ukudlulisa imidiya](#) futhi ifoni izolokhu icuphekile ngesikhathi sokudlulisa amafayela.
- Ikhompyutha:** Linda ize imemori yefoni yakho nememori khadi kuvele njengamadiski angaphandle kwi-*Windows Explorer*.
- Hudula bese uphonsa amafayela akhethiwe phakathi kwefoni nekhompyutha.

Ukunqamula ukuxhuma ikhebula le-USB ngokuphophile

- Qhafaza esidlelni ophawini lwediski ekhiphekayo ku *Windows Explorer*.
- Khetha u *Khipha*.
- Nqamula ikhebula le-USB uma umyalezo olandelayo ukhonjiswa efonini: [Ukuxhumana kwe-USB kuphelite](#). Kuphophile manje ukukhipha ikhebuli le-USB.

Imodi yefoni

Ngaphambi kokuvumelanisa noma ukusebenzisa ifoni yakho njengemodemu kufanele ufake *eye-Sony Ericsson PC Suite isofthiwe kwikhompyutha* yakho. Bheka [Ukuafaka i-Sony Ericsson PC Suite](#) ekhasini 63.

Ukusebenzisa imodi yefoni

- Ikhompyutha:** Qala i-*PC Suite* ephuma ku [Qala/Izinhlelo/Sony Ericsson/PC Suite](#).

62 *Ukuxhumana*

- Xhuma ikhebula le-USB kwifoni nakwikhompyutha.
- Ifony:** Khetha [Imodi yefoni > Imenu > Izinhlelo > eye](#) [Ukuxhumana ithebhу > I-USB > Imodi ye-USB > Imodi yefoni](#).
- Ikhompyutha:** Uma waziswa ukuthi *i-Sony Ericsson PC Suite* isithole ifoni yakho, ungaqala ukusebenzisa izinhlelo zemodi yefoni.

 *- Ngemininingwane yokusebenzisa, bheka ingxenye ethi Sony Ericsson PC Suite Help uma isothiwe isifakiwe kwikhompyutha yakho.*

Kuyavumelaniswa

Ungasebenzisa ikhebula le-USB noma ubuchwepheshe obungenawayo be-Bluetooth ukvumelanisa oxhumana nabo befoni, ama-aphoyintimenti, amabhukhmake, imisebenzi namanothi nohlelo lwekhompyutha olufana ne-Microsoft Outlook. Ungavumelanisa futhi nesevisi ye-Inthanethi ngokusebenzisa i-SyncML noma i-Microsoft® Exchange Server ngokusebenzisa i-Exchange ActiveSync. Ngolunye ulwazi yiya engxenyeneni ethi Ukuqalisa ku www.sonyericsson.com/support.

 Sebenzisa kuphela eyodwa yezindlela zokuvumelanisa ngesikhathi nefoni yakho.

Ukuvumelanisa usebenzisa ikhompyutha

Ngaphambi kokuvumelanisa udinga ukufaka *i-Sony Ericsson PC Suite* ephuma kwi-CD ehambisana nefoni yakho. Isofthiwe ibandakanya ulwazi losizo. Ungavakashela futhi ku www.sonyericsson.com/support ukulanda isofthiwe.

Udinga olunye Iwalezi nhlelo zokusebenza ukusebenzisa i-PC Suite kwikhompyutha yakho:

- I-Windows XP (i-Pro ne-Home)
- I-Windows Vista (32 bhithi no 64 bhithi izihumusho ze: I-Ultimate, Enterprise, Business, Home Premium, Home Basic)

Ukfaka *i-Sony Ericsson PC Suite*

- 1 Vula ikhompyutha yakho bese ufaka i-CD. I-CD iqala nge-othomathikhi ne-installation window liyavuleka.
- 2 Khetha ulimi bese uqhebeza OK.
- 3 Qhebeza *Install Sony Ericsson PC suite* bese ulandela imiyalo esesibukweni.

Ukuvumelanisa ngokusebenzisa eye-Inthanethi isevisi

Ungavumelanisa kulayini ngokusebenzisa isevisi ye-Inthanethi nefoni yakho. Uma amasetthingi e-Inthanethi engekho efonini yakho, bheka *Amasetthingi* ekhasini 56.

Ngaphambi kokuqala ukuvumelanisa Kufanele ufake amasetthingi okuvumelanisa i-SyncML bese ubhalisa i-akhawunti yokuvumelanisa kulayini nomnikezeli wesevisi.

Amasetthingi adingekayo yilawa:

- *Ikheli likanolwazi* – iseva i-URL.
- *Igama ledathabhe.* – idathabheysi ozovumelanisa ngayo.

Ukfaka *amasetthingi e-SyncML*

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Ukw. kuhambi](#).
- 2 Pheqela ku [I-akhawunti ents.](#) bese ukhetha [Engeza](#) > [SyncML](#).
- 3 Faka igama le-akhawunti entsha bese ukhetha [Qhubek](#).
- 4 Pheqela ku *Ikheli likanolwazi*. Faka ulwazi oludingekayo bese ukhetha [Kulungile](#).
- 5 Faka [Igama lomsebenz.](#) ne [Iphasiwedi](#), uma kudingeka.
- 6 Pheqela kweye [Izinhlelo](#) ithebhу ukumaka izinhlelo ozozivumelanisa.

- 7 Pheqela kweye [Amasethingi](#) ohlelo ithebhу bese ukhethа uhlеlo.
- 8 Khetha [Igama ledathabhe](#). bese ufaka imininingwane edingekayo.
- 9 Pheqela kweye [Kuthuthukile](#) ithebhу ukufaka amanye amasethingi okuvumelanisa.
- 10 Khethа [Gcina](#).

Ukususa i-akhawunti

- 1 Kokubekwe eceleni khethа [Imenu](#) > [Umhleli](#) > [Ukw. kuhambi](#).
- 2 Pheqela kwi-akhawunti bese ukhethа [Izinketho](#) > [Susa](#).

Ukuqala ukuvumelanisa

- 1 Kokubekwe eceleni khethа [Imenu](#) > [Umhleli](#) > [Ukw. kuhambi](#).
- 2 Pheqela kwi-akhawunti bese ukhethа [Qala](#).

Ukuvumelanisa ngokusebenzia i-Microsoft® Exchange Server

Ungathola futhi uvumelanise ulwazi lokushintshisana lwezinkampani njenge-imeyli, okuxhunywana nabo nokwekhalenda nge-Microsoft® Exchange Server ngokusebenzia ifoni yakho.

 *Ngeminye imininingwane ngamasethingi okuvumelanisa, xhumana nomphathi wakho we-IT.*

Ngaphambi kokuqala ukuvumelanisa
Kufanele ufake amasethingi e-Exchange ActiveSync ukufinyelela kwi-Microsoft Exchange Server. Amasethingi adingekayo yilawa:

- [Ikheli likanolwazi](#) – iseva i-URL.
- [Inkundla](#) – idomeyni yeseva
- [Igama lomsebenz.](#) – igama lomsebenzisi we-akhawunti
- [Iphasiwedi](#) – iphasiwedi ye-akhawunti.

Ukfaka amasethingi e-Exchange ActiveSync

- 1 Kokubekwe eceleni khethа [Imenu](#) > [Umhleli](#) > [Ukw. kuhambi](#). > MS Exchange.
- 2 Faka igama le-akhawunti entsha bese ukhethа [Qhubek](#).
- 3 Faka amasethingi adingekayo.
- 4 Pheqa phakathi kwamathebhу ukufaka amanye amsethingi.
- 5 Khethа [Gcina](#).

Ukuqala ukuvumelanisa

- 1 Kokubekwe eceleni khethа [Imenu](#) > [Umhleli](#) > [Ukw. kuhambi](#).
- 2 Pheqela kwi-akhawunti bese ukhethа [Qala](#).



I-Update service

Ungabuyekeza ifoni yakho ngesofthiwe yakamuva. Awulahlekelwa yimininingwane eqondene nave noma yefoni.

Kunezindlela ezimbili zokuvuselela ifoni yakho:

- Emoyeni ngefone yakho.
- Ngekhebula le-USB elihlinzekiwe nekhompyutha exhunywe kwi-Inthanethi.

! *I-Update service idinga uthole idatha efana ne-GPRS, 3G noma HSDPA.*

Ngaphambi kokusebenzisa i-Update service

Uma amasetthingi engekho efonini yakho, bheka *Amasetthingi* ekhasini 56.

Ukuhlola isothiwe yamanje efonini

- 1 Kokubekwe eceleni khetha [Imenuy > Izinhlelo > eye Okujwayelekile ithebhу > I-Update service.](#)
- 2 Khetha [Isihum. sesothiwe.](#)

Ukusebenzisa i-Update service ngokusebenzisa ifoni

- 1 Kokubekwe eceleni khetha [Imenuy > Izinhlelo > eye Okujwayelekile ithebhу > I-Update service.](#)
- 2 Khetha [Cinga ukuvuselela bese ulandela imiyalelo evelayo.](#)

Ukusebenzisa i-Update service ngekhebula le-USB

- 1 Yiya ku www.sonyericsson.com/support noma qhebeza *i-Sony Ericsson Update service* kweye PC Suite isothiwe uma ifakiwe kwikhompyutha yakho. Bheka *Ukfaka i-Sony Ericsson PC Suite* ekhasini 63.
- 2 Khetha isifunda noma izwe.
- 3 Landela imiyalelo esesibukweni.

Ukusetha isikhumbuzi sokusebenzisa i-Update service

- 1 Kokubekwe eceleni khetha [Imenuy > Izinhlelo > eye Okujwayelekile ithebhу > I-Update service > Izinhlelo > Isikhumbuzi.](#)
- 2 Khetha ongakhetha kukho.

Ezinye izimpawu

Ama-alamu

Ungasetha umsindo noma umsakazo njengesignali ye-alamu. I-alamu ikhala noma ifoni icishiwe. Uma i-alamu ikhala ungayithulisa imizuzu engu 9 noma uycishe.

Ukusetha i-alamu

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ama-alamu](#).
- 2 Pheqela kwi-alamu bese ukhetha [Hlela](#).
- 3 Pheqela ku [Isikhathi](#): bese ukhetha [Hlela](#).
- 4 Faka isikhathi bese ukhetha [Kulungile](#) > [Gcina](#).

Ukusetha i-alamu yansukuzonke

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ama-alamu](#).
- 2 Pheqela kwi-alamu bese ukhetha [Hlela](#).
- 3 Pheqela ku [Phindaphinda](#): bese ukhetha [Hlela](#).
- 4 Pheqela osukwini bese ukhetha [Maka](#).
- 5 Ukukhetha olunye usuku, pheqela osukwini bese ukhetha [Maka](#).
- 6 Khetha [Kwenziw](#). > [Gcina](#).

Ukusetha isignal i ye-alamu

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ama-alamu](#).
- 2 Pheqela kwi-alamu bese ukhetha [Hlela](#).
- 3 Pheqela ku [Isignal i ye-alamu](#): bese ukhetha [Hlela](#).
- 4 Thola bese ukhetha isignal i ye-alamu. Khetha [Gcina](#).

Ukuthulisa i-alamu

- Uma i-alamu ikhala, cindezela noma iyiphi ikhi.
- Ukuphina i-alamu, khetha [Lala](#).

Ukucisha i-alamu

- Uma i-alamu ikhala, khetha [Cisha](#).

Ukukhansela i-alamu

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Ama-alamu](#).
- 2 Pheqela kwi-alamu bese ukhetha [Cisha](#).

I-alamu kwimodi yokuthula

Ungasetha ukuthi i-alamu ingakhali uma ifoni ikwimodi yokuthula.

Ukusetha i-alamu ukuba ikhale noma cha kwimodi yokuthula

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Ama-alamu](#).
- 2 Pheqela kwi-alamu bese ukhetha [Hlela](#).
- 3 Pheqela kweye  ithebhu.
- 4 Pheqela ku [Imodi ethule](#) bese ukhetha [Hlela](#).
- 5 Khetha ongakhetha kukho.

[Ikhalenda](#)

Ikhalaenda lingavumelaniswa nelekhompyutha, nekhalaenda elikwi-Web noma ne-Microsoft® Exchange Server (Microsoft® Outlook®). Ngolunye ulwazi bheka *Kuyavumelaniswa* ekhasini 62.

Ukubukeka kwedifolthi

Ungakhetha ukuthi yinyanga, yiviki noma wusuku oluzovela kuqala uma uvula ikhalenda.

Ukusetha ukubukeka kwedifolthi

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umhleli](#) > [Ikhalenda](#).
- 2 Khetha [Izinketho](#) > [Okuthuthukile](#) > [Ukubuk okumisiw](#).
- 3 Khetha ongakhetha kukho.

Ama-aphoyintimenti

Ungongeza ama-aphoythimenti amasha noma usebenzise kabusha ama-aphoythimenti akhona.

Ukwengeza i-aphoyintimenti

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umhleli](#) > [Ikhalenda](#).
- 2 Khetha usuku.
- 3 Pheqela ku [I-aphoyintimenti](#) bese ukhetha [Engeza](#).
- 4 Faka ulwazi bese uqinisekisa okufakile.
- 5 Khetha [Gcina](#).

Ukuhlola i-aphoyintimenti

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umhleli](#) > [Ikhalenda](#).
- 2 Khetha usuku.
- 3 Pheqela kwi-aphoynimenti bese ukhetha [Hlola](#).

Ukuhlela i-aphoyintimenti

- 1 Kokubekwe eceleni khetha [Imenu](#) > [Umhleli](#) > [Ikhalenda](#).
- 2 Khetha usuku.
- 3 Pheqela kwi-aphoynimenti bese ukhetha [Hlola](#).
- 4 Khetha [Izinketho](#) > [Hlela](#).
- 5 Hlela i-aphoynimenti bese uqinisekisa okufakile.
- 6 Khetha [Gcina](#).

Ukuthumela i-apoyintimenti

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Ikhalaenda](#).
 - 2 Khetha usuku.
 - 3 Pheqela kwi-apoyntimenti bese ukhetha [Izinketho](#) > [Thumela](#).
 - 4 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Ukuhlola iviki lekhalaenda

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Ikhalaenda](#).
- 2 Khetha usuku.
- 3 Khetha [Izinketho](#) > [Hlola](#) isonto.

Ukusetha ukuthi izikhumbuzi zikhale nini

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Ikhalaenda](#).
 - 2 Khetha usuku.
 - 3 Khetha [Izinketho](#) > [Okuthuthukile](#) > [Izikhumbuzi](#).
 - 4 Khetha ongakhetha kukho.
- ! *Okukhethwa kukho izikhumbuzi okusethwe ekhalendeni kuphazamisa okukhethwa kukho izikhumbuzi okusethwe kwimisebenzi.*

Imisebenzi

Ungongeza imisebenzi emisha noma usebenzise kabusha imisebenzi ekhona.

Ukwengeza umsebenzi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imisebenzi](#).
- 2 Pheqela ku [Umsebenzi](#) omusha bese ukhetha [Engeza](#).
- 3 Khetha ongakhetha kukho.
- 4 Faka iminininingwane bese uqinisekisa uhlu ngalunye.

Ukuhlola umsebenzi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imisebenzi](#).
- 2 Pheqa kumsebenzi bese ukhetha [Hlola](#)

Ukusebenzisa kabusha umsebenzi okhona

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imisebenzi](#).
- 2 Pheqa kumsebenzi bese ukhetha [Hlola](#)
- 3 Khetha [Izinketho](#) > [Hlela](#).
- 4 Hlela umsebenzi bese ukhetha [Qhubek](#).
- 5 Khetha ukusetha isikhumbuzi.

Ukuthumela umsebenzi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imisebenzi](#).
 - 2 Pheqa kumsebenzi bese ukhetha [Izinketho](#) > [Thumela](#).
 - 3 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Ukusetha ukuthi izikhumbuzi zikhale nini

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Imisebenzi](#).
 - 2 Pheqa kumsebenzi bese ukhetha [Izinketho](#) > [Izhumbuzi](#).
 - 3 Khetha ongakhetha kukho.
- ! *Okukhethwa kukho izikhumbuzi okusethwe kwimisebenzi kunomthelela kokukhethwa kukho izikhumbuzi okusethwe kwikhalenda.*

Amanothi

Ungenza amanothi bese uyawagcina. Ungakhombisa futhi inothi kokubekwe eceleni.

Ukwengeza inothi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Amanothi](#).
- 2 Pheqela ku [Inothi entsha](#) bese ukhetha [Engeza](#).
- 3 Bhala inothi bese ukhetha [Gcina](#).

Ukukhombisa inothi kokubekwe eceleni

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Amanothi](#).
- 2 Pheqela kwinothi bese ukhetha [Izinketho](#) > [Khombisa kokube](#).

Ukuthumela inothi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Amanothi](#).
 - 2 Pheqela kwinothi bese ukhetha [Izinketho](#) > [Thumela](#).
 - 3 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Ukusebenzisa into kwinothi

- 1 Uma uhlola inothi, khetha inamba yefoni, i-imelyi nomu ikheli le-Web.
- 2 Khetha [Izinketho](#) > [Sebenzisa](#).
- 3 Khetha ongakhetha kukho.

I-timer, istophuwoshu nomshini wokubala

Ukusebenzisa i-timer

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Isikhathi](#).
- 2 Faka amahora, imizuzu namasekhondi.
- 3 Khetha [Qala](#).

Ukusebenzisa isitophuwashi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Isimisa washī](#) > [Qala](#).
- 2 Ukuhlola isikhathi somzungezo omusha, khetha [Umjikel](#).

Ukusebenzisa umshini wokubala

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Umshi](#). [wokubala](#).
- 2 Cindezela \square noma \square ukukhetha $\div \times - + . \% =$.

Ikhodi memo

Ungagcina amakhodi okuphepha, isibonelo, amakhadi ezikweletu. Kufanele usethe iphasikhodi ukuvula ikhodi memo.

Ishlolimagama

Ishlolimagama siyaqinisekisa ukuthi ufake iphasikhodi efanele. Uma iphasiwedi ilungile, amakhodi alungile ayakhoniswa. Uma iphasiwedi ingalungile, isihlolamagama namakhodi akhonjiswayo nawo awalungile.

Ukuvula ikhodi memo okokuqala

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Isiqophi sekhodi](#).
- 2 Landela imiyalelo evelayo bese ukhetha [Qhubek](#).

3 Faka iphasikhodi bese ukhetha [Qhubek](#).

- 4 Qinisekisa iphasikhodi bese ukhetha [Qhubek](#).
- 5 Faka isihlolimagama bese ukhetha [Kwenziw](#).

Ukwengeza ikhodi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Isiqophi sekhodi](#).
- 2 Faka iphasikhodi bese ukhetha [Qhubek](#).
- 3 Pheqela ku [Ikhodi entsha](#) bese ukhetha [Engeza](#).
- 4 Faka igama elihlobene nekhodi bese ukhetha [Qhubek](#).
- 5 Faka ikhodi bese ukhetha [Kwenziw](#).

Ukuze ushintshe iphasikhodi

- 1 Kokubekwe eceleni khetha [Imenuy](#) > [Umhleli](#) > [Isiqophi sekhodi](#).
- 2 Faka iphasiwedi yakho bese ukhetha [Izinketho](#) > [Shintsha iphasikh](#).
- 3 Faka iphasiwedi yakho entsha bese ukhetha [Qhubek](#).
- 4 Phinda ufake iphasikhodi entsha bese ukhetha [Qhubek](#).
- 5 Faka isihlolimagama bese ukhetha [Kwenziw](#).

Ngabe uyikhohliwe iphasikhodi yakho?

Uma ukhohlwa iphasikhodi yakho, kufanele usethe kabusha ikhodi memo yakho. Lokhu kusho ukuthi konke okufakwe kwikhodi memo kuyasuswa. Ngokuzayo uma ufaka ikhodi memo, kufanele wenze sengathi uyivula okokuqala. Bheka *Ukuvula ikhodi memo okokuqala* ekhasinji 70.

Ukusetha kabusha ikhodi memo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Isiqophi sekhodi**.
- 2 Faka noma iyiphi iphasikhodi ukungena kwikhodi memo. Isihlolamagama namakhodi kuyakhonjiswa akulungile.
- 3 Khetha **Izinketho** > **Hlela kabusha**.
- 4 **Setha kabusha imemo yekhodi?** iyavela.
- 5 Khetha **Yebo**.

Amaphrofayli

Amaphrofayli avumelanisa nge-othomathiki amasethingi athile efon nezimo ezihlukene, isibonelo, ivolumu yokukhala ingaguqulwa ifanelane nomhlangano noma nesisekeli. Ungasetha kabusha wonke amaphrofayli abe yindlela ayesethwe ngayo khathi uthenga ifoni yakho.

Ukukhetha iphrofayli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Okujwayelekile ithebhу** > **Amaphrofayli**.
- 2 Khetha iphrofayli.

Ukuhlola nokuhlela iphrofayli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Okujwayelekile ithebhу** > **Amaphrofayli**.
- 2 Pheqela kuphrofayli bese ukhetha **Izinketho** > **Hlola bese uhlela**.

! **Ngeke ukwazi ukuqamba kabusha iphrofayli elijwayelekile.**

Ukusetha kabusha wonke amaphrofayli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Okujwayelekile ithebhу** > **Amaphrofayli**.
- 2 Khetha **Izinketho** > **Hlela amaqoqo**.

Isikhathi nosuku

Ukusetha isikhathi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Okujwayelekile ithebhу** > **Isikhathi nosuku** > **Isikhathi**.
- 2 Faka isikhathi bese ukhetha **Gcina**.

Ukusetha usuku

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **Isikhathi nosuku** > **Usuku**.
- 2 Faka usuku bese ukhetha **Gcina**.

Ukusetha umkhawuko wesikhathi

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **Isikhathi nosuku** > **Indawo yami yeskhathi**.
 - 2 Khetha umkhawuko wesikhathi okubo ngedolobha.
- ! ***Uma ukhetha idolobha, i Indawo yami yeskhathi ibuyekeze isikhathi uma siguquka isikhathi sokonga emini.***

Amalokhi

Ilokhi yeSIM khadi

Le lokhi ivikela kuphela ukuthenga kwakho. Ifoni yakho izosebenza ne-SIM khadi entsha. Uma ilokhi ivuliwe, kumele ufake i-PIN (Personal Identity Number).

Uma ufaka i-PIN yakho ngokungeyikho izikhathi ezintathu zilandelana, i-SIM khadi iyavinywa futhi udinga ukufaka eyakho i-PUK (Personal Unblocking Key). I-PIN ne-PUK yakho kuhlinzekwa ngopharetha wenethiwekhi yakho.

Ukuvula ukuvinjwa kwe-SIM khadi yakho

- 1 Uma **I-PIN** ivinjiwe kuvela, faka i-PUK yakho bese ukhetha **Kulungile**.
- 2 Faka iPIN entsha enamadjithi amane kuya kwayisishiyagalombili bese ukhetha **Kulungile**.
- 3 Phinda ufake i-PIN entsha bese ukhetha **Kulungile**.

Ukuhlela i-PIN

- 1 Kokubekwe eceleni khetha **Imenuy** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **Ezokuphepha** > **Amalokhi** > **Ukuvikel**. **kweSIM** > **Shintsha uphini**.
- 2 Faka i-PIN yaphasiwedi yakho bese ukhetha **Kulungile**.
- 3 Faka iPIN entsha enamadjithi amane kuya kwayisishiyagalombili bese ukhetha **Kulungile**.
- 4 Phinda ufake i-PIN entsha bese ukhetha **Kulungile**.

- ! ***Uma Amakhodi awahambelani kuvela, ufake i-PIN entsha ngokungeyikho. Uma IPIN okungesiyo kuvela, kulandelwa yi IPIN endala:, ufake IPIN yakho endala ngokungesikho.***

Ukusebenzisa ilokhi ye-SIM khadi

- 1 Kokubekwe eceleni khetha [Imenu](#)
 - > [Izinhelelo](#) > eye [Okujwayelekile](#) ithebhу
 - > [Ezokuphepha](#) > [Amalokhi](#) > [Ukuvikel.](#)
 - [kweSIM](#) > [Vikela.](#)
- 2 Khetha ongakhetha kukho.
- 3 Faka i-PIN yaphasiwedi yakho bese ukhetha [Kulungile.](#)

Ukhiye wefonи

Ungaqedu ukusetshenziswa okungagunyaziwe kweponi yakho. Shintsha ikhodi yakho yokukhiya ifoni (0000) ngokufaka noma yiziphi ikhodi eqondene nawe enezinombolo eziphakathi kwezine neziyiisishiyagalombili

- ! *Kubalulekile ukuthi uyikhumbule ikhodi yakho entsha. Uma uyikhohlwa, kufanele uhambise ifoni yakho kumthengisi wakwa-Sony Ericsson oseduze nawe.*

Ukusebenzisa ilokhi yefoni

- 1 Kokubekwe eceleni khetha [Imenu](#)
 - > [Izinhelelo](#) > eye [Okujwayelekile](#) ithebhу
 - > [Ezokuphepha](#) > [Amalokhi](#) > [Ukuvikel.](#)
 - kweponi > [Ukuvikelka.](#)
- 2 Khetha ongakhetha kukho.
- 3 Faka ikhodi yokukhiya ifoni bese ukhetha [Kulungile.](#)

Ukushintsha ikhodi yokukhiya ifoni

- 1 Kokubekwe eceleni khetha [Imenu](#)
 - > [Izinhelelo](#) > eye [Okujwayelekile](#) ithebhу
 - > [Ezokuphepha](#) > [Amalokhi](#) > [Ukuvikel.](#)
 - kweponi > [Shintsha ikhodi.](#)
- 2 Faka ikhodi endala bese ukhetha [Kulungile.](#)
- 3 Faka ikhodi entsha bese ukhetha [Kulungile.](#)
- 4 Phinda ikhodi bese ukhetha [Kulungile.](#)

Ilokhi yekhiphedi

Ungasetha le lokhi ukugwema ukudayela ngephutha. Izingcingo ezingenayo zingaphendulwa ngaphandle kokuvula ilokhi yekhiphedi.

- ! *Izingcingo ezishayelwa inombolo yomhlaba yezimo eziphuthumayo u-112 zisengenziwa.*

Ukuhlela ukhiye wamabhathini ozenzekelayo

- 1 Kokubekwe eceleni khetha [Imenu](#)
 - > [Izinhelelo](#) > eye [Okujwayelekile](#) ithebhу
 - > [Ezokuphepha](#) > [I-othoma. khilokhi.](#)
- 2 Khetha ongakhetha kukho.

Ukukhiya ngesandla ikhiphedi

- Kokubekwe eceleni cindezela  bese ukhetha [Khiya.](#)

Ukuvula ilokhi yekhiphedi ngesandla

- Kokubekwe eceleni cindezela  bese ukhetha **Vula**.

Inamba ye-IMEI

Gcina ikhophi yenamba yakho ye-IMEI (International Mobile Equipment Identity) ukuze isize uma ifoni yakho yebiwa.

Ukuhlola inamba ye-IMEI yakho

- Kokubekwe eceleni cindezela , , , .

Ukuxazulula

Izinkinga ezithile zizodinga ukuba ufonele u-opharetha wenethiwekhi yakho.

Ngesaphothi ethe xaxa yiya ku www.sonyericsson.com/support.

Imibuzo evamile

Nginezinkinga nomthamo wememori noma ifoni isebenza ngokunensa

Qala kabusha ifoni yakho zonke izinsuku ukukhulula imemori noma yenza i **Isihleli esikhulu**.

I-Master reset

Sewukhethe **Hlela izinhlelo**, izinguquko ozenze ezinhlelweni zizocishwa.

Uma ukhetha **Hlela konke**, ngaphezu kwezinguquku ezinhlelweni, bonke oxhumene nabo, imibiko, ulwazi lwakho kanye nengqikithi oyikhiphe emishinini emikhulu, oyemukele noma oyihlelile, iyocishwa futhi nayo.

Ukusetha kabusha ifoni

- 1 Kokubekwe eceleni khetha **Imenu** > **Izinhlelo** > eye **Okujwayelekile** ithebu > **Isihleli esikhulu**.
- 2 Khetha ongakhetha kukho.
- 3 Landela imiyalelo evelayo.

Angikwazi ukushaja ifoni noma umthamo webhethri uphansi

Ishaja ayixhumekile kahle noma uxhumano lwebhethri lubuthaka. Khipha ibhethri bese uhlanza izixumi.

Ibhethri igugile idinga ukushintshwa. Bheka *Ukushaja ibhethri* ekhasini 7.

Alukho uphawu lwebhethri oluvelayo uma ngiqala ukushaja ifoni

Kungathatha imizuzu embalwa ngaphambi kokuthi uphawu lwebhethri luvele esibukweni.

Okunye okukhethwa kukho imenuykuvela kumpunga

Isevisi ayicushiwe. Xumana no-opharetha wenethiwekhi yakho.

Angikwazi ukusebenzisa imibiko yemibhalo/SMS efonini yami

Izhinlelo ziyashoda noma azilungle. Xumana no-opharetha wenethiwekhi yakho ukuthola uhlelo ijesikhungo sesevisi ye-SMS olulungile. Bheka *Imibiko yombhalo* ekhasini 31.

Angikwazi ukusebenzisa imibiko yesithombe efonini yami

Ukuthenga kwakho akubandakanyi ikhona ledatha. Izinhlelo ziyashoda noma azilungle. Sicela uxhumane no-opharetha wenethiwekhi yakho.

Bheka Usizo efonini yakho

ekhasini 6 noma yiya ku www.sonyericsson.com/support uku-oda amasethingi bese ulandela imiyalo esibukweni. Bheka *Amasethingi* ekhasini 56.

Ngingayivula noma ngiyivale kanjani i-T9 Text Input uma ngibhala?

Uma ufaka umbhalo, cindezela bese ubamba . Uyobona phezulu esibukweni uma i-T9 Text Input icushwa.

Ngingalushintsha kanjani ulwimi lwefonii?

- 1 Kokubeka eceleni khetha *Imenuy* > *Izhinlelo* > eye *Okujwayelekile* ithebhу > *Ulimi* > *Ulimi lwefonii*.
- 2 Khetha ongakhetha kukho.

Angikwazi ukusebenzisa i-Inthanethi

Ukuthenga kwakho akubandakanyi ikhona ledatha. Izinhlelo ze-inethanethi ziyashoda noma azilungle. Sicela uxhumane no-opharetha wenethiwekhi yakho.

Bheka Usizo efonini yakho

ekhasini 6 noma yiya ku www.sonyericsson.com/support uku-oda amasethingi e-Inthanethi, bese ulandela imiyalo esibukweni. Bheka *Amasethingi* ekhasini 56.

Ifoni ayikwazi ukutholwa ngamanye amadivaysi ngobuchwepheshes obungenawaya be-Bluetooth

Awukaluvuli uhlelo Iwe-Bluetooth.

Qinisekisa ukuthi ukubonakala kusethelwe ukukhombisa ifoni. Bheka Ukwamukela into ekhasini 60.

Angikwazi ukuvumelanisa noma ukudlulisa idatha phakathi kwefoni yami nekhompyutha yami, uma ngisebenzisa ikhebula le-USB.

Ikhebula noma isofthiwe okufike nefoni yakho akufakwanga kahle. Yiya ku www.sonyericsson.com/support ufunde amagadyi okuQalisa anemiyalo egcwele yokufaka namagaydi okuxazulula izinkinga.

Ngingalutholaphi ulwazi lokuqondisa olunjengenamba yami ye-IMEI uma ingavuleki ifoni yami?



Imibiko enephutha

Faka ikhadi

Akukho SIM khadi efonini yakho noma kungenzeka ukuba uyifake ngendlela engalungile.

Bheka *Ukushaja ibhethri* ekhasini 7.

Izixumi zeSIM khadi zidinga ukuhlanzwa. Uma ikhadi lilimele, xhumana no-opharetha wenethiwekhi yakho.

Faka ikhadi o kuyilo le-SIM

Ifoni isethwe ukuthi isebenze kuphela nama-SIM khadi athile. Hlola noma usebenzisa iSIM khadi ka-opharetha elunglele yini.

IPIN okungesiyo/UPHINI 2 ayilungle
Ufake iPIN yakho noma iPIN2
ngokungesikho.

Faka i-PIN noma PIN2 efanele bese
ukhetha **Yebo**. Bheka *Faka iSIM khadi*
ekhasini 5.

I-PIN ivinjiwe/Pini-2uvalekile
Ufake iPIN noma iPIN2
ngokungesikho izikhathi ezintathu
zilandelana.

Ukuvula ukuvinjwa, bheka *llokhi yeSIM khadi* ekhasini 72.

Amakhodi awahambelani
Amakhodi owafakile awahambelani.
Uma ufunu ukushintsha ikhodi
yokuphepha, isibonelo i-PIN yakho,
kufanele uqinisekise ikhodi entsha.
Bheka *llokhi yeSIM khadi* ekhasini 72.

Ayikho inethiwekhi
Ifoni yakho ikwi-flight mode.
Bheka *I-Flight mode* ekhasini 6.

Ifoni yakho ayemukeli neyodwa isignal
yenethiwekhi, noma isignal
eyamukelwe ayinamandla. Xhumana
no-opharetha wenethiwekhi yakho
bese uqinisekisa ukuthi inethiwekhi
iyayikhava indawo okuyo.

I-SIM khadi ayisebenzi kahle. Faka
i-SIM khadi yakho kwenye ifoni. Uma
lokhu kusebenza, kungenzeka kube
yifoni ebangela inkinga. Sicela
uxhumane nesevisi ye-Sony Ericsson
yasendaweni.

Izingc. eziphi. kup.
Usendaweni lapho inethiwekhi
itholakala khona, kodwa awuvunyelwe
ukuyisebenzisa. Kepha, esimeni
esiphuthumayo, abanye o-opharetha
benethiwekhi bayakuvumela ukuba
ushayele inombolo ephuthumayo
yomazwe omhlaba jikelele u-112.
Bheka *Izingcingo ezipiphuthumayo*
ekhasini 18.

IPuk ivaliwe. Xhumana no- opharetha.
Ufake ikhodi yakho yokuvula
ukuvunjwa (IPUK) ngokungesikho
izikhathi ezi-10 zilandelana.

Ukushaja, ibhethi okungesilo elakh ona
Ibhethri olisebenzisayo akusilo ibhethri
elivunyelwe u-Sony Ericsson. Bheka
Ibhethri ekhasini 81.

Ulwazi olubalulekile

IWebhusaythi yaBathengi yakwa-Sony Ericsson

Ku www.sonyericsson.com/support kunengxene yeaphothi/yokusekela lapho kutholakala khona usizo namathiphu. Lapha uthola ukuvuselelwa kwesofthiwe yekhompyutha yakamuva namathiphu okuthi ungawusebenzisa kanjani umkhiqizo wakho ngokuyimpumelelo.

Isevizi nokusekela

- Kusukela manje uzokwazi ukungena kwiphophifoliyo yesevizi ekhetheki njengalezi:
- AmaWebhusaythi omhlabajikelele nawasekhaya anikezelza ngesaphothi.
 - Inethiwekhi yomhlabajikelele yama-Call Center.
 - Inethiwekhi ebanzi yophathina besevizi yakwa-Sony Ericsson.
 - Isikhathi sewaranti. Funda kabanzi ngezimiso sewaranti kule Gaydi yomsebenzisi.

Ku www.sonyericsson.com, ngaphansi kwengxene yeaphothi olimini Iwakho olukhethile,

uzothola amathuluzi esaphothi yakamuva nolwazi, njengama-updates eosithiwe, isizinda solwazi, isethaphu yefoni nosizo olwengezevi uma ulidanga.

Ngezimpawu namasevisi agxile ku-opharetha, sicela uxhumane no-opharetha wenethiwekhi yakho ngolwazi oluthe xaxa.

Ungaxhumana futhi nama-Call Center ethu. Bheka inamba yefoni ye-Call Center eseduze ohlwini olungezansi. Uma izwe/isifunda sakho singamelwe ohlwini, sicela uxhumane nomthengisi wangkanini. (Izinamba zefoni ezingezansi bezilungile ngesikhathi kuyophrintra. Ku www.sonyericsson.com ungathola njalo ama-updates akamuva.

Esimeni esingabazekayo lapho umkhiqizo wakho udingga isevisi, sicela uxhumane nomthengisi lapho uthengwe khona noma oyedwa wophathina besevizi. Gcina ubufakazi bokuthenga, uzobudinga uma udingga ukukleyma iwaranti.

Ngokushayela eyodwa yama-Call Center ethu uyoshajawa ngokwamareyhi kazwelonke, kubandakanya intela yangakini, ngaphandle uma inamba yefoni kungeyamahhala.

Izwe

E-Argentina

E-Australia

E-Austria

E-Belgium

E-Brazil

E-Canada

E-Central Africa

E-Chile

E-China

E-Colombia

E-Croatia

E-Czech Republic

E-Denmark

Inamba yefoni

800-333-7427

1-300 650 050

0810 200245

02-7451611

4001-0444

1-866-766-9374

+27 112589023

123-0020-0656

4008100000

18009122135

062 000 000

844 550 055

33 31 28 28

Ikheli le-imeyili

questions.AR@support.sonyericsson.com

questions.AU@support.sonyericsson.com

questions.AT@support.sonyericsson.com

questions.BE@support.sonyericsson.com

questions.BR@support.sonyericsson.com

questions.CA@support.sonyericsson.com

questions.CF@support.sonyericsson.com

questions.CL@support.sonyericsson.com

questions.CN@support.sonyericsson.com

questions.CO@support.sonyericsson.com

questions.HR@support.sonyericsson.com

questions.CZ@support.sonyericsson.com

questions.DK@support.sonyericsson.com

E-Finland	09-299 2000	questions.FI@support.sonyericsson.com
E-France	0 825 383 383	questions.FR@support.sonyericsson.com
E-Germany	0180 534 2020	questions.DE@support.sonyericsson.com
E-Greece	801-11-810-810 210-89 91 919 (ngeselula)	questions.GR@support.sonyericsson.com
E-Hong Kong	8203 8863	questions.HK@support.sonyericsson.com
E-Hungary	+36 1 880 4747	questions.HU@support.sonyericsson.com
E-India	39011111 (Faka ikhodi ye-STD uma udayela ususela kuxhumano lwe-GSM)	questions.IN@support.sonyericsson.com
E-Indonesia	021-2701388	questions.ID@support.sonyericsson.com
E-Ireland	1850 545 888	questions.IE@support.sonyericsson.com
E-Italy	06 48895206	questions.IT@support.sonyericsson.com
E-Lithuania	8 700 55030	questions.LT@support.sonyericsson.com
E-Malaysia	1-800-889900	questions.MY@support.sonyericsson.com
E-Mexico	01 800 000 4722	questions.MX@support.sonyericsson.com
E-Netherlands	0900 899 8318	questions.NL@support.sonyericsson.com
E-New Zealand	0800-100150	questions.NZ@support.sonyericsson.com
E-Norway	815 00 840	questions.NO@support.sonyericsson.com
E-Pakistan	111 22 55 73 Ngaphandle kwe-Karachi: (92-21) 111 22 55 73	questions.PK@support.sonyericsson.com
E-Philippines	02-6351860	questions.PH@support.sonyericsson.com
E-Poland	0 (prefix) 22 6916200	questions.PL@support.sonyericsson.com
E-Portugal	808 204 466	questions.PT@support.sonyericsson.com
E-Romania	(+4021) 401 0401	questions.RO@support.sonyericsson.com
E-Russia	8(495) 787 0986	questions.RU@support.sonyericsson.com
E-Singapore	67440733	questions.SG@support.sonyericsson.com
E-Slovakia	02-5443 6443	questions.SK@support.sonyericsson.com
E-Ningizimu Afrika	0861 632222	questions.ZA@support.sonyericsson.com
E-Spain	902 180 576	questions.ES@support.sonyericsson.com
E-Sweden	013-24 45 00	questions.SE@support.sonyericsson.com
E-Switzerland	0848 824 040	questions.CH@support.sonyericsson.com
E-Taiwan	02-25625511	questions.TW@support.sonyericsson.com
E-Thailand	02-2483030	questions.TH@support.sonyericsson.com
E-Turkey	0212 47 37 777	questions.TR@support.sonyericsson.com
E-Ukraine	(+380) 44 590 1515	questions.UA@support.sonyericsson.com

E-United Arab Emirates	43 919880
E-United Kingdom	08705 23 7237
E-United States	1-866-766-9374
E-Venezuela	0-800-100-2250

questions.AE@support.sonyericsson.com
 questions.GB@support.sonyericsson.com
 questions.US@support.sonyericsson.com
 questions.VE@support.sonyericsson.com

Imihlahlandlela yezokuphepha futhi esizayo ekusebenziseni ucingo

Sicela ufunde le mininingwane ngaphambi kokusebenzisa ucingo lwakho oluphathekayo.

Le miyalelo yenzelwe ukuphepha kwakho. Sicela ulandele le mihlahlandlela. Uma umkhiqizo uke waba sezimeni ezinjengalezi ezbihalwe ngezansi nomu unokungaba kokusebenza ngokuyikho qinisekisa ukuthi umkhiqizo wakho uhlolwa uphathina wesevusi ogunyaziwe ngaphambi kokuwushaja nomu kokuwusebenza. Ukuhluleka ukwenza njalo kungaholela engcupheni yokungasebenzi kahle komkhiqizo nomu ngisho ebungozini bempilo yakho.

Izincomo zokusetshenziswa okuphephile komkhiqizo (ifoni ephathekayo, ibhethri, ishaja nezinye izesekeli)

- Njalo phatha ngobunono umkhiqizo wakho, uwugcine endaweni ehanlezekile futhi engenazo izintuli.
- Isexwayiso!** Ingaghuma uma iseduze nomilo.
- Ungawubeki umkhiqizo wakho endaweni emananzi nomu eswakeme nomu enomhwamuko.
- Ungawubeki umkhiqizo wakho ezingeni lokushisa eliphezu kakhulu nomu eliphansi kakhulu. Ungalibeki ibhethri endaweni eshisa ngaphezu kuka +60°C (+140°F).
- Ungawubeki umkhiqizo wakho endaweni enamalangabi avukelile nomu kwimikiqizo evuthayo kagwayi.



- Ungawuwisi, ungawujikijeli nomu uzame ukwuphula umkhiqizo wakho.
- Ungawupendi umkhiqizo wakho.
- Ungazami ukuqaqa nomu ukuguqula umkhiqizo wakho. Umuntu ogunyazwe u-Sony Ericsson kuphela okufanale enze lo msebenzi.
- Ungawusebenzisi umkhiqizo wakho eduze namathuluzi esibhedlela ngaphandle kokucela imvume kudokotela wakho okwelaphayo nomu ogunyaziwe osebenza esibhedlela.
- Ungawusebenzisi umkhiqizo wakho uma ungaphakathi, nomu useduze nebhanoiyi, nomu izindawo ezbihalwe ukuthi "cisha u-ova".
- Ungawusebenzisi umkhiqizo wakho endaweni lapho kunezinto eziyiziqhumaene.
- Ungawubeki umkhiqizo wakho nomu ufake impahlia engenawaya endaweni engapezu kwesikhwama somoya semoto.
- Isexwayiso:** imiboniso eklayekile nomu ephukile ingadala okuseceleni okubukhalu okungaba yingozisima kuthintwa.

IZINGANE

WUGCINE LAPHO KUNGAFINYELELI
KHONA IZINGANE. MUSA
UKUVUMELA IZINGANE ZIDLALE
NGEFONI YAKHO EPHATHEKAYO
NOMA NGEZISEKELI. UFONI YAKHO EHAMBAYO
NOMA ISIXHUMI SINGABA NEZINGXENYANA
EZINCANE EZINGAHLE ZIPHUME BESE ZIBANGA
INGOZI YOKUSHOKEKA.



Amandla kagesi (Ishaja)

Xhuma i-isixhumi sakho samandla kagesi ukuze ufade ugesi endaweni kuphela ekhonjiswe ngokucacile ukuthi yenzelwelokho. Qiniseka ukuthi intambo imiswe kahle ukuze ingalimali noma icindezelele. Ukuze kuncishiswe ingozi yokuthi umuntu abanjwe ugesi, kufanele impahlia isuswe lapho kade ishajwa khona ngaphambili kokuzama ukuyihlanza. isixhumi samandla kagesi kufanele sisetshenziswe ngaphandle endlini noma ezindaweni zokulahlala. Ungalinge uguqule intambo noma ipulaki. Umaiplagi ingangeni kule ndawo yamandla, thola abasebenza ngogesi abaqeqeshiwe bakufakele lezo zinto ezifanele zokudouna ugesi.

Sebenzisa kuphela amashaja akwa-Sony Ericsson enzelwe ukusebenza nefoni yakho ephathekayo. Amanye amashaja kungenzeka angadizyinelwa ukuphepha nemigomo yokusebenza efanayo.

Ibhethri

Sincoma ukuthi uyibhuste ngokugcweli ifoni yakho ephathekayo ngenkathi uyibhusta okokuqala. Ibhetri elisha noma ebelingasabeni isikhathni eside lingaciphsisa umthamo wamandla ngemizuwana emibalwa uyisebenzisa. Ibhetri lingashajwa kuphela emazingeni okushisa aphakathi kuka +5°C (+41°F) no +45°C (+113°F).

Sebenzisa kuphela amabhethri akwa-Sony Ericsson enzelwe ukusebenza nefoni yakho ephathekayo. Ukusebenzisa amanye amabhethri nokunye kokuxhuma, kungaba yingozi. Izikhathi zokukhuluma nezokubeka eceleni zincike ezimini eziningana ezihluleke njengamandla esignalini, izinga lokushisa lokusebenza, amaphethini okusebenza ohlelo, izimpawu ezikhethiwe nezidulilisi zezwi noma zedathatha uma usebenzisa ifoni ephathekayo.

Icime ifoni yakho ephathekayo ngaphambili kokukhipha ibhethri. Ungayifaki ibhethri emlonyeni wakho. Izinhlayiya zebhethri zingaba nobuthi uma

zigwinyiwe. Ungavumeli izinsimbi zebhethri zithintane nenyi into enensimbi. Ukwenza lokhu kungenza ibhethri yakho iphelelwengamandla bese ilimala. Sebenzisa ucingo ngezinhlosa kuphela ezibekelwe lokho.

Izinto ezakhelwe wena zezokwelapha

Amafoni ahambayo angakuphazamisa ukusebenza kwamawashi enhlizyo nezinyo izinto ezifakelwa kumuntu. Sicela ukugweme ukubeka ifoni ephathekayo ngaphezu kwewahlili enhlizyo, isb. ephaketheni elisemabeleni. Uma usebenzisa ifoni ahambayo, yisebenzise endliebeni esesayidini lomzimba enghelenayo inhlizyo yewashi. Uma kugcincina ukuphelelana okwanele okungu 15 cm (ama-intshi angu-6) phakathi kfewoni ephathekayo newashi enhlizyo, amathuma okuthikamezana kwalezi zisimbi mancane. Uma unesizuthi sokusola ukuthi kuhkona ukuthikamezeka okwenzekayo, cisha ucingo Iwakho ngokushesha. Thintana nodokotela wakho wenhlizyo uma ufuna olunye ulwazi.

Mayelana namanye amadivaysi okwelapha, sicela uxhumane nodokotela wakho nomkhiqizi wedivaysi.

Ukushayela

Sicela ubheke noma imithetho nezinqubo ziayakuvimbela yini ukuba usebenzise amafoni aphanthekayo ngenkathi ushayela noma zifuna ukuba abashayeli basebenzise ihandisifri yokuxhuma emotweni. Sincoma ukuthi usebenzise kuphela izixazululu zehendisifri zakwa-Sony Ericsson ezenzelwe ukusetshenziswa nomkhiqizo wakho.

Sicela wazi ukuthi ngenxa yokushayisana kwezinto zkigasesi, abanya abakhiqizi bezimoto bayakunqabelu ukusetshenziswa kwamafoni aphanthekayo ezimotweni zabo ngaphandle uma ikhithi yehendisifri enothi oluphumele ngaphandle ifakiwe.

Hlala njalo uqaphele ukushayela kwakho, ubuyele eceleni komgwaqo ume, ngaphambi kokuba uphendule noma ushaye ucingo uma isimo somgwaqo sikuvumela.

Izingcingo eziphuthumayo

Amafoni aphathekayo asebenzisa izibonisi zomsakazo ezingeke zikuqinisekise ukuxhumaneka ngaphansi kwazo zonke izimo. Ngakho-ke, musa ukuthembela kuphela efonini ephathekayo mayelana nokuxhumana okubakile (njengokuphatheleno nezempiilo).

Izingcingo eziphuthumayo kungenzeka zingenzeki kuzo zonke izindawo, kuwo wonke amanethiwekhi amaselula, noma uma amasevisi athile enethiwekhi/ noma izimpawu zefoni zisebenza. Thintana nomnikezeli wesevisi wangakini.

Uthi

Le foni iqukethe uthi olakhelwe ngaphakathi. Ukusetshenziswa kwamadivaysi othi angamakethwanga u-Sony Ericsson aqondena nale modeli angalimaza ifoni yakho ephathekayo, anganciphisa ukusebenza, akhijze amazinga e-SAR angaphezu komkhawulo obekwi (bheka ngezansi).

Ukusetshenziswa ngokuyikho

Bamba ifoni yakho ephathekayo ngendlela obewungabamba ngayo noma iypifi ifoni. Ungalembozi ingaphezulu lefoni uma isebeza, njengoba lokhu kupahazama izinga lezingcingo kanti futhi kungadala ukuba ifoni isebenzise amazinga aphezulu amandla kunokuba kudingekile, lokho bese kunciphisa ingxoxo kanye nezikathhi ezibekwe eceleni.

Ukuvulelekwa kwifrikhwensi yomsakazo (RF) naku Specific Absorption Rate (SAR)

Ucingo Iwakho oluphathekayo luwumsakazo osebenzisa amandla amancane futhi luyemukela. Uma luvuliwe, lukhipha amazinga aphansi amandla omsakazo (lokhu kwaziwa futhi njengamagagasi omsakazo noma izinkundla zamandla omsakazo). OHulumeni emhlabeni wonke sebekhiphe imigudu enqala yokuphepha ethuthukiswe izinhlango zezesayensi, njenge ICNIRP (lkhomishana yoMhlaba Jikelele yezokuVikelwa kokuKhishwa kweNunzi kwiMisebe kaGesi), ne-IEEE (lsikhungo soNjiniyela bakaGesi nabama-elethronikhijezihloliwe ngezikathhi ezithile nangokuhluo ngokujulile izifundo zesayensi. Lezi zinkombanqubo zakha amazinga afanelle amagagasi omsakazo avumelekile kumpifikathi wonkana. La mazinga afaka nesilinganiso sokuphepha esiqinisekisa ukuphepha kwawo wonke umuntu, kungakhethi budala noma impilo yalowo mutu, kanye nokuphendula mayelana nanoma ikuphi ukuhluka okungenzeka.uma kukalwa.

Izinga eliThile lokuMunca (SAR) into yokukala umthamo wamandla omsakazo womoya omncwua umzimba ngenkathi usebenzisa ifoni yakho ephathekayo. Inani le-SAR ilikwala ezingeni eliphezulu kakhulu lokuqinisekisa amandla kwizimo zamalabshorekthi, kodwa izinga langempela le-SAR kwifoni ephathekayo ngenkathi isebeza lingaba ngaphansi kwalehi nani. Lokhu yingoba ifoni ephathekayo yakhelwe ukusebenzisa amandla enele ukuze ikwazi ukuthola inethiwekhi.

Ukwehluka kwi-SAR ngaphansi kwezinkombanqubo zokuvulelekwa kwamagagasi omsakazo womoya, akusho ukuthi kunokwehluka kwezokuphepha. Yize kungaba nokwehluka kumazinga e-SAR emafonini ehlukahlukene aphathekayo, zonke izinhlobo zamafoni aphathekayo akwa Sony Ericsson ahlelelwé

ukuhlangabezana nezinkombanqubo zokuvuleleka kumagagasi omsakazo womoya.

Kumafoni adayiswa e-U.S., ngaphambhi kokuthi imodeli yefoni itholakale ukudayiselwa umphakathi, kufanele ihlolwe futhi igunyazwe yi-Federal Communications Commission (FCC) ukuthi ayidulu umkhawulo obekwe yizidingo zikahulumeni zokuvuleleka okuphephile. Uhloko Iwenziva ezindaweni (okungukuthi, endlebeni futhi zigqokwe emzimbeni) njengoba kudingwa yi-FCC ngemodeli ngayinye. Ngomsebenzi wokugqokwa emzimbeni, le foni ihlolwe futhi yahlangabezana nemihlahlandelela yokuvuleleka kwe-FCC RF uma ihedisethi ibekwe ebuncaneni obungu -15 mm emzimbeni ngaphandle kwezingxene zensimbi endaweni yefoni noma uma isetshenziswa nesesekeli esigqokwa emzimbeni sakwa-Sony Ericsson esenzelwe le foni. UKusetshenziswa kwezesekeli ngeke waqainisekisa ukuvumelana nemihlahlandelela yokuvuleleka ye-FCC RF.

Ibhukwana eliseceleni elinolwazi lwe-SAR ngalolu hloba lwefonni ehambayo, lifakwe nale mpahla ehambisana lale foni ehambayo. Lolu lwazi lungatholwa, kanye nolunye ulwazi, kumagagasi okuvuleleka kwezomsakazo womoya kanye ne-SAR, ku: www.sonyericsson.com/health.

Izixazululo Ezitholakalayo/Izidingo Ezikhethekile

Ngamafoni adayiswa e-US, ungasebenzisa itheminali yakho ye-TTY nefoni yakho yakwa-Sony Ericsson (nesesekeli esidingekeyo). Ngolwazi ngeZixazululo Ezitholakalayo zabantu abanezidingo ezikhethekile shayela i-Special Needs Center yakwa-Sony Ericsson ku 877 878 1996 (TTY) noma 877 207 2056 (izwi), noma vakashela i-Special Needs Center yakwa-Sony Ericsson ku www.sonyericsson-snc.com.

Ukulahlwa kwezinto ezindala ezisebenza ngogesi nange-elektronikhki

Lolu phawu lukhomba ukuthi zonke izinto zikagesi neze-elektroniki ezifakiwe ngeke ziphathe njengemfucuza yomdeni. Esikhundleni salokho kufanele uyswe endaweni efanele lapho kuqoqwa khona udoti ojikeleziswayo ongamathuluzi kagesi nawe-elektronikhki. Ngokuqinisekisa ukuthi lo mkhiqizo ulahlwe ngendlela ekahe, uysosa ukuvukilema imiphumela engemihle ebingadaleka endaweni nasezipilweni zabantu, obekungadalwa ukuphatthwa ngendlela engafanele kwalo mkhiqizo. Ukujikeleziswa kwezinto kuyosiza ukulonda izinto zemvelo. Ngolwazi oluthe xaxa ngokujikelezisa lo mkhiqizo, sicela uxhumane nehhovisi ledolobha langakini noma isevisi yokulahlwa kukadoti noma isitolu lapho uthenge khona lo mkhiqizo.

Ukulahlha ibhethri

Sicela uhole imithetho yangakini mayelana nokulahla amabhetri noma shayela i-Call Center yakwa-Sony Ericsson ukuze uthole ulwazi.

Ibhethri akufanele lifakwe emgqonyeni kadoti kamasipala. Sebenzisa into yokulahlela ibhethri uma ikhona.

Imemori khadi

Umkhiqizo wakho ufika uphelele nememori khadi ekhiphekayo. Ngokuvamile kuyahambisana nehendisethi ethengiwe kodwa kungahle kungahambisana namanye amadivaysi noma amakhono amamemori khadi awo. Hlola amanye amadivaysi ukuthi ayahambisana yini ngaphambhi kokuthenga noma kokusebenzisa.

Imemori khadi ifomathwa ngaphambhi kokuthunyelwa. Ukuformatha kabusha imemori



khadi, sebenzisa idivaysi ehambisanayo. Ungasebenzisi ukufomatha kohlelo lokusebenzisa oluvamile uma ufomatha imemori khadi kwi-PC. Ngemininingwane, bheka imiyalelo yokusebenzisa yedivaysi noma uthintane nabasekela amakhastoma.

ISEXWAYISO:

Uma idivaysi yakho idinga i-adaptha ukuze ishuthewke kwhihendisethi noma kwenye idivaysi, ungashutheki ikhadi ngqo ngaphandle kwe-adaptha.

Okumele kuqashelwe Ngokusebenzisa iMemori Khadi

- Ungayisondezi kumswakama imemori khadi.
- Ungawathinti amatheminali okuxhuma ngesedala noma ngento eyinsimbi.
- Ungayishayi, ungayigobisi, futhi ungayiwisi imemori khadi.
- Ungaazami ukuqaqa noma ukuguqula imemori khadi yakho.
- Ungasebenzisi noma ugcine imemori khadi ezindaweni eziywakeme noma ezzigqwalie noma ekushiseni okwedulele njengemoto evaliwe ehlobo, elangeni ngqo noma eduze kwehittha, njil.
- Ungacindezelii noma ugobise ukuphala kwe-adaptha yememori khadi ngamandla eqile.
- Ungavumeli ukungcola, uthili, noma izinto zangaphandle kube sembotsheni yokufaka yanoma iyiphi i-adaptha yememori khadi.
- Hlola ukuthi uyishutheke kahle yini imemori khadi.
- Shuthela imemori khadi kakhulu ngangokuvuma kwalo kunoma iyiphi i-adaptha yememori khadi edingekeyo. Imemori khadi ingaha ngasebenzi kahle uma ingashuthekiwe ngokugcwele.
- Sincorma ukuthi wenze ikhophi eyibhekaphu yezinto ezisemqoka. Ngeke silithwale icala lanoma wukuphi ukulahleka noma ukonakala kokuqukethwe okugcine kwimemori khadi.

- Imininingwane eqoshiwe ingonakala noma ilahleke uma ukhipha imemori khadi noma i-adapha yememori khadi, ucisha ugesi ngesikhathi ufomatha, ufunda noma ubhala okuthile, noma uma usebenzisa imemori khadi ezindaweni eziphazanyiswa yisteythikhi noma ukukhishwa okuphakeme kukagesi.

Ukuvikelwa kweminingwane eqondene nawe

Ukugada ukungasese bakho nokuvimba ukutholwa kolwazi yiqembu leshitathu, kufanele uciše yonke idatha eqondene nawe ngaphambi kokudayisa noma kokulahda umkhiqizo. UKUSUSA IZINTO KWIMEMORI YEFONI AKUQINISEKISI UKUTHI LEYO MINININGWANE NGEKE IBUYISWE WUMSEBENZISI OLANDELAYO. U-SONY ERICSSON AKANAWARANTI EQONDENE NOMSEBENZISI OLANDELAYO WEDIVAYSİ OTHOLA ULWAZI LWAKHO FUTHI AKANASIBOPHO NGOKUDALULWA KWAKAMUVA KWALOLO LWAZI NGISHO NOMA SEYENZIWE I-MASTER RESET. Uma ukhathazekile ngaloku dalulwa okungenzeka, yigcine idivaysi yakho noma uqinisekise ukucekelwa phansi kwayo konomphelo.

Izesekeli

U-Sony Ericsson uncoma ukusebenzisa izesekeli zakwa-Sony Ericsson zasekuqaleni ukuze isetshenziswe ngokuphepha nangendlela efanele imikhiqizo yakhe. Ukusetshenziswa kwezisekeli zamaqembu esithathu kunganciphisa ukusebenza ngemfanelo noma kube yingozi emplilweni noma ekuphepheni kwakho.

ISEXWAYISO SOMSINDO:

Ucelwa ukuba ulungise ivolumu yokulalelwayo ngokugaphela uma usebenzisa izesekeli zokulalelwayo zamaqembu estithathu ukugwema amazinga evolumu angahle abe yingozи ezindlebeni zakho. U-Sony Ericsson akakuhloli ukusetenzhensiwa kweziksethi kozukulalelwayo zamaqembu estithathu kule foni ephathwayo. U-Sony Ericsson uncoma ukusebenzisa izesekeli zasekuqaleni kuphela zakwa-Sony Ericsson.

Isivumelwano Selayisense Yomsebenzisi Wokugcina

Le divaysi engenawaya, kubandakanya napandle kwemikawuko noma iyipi imidya edilivwe nedivisi, ("Idivaysi") ikuke the isofthiwe yakwa-Sony Ericsson Mobile Communications AB nezinkampani ezinapansi kwayo ("Sony Ericsson") nabathengisi-mphabla abangabesithathu kanye nabaniki layisense ("Isofthiwe").

Njengomsebenzisi wale Divaysi, u-Sony Ericsson ukunika layisense elingakhethiyo, elingadululisa nelininganikezelwa ukuthi usebenzise iSoftthiwe kuphela ngokuhlangana ne-Divaysi okufakwe kuyo/noma edilivwe nayo. Aukhu lapha okungahunyushwa njengokuthengiswa kweSoftthiwe kumsebenzisi wale Divaysi. Ngeke wakhiqiza kabusha, uguqule, wabele, uphendule okukhandiye, uhlakaze, noma ushintshe noma usebenzise noma yini ukuthola ikhodi elingumthombo weSoftthiwe noma wengxenyе yeSoftthiwe. Ukugwema ukungabaza, ngaso sonke isikhathi unelungelo lokudululisa wonke amalungelo nezibophе zeSoftthiwe kowesithathu, kuphela kanye neDivaysi owamukele ngayo iSoftthiwe, ngaphandle uma lesithathu sivuma ngokubhala phansi ukuthi sizibophezele kule mithetho.

Unikwa le layisense isikhathi sempilo yale Divaysi ezobе isebeza ngaso. Ungayinqamula le layisense ngokudululisa wonke amalungelo akho kwiDivaysi

owamukele kwi-Software uwadlulisele kwisithathu ngokubhala phansi. Uma uhuleka ukuvuma ukwenza imigomo nezimiso ezibekwe kule layisense, iyonqamuka ngokusheshesha.

U-Sony Ericsson nabathengisi-mpahla besithathu bakhe nabaniki layisense bangabanakazi kuphela abakhethayo futhi bananalungelo onke, ubunikazi futhi banenzuo kwiSoftthiwe. U-Sony Ericsson, no, uma iSoftthiwe ikukethe impahla noma ikhodi lesithathu, leso sithathu, siyokuba umudlimaфа wayezi zimiso.

Ukuba semthethweni, ukwakhiwa nokusebenza kwale layisense kuyobuswa imithetho yase-Sweden. Ukyekwa kuyokwenzeka ngokugcwale ngemvume, uma kufanele, yomthetho wamalungelo omthengi.

Iwaranti Enomkhawuko

Sony Ericsson Mobile Communications AB, SE-221 88 Lund, Sweden, (Sony Ericsson) noma inkampani yasendaweni esebezensisana nayo, ikuhlinzaka ngale Waranti enomkhawuko yefoni yakho ephathwayo nezesekeli zokuqala ezithunyelwe nefoni yakho (ezobizwa emva kwalokhu ngo "Mkhiqizo").

Uma uMkhiqizo wakhu udlinga iesevisi yesiqinisekiso, sicela uwubuyisele kulowo owuthenge kuye, noma xhumana ne-Call Center yakwa-Sony Ericsson yangakini (amareyti kazwelonke angasebenza) noma vakashela ku www.sonyericsson.com ukuze uthole ulwazi oluthe xaxa.

Iwaranti yethu

Kuncike kwizimo zeWaranti eneMikhawulo, u-Sony Ericsson uqinisekisa ukuthi lo Mkhqizo awutholanga kulimala ekwakhiweni kwavo, kwizinto ezikuwo, noma kulabo abebewakha ngenkathi uthengwa umthengi okokuqala.

Le Waranti enoMkhawuko izothatha isikhathi esiwunyaka owodwa (1) kusukela ngosuku lwasekuqaleni lokuthengwa koMkhiqizo.

Esizokwenza

Uma ngalesi sikhathi sewaranti, lo Mkhqiqizo uhuleka ukusebenza ngokujwayelekile nakumasevisi ajwayelekile, ngenxa yokulimala ekwakhwiensi kwavo, kwizinto ezikuwo noma kubuchwepheshe bawo, abasabalalisi noma ophathina besevisi abagunyazwe wu-Sony Ericsson, ezweni* la uthenge khona uMkhqiqizo, bazokhetha noma bayawukhanda noma bayawushintsha uMkhqiqizo ngokuhambisana nemigomo nemibandala echa Zwe lapha.

U-Sony Ericsson nasebenzisana naye bayaligodla ilungelo lokukhokhisa imali yokuphatha ngezandla kwabo uMkhqiqizo, uma kungukuthi ubuyiswe nje awukhu ngaphansi kwesiqinisekiso ngokwalezi zimo ezingezansi.

Sicela wazi ukuthi amanye amasethingi aqondene nave, okulandwayo noma olunye ulwazi kungalahleka uma uMkhqiqizo wakho we-Sony Ericsson ukhandwa noma ushintshwa ngomunye. Njengamanje u-Sony Ericsson angavinjelwa umthetho osebenzayo, ezinye izimiselo noma imikhwalo yobuchwepheshe ekwakheni ikhophi yokugada ingozi yokulandwayo okuthile. U-Sony Ericsson akazibophezelini olwazini olulahlekayo Iwanoma yiluphi uhlolo futhi ngeke akukhokheli ngokulahlekelwa kw فهو. Kufanele njalo wenze amakhophi agade ingozi alonke ulwazi olugciniwe eMkhqiqizweni wakho we-Sony Ericsson njengokulandwayo, ihalenda noxhumene nabo ngaphambi kokuwuletha uMkhqiqizo wakho we-Sony Ericsson ukuzokhwandwa nokushintshwa.

Imibandela

- 1 Le Waranti enoMkhawuko isebenza kuphela uma kukhishwe ubufakazi bokuthenga basekuqaleni obanikwa umthengi enikwa ngumdayisi ogunyaziwe wakwa-Sony Ericsson obuchaza usuku okwathengwa ngalo nesirili namba**, konke akuvezwem noMkhqiqizo lowo ofuna ukulungiswa

noma ukushintshwa. U-Sony Ericsson uyaligodla ilungelo lokunganikezeli ngesevisi yewaranti uma le mininingwane isusiwem noma ishintshiwe emveni kokuba uMkhqiqizo wathengwa okokuqala kumthengisi.

- 2 Uma u-Sony Ericsson elungisa noma eshintsha uMkhqiqizo, lowo Mkhqiqizo olungisiwe noma oshintshiwe usazoba nesiqiniseko esilingene isikhathi esisele sesiqiniseko, noma izinsuku ezingamamashumi ayishiaygalolunye (90) emveni kokulungisa noma kokushintshwa, kuye ngokuthi yisiphi isikhathi eside. Ukulungisa noma ukushintshwa kungasho ukusethenzisa izingxenye ezisabenza ngokufanayo kodwa esezilungiswe kabusha. Izinxenye ezikhishwiwe kwafakwa ezinye esikhundleni sazo noma okuyakhile ifoni kuzoba impahla ka-Sony Ericsson.
- 3 Lesi siqiniseko asifaki ukululeka kokusebenza koMkhqiqizo ngenxa yokuguga, noma ukungasethenzisa kahle kwavo, kubandakanya, kodwa hhayi kuhphela, ukuwusebenza ngendlela engajawayelekile nengalangule futhi engahambisanii nemithetho ka-Sony Ericsson yokusethenziswa nokunakekelwa koMkhqiqizo. Kanti futhi lesi siqiniseko asifaki ukululeka koMkhqiqizo ukusebenza ngenxa yengozi, isothiwe ukuguqlwa noma ukuhlelewa kabusha, ngokwenziwa nguMdali, ngokulimala okudalwa izinto eziwuketshezi. Ibhethri elishajekayo lingashajwa futhi lisethsheni sisikhathi ezingamakulu. Nokho, liyogcina ligugile - lokhu akukona ukwephuka kuthi kuwukuguga okwathengleleka. Uma isikhathi sokukhuluma noma isikhathi esimiswe okwesikhashna sisifishane kakhulu, kusho ukuthi sekuyisikhathi sokuba ufake linye ibhethri. U Sony Ericsson uncoma ukuthi usebenzise kuphela amabhetri kanye namashaja agunyazwe ngen Sony Ericsson. Izinguukoko ezingcane ekubonisweni kokugqama nombalwa kungenzeka phakathi kwamafoni. Kungenzeka kubo namachashazi aggqamile noma amnyama esibukwemi. Abizwa ngama-pixel

- aphundlekile futhi kungenzeka uma kunamachashazi angasebenzanga kahle futhi angalungiseki. Amaphikselli amabili anenkinga kuthiwa amukelekile.
- Izinguquko ezincane ekubukekeni kwekhamera zingenze phakathi kwamafoni. Lokhu akusyo into engajwayeleyele futhi ayithathwa njengemojuli yekhamera ephundlekile.
- 4 Ngoba uhlelo lwestelula lapho lo Mkhiqizo usebenza khona, lunikezelwa umnikezel iongahlangene no-Sony Ericsson, u-Sony Ericsson ngeke athweswe cala ngokusebenza, ukubakhona, ukwembozeza kwamasevisi kanye nokuhleka kwalolo luhelo.
 - 5 Le waranti ayibandaki ukuhleuleka koMkhiqizo okudalwe ukufaka, ukuhlela kabusha, ukuhanda noma ukuvulwa koMkhiqizo ngumuntu ongagunyaziwe ngu-Sony Ericsson.
 - 6 Lesi siqinisekiso asikubandaki ukwhehluleka koMkhiqizo okudalwe ukusebenzia izisekeli noma ezinye izintu zokuxhuma ifoni okuyizisekeli okungesizo ezakhelwe u-Sony Ericsson ekhiloselle ukusetshenziswa noMkhiqizo.
 - 7 Ukulimaza noma yisiphi sisivalo (seal) salo Mkhqizo kuyobanga ukuthi isiqinisekiso singasabenza.
 - 8 AZIKHO EZINYE IZIQINISEKISO EZISHIWO, KUNGABA EZIBHALIWE NOMA ZOMLOMO , NGAPHANDLE KWALEZI EZINOMKHAWUKO EZIBHALWE LAPHA. ZONKE IZIQINISEKISO EZICATSHANGELWAYO KUBANDAKANYA KODWA HHAYI KUPHELA IZIQINISEKISO EZICATSHANGELWAYO ZOKUFAKA IMPAHALA NOKULUNGELA KAHLE INHLISO ETHILE, KONKE KUKALELWE ISIKHATHI SALESI SIQINISEKISO ESENOMKHAWUKO. AKUKHO SIMO ESINGENZA U SONY ERICSSON NOMA ABANIKEZELI BAKHE BELAYISENSE, UKUBA BAKHOKHSWE NGOKULIMALA OKUYINGONZI NOMA OKWAMABOMU KWANOMA YILUPHI UHLOBO, KUBANDAKANYA, KODWA HHAYI KUPHELA, UKULAHLEKA KWENZUZO NOMA KOKUTHENGISA, NGOKUGCWELE NJE LOKHO KULIMALA KUNGACHITHWA NGUMTHETHO.
- Amanye amazwe/imibuso ayikuvumeli ukungabandakanywa noma ukunkunywa komonakalo wengozi noma waramabomu, noma umkhawukho wesikhathi esicatshangwayo, ngakha-ke lezi ziqiniseko ezibalwe ngenhla noma okungeke kwenziwa, kungenzeka kungakuthinti wena.
- Iwaranti ehlizekiwi ayiwakhinyabezi amalungelo umthengi anawo ngaphansi komthetho osebenzayo njengamanje, futhi asiwakhinyabezi amalungelo umthengi anawo kumthengisi avela ekuthengiselaneni kwabo/isivumelwano sokuthenga.

*Ukusabalala kumazwe kwewaranti

Uma uthenge uMkhiqizo wakho ezweni eliyilungu le-European Economic Area (EEA) noma e-Switzerland noma e-Republic of Turkey, futhi lowo Mkhqizo wawuhlosewe ukudayisa kwi-EEA noma e-Switzerland noma e-Turkey, uMkhiqizo wakho ungaseviswa kunoma iliphi izwe le-EEA noma e-Switzerlonomu e-Turkey, ngaphansi kwemibandela yewaranti esebezena ezweni odinga kulo isevisi, inqobo uma uMkhiqizo ofanayo udayiswa kulelo zwe wumsabalalisi ogunyazwe ngu-Sony Ericsson. Uma ufuna ukuthola noma uMkhiqizo wakho uyadayiswa yini ezweni okulo, sicela ufonele i-Call Centre yakwa-Sony Ericsson yangakini. Sicile wazi ukuthi amanye amasevisi ngeke enziwa noma yikuphi kuphela ezweni othenge kulo, isibonelo, ngenza yokuthi uMkhiqizo wakho unengaphakathi noma ingaphandle elehlukile kule nhlobo eanayo edayiswa kwamanye amazwe. Ucelwa ukuba wazi ngaphezu kwalokho ukuthi kwsesinye isikhathi kungangenzeki ukukhanda iMkhiqizo ekhiyhe ama-SIM.

**** Kumazwe/kwifundza ezithile eminye imininghwane (njengekhadi lewaranti elisebenzayo) ingacelwa.**

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Declaration of Conformity

We, Sony Ericsson Mobile Communications AB of
Nya Vattentornet
SE-221 88 Lund, Sweden
declare under our sole responsibility that our
product

Sony Ericsson type AAD-3252011-BV

and in combination with our accessories, to which
this declaration relates is in conformity with
the appropriate standards 3GPP TS 51.010-1,
EN 301908-1, EN 301489-7, EN 301489-24,
EN 300328, EN 301489-17 and EN 60950,
following the provisions of, Radio Equipment and
Telecommunication Terminal Equipment directive
99/5/EC with requirements covering EMC directive
89/336/EEC, and Low Voltage directive 73/23/EEC.

Lund, April 2007

CE 0682

A handwritten signature in black ink, appearing to read "Shoji Nemoto".

Shoji Nemoto,
Head of Product Business Group GSM/UMTS

Siyazifeza izidingo zeMiyalelo ye-R&TTE (99/5/EC).

Uhla Iwamagama

A

Abangani bami	37
ama-alamu	66
ama-aphoyintimenti	67
amabhzinesi khadi	22
Ama-feed e-Web	58
amakhi	8
amamenyu	12
amamenyu amancane	12
amanothi	69
amaphrofayli	71
amaqembu	23
amaringithoni	53
amaringithoni aqondene nomshayi	
lucingo	20
amasethingi	
I-inthanethi	56
i-Java™	55
amashothikhathi	13
amathegi ezithombe	45
declaration of conformity	88

D

I

ibhethri	
ukufaka	5
ukusebenzisa nokunakekela	81
ukushaja	7
I-Bluetooth™ wireless technology	59
igama eliwumplingo	25
igama lefoni	56
ihendisfri	24, 47
Ubuchwepheshes be-Bluetooth	59
i-imeyli	35
I-inthanethi	
amabhukumaka	57
amasethingi	56
ukuphepha nezitifiketi	58
i-Java™	55
ikhalenda	67–68
ikhamera	
amasethingi	42
uhlolojikelele	40
ikhodi memo	70
ilokhi	
ifoni	73
ikhiphedi	73
I-SIM khadi	72
ilokhi yekhiphedi	73

imakhrofoni	17	I-PUK	6, 72
i-master reset	74	i-push imeyli	36
Imemori khadi	14	isevisi yokuphendula	24
imenenja yefayela	14	isibuko sokuqalisa	6
Imenenja yeMidiya	48	isidlali sevidyo	48
imenuy yomsebenzi	13	isidlali somculo	47
imeyili yezwi	24	isikhathi	71, 72
imibiko		isikhathi socingo	30
i-imeyli	35	isilawuli sezwi	24
isithombe	32	I-SIM khadi	
izwi	34	kukopishelwa ku/kuvela ku	20, 21
ulwazi lwendawo nolweselula	39	lokha uvule ukuvimba	72
umbhalo	31	isirekhodi somsindo	54
imibiko yesithombe	32	isitophuwashi	69
imibiko yezwi	34	I-SMS <i>Bheka</i> imibiko yezithombe	
imibiko yombhalo	31	I-SMS <i>Bheka</i> imibiko yombhalo	
imidlalo	54	I-SOS <i>Bheka</i> izinamba zesimo	
imihlahlandlela yezokuphepha	80	esiphuthumayo	
imisebenzi	68–69	i-timer	69
I-MusicDJ™	53	I-T9™ Text Input	16
Inamba ye-IMEI	74	I-Update service	65
indlela yokudulisia		ividyo rekhoda	40
I-USB	61	ivolumu	
Ubuchwepheshe be-Bluetooth	59	iringithoni	53
I-PhotoDJ™	46	Ispikha sasendlebeni	17
I-PIN khodi		Iwaranti Enomkhawuko	85
kuyashintshwa	72	izibonisi	34
kuyavulwa	6	izinamba zesimo esiphuthumayo	18
I-PlayNow™	52	izinga lememori	22

I	izingcingo		kuyathunyelwa	
	eziphuthumayo	18	ama-aphoyintimenti	
	ezomhlaba jikelele	17	nemisebenzi	68
	ividyo	18	amabhizinesi khadi	23
	kuyarekhodwa	54	amanothi	69
	ukulindisa	27	imiculo namaringithoni	54
	ukuphatha izingingo ezimbili	28	izithombe	44
	ukuphendula nokudikila	17	umculo	48
	ukushaya nokwamukela	17	kuyavulwa/kuyavalwa	
	ukwemukela	29	I-Bluetooth	59
	izingingo eziphanjuliwe	26	ukhiye wefoni	73
	izingingo zesigungu	28	Ukuvikelwa kwelokhi yeSIM	73
	izingqikithi	46–53	kuyavumelaniswa	62–64
	izinhla zokudlala	50	O	
	izinhlelo	55	okubekwe eceleni	6
	izinombolo zami	28	okukhethwa kukho okuthintwayo	12
	izithombe	45	oxhumene nabo	
	hlela	46	amaqembu e	23
	i-zoom	41	kuyavumelaniswa	62
K			kwengezwa oxhumene	
	kudayelwa kabusha		nabo efonini	19
	nge-othomathikhi	17	oxhumene nabo bedifolthi	19
	kuhanjwa kumamenyu	12	S	
	kuyadluliswa		shayela izinamba embikweni	32
	amafayela	61		
	izithombe zekhamera	43		
	umculo	49		
	umsindo	60		

U

uhla lwezingcingo	23
uhlolojikelele lwemenyu	10
ukudayela okuhleliwe	30
ukudayela okusheshayo	24
ukufaka umbhalo	15
ukuhlanganisa	5
ukuphendula ngezwi	26
ukuvula i-SIM khadi	72
ulimi	15
umkhawuko wesikhathi	72
umshini wokubala	69
usizo	6
usuku	71