

Ukuqalisa 5

Ukuhlanganisa	5
Ukuvula ifoni	6
Usizo efonini yakho	7
Ukushaja ibhethri	7
Uhlolajikelele lwefoni	8
Uhlolajikelele lwemenyu	10
Ukuhamba	12
Ibha lamathuluzi	12
Amafayela Ami	12
Ulimi lwefoni	13
Ukufaka umbhalo	13

Kushaywa ucingo 14

Ukushaya nokwamukela izingcingo	14
Oxhumene nabo	16
Uhla lwezingcingo	19
Ukudayela okusheshayo	20
Imeyili yezwi	20
Ukulawula izwi	20

Ukuthumela imibiko 23

Imibiko yombhalo (SMS)	23
Iposikhadi	25
I-imeyli	25
Isithunywa se-Vodafone	27

Ukufanekisa 29

Ikhamera nevidyo rekhoda	29
Ukusebenzisa ikhamera	30
Izimpawu namasethingi kwekhamera	30
Kudluliswa izithombe	30
Izithombe	31
I-live! Studio	32

Ezokuzithokozisa 32

Ihendisfri ephathekayo yestiryo	32
Umculo nezidlali mavidyo	32
I-TrackID™	33
Umsakazo	33
Amaringithoni kanye nemiculo	34
Isirekhodi somsindo	35

Ukuxhumana 35

I-Vodafone live!	35
Xhuma ku Vodafone live!	36
Amasethingi	36
Ama-feed e-Web	37
I-Bluetooth™ wireless technology	38
Ukusebenzisa ikhebula le-USB	39

Ukuxazulula izinkinga 41

Imibuzo evamile	41
Imibiko enephutha	43

Ulwazi olubalulekile 44

Imihlahlandlela yezokuphepha futhi esizayo ekusebenziseni ucingo	46
Isivumelwano Selayisense Yomsebenzisi Wokugcina	51
Iwaranti Enomkhawuko	51
FCC Statement	54
Declaration of Conformity	54

Uhla lwezihloko 55

I-Sony Ericsson V640i

UMTS 2100 GSM 900/1800/1900

Le Gaydi yokusebenzisa ifoni ishicilelwe ngabakwa-Sony Ericsson Mobile Communications AB noma inkampani yangakini esebenzisana nabo, ngaphandle kwewaranti ethile. Ubungcono nezinguquko kule Gaydi yokusebenzisa ifoni okwenziwe amaphutha okuthayipha, ukungalingi kolwazi lwamanye, noma ubungcono ezinhlelweni kanye/noma amathuluzi, kungenziwa ngu-Sony Ericsson Mobile Communications AB noma inkampani yangakini esebenzisana naye noma ingasiphi isikhathi ngaphandle kwesaziso. Izinguquko ezinjalo, ngakho, ziyongeniswa kwizihumusho ezintsha zale Gaydi yokusebenzisa ifoni.

Wonke amalungelo agodliwe.

©Sony Ericsson Mobile Communications AB, 2007

Inamba yesishicilelo: 1201-2166.1

Sicela wazi:

Amanye amasevisi akule Gaydi yokusebenzisa ifoni awasekelwe yiwo wonke amanethiwethi.

Lokhu futhi kuyenzeka kwiNamba Ephuthumayo Yomhlaba ye-GSM u 112.

Sicela uxhumane no-opharetha wenethiwekhi yakho noma umnikezeli wakho wesevisi uma ungangaba noma ungasebenzisa isevisi ethile noma qha.

Sicela ufunde *Imihlahlandlela yokuphepha nokusebenza okuyikho* kanye namakhasi *Ewaranti yomkhawuko* ngaphambi kokusebenzisa ifoni yakho ephathekayo.

Ifoni yakho inamandla okulanda, kulonda nokudlulisa okuqukethwe okwengeziwe, isb. amaringithoni. Ukusetshenziswa kokuqukethwe okufana nalokho kungavinjelwa noma kngqathelwe ngamalungelo abantu besithathu, okubandakanya kodwa kungakalelwe kwizivimbelo ezingaphansi kwemithetho yamalungelo okushicilela afanele. Wena, nhayi u-Sony Ericsson, unamandla aphelele kokuqukethwe okwengeziwe okulanda noma okudlulisa kuvela efonini yakho. Ngaphambi kokusebenzisa okuqukethwe okwengeziwe, sicela uqinisekise ukuthi ukusebenzisa okuhlosile kulayisensive noma kugunyaziwe. U-Sony Ericsson akajinisekisi ngokungabi naphutha,

ubuqotho noma ikhwalithi yokuqukethwe okwengeziwe noma okunye okuqukethwe kwabantu besithathu. U-Sony Ericsson ngeke abekwe icala ngokusebenzisa kwakho okungalingile kokuqukethwe okwengeziwe noma okunye okuqukethwe kwabantu besithathu.

I-Bluetooth™ inguphawu lokuthengisa noma inguphawu lokuthengisa olubhalisiwe lakwa-Bluetooth SIG Inc.

I-logo edalulayo ewuketshezi, ne-TrackID yizimpawu zokuthengisa noma izimpawu zokuthengisa ezibhalisiwe ze-Sony Ericsson Mobile Communications AB.

I-Sony, Memory Stick Micro™ and M2™ yizimpawu zokuhweba noma yizimpawu zokuhweba ezibhalisiwe zakwa-Sony Corporation.

I-Ericsson wuphawu lokuhweba noma wuphawu lokuhweba noma wuphawu lokuhweba olubhalisiwe lwakwa- Telefonaktiebolaget LM Ericsson.

I-Adobe® Photoshop® Album Starter Edition wuphawu lokuthengisa olubhalisiwe lwe-Adobe Systems Incorporated.

I-ActiveSync, Microsoft, i-Windows, i-Outlook, i-Vista ne-PowerPoint yizimpawu zokuthengisa ezibhalisiwe noma izimpawu zokuthengisa ze-Microsoft Corporation e-U.S. nakwamanye amazwe.

I-T9™ Text Input inguphawu lokuthengisa noma uphawu lokuthengisa olubhalisiwe lwe-Tegic Communications. I-T9™ Text Input ilayisenswe ngaphansi kokukodwa noma okungaphezulu kwalokhu okulandelayo: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, no 6,011,554; Canadian Pat. No. 1,331,057, United Kingdom Pat. No. 2238414B; Hong Kong Standard Pat. No. HK0940329; Republic of Singapore Pat. No. 51383; Euro.Pat. No. 0 842 463 (96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; kanye namaphathenti engezwe asazofika emhlabeni jikelele.

I-Java kanye nazo zonke izimpawu zokuthengisa ezigxile kwi-Java namalogo kuyizimpawu zokuthengisa noma izimpawu zokuthengisa ezibhalisiwe ze-Sun Microsystems, Inc. e-U.S. nakwamanye amazwe.

Isivumelwano selayisense yomsebenzisi wokugcina we-Sun™ Java™ J2ME™.

Izivimbelo: I-Software ingulwazi lwamalungelo agodliwe oluyimfihlo lakwa-Sun futhi isihloko kuwo wonke amakhophi agcinwe ngu-Sun no/noma abantu bakhe bamalaysense. Umthengi ngeke aguqule, ahlakaze, ahlukalise, acacise, akhiphe noma ahlehise i-Software kanjiniyela. I-Software ngeke yaqashiswa, yanikezelwa, noma yalaysiswa ngaphansi kwelaysense, iphelele noma ingxenye yayo.

Imithetho Yokuthelkela: I-Software, kubandakanya idatha yomsebenzi osizayo, ingaphansi kwemithetho elawula ukuthelkela yase-U.S., kubandakanya Umthetho Owengamele Ukuthelkela wase-U.S. kanye nemigomo yawo ehlobene nawo, futhi kungaba ngaphansi kwemigomo yokuthelkela noma yokungenisa kwamanye amazwe. Umthengi uvuma ukuzibophezela kuyo yonke imigomo enjalo futhi uyavuma ukuthi unesibopho sokuthola amalaysense okuthelkela, ukuthelkela kabusha, noma ukungenisa i-Software. I-Software ngeke yalandwa, noma ithekeliswe noma ithekeliswe kabusha (i) ku, noma ezweni noma kumhlali wase, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (njengoba lolu hlu lungabuyekwezwa ngezikhathi ezithile) noma kunoma iliphi izwe i-U.S. evimbele izimpahla kulo; noma (ii) kunoma ubani oshlwini lwe-U.S. Treasury Department ye-Specially Designated Nations noma i-U.S. Commerce Department's Table of Denial Orders. Amalungelo Avinjelwe: Ukuseshenziswa, ukuphindwa noma ukuvezwa nguhulumeni wase-United States kungaphansi kwezivimbelo njengoba zibekiwe ngaphambili kwi-Rights in Technical Data and Computer Software Clauses kwi-DFARS 252.227-7013(c) (1) (ii) ne FAR 52.227-19(c) (2) njengoba kufanele.

Amanye amagama omkhqizo nezinkampani abalwe lapha kungaba izimpawu zokuthengisa zabanikazi abafanele.

Noma imaphi amalungelo angabaliwe lapha agodliwe. Yonke imifanekiso iyimifanekiso kuphela futhi ayibonisi ifoni yangempela.

Izimpawu zemiyalelo

Lezi mpawu zivela kwigaydi yoMsebenzisi.



Yazi



Ithiphu



Isexwayiso



Isevisi noma umsebenzi uncike kwintethiwekhi noma kokuthengiwe. Xhumana no-opharetha wenethiwekhi yakho noma vakashela ku www.vodafone.com ngeminingwane.


- > Sebenzisa ikhi lokukhetha noma lokuhambisa ukupheqa bese ukhetha. Bheka *Ukuhamba* ekhasini 12.

Ukuqalisa


Ukuhlanganisa

Ngaphambi kokuqala ukusebenzisa ifoni yakho, kufanele ufake i-SIM khadi nebhethri.

Faka iSIM khadi.




1 Khipha ikhava yebhethri.




2 Shelelisela phambili i-SIM khadi (1), bese uya emuva ngaphansi kwesibambi (2) – okokuthintana okusagolide kubheke phansi.

Ukufaka ibhethri



1 Faka ibhethri isayidi lelebuli libheke phezulu nezixhumi zibhekane.



2 Vala bese ushelezisa ikhava yebhethri endaweni.

Ukuvula ifoni

Ukuvula ifoni



- 1 Cindezela bese ubamba ①.
- 2 Khetha imodi:
 - **Okuvamile** – ukusebenza okugcwele
 - **I-Flight mode** – okunomkhawuko.
- 3 Faka iPIN yeSIM khadi yakho, uma iceliwe bese ukhetha **OK**.

- 4 Khetha ulimi.
- 5 Khetha **Qhubeka** > **Yebo** ukusebenzisa isethaphu wizadi ngesikhathi kalandwa amasethingi.

💡 *Uma ufuna ukulungisa iphutha khathi ufaka i-PIN, cindezela **C**.*

⚠ *Ungahle ucelwe ukuba ubhalise ifoni yakho kwa-Sony Ericsson. Uma uvuma ukubhalisa ifoni yakho, ayikho idatha eqondene nawe, njengenamba yakho yefoni, ezodluliselwa kwa noma ezosetshenzwa ngu-Sony Ericsson.*

Okubekwe eceleni

Emva kokuba usuyivulile ifoni yakho wakafa ne-PIN yakho, igama lika-opharetha wenethiwekhi liyavela. Lokhu kuthiwa okubekwe eceleni.

Usizo efonini yakho

Usizo nolwazi kuyatholakala efonini yakho. Bheka *Ukuhamba* ekhasini 12.

Ukusebenzisa isethaphu wizadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Okujwayelekile** ithebhu > **Isethaphu wizadi**.
- 2 Khetha okukhethwa kukho.

Ukuhlola ulwazi ngemisebenzi

- Pheqela kumsebenzi bese ukhetha **Ulwazi**, uma lukhona. Kokunye, i **Ulwazi** ivela ngaphansi kwe **Izinketho**.


Ukuhlola ulwazi lezinga

- Kokubekwe eceleni cindezela ukhuphule ikhi yevolumu.

Ukushaja ibhethri

Ibhethri yefoni ishajeke kancane uma uyithenga.

Ukushaja ibhethri



- 1 Xhuma ishaja efonini. Kuthatha cishe 2.5 amahora ukushaja ibhethri ngokugcwele. Cindezela ikhi ukuhlola isibuko.
 - 2 Khipha ishaja ngokutshekisela phezulu ipulaki.
- 💡 *Ungayisebenzisa ifoni yakho ngesikhathi isashaja. Ungashaja ibhethri noma nini isikhathi esingaphezu noma esingaphansi kuka 2.5 amahora. Ungakumisa ukushaja ngaphandle kokulimaza ibhethri.*

Uhlolojikelele lwefoni

- 1 Ikhamera yocingo lwevidyo
- 2 Ispikha sasendlebeni
- 3 Isibuko
- 4 Amabathini okukhetha
- 5 Ikhi yokushaya ucingo
- 6 Eyebha yamathuluzi ikhi yemenyu
- 7 Ikhi yokuhamba
- 8 Ikhi lekhillokhi
- 9 Ivolumu, amakhi e-zoom edijithali
- 10 Ikhi yokuqeda
- 11 Ikhi lekhamera
- 12 Ikhi ye-C (Sula)
- 13 Ikhi lokuthulisa
- 14 Isixhumi seshaja, ihendisfri nekhebula le-USB



- 15 Ikhi yokuvula/yokucisha
- 16 Ikhamera
- 17 Imbotshana yememori khadi



Uhlojikelele lwemenyu



Imidlalo

Imidlalo Yami
Mobile TV
TrackID™
VideoDJ™
PhotoDJ™
I-MusicDJ™



I-inthanethi



Izinhlelo Zami



Ikhamera



Imibiko ethunyel.

Bhala okusha Thumela izinhla
Ibhokisi lokunge Izinhlamvu ezigc
I-imeyli Izibonisi
Ama-feed eWeb Isevisi yeweb 1
Fonela isiqqoha. Lawula imiyalez
Izinhlaka Izinhlelo
Ibhokisi lokuphu



Imidiya



Umhleli

Amasevisi
akulayi.***
Imenenja yefayela**
Ucingo lwevidyo
Ikhallenga
Imisebenzi
Qopha umsindo
Amanothi

Ukw. kuhambi.
Isikhathi
Isimisa washi
Umshin wokbala
Isilawuli buqama
Isiqophi sekhodi



Ifonibhuku

Mina qobo
Oxhumene naye



Umsakazo



Ama-alamu Izingcingo**



Konke



Luphenduliwe



Ludayeliwe



Aluphendulwanga



Izinhlelo**



Okujwayelekile
Amaphrofayili
Isikhathi nosuku
Ulimi
Lawula izwi
Imenyu yomseb.
Oshothikhathi
I-Flight mode
Ezokuphepha
Isethaphu wizadi
Izinga lefoni
Isihleli esikhulu



Imisindo nezibonis
Ivolumu yeringith.
Iringithoni
Imodi ethule
Nyusa umsindo
Isixwa. sokudlikiza
Osungafundwa
Ikhi lomsindo



Khombisa
Iphepha
Iodonga
Izingqikithi
Isibuko
sokuqalisa
Londa isibuko
Usayizi wewashi
Ukugqama



Izingcingo
Dayel ngokushesh
Smart search
Phambula
Singatha izin.
Phendulela ku-2*
Isikhathi
nezindlek*
Kho./fihla ina.yami
Ihendisifri



Ukuxhumana*
I-Bluetooth
I-USB
Igama lefoni
Ukuhlan ngeneth
Ukw. kuhambi.
Ukusingath kwedi
Amanethiwekhi a
Izinhlelo ze-inthan
Izinhlelo zokuham
Izinhlelo zombiko*
Izesekele

* Amanye amamenyu ancike ku-opharetha, kwinethiwekhi nasekuthengeni.


** Ungasebenzisa ikhi lokuhamba ukupheqa kumathebhu kumamenyu amancane. Ngolunye ulwazi, bheka Ukuhamba ekhasini 12.

*** Le sevisi ayitholakali kuwo wonke amazwe.

Ukuhamba

Amamenyu amakhulu akhonjiswa njengezimpawu. Amanye amamenyu amancane abandakanya amathebhu.

Ukuhamba kumamenyu efon



Ikhi yokuhambisa ephakathi

- 1 Kokubekwe eceleni khetha **Imenyu**
- 2 Sebenzisa ikhi yokuhamba ukuhamba kumamenyu.

Ukupheqa kumathebhu

- Pheqela kwithebhu ngokucindezela ikhi lokuhamba esinxeleni noma kesokudla.

Ukuhlola okukhethwa kukho kwento

- Khetha **Izinketho** ukuze, isibonelo, uhlele.

Ukubuyela kokubekwe eceleni

- Cindezela .


Ukuqeda umsebenzi

- Cindezela .

Tukuhamba kwimidy yakho

- 1 Kokubekwe eceleni khetha **Imidiya**.
- 2 Sebenzisa ikhi yokuhamba ukuya phezulu, phansi, esinxeleni nakwesokudla kumamenyu.


Ukususa izinto

- Cindezela  ukususa izinto ezifana nezinamba, izinhlamvu, izithombe nemisindo.

Ibha lamathuluzi

Ibha yamathuluzi yenza ufinyelele ngokushesha kwimisebenzi ethile.

Ukuvula imenyu yebha yamathuluzi

- Cindezela .

Amathebhu ebha yamathuluzi yilawa:

- **Izig. ezintsha** – izingcingo ezingabanjwanga nemibiko emisha.
- **Izinhlelo ezih.** – izinhlelo ezihambayo ngemuva kwisendlalelo.
- **Amashothikh ami** – ngeza imisebenzi oyikhonzile ukuze ufinyelele kuyo ngokushesha.
- **I-inthanethi** – ukufinyelela ngokushesha kwi-Inthanethi.

Amafayela Ami

Ungasebenzisa Amafayela Ami ukusingatha amafayela agcinwe kwimemori yefoni noma kwimemori khadi.

- ! *Kungadingeka uthenge imemori khadi eceleni.*

Ukusingatha amafayela

Ungahambisa futhi ukopishe amafayela phakathi kwefoni yakho, ikhompuyutha nememori khadi. Amafayela agcinwa kwimemori khadi kuqala bese kuba yikwimemori yefoni. Angaziwa amafayela agcina kweye **Okunye** ifolda.

Ukuhambisa ifayela ku- Amafayela Ami

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Imenjenja yefayela**.
- 2 Thola ifayela bese ukhetha **Izinketho** > **Singatha ifayela** > **Hambisa**.
- 3 Khetha okukhethwa kukho.

Ukukhetha ngaphezu kwefayela elilodwa kwifolda

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Imenjenja yefayela**.
- 2 Pheqela kwifolda bese ukhetha **Vula**.
- 3 Khetha **Izinketho** > **Maka** > **Maka okuningi**.
- 4 Kwifayela ngalinye ofuna ukulimaka, pheqela kulona bese uyalikhetha **Maka**.

Ukusula ifayela ku- Amafayela Ami

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Imenjenja yefayela**.
- 2 Thola ifayela bese ucindezela **(C)**.


Ulimi lwefoni

Ungakhetha ulwimi ozolusebenzisa efonini yakho.

Ukushintsha ulimi lwefoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Okujwayelekile** ithebhu > **www.vodafone.com Ulimi** > **Ulimi lwefoni**.
- 2 Khetha okukhethwa kukho.

Ukufaka umbhalo

Ungasebenzisa i-multitap text input noma i-T9™ Text Input  ukufaka umbhalo. Indlela ye-T9 Text Input isebenzisa isichazamazwi esakhelwe ngaphakathi.

Ukushintsha indlela ye-text input

- Uma ufaka umbhalo, cindezela bese ubamba **(*)a/0***.

Ukushintsha pakathi kosonhlamvukazi abakhulu nabancane.

- Uma ufaka umbhalo, cindezela **(*)a/0***.


Ukufaka izinamba

- Uma ufaka umbhalo, cindezela bese ubamba **(0)** – **(9)**.

Ukufaka amafulstophu namakhoma

- Uma ufaka umbhalo, cindezela **(1)**.

Ukufaka umbhalo usebenzisa i-T9™ Text Input

- 1 Kokubekwe eceleni khetha, isibonelo, **Imenyu** > **Imibiko ethunyel.** > **Bhala okusha** > **Umbiko**.
- 2 Uma  kungakhonjiswa, cindezela bese ubamba **(*)a/0*** ukushintshela ku-T9 Text Input.

- Cindezela ikhi ngayinye kanye kuphela, noma ngabe lolo hlamvu olufunayo akulona olokuqala kwikhi. Isibonelo, ukubhala igama elithi “Jane”, cindezela (5), (2), (6), (3). Bhala lonke igama ngaphambi kokubuka imibono.
- Sebenzisa (👤) or (👤) ukuhlola imibono.
- Cindezela (#↔) ukwamukela umbono.

Ukufaka umbhalo ngokusebenzisa i-multitap

- Kokubekwe eceleni khetha, isibonelo, **Imenyu > Imibiko ethunyel. > Bhala okusha > Umbiko.**
- Uma (📧) kukhonjiswa, cindezela bese ubamba (📧) ukushintshela ku-multitap text input.
- Cindezela (2) – (9) ngokuphindelela kuze kuvele uhlamvu olufunayo.
- Uma igama libhalwa, cindezela (#↔) ukwengeza isikhala.

Ukwengeza amagama kwisichazamazwi esakhelwe ngaphakathi

- Uma ufaka umbhalo usebenzisa i-T9 Text Input, khetha **Izinketho > Pela igama**
- Bhala igama usebenzisa i-multitap input bese ukhetha **Faka.**

Kushaywa ucingo

Ukushaya nokwamukela izingcingo

Udinga ukuvula ifoni yakho bese uba sendaweni eyamukela inethiwekhi.

Ukushaya ucingo

- Kokubekwe eceleni faka inamba yefoni (nekhodi lamazwe omhlaba jikelele nekhodi lendawo, uma kudingeka).
- Cindezela (📞).

💡 *Ungashayela izinamba ezikoxhumene nabo nasohlwini lwezingcingo. Bheka Oxhumene nabo ekhsini 16, ne Uhla lwezingcingo ekhasini 19. Ungasebenzisa futhi izwi lakho ukushaya izingcingo. Bheka Ukulawula izwi ekhasini 20.*

Ukushaya izingcingo zomhlaba jikelele

- Kokubekwe eceleni cindezela (☞+) kuze kuvele uphawu “+”.
- Faka ikhodi lezwe, ikhodi lendawo (ngaphandle kukazero wokuqala) nenamba yefoni.
- Cindezela (📞).

Ukudayela kabusha inombolo

- Uma **Phinda uzame?** kuvela khetha **Yebo.**

! *Ungayibeki ifoni yakho endlebeni ngenkathi usalindle. Uma ucingo luxhuma, ifoni inika isignali enomsindo.*

Ukuphendula ucingo

- Cindezela .



Ukudikila ucingo

- Cindezela .

Ukushintsha ivolumu yesipikha sendlebe ngesikhathi socingo

- Cindezela ikhi yevolumu iye phezulu noma ezansi.

Ukuthulisa imakhrofoni ngesikhathi socingo



- 1 Cindezela bese ubamba .
- 2 Cindezela bese ubamba  futhi ukuqhubeka.

Ukuvula ilawudispikha ngesikhathi socingo

- Khetha **Ispikha**.

! *Ungayibeki endlebeni ifoni yakho ngenkathi usebenzisa ilawudispikha. Lokhu kungalimaza izindlebe zakho.*

Ukuhlola izingcingo ezingabanjwanga kokubekwe eceleni


- Cindezela  bese upheqela kweye **Izgamek. ezintsha** ithebhhu bese ukhetha inamba.
- Cinezela  ukuvula uhlu lwezingcingo.

Izingcingo eziphuthumayo

Ifoni yakho isekela izinombolo zamazwe omhlaba jikelele eziphuthumayo, isibonelo, u-112 no-911. Lezi zinombolo zingasetshenziswa ngendlela ejwayelekile ukushayela inombolo ephuthumayo kunoma yiliphi izwe, kufakwe noma ingafakiwe i-SIM khadi, uma nje inethiwekhi ye-3G (UMTS) noma ye-GSM isohlelweni lokwemukela izingcingo.

! *Kwamanye amazwe, ezinye izinombolo eziphuthumayo zingakhangiswa. U-opharetha wakho kungenzeka ukuba uvele usezigcinile kwi-SIM khadi yakho izinombolo ezenzenziwe eziphuthumayo zasekhaya.*


Ukushaya ucingo oluphuthumayo

- Kokubekwe eceleni faka 112 (inamba yezimo eziphuthumayo yomhlal awonke) bese ucindezela .

Ukuhlola izinombolo eziphuthumayo zakho zasekhaya

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Izinombolo ezithile** > **Izinamba eziphuth.**



Ucingo lwevidyo

Bona umuntu esibukweni ngesikhathi zezingcingo. Womabili amaqwambu adinga ukuthenga okwesekela isevisi ye-3G (UMTS), futhi udinga ukuba ukwazi ukwamukela inethiwekhi ye-3G (UMTS). Inethiwekhi ye-3G (UMTS) iyatholakala uma  kuvela.

Ukushaya ucingo lwevidyo

- 1 Kokubekwe eceleni faka inamba yefoni (nesiqalo samazwe omhlaba jikelele nekhodi lendawo uma kudingeka).
- 2 Khetha **Izinketho** > **Shaya ucingo lwe**.

Ukusebenzisa i-zoom nocingo oluphumayo lwevidyo

- Cindezela  noma .

Ukuhlola okukhethwa kukho kwezingcingo zavidyo

- Ngesikhathi socingo, khetha **Izinketho**.

Oxhumene nabo

Ungagcina amagama, izinamba zefoni nolwazi oluqondene nawe ku **Ifonibhuku**. Ulwazi lungacinwa kwimemori yefoni noma kwi-SIM khadi.

Oxhumene naye wedifolthi

Ungakhetha ukuthi yiluphi ulwazi loxhumene nabo olukhonjiswa njengedifolthi. Uma **Abangani** ekhethwe

njengedifolthi, oxhumana nabo bakhombisa lonke ulwazi olugcinwe ku **Ifonibhuku**. Uma ukhetha **Izinombolo zeSIM** njengedifolthi, oxhumana nabo bakhombisa amagama nezinamba okugcinwe kwiSIM khadi.

Ukukhetha oxhumene nabo bedifolthi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinkethi** > **Kuthuthukile** > **Oxhu nab bedif**.
- 3 Khetha ongakhetha kukho.

Oxhumene nabo befoni


Oxhumana nabo befoni bangaba namagama, izinamba zefoni nolwazi oluqondene nabo. Igcinwa kwimemori yefoni.


Ukwengeza oxhumana naye efonini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Engeza**.
- 3 Faka igama bese ukhetha **OK**.
- 4 Faka igama bese ukhetha **OK**.
- 5 Khetha okukhethwa kukho inamba.
- 6 Pheqa phakathi kwamathebhu bese ukhetha izindima ukwengeza ulwazi.
- 7 Khetha **Gcina**.


Ukufonela oxhumana nabo

Ukushayela oxhumana naye efonini


- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela koxhumana naye bese ucindezela .

 *Ukuya ngqo koxhumene naye, kokubekwe eceleni cindezela bese ubamba (2) – (9).*

Ukufonela oxhumana naye we-SIM ophuma koxhumana nabo befoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinkethi** > **Izinombolo zeSIM**.
- 3 Pheqela koxhumana naye bese ucindezela .

Ukufona nge-Smart search

- 1 Kokubekwe eceleni cindezela (1) – (9) ukufaka igama noma inamba yefoni koxhumana naye. Konke okufakwayo okuhambisana nokulandelana kwamadijithi noma izinhlamvu kukhonjiswa ohlwini.
- 2 Pheqela koxhumana naye noma inamba yocingo bese ucindezela .


Ukuvula noma ukuvula i-Smart search

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Izingcingo** ithebhu > **Smart search**.
- 2 Khetha okukhethwa kukho.

Ukukhela oxhumana nabo

Ukwengeza ulwazi koxhumene naye efonini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela koxhumana naye bese ukhetha **Izinketho** > **Hlela oxhum nay**.
- 3 Pheqa phakathi kwamathebhu bese ukhetha **Engeza**.
- 4 Khetha okukhethwa kukho nento ozokufaka.
- 5 Khetha **Gcina**.

 *Uma okuthengwayo kwakho kusekela isevisi Ukwaziswa Kodayini Ofonayo (CLI), unganikezela iringithoni eqondene nawe koxhumane nabo.*

Ukukopishela amagama nezinombolo kwiSIM khadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Kopisha kwiSIM**.
- 3 Khetha okukhethwa kukho.

Ukugcina nge-othomathikhi amagama nezinamba zefoni kwiSIM khadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Zigcinele kwi-SIM**.
- 3 Khetha okukhethwa kukho.

Ukugcina oxhumana nabo kumemori khadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Ibhekh yemem kh**.

Oxhumene nabo be-SIM


Oxhumana nabo be-SIM bangaba namagama nezinamba kuphela. Bagcinwa kwi-SIM khadi.

Ukwengeza oxhumene naye we-SIM

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Engeza**.
- 3 Faka igama bese ukhetha **OK**.
- 4 Faka igama bese ukhetha **OK**.
- 5 Khetha okukhethwa kukho kwenamba bese wengeza olunye ulwazi, uma lukhona.
- 6 Khetha **Gcina**.

- ! *Uma ukopisha bonke oxhumene nabo basuke efonini baye kwiSIM khadi, lonke ulwazi olukwiSIM khadi luyasuswa kufakwe olusha.*

Ukushayela ucingo oxhumene naye kwi-SIM


- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela koxhumana naye bese ucindezela .

Ukukopisha amagama nezinamba koxhumana nabo efonini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Kopisha kwi-SIM**.
- 3 Khetha okukhethwa kukho.

Ukususa oxhumana nabo

Ukususa oxhumene naye

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela koxhumana naye bese ucindezela .

Ukususa bonke oxhumene nabo befonini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Sus bonk oxh nab**.

Ukuthumela oxhumana nabo

Ukuthumela oxhumene naye

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
 - 2 Pheqela koxhumana naye bese ukhetha **Izinketho** > **Thumela axh nay**.
 - 3 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Izinga lememori

Isibalo soxhumene nabo ongabagcina kwifoni yakho noma kwiSIM khadi sincike kwimemori etholakalayo.

Ukuhlola izinga lememori

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinketho** > **Kuthuthukile** > **Izinga lesiqophi**.

Mina

Ungafaka ulwazi olumayelana nawe bese, isibonelo, uthumela ibhizinesi khadi yakho.

Ukufaka ulwazi Lwami

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Mina qobo** bese ukhetha **Vula**.
- 3 Pheqela kokukhethwa kukho bese uhlela ulwazi.
- 4 Khetha **Gcina**.

Amaqembu

Ungakha iqoqo lezinamba zefoni namakheli e-imeyli nge **Abangani** ukuthumela imibiko ku. Bheka *Ukuthumela imibiko* ekhasini 23.

Ungasebenzisa futhi amaqembu (nezinamba zezingcingo) uma wakha izinhla zabafonayo abamukelekile.



Ukwakha iqoqo lezinamba namakheli e-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinkethi** > **Amaqembu**.
- 3 Pheqela ku **Iqembu elisha** bese ukhetha **Engeza**.
- 4 Faka igama leqembu bese ukhetha **Qhubeka**.
- 5 Pheqela ku **Okusha** bese ukhetha **Engeza**.
- 6 Kuleyo naleyo namba yoxhumana naye noma ikheli le-imeyli ofuna ukukumaka, pheqela kukona bese ukhetha **Maka**.
- 7 Khetha **Qhubeka** > **Kwenziw**.

Uhla lwezingcingo

Ungahlola ulwazi mayelana nezingcingo zakamava.

Ukushayela inombolo ohlwini lwezingcingo

- 1 Kokubekwe eceleni cindezela  bese upheqela kwithebhhu.
- 2 Pheqela kwigama noma inamba yocingo bese ucindezela .

Ukwengeza inombolo yohlu lwezincingo koxhumene nabo

- 1 Kokubekwe eceleni cindezela 🏹 bese upheqela kwithebhu.
- 2 Pheqa enambeni bese ukhetha **Gcina**
- 3 Khetha **Oxhumene naye** ukwakha oxhumene naye omusha noma khetha oxhumene naye ovele okhona ukwengeza inamba kuye.

Ukudayela okusheshayo

Ukudayela okusheshayo kukuvumela ukhethe oxhuman anabo abayisishiyagalolunye ongabashayela ngokushesha. Oxhumana nayo bangacina ezindaweni 1-9.

Ukwengeza oxhumana nabo kwizinamba zokudayela ngokushesha

- 1 Kokubekwe eceleni khetha **Imenyu** > **Ifonibhuku**.
- 2 Pheqela ku **Oxhumene naye** bese ukhetha **Izinkethi** > **Dayel ngokushesh.**
- 3 Pheqela kwinamba yesikhala bese ukhetha **Engeza**.
- 4 Khetha oxhumana naye.

Ukudayela ngokushesha

- Kokubekwe eceleni faka inamba yendawo bese ucinezela 🏹.



Imeyili yezwi

Uma ukuthenga kwakho kubandakanya izevisi yokuphendula, umshayilucingo angashiya umbiko kwisiqophambiko uma ungeke ukwazi ukuphendula ucingo.

Ukuhlela inamba yemeyili yezwi yakho

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Izinhlelo** > **eye** > **Izinhlelo zombiko** ithebhu > **Inomb yemey zwi.**
- 2 Faka igama bese ukhetha **OK**.

Ukushayela izevisi yemeyili yezwi yakho

- Kokubekwe eceleni cindezela bese ubamba **1**.

Ukulawula izwi

Ngokwakha imiyalo yezwi unga:

- Dayela ngezwi – fonela umuntu ngokuthi usho igama lakhe.
- Vula ukudayela ngezwi ngokuthi usho “igama eliwumlingo”.
- Phendula noma udikile izincingo ngenkathi usebenzisa ihendisifri.

Ukurekhoda umyalo wezwi ngokusebenzisa ukudayela ngezwi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Okujwayelekile** ithebhu > **Lawula izwi** > **Ukudayela ngezwi** > **Cupha**.
- 2 Khetha **Yebo** > **Izwi elisha lomyal** bese ukhetha oxhumana naye. Uma oxhumana naye enezinamba ezingaphezu kweyodwa, khetha inamba ozofaka kuyo umyalo wezwi.
- 3 Rekhoda umyalelo wezwi njengokuthi “John mobile”.
- 4 Landela imiyalelo evelayo. Linda ithoni bese usho umyalelo ozowurekhoda. Umyalelo wezwi uyadlalelwa wona.
- 5 Uma imisindo yokurekhoda ikahle, khetha **Yebo**. Uma kungenjalo, khetha **Cha** bese uphinda izinyathelo 3 no 4.

! *Imiyalo yezwi igcinwa kwimemori yefoni kuphela. Ayikwazi ukusetshenziswa kwenye ifoni.*

Ukudayela ngezwi

Ungalalela igama loxhumene naye omrekhodile uma wamukela uringo oluvela kuyena.

Ukudayela ngezwi

- 1 Kokubekwe eceleni cinezela bese ubamba ikhi yevolumu.
- 2 Linda ithoni bese usho igama elirekhodiwe, isibonelo “John mobile”. Igama uyadlalelwa lona bese uringo luxhunywana.

Igama eliwumlingo


Ungarekhoda bese usebenzisa umyalelo wezwi njengegama eliwumlingo ukucupha ukudayela kwezwi ngaphandle kokucindezela amakhi. Ihendisfri yakho kufanele ixhumeke kwifoni yakho uma usebenzisa igama eliwumlingo.

! *Kumele ukhethe igama elide nelingajwayelekile noma umshwana ongahlukaniswa kalula enkulumeni eyejwayelelike neyisendlalelo. Ihendisfri ye-Bluetooth ayisesekeli le sici.*

Ukuvula nokuqopha igama eliwumlingo

- 1 Kokubekwe eceleni khetha **Imenyu**
> Izinhlelo > eye **Okujwayelekile** ithebhu
> **Lawula izwi** > **Igama eliwumlingo**
> **Cupha**.
- 2 Landela imiyalelo evelayo bese ukhetha **Qhubeka**. Lindela izwi bese usho igama eliwumlingo.
- 3 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.
- 4 Landela imiyalelo evelayo bese ukhetha **Qhubeka**.
- 5 Khetha ukuthi lizocushwa kuphi igama lakho eliwumlingo.

Ukushaya ucingo ngokusebenzisa igama eliwumlingo

- 1 Kokubekwe eceleni qinisekisa ukuthi i  iyabonakala.
- 2 Yisho igama eliwumlingo.
- 3 Lindela ithoni bese usho umyalelo wezwi.

Ukuphendula ngezwi

Uma usebenzisa ihendisfri, ungaphendula noma udikile izingcingo ezingenayo ngezwi lakho.

Ukuvula uhlelo lokuphendula ngezwi bese uqopha imiyalelo yokuphendula ngezwi

- 1 Kokubekwe eceleni khetha **Imenyu**
> Izinhlelo > eye **Okujwayelekile** ithebhu
> **Lawula izwi** > **Ukuphendula ngez**
> **Cupha**.
- 2 Landela imiyalelo evelayo bese ukhetha **Qhubeka**. Lindela ithoni uthi “Phendula”, noma elinye igama.
- 3 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.
- 4 Landela imiyalelo evelayo bese ukhetha **Qhubeka**. Lindela izwi bese usho igama eliwumlingo “Bhizi”, noma elinye igama.
- 5 Khetha **Yebo** ukwamukela noma **Cha** ngokurekhoda okusha.
- 6 Landela imiyalelo evelayo bese ukhetha **Qhubeka**.
- 7 Khetha ukuthi kuzocushwa kuphi ukuphendula ngezwi kwakho.

Ukuphendula ucingo usebenzisa imiyalelo yezwi

- Yithi “Phendula”.

Ukudikila ucingo usebenzisa imiyalelo yezwi

- Yithi “Bhizi”.

Ukuthumela imibiko

Ukwamukela nokugcina imibiko

Uyaziswa uma wamukela umbiko. Imibiko igcinwa nge-othomathikhi kwimemori yefoni. Uam imemori yefoni isigcwele, ungasusa imibiko noma uyigcune kwimemori khadi noma kwi-SIM khadi.

Ukugcina umbiko kumemori khadi

- Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Izinhlelo** > **eye Izinhlelo zombiko** ithebhu > **Gcina ku** > **Imemori khadi.**

Ukugcina umbiko kwi-SIM khadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** bese ukhetha ifolda.
- 2 Pheqela kumbiko bese ukhetha **Izinketho** > **Gcina umbiko.**

Imibiko yombhalo (SMS)

Ifoni yakho isekela amasevisi anhlobonhlobo okuthumela imibiko. Ucelwa ukuba uxhumane no-opharetha wenethiwekhi yakho mayelana namasevisi ongawasebenzisa, noma ngolunye ulwazi, yiya ku www.vodafone.com noma www.sonyericsson.com/support.

Akha imibiko ngombhalo nezimpawu kuphela, ukuyithumela njengemibiko yombhalo (SMS). Ngeza izithombe, amavidyo, imisindo nokunye kwimibiko ozoyithumela njengemibiko yezithombe (MMS). Ungathumela imibiko yezithombe kwiselula noma ekhelini le-imeyli. Ungakha futhi bese usebenzisa izibonisi ngemibiko yakho.



Uma uthumela umbiko eqenjini, uyakhokhiswa ngelungu ngalinye. Bheka Amaqembu ekhasini 19.

Ngaphambi kokusebenzisa imibiko yombhalo

Inamba eya kwisikhungo sesevisi yakho isivele ikumasethingi efoni yakho. Nokho, ungayifaka wena inamba yesikhungo sakho sesevisi.

Ukufaka inamba yesikhungo sesevisi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Ukuxhumana** ithebhu > **Izinhlelo zombiko** > **Umbiko womb.** Uma inamba yesikhungo sesevisi igcinwe kwi-SIM khadi iyakhonjiswa.
- 2 Uma ingekho inamba ekhonjisiwe, pheqela ku **Isikhungo esisha s** bese ukhetha **Engeza.**
- 3 Faka inamba, kubandakanya olwamazwe omhlaba uphawu oluthi “+” nekhodi yezwe.
- 4 Khetha **Gcina.**

Ngaphambi kokusebenzisa imibiko yezithombe




Wena nomemukeli kufanele nibe nokuthenga okusekela imibiko yesithombe. Uma lingekho iphrofayli le-inthanethi noma iseva yombiko ekhona, ungamukela wonke amasethingi e-MMS nge-othomathikhi avela ku-opharetha wakho wenethiwekhi ku www.vodafone.com, or at www.sonyericsson.com/support.


Ikheli leseva yakho yemibiko nephrofayli ye-Inthanethi kusethiwe.

Ukuhlola amasethingi e-MMS

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Ukuxhumana** ithebhu > **Izinhlelo zombiko** > **Umbiko wesitho** > **Iphrofayli le-MMS**.
- 2 Pheqela kwiphrofayli bese ukhetha **Izinketho** > **Hlela**.

Ukubhala nokuthumela umbiko

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Bhala okusha** > **Umbiko**.
- 2 Bhala umbiko noma ukhetha > **Izinketho** > **Faka uphawu**.
- 3 Pheqa  ukusebenzisa okukhethwa kukho ibha lamathuluzi. Pheqa noma  noma  ukukhetha okukhethwa kukho.

4 Khetha **Qhubeka**. (Ungagcinela ikamuva umbiko **Izinhlaka** ngokucindezela  bese ukhetha **Gcina umbiko**).

5 Khetha **Bheka ifonibhuku**.

6 Khetha umamukeli bese ukhetha **Thumela**.

Umbiko uziguqula nge-othomathikhi embikweni wombhalo (SMS) uye embikweni wesithombe (MMS) uma usebenzisa okukhethwa kukho ibha lethuluzi njengokwengeza izithombe, imisindo nokuthe xaxa. Uma usebenzisa umbhalo kuphela, umbiko uyohlala njengombiko wombhalo.

Ukukopisha nokunamathisela umbhalo embikweni

- 1 Uma ubhala umbiko wakho khetha **Izinketho** > **Kopisha unama**.
- 2 Khetha **Kopisha konke** noma > **Maka & kopisha**. Pheqela kumbiko bese umaka umbhalo kuwo.
- 3 Khetha **Izinketho** > **Kopisha unama**. > **Namathisela**.

Ukuhlela into embikweni

- 1 Uma ubhala umbiko khetha into ozoyihlela bese ukhetha **Izinketho**.
- 2 Khetha okukhethwa kukho.

Ukususa umbiko

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** bese ukhetha ifolda.
- 2 Khetha umbiko ozowususa bese ukhetha **Izinketho.** > **Susa.**

Ukusetha okukhethwa kukho umbiko wombhalo (SMS)

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu yamasehthingi > **Izinhlelo zombiko** > **Umbiko womb.**
- 2 Pheqela kokukhethwa kukho bese ukhetha **Hlela.**

Iposikhadi

Njengengxenywe ye-Vodafone live! Ungadilivelwa umbiko onesithombe nombhalo njengeposikhadi kwikheli lomgwaqo.

Ukuthumela iposikhadi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Bhala okusha** > **Iphosikhadi.**
- 2 Khetha **Thatha isithombe** ukufaka isithombe esisha noma ukukhetha isithombe ku **Izithombe** noma **I-albhamu yekhamer.**

- 3 Bhala umbiko ozophelezela isithombe.
- 4 Khetha umamukeli bese ukhetha **Thumela** > **Njengeposikhadi.** Isithombe nombiko kuzophrintwa kwiposikhadi bese kuthunyelwa kwikheli olikhethayo.



Sicela ubuze u-opharetha wenethiwekhi yakho noma ungathumela amaPosikhadi ngefoni yakho noma vakashela ku www.vodafone.com.



I-imeyli

Ungasebenzisa imisebenzi ejwayelekile ye-imeyli nekheli le-imeyli lekhompyutha yakho efonni yakho.

Ngaphambi kokusebenzisa i-imeyli

Ungasebenzisa isethaphu wizadi ukuhlola noma amasehthingi ayatholakala e-akhawunti yakho ye-imeyli noma ungawafaka ngesandla. Ungamukela futhi amasehthingi ku www.vodafone.com noma www.sonyericsson.com/support.

Ukwakha i-akhawunti ye-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ama-akhawunti.**
- 2 Pheqela ku **I-akhawunti entsha** bese ukhetha **Engeza.**



Uma ufaka amasethingi ngesandla, ungaxhumana nomnkezeli we-imeyli yakho ngeminye imininigwane. Umnikezeli we-imeyli kungaba yinkampani eyakunika ikheli lakho le-imeyli.

Ukubhala nokuthumela umbiko we-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Bhala okusha.**
- 2 Khetha **Engeza** > **Faka ikheli le-ime.** Faka ikheli le-imeyli bese ukhetha **OK.**
- 3 Ukufaka abanye abemukeli, khetha **Hlela.** Pheqela kokukhethwa kukho bese ukhetha **Engeza** > **Faka ikheli le-ime.** Faka ikheli le-imeyli bese ukhetha **OK.** Uma usulungile, khetha **Kwenziv.**
- 4 Pheqela ku **Isihloko:**. Khetha **OK** bese ufaka isihloko.
- 5 Pheqela ku **Umbhalo:**. Khetha **OK** bese ufaka umbhalo.
- 6 Pheqela ku **Izinamatheliso:**. Khetha **Engeza** bese ukhetha ifayela ozolinamathisela.
- 7 Khetha **Qhubeka** > **Thumela.**

Ukwamukela nokufunda umbiko we-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ibhokisi lokunge** > **Izinketho** > **Thumela.**
- 2 Pheqa kumbiko bese ukhetha **Hlola.**

Ukugcina umbiko we-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ibhokisi lokunge.**
- 2 Pheqa kumbiko bese ukhetha **Izinketho** > **Gcina umbiko.**

Ukuphendula umbiko we-imeyli

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ibhokisi lokunge.**
- 2 Pheqa kumbiko bese ukhetha **Izinketho** > **Phendul.**
- 3 Bhala impendulo bese ukhetha **OK.**
- 4 Khetha **Qhubeka** > **Thumela.**

Ukuhlola isinamathiselo embikweni we-imeyli

- Uma uhlola umbiko, khetha **Izinketho** > **Izinamathiseli** > **Hlola.**

Ukugcina isinamathiselo embikweni we-imeyli

- Uma uhlola umbiko, khetha **Izinketho** > **Izinamathiseli** > **Hlola** > **Gcina.**

Ukususa i-imeyli (POP3)

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ibhokisi lokunge.**
- 2 Pheqa kumbiko bese ukhetha **Izinketho** > **Maka ukuze kucis.**

- ! Imibiko emakiwe iyosuswa ngesikhathi esizayo uma uxhuma kwiseva yakho.

Ukususa i-imeyli (IMAP4)

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **I-imeyli** > **Ibhokisi lokunge.**
- 2 Pheqa kumbiko bese ukhetha **Izinketho** > **Maka ukuze kucis.**
- 3 Khetha **Izinketho** > **Sula ibhokisi lemi.**

- ! Imibiko ye-imeyli emakiwe izosuswa efonini nakwiseva.



Isithunywya se-Vodafone

Ungaxhuma bese ungena kwiseva ya Abangani bami ukuxhumana kulayini nemibiko yokuxoxa. Uma ukuthenga kwakho kusekela amasevisi okuthumela imibiko ngokushesha nawokukhona, ungathumela bese wamukela imibiko bese ubheka izinga loxhumana naye uma ekulayini ovuliwe. Uma amasethingi achazwe ngaphambilini engekho efonini yakho, ngeke uwadinge amanye amasethingi.

Xhumana no-opharetha wenethiwekhi yakho ngolwazi oluthe xaxa.

Ukungena kwiseva yeSithunywya yakho

- Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > **Qalisa.**

Ukuphuma kwiseva yeSithunywya



- Khetha **Izinketho** > **Qeda.**

Ukwengeza oxhumene naye ohlwini

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Oxhumene nabo** ithebhu.
- 2 Khetha **Izinketho** > **Ngeza oxh naye.**

Ukuthumela umbiko wengxoxo ovela ku Isithunywya

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Oxhumene nabo** ithebhu.
- 2 Pheqela koxhumana naye bese ukhetha **Ingxoxo.**
- 3 Bhala umyalezo wakho bese ukhetha **Thumela.**

Ungaqhubeka futhi nengxoxo, sebenzisa  noma  ukuqheqela kweye **Izingxoxo** ithebhu.

Izinga

Ungakhombisa izinga lakho, isibonelo, **Thokozile** noma **Bhizi**, koxhumana nabo kuphela. Ungakhombisa futhi izinga lakho kubo bonke abasebenzisi kwiseva ya Abangani bami.

Ukukhombisa izinga lami

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > **Izinketho** > **Izinhlelo** bese ukhetha **Khombisa izinga la.**
- 2 Khetha okukhethwa kukho.

Ukubuyekeza izinga lakho

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Izinga lami** ithebhu.
- 2 Hlela ulwazi.

Iqembu lengxoxo

Iqembu lengxoxo lingaqaliswa umnikezeli wakho wesevisi, umsebenzisi oyisiThunywa noma nguwe. Ungalonda amaqembu engxoxo ngokugcina isimemo sezingxoxo noma ngokucinga iqembu elithile lengxoxo.

Ukwakha iqembu lengxoxo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Amaqembu engxo.** ithebhu.
- 2 Khetha **Izinketho** > **Engeza iqe. lengx.** > **Iqe. lengxo. elisha.**

- 3 Khetha ukuthi uzomema bani eqenjini lezingxoxo ohlwini lwakho loxhumana nabo > **Qhubeka.**
- 4 Faka umbhalo wesimemo omfishane > **Qhubeka** > **Thumela.**

Ukwengeza iqembu lengxoxo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Amaqembu engxo.** ithebhu.
- 2 Khetha ongakhetha kukho.

! Umlando wengxoxo ulondwa phakathi kokungena nokuphuma ukukuvumela ukuthi ubuyele emibikweni yengxoxo esezingxoxweni zakudala.

Ukugcina ingxoxo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Izingxoxo** ithebhu.
- 2 Pheqela kwingxoxo bese ukhetha **Izinketho** > **Gcina ingxoxo.**

Ukuhlola ingxoxo egciniwe

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Izingxoxo** ithebhu.
- 2 Khetha **Izinketho** > **Gcina ingxoxo.**

Ukuhlola abasebenzisi ababukelayo

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami** > eye **Oxhumene nabo** ithebhu.
- 2 Khetha **Izinketho** > **Kubukelwa abase.** Uhu lwabasebenzisi kwiseva yeSithunywa ababukela ulwazi lwami lwezinga luyavela.

Ukuhlola noma ukuhlela amasethingi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel.** > **Abangani bami.**
- 2 Khetha **Izinketho** > **Izinhlelo** bese ukhetha okukhethwa kukho:
 - **Khombisa izinga la.**
 - **Sotha oxhu. nabo:**
 - **Isexwayisi sengxoxo:**
 - **Izinhlelo zikanolwazi:**
 - **Umshini wokuvula:**
 - **Vumel ukuxhuma:**

! *Xhumana no-opharetha wenethiwekhi yakho ngolwazi oluthe xaxa.*


Ukufanekisa

Ikhamera nevidyo rekhoda

Ungathatha izithombe futhi urekhode amavidyo kliphu ozowahlola, uwagcine noma uwathumele.

Isitholi sokubonayo namakhi ekhamera

Isibuko yisitholi sokubonwayo sakho uma usebenzisa ikhamera.




1 Sondeza noma hlehlisa





2 Thattha izithombe/Rekhoda ividyo


Ukusebenzisa ikhamera

Ukucupha ikhamera





- Kokubekwe eceleni cindezela bese ubamba .

Ukuthatha isithombe


- 1 Qalisa ikhamera bese ucindezela  noma  to ukupheqela ku .
- 2 Cindezela  ukuthatha isithombe.
- 3 Isithombe sigcineka nge-othomathiki kwimemori khadi.

-  *Ungarekhodi uma kukhona umthombo wokukhanya onamandla ngemuva. Sebenzisa isaphothi noma i-timer ukugwema isithombe esilufifi.*

Ukurekhoda ividyo klipu

- 1 Qalisa ikhamera bese ucindezela  noma  ukupheqela ku .
- 2 Cindezela  ukuqala ukurekhoda.

Ukuyeka ukuqopha

- 1 Cindezela .
- 2 Ividyo klipu isigcineka nge-othomathiki kwimemori khadi.




Ukusebenzisa i-zoom

- Cindezela ikhi yevolumu iye phezulu noma ezansi.

Ukuhlela ukugqama

- Cindezela  noma .


Ukuhlola izithombe namavidyo klipu

- 1 Qalisa ikhamera bese ucindezela  noma  ukupheqela ku .
- 2 Ukuhlola izithombe zakho namavidyo klipu, cindezela ikhi yokuhambisa ephakathi.

Izimpawu namasethingi kwekhamera

Izimpawu ezisesibukweni zazisa ngesethingi ekhona ngaleso sikhathi. Amanye amasethingi ekhamera ayatholakala ku [Amasethingi](#).

Ukushintsha amasethingi

- Cupha ikhamera bese uyakhetha .

Ukuhlola ulwazi ngamasethingi

- Pheqela kwisethingi bese ukhetha .

Kudluliswa izithombe

Dlulisa uyise noma ususe izithombe kwikhompyutha yakho

Ungasebenzisa i-Bluetooth™ wireless technology nekhebula le-USB ukudlulisa izithombe namavidyo klipu phakathi kwekhompyutha nefobi yakho. Ngolunye ulwazi, bheka *I-Bluetooth™ wireless technology* ekhasini 38 ne *Ukusebenzisa ikhebula le-USB* ekhasini 39.

Ungahlola, wenze ngcono futhi uhlele izithombe namavidyo kliphu kwakho kwikhompyutha yakho ngokufaka i *Adobe™ Photoshop™ Album Starter Edition* noma i *Sony Ericsson Media Manager*. Lokhu kufakiwe kwi-CD efika nefoni yakho futhi kuyatholakala uma kulandwa ku www.sonyericsson.com/support.

I-blog yesithombe

I-blog yesithombe yikhasi lakho siqu le-Web. Uma ukuthenga kwakho kuyisekela le sevisi, ungathumela izithombe kwi-blog.

! Isevisi ye-Web ingadinga isivumelwano selayisense esihlukile phakathi kwakho nomnikezeli wesevisi yakho. Kungasebenza izilungiso namashaji engeziwe. Xhumana nomnikezeli wakho wesevisi noma yiya ku www.vodafone.com.

Ukuthumela izithombe zekhamera kwi-blog

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Ifotho** > **I-albhamu yekhamer**.
- 2 Pheqela kwinyanga nesithombe. Khetha **Hlola**.
- 3 Khetha **Izinketho** > **Thumela** > **Ukubloga**.
- 4 Engeza isihloko nombhalo.
- 5 Khetha **OK** > **Shicilela**.

Ukuthumela isithombe noma ividyo kliphu

- 1 Kokubekwe eceleni khetha **Imidiya**.
 - 2 Pheqela entweni bese ukhetha **Izinketho** > **Thumela**.
 - 3 Khetha indlela yokudlulisa.
- ! *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

Izithombe

Ungahlola, wengeze, uhlele noma ususe izithombe ku **Imidiya**.

Ukusebenzisa izithombe

Ungongeza isithombe kokhumana naye, sisebenzise ngesikhathi uqalisa ifoni, njengephepha lodonga kokubekwe eceleni noma njengesivikeli sibuko.

Ukusebenzisa izithombe

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Ifotho** > **I-albhamu yekhamer**.
- 2 Pheqela kwinyanga nesithombe. Khetha **Hlola**.
- 3 Khetha **Izinketho** > **Sebenzisa njenge**.
- 4 Khetha okukhethwa kukho.

Ukuhlola izithombe nge-slide show

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Ifotho** > **I-albhamu yekhamer**.
- 2 Pheqela kwinyanga nesithombe. Khetha **Hlola**.
- 3 Khetha **Izinketho** > **Veza isikhashana**.
- 4 Khetha isimo-ngqondo.



I-live! Studio

Yiya ku www.vodafone.com ngemininingwane. Le sevisi ayitholakali kuwo wonke amazwe.

Nge **I-inthanethi** ungagcina izithombe kwi-albhamu egxile kwi-Web. Lokhu kuwusizo uma usuphelelwa imemori yefoni, noma uma ufisa ukukhombisa abangani bakho izithombe zakho nge-albhamu e-virtual abangangena kuyo kwi-Web.

Ukulayisha isithombe esikokubekwe eceleni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Imeninja yefayela** > eye **Wonke amafayela** ithebhu > **Izithombe**.
- 2 Pheqela kwisithombe bese ukhetha **Izinketho**> **Thumela** > **Isevisi yeweb 1**.

Ukulayisha isithombe esikwikhamera

- Thatha isithombe bese ukhetha **Thumela** > **Isevisi yeweb 1**.

Ezokuzithokozisa



Ukuhamba kwimidiya yakho bheka Ukuhamba ekhasini 12.

Ihendisfri ephathekayo yestiryo



Ukusebenzisa ihendisfri

- Xhuma ihendisfri ephathwayo. Umculo uyama uma wamukela ucingo bese uqhubeka uma seluvaliwe ucingo.

Umculo nezidlali mavidyoyi

Ukudlala umculo

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Umculo**.
- 2 Pheqela kwisihloko bese ukhetha **Dlala**.

Ukudlala amavidyo

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Ividiyo**.
- 2 Pheqela kwisihloko bese ukhetha **Dlala**.

Umculo nezilawuli mavidyo

Ukumisa ukudlala umculo

- Cindezela ikhi yokuhambisa ephakathi.



Ukuqhubeka ukudlala umculo

- Cindezela ikhi yokuhambisa ephakathi.



Ukushintsha ivolumu

- Uma ulalela umculo, cindezela amakhi evolomu aye phezulu noma phansi.

Ukuhamba phakathi kwamathrekhi

- Uma ulalela umculo, cindezela  noma .

Ukusheshisa phambili nokusheshisa emuva

- Uma ulalela umculo, cindezela bese ubamba  noma .

Ukubuyela kumamenyu esidlali

- Khetha **Emuva**.

Ukubuyela kwizidlali

- Khetha **Izinketho > Qhubeka**.

Ukuphuma kumamenyu esidlali

- Cindezela bese ubamba .

Ukuthumela umculo

- 1 Kokubekwe eceleni khetha **Imidiya** bese upheqela ku **Umculo**.
- 2 Pheqela kwisihloko bese ukhetha **Izinketho > Thumela**.
- 3 Khetha indlela yokudlulisa.



- *Qinisekisa ukuthi idivaysi eyamukelayo iyayisekela indlela yokudlulisa oyikhethayo.*

I-TrackID™

I-TrackID™ iyi sevisi ekhumbula umculo. Cinga izihloko zamaculi, abaculi namagama ama-albhamu.



- *Ukusebenzisa i-TrackID™ kungahambisana nezindleko.*

Ukucinga ulwazi lweculo

- Uma uzwa iculo ngelawudispikha, kokubekwe eceleni khetha **Imenyu > Imidlalo > TrackID™**.
- Uma umsakazo udlala khetha **Izinketho > TrackID™**.

Umsakazo



- *Ungayisebenzisi ifoni njengomsakazo ezindaweni lapho zivinjelwe khona.*

Ukulalela umsakazo

- 1 Xhuma ihendisfiri kwifoni.
- 2 Kokubekwe eceleni khetha **Imenyu > Umsakazo**.



Ukushintsha ivolumu

- Uma umsakazo udlala, cindezela amakhi evolumu aye phezulu noma phansi.



Ukucinga amashaneli nge-othomathikhi

- Uma umsakazo udlala, khetha **Cinga**.

Ukucinga amashaneli ngesandla

- Uma umsakazo udlala, cindezela  noma .

Ukushintsha phakathi kwamashaneli asehleliwe

- Uma umsakazo udlala, cindezela  noma .

Ukugcina amashaneli

Ungagcina kuze kufike kumashaneli angu 20 asethwe phambilini.



Ukugcina amashaneli

- Uma usuthole ishaneli yomsakazo khetha **Izinketho** > **Gcina**.



Ukukhetha amashaneli agciniwe

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umsakazo** > **Izinketho** > **Amashaneli**.
- 2 Khetha ishaneli yomsakazo.

Ukugcina amashaneli kwizindawo 1 kuyaku 10

- Uma usuthole ishaneli yomsakazo, cindezela ubambe  - .

Ukukhetha amashaneli agciwe kwizindawo 1 kuyaku 10



- Uma umsakazo udlala, cindezela  - .

Amaringithoni kanye nemiculo



Ukusetha iringithoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlalo** > eye **Imisindo nezibonis** ithebhu > **Iringithoni**.
- 2 Thola bese ukhetha iringithoni.

Ukusetha ivolumu yeringithoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlalo** > eye **Imisindo nezibonis** ithebhu > **Ivolumu yeringithoni**.
- 2 Ukushintsha ivolumu, cindezela  noma .
- 3 Khetha **Gcina**.

Ukucisha iringithoni

- Kokubekwe eceleni cindezela bese ubamba .
-  **Wonke amasignali ngaphandle kwesiganali ye-alamu ayaphazamiseka.**

Ukusetha isixwayisi sokudlikiza

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlalo** > eye **Imisindo nezibonis** ithebhu > **Isixwa. sokudlikiza**.
- 2 Khetha okukhethwa kukho.

Isirekhodi somsindo

Ungarekhoda imemo yezwi noma ucingo. Imisindo erekhodiwe ingasehwa njengamaringithoni.

- ! Kwamanye amazwe noma kumasteythi umthetho wakhona udinga ukuthi umazise omunye umuntu ngaphambi kokurekhoda ucingo.

Ukurekhoda umsindo

- Kokubekwe eceleni khetha **Imenyu** > **Imidlalo** > **Qophu umsindo**.

Ukulalela okurekhodiwe

- 1 Kokubekwe eceleni khetha **Imenyu** > **Umhleli** > **Imenenja yefayela**.
- 2 Pheqela ku **Umculo** bese ukhetha **Vula**.
- 3 Pheqela kokurekhodiwe bese ukhetha **Dlala**.

Ukuxhumana



I-Vodafone live!

I-Vodafone live! inayo yonke into oyidingayo futhi inolwazi oluphelele, imidlalo, umculo, amaringithoni nokunye kokuzithokozisa. Kulula ukuyisebenzisa futhi “ingahlala ivuliwe”, ukuze kungalindwa ukudayela. Ukhokhela kuphela idatha oyithumelayo noyamukelayo, hhayi isikhathi osixhumile.


Ifoni yakho isivele isethelwe ukukufinyelelisa ku-Vodafone live! – iphothali ye-Vodafone ye-Inthanethi yeselula. Kufanele ukuthi usubhalisile, futhi awudingi ukushintsha noma ukuguqula amasethingi.

Uma unezinkinga ngokuxhuma kwi-Vodafone live!, i-Inthanethi noma ukusebenzisa i-imeyli, ucelwa ukuba uxhumane no-opharetha wenethiwekhi yakho noma yiya ku www.vodafone.com. Isikhungo senethiwekhi yakho sokunakekela amakhastoma singakunika amasethingi afanele ngombiko wombhalo. Amasethingi ayatholakala futhi ku www.sonyericsson.com/support.

Ukulanda amasethingi

- 1 Kwikhompyutha yakho, pheqa ku www.sonyericsson.com/support.
- 2 Khetha isifunda nezwe noma indawo esekela Ezomhlabajikelele.
- 3 Khetha ithebhu ye Sethaphu Yefoni, bese ukhetha imodeli yefoni.
- 4 Khetha ukuthi uzolanda luphi uhlelo efonini yakho.

Xhuma ku Vodafone live!

- Kokubekwe eceleni khetha **Imenyu** > **I-inthanethi**.
- Ungakhetha futhi  ukuthola **I-inthanethi**.

Ukuphuma ku-Vodafone live

- Cindezela .

Amasevisi e-Vodafone live!

Landa imisindo namaringithoni, izithombe ama-animations nephepha lodonga, umdlalo omusha, amavidyo amakliphu omculo nezingqikithi ngokubukeka okusha kwamamenyu. Ungathutha futhi ividyo nomculo.

- **I-inthanethi** – isilondi sakulayini ovuliwe wezithombe nemisindo yakho.
- Imeyili ye-Vodafone – ibhokisi lemeyili elifodwa layo yonke imibiko yakho yemeyili, imeyili yezwi namafeksi.

- Isithunywa se-Vodafone – ukuthunyelwa okusheshayo kwiselula yakho.
- Izindaba – thola imibiko yezindaba yakamuva nesibikezelo sezulu.
- Ezemidlalo – imiphumela yezindaba, neziko zakamuva.
- Cinga – thola okudingayo kwi-Vodafone live!.



I-Vodafone live! iyakhula futhi iyavuselelwa nsuku zonke, ngakho-ke lokhu okukhethwa kukho kungashintsha. Hlala uyihlola ukubona ukuthi yikuphi okusha. Imibuzo ngermikhiqizo namasevisi e-Vodafone live! kufanele ibhekiswe ku-Vodafone Customer Services



Amanye ala masevisi awatholakali kuwo wonke amazwe noma amagama angahluka.

Ukulanda kwiphothali ye-Vodafone live!

- 1 Kokubekwe eceleni khetha **I-inthanethi** bese ukhetha ilinki.
- 2 Pheqa ikhasi leWeb, khetha ifayela ozolilanda bese ulandela imiyalelo evelayo.

Amasethingi

Ngaphambi kokuvumelanisa nesevisi ye-Inthanethi, sebenzisa i-Inthanethi, i-Java, imiyalezo yezithombe, i-imeyli ne-blog yezithombe okudingayo ukuba namasethingi efonini yakho.

Uma amasethingi engakafakwa, ungalanda amasethingi ngokusebenzisa isethaphu wizadi noma ngokuya ku www.sonyericsson.com/support.

Ukulanda amasethingi ngokusebenzisa iwizadi ye sethaphu

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Okujwayelekile** ithebhu > **Isethaphu wizadi** > **Landa izinhlelo**.
 - 2 Landela imiyalelo evelayo.
- *Xhumana no-opharetha wenethiwekhi yakho noma umnikezeli wakho wesevisi ngolwazi oluthe xaxa.*

Ukuthumela ukuxhumana

- 1 Uma upheqa kwi-Inthanethi, khetha **Izinketho** > **Amathuluzi** > **Thumela ukuxh**.
- 2 Khetha okukhethwa kukho.

Usebenzisa amabhukumaka

Ungakha bese uhlela amabhukumaka njengokuxhumana okusheshayo okuya kumakhasi akho athandwayo e-Web.


Ukwakha ibhukumaka

- 1 Uma upheqa kwi-Inthanethi, khetha **Izinketho** > **Amathuluzi** > **Ngeza ibhukuma**. > **Mabhukumaka**.
- 2 Faka isihloko nekheli. Khetha **Gcina**.

Ukukhetha ibhukumaka

- 1 Kokubekwe eceleni khetha **Imenyu** > **I-inthanethi**.
- 2 Khetha **Izinketho** > **Yiya ku** > **Mabhukumaka**.
- 3 Pheqela kwibhukumaka bese ukhetha **Yiya ku**.

Ama-feed e-Web

Ungamukela okuqukethwe okubuyekwezwa njalo, njengama-podcast noma izihloko zezindaba, njengama-feed e-Web. Ungongeza ama-feed ekhasi, uma linalolu  phawu.

Ukwengeza ama-feed amasha ekhasi le-Web

- Uma upheqa ikhasi kwi-Inthanethi elinama-feed e-Web, khetha **Izinketho** > **Ama-feed eWeb**.


Ukwakha i-feed entsha ye-Web

- 1 Kokubekwe eceleni khetha **Imenyu** > **Imibiko ethunyel**. > **Ama-feed eWeb** > **Izinketho** > **I-feed entsha**.
- 2 Faka ikheli bese ukhetha **Yiya ku**.

I-Bluetooth™ wireless technology

Uhlelo lwe-Bluetooth lwenza ukuxhumana okungenawaya kwamanye amadivaysi e-Bluetooth enzeke. Isibonelo, unga:

- Xhuma kumadivaysi ehendisfri.
- Xhuma kumadivaysi amaningi ngesikhathi esisodwa.
- Xhuma kumakhompyutha bese ungena kwi-Inthanethi.
- Shintshanisa izinto bese udlala imidlalo edlalwa abadlali abaningi.

 *Sincoma ibanga eliphakathi kwamamitha ayi-10, kungabi nazo izinto eziqinile phakathi nendawo, ekuxhumaneni kwe-Bluetooth.*

Ngaphambi kokuba usebenzise ubuchwepheshe obungenawaya be-Bluetooth

Kufanele uvule umsebenzi we-Bluetooth ukuxhumana namanye amadivaysi. Kufanele futhi ubhangqe ifoni yakho namanye amadivaysi e-Bluetooth.

Ukuvula uhlelo lwe-Bluetooth

- Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu > **I-Bluetooth** > **Vula**.
- **Qinisekisa ukuthi idivaysi ofuna ukuyibhangqa nefoni yakho inomsebenzi we-Bluetooth ocushiwe futhi obonakalayo.**

Ukubhangqa ifoni nedivaysi

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu > **I-Bluetooth** > **Imishini yami**.
- 2 Pheqa ku **Umshini omusha** bese ukhetha **Engeza** ukucinga amadivaysi atholakalayo.
- 3 Khetha idivaysi.
- 4 Faka iphasikhodi, uma kudingeka.

Ukuvumela ukuxhumana nefoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu > **I-Bluetooth** > **Imishini yami**.
- 2 Khetha idivaysi ohlwini.
- 3 Khetha **Izinketho** > **Vumela ukuxhu**.

Ukubhangqa ifoni nehendisfri ye-Bluetooth ngokokuqala

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu > **I-Bluetooth** > **Ihendisifri**.
- 2 Khetha **Yebo**.
- 3 Faka iphasikhodi, uma kudingeka.

Ukubhangqa ifoni namahendisfri e-Bluetooth angaphezu kweyodwa

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > eye **Ukuxhumana** ithebhu > **I-Bluetooth** > **Ihendisifri** > **Ihendisifri yami** > **Ihendisifri entsha**.
- 2 Pheqela kwidivaysi bese ukhetha **Engeza**.

Ukubonakala

Uma ufuna amanye amadivaysi e-Bluetooth akwazi ukuthola ifoni yakho, ungakhetha ukwenza ifoni yakho ibonakale.

Ukwamukela into

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Ukuxhumana** ithebhu > **I-Bluetooth** > **Kuyabonakala** > **Bonisa ifoni**.
- 2 Uma wamukela into ethile, landela imiyalelo evelayo.

Ukusebenzisa ikhebula le-USB

Ungaxhuma ifoni yakho kwikhompyutha ngekebula le-USB ukudlulisa amafayela ngokusebenzisa **Londoloz kuning** noma **Ukudlulis midya**. Futhi ungavumelanisa, udlulise amafayela bese usebenzisa ifoni yakho njengemodemu ngokusebenzisa **Imodi yefoni**. Ngolunye ulwazi yiya engxenyeni ethi Ukuqalisa ku www.sonyericsson.com/support.

Ngaphambi kokusebenzisa ikhebula le-USB

Udinga olunye lwalezi nhlelo zokusebenza ukuze udlulise amafayela ngokusebenzisa ikhebula le-USB:

- I-Windows® 2000
- I-Windows XP (i-Pro ne-Home)
- I-Windows Vista (32 bhithi no 64 bhithi izihumusho ze: I-Ultimate, Enterprise, Business, Home Premium, Home Basic)


Ukudlulisa imidya nokulondoloza uMthamo


Ungahudula bese uphonsa amafayela phakathi kwefoni yakho noma imemori khadi nekhompyutha ku *Microsoft Windows Explorer*.



Sebenzisa kuphela ikhebula le-USB elisekelwe yifoni yakho. Ungalikhphi ikhebula le-USB efonini noma kwikhompyutha yakho ngesikhathi sokudlulisa amafayela njengoba lokhu kungonakalisa imemori yefoni noma imemori khadi.

Ukusebenzisa imodi yokudlulisa imidya nokulondoloza umthamo



 Ngaphambi kokudlulisa amafayela kufanele ufake isofthiwe ye-Sony Ericsson PC Suite kwikhompyutha yakho.

- 1 Xhuma ikhebula le-USB kwifoni nakwikhompyutha.
- 2 **Ifo**ni: Khetha **Londoloz kuning** > **Imenyu** > **Izinhlelo** > **eye Ukuxhumana** ithebhu > **I-USB** > **Imodi ye-USB** > **Londoloz kuning**. Ifo ni izozivala kule modi bese iqala kabusha uma inqanyulwa kwikhebula le-USB.

- 3 **Ifo**ni: Khetha **Ukudlulis midya** futhi ifoni izolokhu icuphekile ngesikhathi sokudlulisa amafayela.
- 4 **Ikhompyutha**: Linda ize imemori yefoni yakho nememori khadi kuvele njengamadiski angaphandle kwi-*Windows Explorer*.
- 5 Hudula bese uphonsa amafayela akhethiwe phakathi kwefoni nekhompyutha.

Ukunqamula ukuxhuma ikhebula le-USB ngokuphephile


- 1 Qhafaza esidlelni ophawini lwediski ekhiphekayo ku *Windows Explorer*.
- 2 Khetha u *Khipha*.
- 3 Nqamula ikhebula le-USB uma umyalezo olandelayo ukhonjiswa efonini: **Ukuxhumana kwe-USB kuphellele**. Kuphephile manje ukukhipha ikhebula le-USB.

Imodi yefoni

Ngaphambi kokuvumelanisa noma ukusebenzisa ifoni yakho njengemodemu kufanele ufake **eye-Sony Ericsson PC Suite** isofthiwe kukhompyutha yakho.

Ukusebenzisa imodi yefoni

- 1 **Ikhompyutha:** Qala *i-PC Suite* ephuma ku *Qala/Izinhlelo/Sony Ericsson/PC Suite*.
- 2 Xhuma ikhebula le-USB kwifoni nakwikhompyutha.
- 3 **Ifoni:** Khetha **Imodi yefoni** > **Imenyu** > **Izinhlelo** > **eye Ukuxhumana** ithebhu > **I-USB** > **Imodi ye-USB** > **Imodi yefoni**.
- 4 **Ikhompyutha:** Uma waziswa ukuthi *i-Sony Ericsson PC Suite* isithole ifoni yakho, ungaqala ukusebenzisa izinhlelo zemodi yefoni.

 Ngemininingwane yokusebenzisa, bheka *ingxenye ethi Sony Ericsson PC Suite Help uma isofthiwe isifakiwe kwikhompyutha yakho.*

Ukuxazulula izinkinga

Izinkinga ezithile zizodinga ukuba ufonele u-opharetha wenethiwekhi yakho.

Ngesaphothi ethe xaxa yiya ku www.sonyericsson.com/support.

Imibuzo evamile

Nginezinkinga nomthamo wememori noma ifoni isebenza ngokunensa

Qala kabusha ifoni yakho zonke izinsuku ukukhulula imemori noma yenza i **Isihleli esikhulu**.

I-Master reset

Sewukhethe **Hlela izinhlelo**, izinguquko ozenze ezinhlelweni zizocishwa.

Uma ukhetha **Hlela konke**, ngaphezu kwezinguquko ezinhlelweni, bonke oxhumene nabo, imibiko, ulwazi lwakho kanye nengqikithi oyikhiphe emishinini emikhulu, oyemukele noma oyihlelile, iyocishwa futhi nayo.

Ukusetha kabusha ifoni

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlelo** > **eye Okujwayelekile** ithebhu > **Isihleli esikhulu**.
- 2 Khetha okukhethwa kukho.
- 3 Landela imiyalelo evelayo.

Angikwazi ukushaja ifoni noma umthamo webhethri uphansi

Ishaja ayixhumekile kahle noma uxhumano lwebhethri lubuthaka. Khipha ibhethri bese uhlanza izixhumi.

Ibhethri igugile idinga ukushintshwa. Bheka *Ukushaja ibhethri* ekhasini 7.

Alukho uphawu lwebhethri oluvelayo uma ngiqala ukushaja ifoni

Kungathatha imizuzu embalwa ngaphambi kokuthi uphawu lwebhethri luvele esibukweni.



Okunye okukhethwa kukho imenyu kuvela kumpunga

Isevisi ayicushiwe. Xhumana no-opharetha wenethiwekhi yakho.

Angikwazi ukusebenzisa imibiko efonini yami

Izinhlalo ziyashoda noma azilungile. Xhumana no-opharetha wenethiwekhi yakho. Bheka *Usizo efonini yakho* ekhasini 7 noma yiya ku www.sonyericsson.com/support uku-oda amasehingi bese ulandela imiyalo esesibukweni. Bheka *Imibiko yombhalo (SMS)* (SMS) ekhasini 23 noma *Amasehingi* ekhasini 36.

Ngingayivula noma ngiyivale kanjani i-T9 Text Input uma ngibhala?

Uma ufaka umbhalo, cindezela bese ubamba . Uyobona  phezulu esibukweni uma i-T9 Text Input icushwa.

Ngingalushintsha kanjani ulwimi lwefoni?

- 1 Kokubekwe eceleni khetha **Imenyu** > **Izinhlalo** > eye **Okujwayelekile** ithebu > **Ulimi** > **Ulimi lwefoni**.
- 2 Khetha okukhethwa kukho.

Angikwazi ukusebenzisa i-Inthanethi

Ukuthenga kwakho akubandakanyi ikhona ledatha. Izinhlalo ze-inethanethi ziyashoda noma azilungile. Sicela uxhumane no-opharetha wenethiwekhi yakho.

Bheka *Usizo efonini yakho* ekhasini 7 noma yiya ku www.sonyericsson.com/support uku-oda amasehingi e-Inthanethi, bese ulandela imiyalo esibukweni. Bheka *Amasehingi* ekhasini 36.

Itoni ayikwazi ukutholwa ngamanye amadivaysi ngobuchwepheshe obungenawaya be-Bluetooth
Awukaluvuli uhlelo lwe-Bluetooth.

Qinisekisa ukuthi ukubonakala kusethelwe ku **Bonisa ifoni**.

Angikwazi ukuvumelanisa noma ukudlulisa idatha phakathi kwefoni yami nekhompyutha yami, uma usebenzisa ikhebula le-USB.

Ikhebula noma isofthiwe okufike nefoni yakho akufakwanga kahle. Yiya ku www.sonyericsson.com/support ufunde amagadyi oku Qalisa anemiyalo egcwele yokufaka namagaydi okuxazulula izinkinga.

Imibiko enephutha

Faka ikhadi

Akukho SIM khadi efonini yakho noma kungenzeka ukuba uyifake ngendlela engalungile.

Bheka *Ukushaja ibhethri* ekhasini 7.

Izixhumi zeSIM khadi zidinga ukuhlanzwa. Uma ikhadi lilimele, xhumana no-opharetha wenethiwekhi yakho.

Faka ikhadi o kuyilo le-SIM

Ifoni isethwe ukuthi isebenze kuphela nama-SIM khadi athile. Hlola noma usebenzisa iSIM khadi ka-opharetha elungile yini.

iPIN okungesiyo/UPHINI 2 ayilungile

Ufake iPIN yakho noma iPIN2 ngokungesikho.

Faka i-PIN noma PIN2 efanele bese ukhetha **Yebo**. Bheka *Faka iSIM khadi*. ekhasini 5.

I-PIN ivinjwe/Pini-2uvalekile

Ufake iPIN noma iPIN2 ngokungesikho izikhathi ezintathu zilandelana.

Amakhodi awahambelani

Amakhodi owafakile awahambelani. Uma ufuna ukushintsha ikhodi yokuphepha, isibonelo i-PIN yakho, kufanele uqinisekise ikhodi entsha.

Ayikho inethiwekhi

Ifoni yakho ikwi-flight mode.

Ifoni yakho ayemukeli neyodwa isignali yenethiwekhi, noma isignali eyamukelwe ayinamandla. Xhumana no-opharetha wenethiwekhi yakho bese uqinisekisa ukuthi inethiwekhi iyayikhava indawo okuyo.

I-SIM khadi ayisebenzi kahle. Faka i-SIM khadi yakho kwenye ifoni. Uma lokhu kusebenza, kungenzeka kube yifoni ebangela inkinga. Sicela uxhumane nesevisi ye-Sony Ericsson yasendaweni.

Izingc. eziphu. kup.

Uwendaweni lapho inethiwekhi itholakala khona, kodwa awuvunyelwe ukuyisebenzisa. Kepha, esimeni esiphuthumayo, abanye o-opharetha benethiwekhi bayakuvumela ukuba ushayele inombolo ephuthumayo yomazwe omhlaba jikelele u-112. Bheka *Izingcingo eziphuthumayo* ekhasini 15.

IPuk ivaliwe. Xhumana no- opharetha.

Ufaka ikhodi yakho yokuvula ukuvinjwa (iPUK) ngokungesikho izikhathi ezi-10 zilandelana.

Ukushaja, ibhethi okungesilo elakh ona

Ibhethri olisebenzisayo akusilo ibhethri elivunyelwe u-Sony Ericsson. Bheka *Ibhethri* ekhasini 47.

Ulwazi olubalulekile

Iwebhusaythi yaBathengi be-Sony Ericsson

Ku www.sonyericsson.com/support kunengxenywe yesaphothi/yokusekela lapho kutholakala khona usizo namathiphu. Lapha uthola ukuvuselelwa kwesofthiwe yekhompyutha yakamuva namathiphu okuthi ungawusebenzisa kanjani umkhqizo wakho ngokuyimpumelelo.

Isevisi nokusekela

Kusukela manje uzokwazi ukungena kwiphothifolayo yesevisi ekhethekile njengalezi:

- AmaWebhusaythi omhlabajikelele nawasekhaya anikezela ngesaphothi.
- Inethiwekhi yomhlabajikelele yama-Call Center.
- Inethiwekhi ebanzi yophathina beisevisi yakwa-Sony Ericsson.
- Isikhathi sewaranti. Funda kabanzi ngezimiso zewaranti kule Gaydi yomsebenzisi.

Ku www.sonyericsson.com, ngaphansi kwengxenywe yesaphothi olimini lwakho olukhethile, uzothola amathuluzi esaphothi yakamuva nolwazi, njengam a-updates esofthiwe, isizinda solwazi, isethaphu yefoni nosizo olwengeziwe uma ulidinga.

Ngezimpawu namasevisi agxile ku-opharetha, sicela uxhumane no-opharetha wenethiwekhi yakho ngolwazi oluthe xaxa.

Ungaxhumana futhi nama-Call Center ethu.

Bheka inamba yefoni ye-Call Center eseduze ohlwini olungezansi. Uma izwe/isifunda sakho singamelwe ohlwini, sicela uxhumane nomthengisi wangakini. (Izinamba zamafoni ezingezansi bezilungile ngesikhathi kuyophrintwa.

Ku www.sonyericsson.com ungathola njalo ama-updates akamuva.

Esimeni esingabazekayo lapho umkhqizo wakho udinga isevisi, sicela uxhumane nomthengisi lapho uthengwe khona noma oyedwa wophathina besevisi. Gcina ubufakazi bokuthenga, uzobudinga uma udinga ukukleyma iwaranti.

Izwe

Argentina	800-333-7427
Australia	1-300650-600
Belgique/België	02-7451611
Brasil	4001-04444
Canada	1-866-766-9374
Central Africa	+27 112589023
Chile	123-0020-0656
Colombia	18009122135
Česká republika	844550 055
Danmark	33 31 28 28
Deutschland	0180 534 2020
Ελλάδα	801-11-810-810 210-89 91 919
España	902 180 576
France	0 825 383 383
Hong Kong/香港	8203 8863
Hrvatska	062 000 000
India/भारत	39011111
Indonesia	021-2701388
Ireland	1850 545 888
Italia	06 48895206
Lietuva	8 70055030
Magyarország	+36 1 880 4747
Malaysia	1-800-889900
México	01 800 000 4722
Nederland	0900 899 8318
New Zealand	0800-100150
Norge	815 00 840
Österreich	0810 200245
Pakistan	111 22 55 73 (92-21) 111 22 55 73

Ngokushayela eyodwa yama-Call Center ethu uyoshajwa ngokwamareyithi kazwelonke, kubandakanya intela yangakini, ngaphandle uma inamba yefoni kungeyamahhala.

Ikheli le-imeyili

questions.AR@support.sonyericsson.com
questions.AU@support.sonyericsson.com
questions.BE@support.sonyericsson.com
questions.BR@support.sonyericsson.com
questions.CA@support.sonyericsson.com
questions.CF@support.sonyericsson.com
questions.CL@support.sonyericsson.com
questions.CO@support.sonyericsson.com
questions.CZ@support.sonyericsson.com
questions.DK@support.sonyericsson.com
questions.DE@support.sonyericsson.com

questions.GR@support.sonyericsson.com
questions.ES@support.sonyericsson.com
questions.FR@support.sonyericsson.com
questions.HK@support.sonyericsson.com
questions.HR@support.sonyericsson.com
questions.IN@support.sonyericsson.com
questions.ID@support.sonyericsson.com
questions.IE@support.sonyericsson.com
questions.IT@support.sonyericsson.com
questions.LT@support.sonyericsson.com
questions.HU@support.sonyericsson.com
questions.MY@support.sonyericsson.com
questions.MX@support.sonyericsson.com
questions.NL@support.sonyericsson.com
questions.NZ@support.sonyericsson.com
questions.NO@support.sonyericsson.com
questions.AT@support.sonyericsson.com

questions.PK@support.sonyericsson.com

Philippines/Pilipinas	02-6351860
Polska	0 (prefiks) 22 6916200
Portugal	808 204 466
România	(+4021) 401 0401
Россия	8 (495) 787 0986
Schweiz/Suisse/Svizzera	0848 824 040
Singapore	67440733
Slovensko	02-5443 6443
South Africa	0861 6322222
Suomi	09-299 2000
Sverige	013-24 45 00
Türkiye	0212 47 37 777
Україна	(+0380) 44 590 1515
United Kingdom	08705 23 7237
United States	1-866-7669347
Venezuela	0-800-100-2250
الإمارات العربية المتحدة	43 919880
中国	4008100000
台灣	02-25625511
ไทย	02-2483030

Imihlahlandlela yezokuphepha futhi esizayo ekusebenziseni ucingo

Sicela ufunde le mininingwane ngaphambi kokusebenzisa ucingo lwakho oluphathekayo. Le miyalelo yenzelwe ukuphepha kwakho. Sicela ulandele le mihlahlandlela. Uma umkhqiqo uke waba sezimeni ezinjengalezi ezibhalwe ngezansi noma unokungaba kokusebenza ngokuyikho qinisekisa ukuthi umkhqiqo wakho uhlohlwa uphathina wesevisi ogunyaziwe ngaphambi kokuwushaja noma kokuwusebenzisa. Ukuhluleka ukwenza njalo kungaholela engcupheni yokungasebenzi kahle komkhqiqo noma ngisho ebungozini bempilo yakho.



questions.PH@support.sonyericsson.com
 questions.PL@support.sonyericsson.com
 questions.PT@support.sonyericsson.com
 questions.RO@support.sonyericsson.com
 questions.RU@support.sonyericsson.com
 questions.CH@support.sonyericsson.com
 questions.SG@support.sonyericsson.com
 questions.SK@support.sonyericsson.com
 questions.ZA@support.sonyericsson.com
 questions.FI@support.sonyericsson.com
 questions.SE@support.sonyericsson.com
 questions.TR@support.sonyericsson.com
 questions.UA@support.sonyericsson.com
 questions.GB@support.sonyericsson.com
 questions.US@support.sonyericsson.com
 questions.VE@support.sonyericsson.com
 questions.AE@support.sonyericsson.com
 questions.CN@support.sonyericsson.com
 questions.TW@support.sonyericsson.com
 questions.TH@support.sonyericsson.com

Izincomo zokusetshenziswa okuphephile komkhqiqo (ifoni ephathekayo, ibhethri, ishaja nezinye izesekeli)

- Njalo phatha ngobunono umkhqiqo wakho, uwugcine endaweni ehlanzekile futhi engenazo izintuli.
- Isexwayiso!** Ingaqhuma uma ibekwe emlilweni.
- Ungawubeki umkhqiqo wakho endaweni emanansi noma eswakeme noma enomhnamukho.
- Ungawubeki umkhqiqo wakho ezingeni lokushisa eliphezulu kakhulu noma eliphansi kakhulu. Ungalibeki ibhethri endaweni eshisa ngaphezu kuka +60°C (+140°F).
- Ungawubeki umkhqiqo wakho endaweni enamalangabi avulekile noma kwimkhqiqo evuthayo kagwayi.



- Ungawuwisi, ungawujikjeli noma uzame ukuwuphula umkhqiqo wakho.
- Ungawupendi umkhqiqo wakho.
- Ungazami ukuqaqa noma ukuguqula umkhqiqo wakho. Umuntu ogunyazwe u-Sony Ericsson kuphela okufanele enze lo msebenzi.
- Ungasebenzisi umkhqiqo wakho eduze namathuluzi yasesibhedlela ngaphandle kokucela imvume kudokotela okwelaphayo noma nabasebenzi basesibhedlela abagunyaziwe.
- Ungawusebenzisi umkhqiqo wakho uma ungaphakathi, noma useduze nebhanyi, noma izindawo ezibhalwe ukuthi "cisha u-ova".
- Ungawusebenzisi umkhqiqo wakho endaweni lapho kunezinto eziyiziqhumane.
- Ungawusebenzisi umkhqiqo wakho noma ufake impahla engenawaya endaweni engaphezu kwesikhwama semoya semoto.
- Isexwayiso: imiboniso eklayekile noma ephukile ingadala okuseceleni okubukhali okungaba yingozi uma kuthintwa.



IZINGANE

WUGCINE LAPHO KUNGAFINYELELI KHONA IZINGANE. MUSA UKUVUMELA IZINGANE ZIDLALE NGEFONI YAKHO EPHATHEKAYO NOMA NGEZISEKELI. UFONI YAKHO EPHATHEKAYO NOMA ISIXHUMI SINGABA NEZINGXENYANA EZINCANE EZINGAHLE ZIPHUME BESE ZIBANGA INGOZI YOKUSHOKEKA.



Amandla kagesi (Ishaja)

Xhuma i-isixhumi sakho samandla kagesi ukuze ufake ugesi endaweni kuphela ekhonjiswe ngokucacile ukuthi yenzelwe lokho. Qiniseka ukuthi intambo imiswe kahle ukuze ingalimali noma icindezeleke. Ukuze kuncishiswe ngozi yokuthi umuntu abanjwe ugesi, kufanele impahla isuswe lapho kade ishajwa

khona ngaphambi kokuzama ukuyihlanza. Isixhumi samandla kagesi kufanele sisetshenziswe ngaphandle endlini noma ezindaweni zokulaha. Ungalinge uguqule intambo noma ipulaki. Uma ipalagi ingangeni kule ndawo yamandla, thola abasebenza ngogesi abaqeqeshiwe bakufakele lezo zinto ezifanele zokudonsa ugesi.

Sebenzisa kuphela amashaja akwa-Sony Ericsson enzelwe ukusebenza nefoni yakho ephathekayo. Amanye amashaja kungenzeka angadiziyinelwa ukuphepha nemigomo yokusebenza efanayo.

Ibhetthri

Sincoma ukuthi uyibhuste ngokugcwele ifoni yakho ephathekayo ngenkathi uyibhusta okokuqala. Ibhetthri elisha noma ebelingasebenzi isikhati eside linganciphisa umthamo wamandla ngenimizwana emibalwa uyisebenzisa. Ibhetthri lingashajwa kuphela emazingeni okushisa aphakathi kuka +5°C (+41°F) no +45°C (+113°F). Sebenzisa kuphela amabhetthri akwa-Sony Ericsson enzelwe ukusebenza nefoni yakho ephathekayo. Ukusebenzisa amanye amabhetthri nokunye kokuxhuma, kungaba yingozi.

Izikhathi zokukhuluma nezokubeka eceleni zincike ezimeni eziningana ezihlukele njengamandla esiginali, izinga lokushisa lokusebenza, amaphethini okusebenzisa ohlelo, izimpawu ezikhethiwe nezidlulisi zezwi noma zedatha uma usebenzisa ifoni ephathekayo.

Icime ifoni yakho ephathekayo ngaphambi kokukhupha ibhetthri. Ungayifaki emlonjeni wakho ibhetthri. Izinhlaiya zebhetthri zingaba nobuthi uma zigwinyiwe. Ungavumeli izinsimbi zebhetthri zithintane nenyene into enensimbi. Lokhu kungenza ibhetthri yakho iphelelwe ngamandla bese ilimala. Sebenzisa ucingo ngezinhloso kuphela ezibekelwe lokho.

Izinto ezakhelwe wena zezokwelapha

Amafoni apathekayo angakuphazamisa ukusebenza kwamawashi enhlizyo nezinyo izinto ezifakelwa kumuntu. Sicela ukugweme ukubeka

ifoni ephathekayo ngaphezu kwewashi lenhliziyo, isb. ephaketheni elisemabeleni. Uma usebenzisa iselula, sebenzisa indlebe ekwesinye isandla senhliziyo yewashi. Uma kugcinwa ukuqhelelana okwanele okungu 15 cm (ama-intshi angu-6) phakathi kwefoni ephathekayo newashi lenhliziyo, amathuma okuthikamezana kwalezi zisimbi mancane. Uma unesizathu sokusola ukuthi kukhona ukuthikamezeka okwenzekayo, cisha ucingo lwakho ngokushesha. Thintana nodokotela wakho wenhliziyo uma ufuna olunye ulwazi. Mayelana namanye amadivaysi okwelapha, sicela uxhumane nodokotela wakho nomkhqi zi wedivaysi.

Ukushayela

Sicela ubheke noma imithetho nezinqubo ziyakuvimbela yini ukuba usebenzise amafoni aphaathekayo ngenkathi ushayela noma zifuna ukuba abashayeli basebenzise ihandisifiri yokuxhuma emotweni. Sincoma ukuthi usebenzise kuphela izixazululo zehendisifiri zakwa-Sony Ericsson ezenzelwe ukusetshenziswa nomkhqi ziwo. Sicela wazi ukuthi ngenxa yokushayisana kwezinto zikagesi, abanye abakhqi zi bezimoto bayathqabala ukusetshenziswa kwamafoni aphaathekayo ezimotweni zabo ngaphandle uma kunesethi yehandisifiri enothi oluphumele ngaphandle olusekela ukufakwa kwefoni. Hlala njalo uqaphele ukushayela kwakho, ubuyele eceleni komgwaqo uma ngaphambi kokuba uphendule noma ushaye ucingo uma isimo somgwaqo sikuvumela.

Izingcingo eziphuthumayo

Amafoni aphaathekayo asebenzisa izibonisi zomsakazo ezingeke zikuqinisekise ukuxhumaneka ngaphansi kwazo zonke izimo.

Ngakho-ke musa ukuthembela kuphela efonini ephathekayo mayelana nokuxhumana okubalukile (isib. Eziphuthumayo zezempilo).

Izingcingo eziphuthumayo kungenzeka zingenzeki kuzo zonke izindawo, kuwo wonke amanethiwekhi amaselula, noma uma amasevisi athile enethiwekhi/ noma izimpawu zefoni zisebenza. Izingcingo eziphuthumayo kungenzeka zingenzeki kuzo zonke izindawo, kuwo wonke amanethiwekhi amaselula, noma uma amasevisi athile enethiwekhi/ noma izimpawu zefoni zisebenza.

Uthi

Le foni iqukethe uthi olakhelwe ngaphakathi. Ukusetshenziswa kwamadivaysi othi angamakethwanga u-Sony Ericsson aqondana nale modeli angalimaza ifoni yakho ephathekayo, anganciphisa ukusebenza, akhiqize amazinga e-SAR angaphezu komkhawulo obekiwe (bheka ngezansi).

Ukusetshenziswa ngokuyikho

Bamba ifoni yakho ephathekayo ngendlela obewungabamba ngayo noma iyiphi ifoni. Ungalembози ingaphezulu lefoni uma isebenza, njengoba lokhu kuphazamisa izinga lezingcingo kanti futhi kungadala ukuba ifoni isebenzise amazinga aphezulu amandla kunokuba kudingekile, lokho bese kunciphisa ingxoxo kanye nezikhathi ezibekwe eceleni.

Ukuvuleleka kwifrikhwensi yomsakazo (RF) nakuSpecific Absorption Rate (SAR)

Ucingo lwakho oluphathekayo luwumsakazo osebenzisa amandla amancane futhi luyemukela. Uma luwuliwe, lukhipha amazinga aphantsi amandla omsakazo (lokhu kwaziwa futhi njengamagagasi omsakazo noma izinkundla zamandla omsakazo).

OHulumeni emhlabeni wonke sebekhiphe imigudu enqala yokuphepha ethuthukiswe izinhlangano zezesayensi, njenge ICNIRP (Ikhomishana yoMhlaba Jikelele yezokuVikelwa kokuKhiswa kweNuzi kwiMisebe kaGes)i, ne-IEEE (Isikhungo soNjiniyela bakaGes) nabama-eletronikhijezihlolwa ngezikhathi ezithile nangokuhlola ngokujulile izifundo zesayensi. Lezi zinkombanqubo zakha amazinga afanele amaganga omsakazo avumelekele kumphakathi womkana. La mazinga afaka nesilinganis sokuphepha esiqinisekisa ukuphepha kwawo wonke umuntu, kungakhethi budala noma impilo yalowo muntu, kanye nokuphendula mayelana nanoma ikuphi ukuhluka okungenzeka.uma kukalwa.

Izinga eliThile lokuMunca (SAR) into yokukala umthamo wamandla omsakazo womoya omuncwa umzimba ngenkathi usebenzisa ifoni yakho ephathekayo. Inani le-SAR likalwa ezingeni eliphezulu kakhulu lokuqinisekisa amandla kwizimo zamaLabhorekthi, kodwa izinga langempela le-SAR kwifoni ephathekayo ngenkathi isebenza lingaba ngaphansi kwaleli nani. Lokhu yingoba ifoni ephathekayo yakhelwe ukusebenzisa amandla enele ukuze ikwazi ukuthola inethiwekhi.

Ukwehluka kwi-SAR ngaphansi kwezinkombanqubo zokuvuleleka kwamaganga omsakazo womoya, akusho ukuthi kunokwehluka kwezokuphepha. Yize kungaba nokwehluka kumazinga e-SAR emafonini ehluhahlukene aphaathekayo, zonke izinhlobo zamafoni aphaathekayo akwa Sony Ericsson ahlelelwe ukuhlangabezana nezinkombanqubo zokuvuleleka kumaganga omsakazo womoya.

Kumafoni adayiswa e-U.S., ngaphambi kokuthi imodeli yefoni itholakale ukudayiselwa umphakathi, kufanele ihlolwe futhi igunyazwe yi-Federal Communications Commission (FCC) ukuthi ayidluli umkhawulo obekwe yizidingo zikahulumeni zokuvuleleka okuphephile. Uhlolo lwenziwa ezindaweni (okungukuthi, endlebeni futhi zigqokwe emzimbeni) njengoba kudingwa yi-FCC ngemodeli ngayinye. Ngomsebenzi wokugqokwa emzimbeni, le foni ihlolwe futhi yahlangabezana

nemihlahlandlela yokuvuleleka kwe-FCC RF uma ihedisethi ibekwe ebuncaneni obungu -15 mm emzimbeni ngaphandle kwezizingxenye zensimbi endaweni yefoni noma uma isetshenziswa nesesekeli esigqokwa emzimbeni sakwa-Sony Ericsson esenzelwe le foni. Ukusetshenziswa kwezesekeli ngeke kwaqinisekisa ukukumelana nemihlahlandlela yokuvuleleka ye-FCC RF. Ibhukwana eliseceleni elinolwazi lwe-SAR ngameleli yefoni ehambayo, lifakwe nale mpahla ehambisana nale foni ehambayo. Lolu lwazi lungatholwa, kanye nolunye ulwazi, kumagangasi okuvuleleka kwezomsakazo womoya kanye ne-SAR, ku: www.sonyericsson.com/health.

Izixazululo Ezitholakayo/Izidingo Ezikhethekile

Ngamafoni adayiswa e-US, ungasebenzisa itheminali yakho ye-TTY nefoni yakho ephathwayo yakwa-Sony Ericsson (nesesekeli esidingekayo). Ngolwazi Kwizixazululo Ezitholakayo ngabantu abanezidingo ezikhethekile shayela i-Sony Ericsson Special Needs Center ku 877 878 1996 (TTY) noma 877 207 2056 (izwi), noma vakashela i-Sony Ericsson Special Needs Center ku www.sonyericsson-snc.com.

Ukulahlwa kwezinto ezindala ezisebenza ngogesi nange-elektronikhi

Lolu phawu lubonisa ukuthi wonke amathuluzi kagesi nawe-elektronikhi afakiwe akufanele aphaathwe njengodoti wasendlini. Esikhundleni salokho kufanele uyidise endaweni efanele lapho kuqoqwa khona udoti ojikeleziswayo ongamathuluzi kagesi nawe-elektronikhi. Ngokujinisekisa ukuthi lo mkhiziqo ulahwe ngendlela ekahle, uyosiza ukuvikela imiphumela engemihle ebingadaleka endaweni nasezimpilweni zabantu, obekungadlwa ukuphawula ngendlela engafanele kwalo mkhiziqo. Ukujikeleziswa



kwezinto kuyosiza ukulonda izinto zemvelo. Ngolwazi oluthe xaxa ngokujikelezisa lo mkhqiizo, sicela uxhumane nehhovisi ledolobha langakini noma isevisi yokulahlwa kukadoti noma isitolo lapho uthenge khona lo mkhqiizo.

Ukulahla ibhethri

Sicela uhlole imithetho yangakini mayelana nokulahla amabhethri noma shayela i-Call Center yakwa-Sony Ericsson yangakini ukuze uthole ulwazi.

Ibhethri akufanele lifakwe emgqonyeni kadoti kamasipala. Sebenzisa into yokulahlela ibhethri uma ikhona.



Imemori Khadi

Umkhqiizo wakho uza uphelele nememori khadi ekhiphekayo. Ihambelana nehendisethi ethengiwe kodwa ingangahambelana namanye amadivaysi noma namandla amamemori khadi awo. Hlola amanye amadivaysi ngokuhambelana ngaphambi kokuthenga noma kokusebenzisa.

Imemori khadi ifomethwe ngaphambi kokuthunyelwa. Ukufometha kabusha imemori khadi, sebenzisa idivaysi ehambelanayo. Ungayisebenzisi ifomethi yesistimu yokusebenza eJwayelekile uma ufometha imemori khadi kwi-PC. Ngeminingwane, yiya kwimiyalelo yokusebenzisa yedivaysi noma xhumana nesaphothi yamakhasi.

ISEXWAYISO:

Uma idivaysi yakho idinga i-adaptha ukuze ifakwe kwiendisethi noma kwenye idivaysi, ungalfaki ikhad ngqo ngaphandle kwe-adaptha edingekayo.

Okumele kuqashelwe Ngokusebenzisa iMemori Khadi

- Ungayibeki imemori khadi enomsakama.
- Ungazithinti izixhumi zetheminali ngesandla sakho noma yinoma yini eyinsimbi.

- Ungayishayi, uyigobise, noma uyiwise imemori khadi.
- Ungazami ukuqaqa noma ukuguqula imemori khadi yakho.
- Ungayisebenzisi noma ulonde imemori khadi yakho ezindaweni ezinomhnamuko noma ezibolisa insimbi noma ezinokushisa okweqile njengasemotweni evalive ehlobo, ilanga elishaya ngqo noma eduze nehitha, nokunye.
- Ungacindezeli noma ugobise ukuphela kwe-adaptha yememori khadi ngamandla eqile.
- Ungavumeli ukungcola, uthuli, noma izinto zangaphandle kube sembotsheni yokufaka yanoma iyiphi i-adaptha yememori khadi.
- Hlola ukuthi uyishutheke kahle yini imemori khadi.
- Faka imemori khadi ingene yonke kwi-adaptha yememori khadi edingekayo. Imemori khadi kungenzeka ingasebenzi kahle ngaphandle uma ifakwe yonke.
- Sincoma ukuthi wenze ikhophi eyibhekaphu yedatha ebalulekile. Asihlangene nokulahleka noma ukulimala kokuqokethwe okulonde kwimemori khadi.
- Idatha erokhodiwe ingalimala noma ilahleke uma ukhipha imemori khadi noma i-adaptha yememori khadi, vala amandla omililo ngenkathi ufometha, ufunda noma ubhala idatha, noma sebenzisa imemori khadi ezindaweni ezinogesi onganqamuki noma izindima ezikhipha ugesi omningi.

Ukuvikelwa kweminingwane eqondene nawe

Ukugada ukungase bakho nokuvimba ukutholwa kolwazi yiqembu lesithathu, kufanele ucishe yonke idatha eqondene nawe ngaphambi kokudayisa noma kokulahla umkhqiizo. Ukususa idatha eqondene nawe, yenza i-master reset bese ukhipha imemori khadi. UKUSUSA IZINTO KWIMEMORI YEFONI AKUQINISEKISI UKUTHI LEYO MININGWANE NGEKE IBUYISWE WUMSEBENZISI OLANDELAYO. U-SONY ERICSSON AKANAWARANTI EQONDENE NOMSEBENZISI OLANDELAYO WEDIVAYISI OTHOLA ULWAZI LWAKHO FUTHI AKANASIBOPHO NGOKUDALULWA KWAKAMUVA

KWALOLO LWAZI NGISHO NOMA SEYENZIWE I-MASTER RESET. Uma ukhathazekile ngaloku dalulwa okungenzeka, yigcine idivaysi yakho noma uqinisekise ukucekelwa phansi kwayo konomphelo.

Izesekeleli

U-Sony Ericsson uncoma ukusebenzisa izesekeleli zakwa-Sony Ericsson zasekuqaleni ukuze isetshenziswe ngokuphepha nangendlela efanele imikhizyo yakhe. Ukusetshenziswa kwezisekeleli zamaqembu esithathu kunganciphisa ukusebenza ngemfanelo noma kube yingozi empilweni noma ekuphepheni kwakho.

ISEXWAYISO SOMSINDO:

Ucelwa ukuba ulungise ivolumu yokulalelwayo ngokuqaphela uma usebenzisa izesekeleli zokulalelwayo zamaqembu esithathu ukugwema amazing aevolumu angahle abe yingozi ezindlebeni zakho. U-Sony Ericsson akakuhloli ukusetshenziswa kwezisekeleli zokulalelwayo zamaqembu esithathu kule foni ephathwayo.

U-Sony Ericsson uncoma ukusebenzisa izesekeleli zasekuqaleni kuphela zakwa-Sony Ericsson.

Isivumelwano Selayisense Yomsebenzisi Wokugcina

Le divaysi engenawaya, kubandakanya napandla kwemikawuko noma iyiphi imidya edilivwe nedivaysi, (“Idivaysi”) iqukethe isofthiwe yakwa-Sony Ericsson Mobile Communications AB nezinkampani ezinapansi kwayo (“Sony Ericsson”) nabathengisi-mpahla abangabesithathu kanye nabanikeli layisense (“Isofthiwe”).

Njengomsebenzisi wale Divaysi, u-Sony Ericsson ukunika ilayisense elingakhethiyo, elingadluliselwa nelinganikezelwa ukuthi usebenzise i-Software kuphela ngokuhlanguka ne-Divaysi okufakwe

kuyo/noma edilivwe nayo. Akukho lapha okungahunyushwa njengokuthengiswa kwe-Software kumsebenzisi wale-Divaysi.

Ngeke wakhiqiza kabusha, uguqule, wabele, uphendule okukhandiwe, uhlakaze, noma ushintsheshe noma usebenzise noma yini ukuthola ikhodi elingumthombo we-Software noma wengxenyeye-Software. Ukugwema ukungabaza, ngaso sonke isikhathi unelungelo lokudlulisa wonke amalungelo nezibopho ze-Software kowesithathu, kuphela kanye ne-Divaysi owamukele ngayo i-Software, ngaphandle uma lesithathu sivuma ngokubhala phansi ukuthi sizibophezele kule mithetho.

Unikwa le layisense isikhathi sempilo yale-Divaysi ezobe isebenza ngaso. Ungayinqamula le layisense ngokudlulisa wonke amalungelo akho kwi-Divaysi owamukele kwi-Software uwadlulisele kwisithathu ngokubhala phansi. Uma uhleleka ukuvuma ukwenza imigomo nezimiso ezibekwe kule layisense, iyonqamuka ngokushesha.

U-Sony Ericsson nabathengisi-mpahla besithathu bakhe nabanikeli layisense bangabanikazi kuphela abakhethayo futhi banamalungelo onke, ubunikazi futhi banenzuzo kwiSofthiwe. U-Sony Ericsson, no, uma iSofthiwe iqukethe imphahla noma ikhodi lesithathu, lesi sithathu, siyokuba umudlimafa wayezi zimiso.

Ukuba semthethweni, ukwakhiwa nokusebenza kwale layisense kuyobuswa imithetho yase-Sweden. Ukuyekwa kuyokwenzeka ngokugcwele ngemvume, uma kufanele, yomthetho wamalungelo omthengi.

Iwaranti Enomkhawuko

Sony Ericsson Mobile Communications AB, SE-221 88 Lund, Sweden, (Sony Ericsson) noma inkampani yasendaweni esebenzisana nayo, ikuhluzeka ngale Waranti enomkhawuko yefoni yakho ephathwayo nezesekeleli zakuqala ezithunyelwe nefoni yakho (ezobizwa emva kwalokhu ngo “Mkhiqizo”).

Uma uMkhiziqo wakho udinga isevisi yesiqinisekiso, sicela uwubuyisele kulowo owuthenge kuye, noma xhumana ne-Call Center yakwa-Sony Ericsson yangakini (amareyithi kazwelonke angasebenza) noma vakashela ku www.sonyericsson.com ukuze uthole ulwazi oluthe xaxa.

Iwaranti yethu

Kuncike kwizimo zesiQinisekiso esibekelwe iMkhawulo, u-Sony Ericsson uqinisekisa ukuthi lo Mkhiziqo awutholanga kulimala ekwakhiweni kwawo, kwizinto ezikuwo, noma kulabo abebewakha ngenkathi uthengwa umthengi okokuqala kuze kube isikhathi esingangonyaka (1). IWaranti Enomkhawuko izothatha isikhathi esiwunyaka owordwa (1) kusukela osukwini lokuqala lokuthenga uMkhiziqo.

Esizokwenza

Ema ngalesi sikhathi sewaranti, lo Mkhiziqo uhluleka ukusebenza ngokujwayelekile nakumasevisi ajwayelekile, ngenxa yokulimala ekwakhiweni kwawo, kwizinto ezikuwo noma kubuchwepheshe bawo, abasabalalisi noma ophathina bevesisi abagunyazwe wu-Sony Ericsson, ezweni la uthenge khona uMkhiziqo, bazokhetha noma bayawukhanda noma bayawushintsha uMkhiziqo ngokuhambisana nemigomo nemibandela echazwe lapha.

U-Sony Ericsson nasebenzisana nabo bayaligodla ilungelo lokukhokhisa imali yokuphatha ngezandla kwabo uMkhiziqo, uma kungukuthi ubuyiswe nje awukho ngaphansi kwesiqinisekiso ngokwalezi zimo ezingezansi.

Sicela wazi ukuthi ezinye izinhlelo eziqondene nawe, okulandwayo noma olunye ulwazi lungalahleka uma uMkhiziqo wakho we-Sony Ericsson ukhanda noma ushintshwa ngomunye. Njengamanje u-Sony Ericsson angavinjelwa umthetho osebenzayo, ezinye izimiselo noma imikhawulo yobuchwepheshe

ekwakheni ikhophi yokugada ingozi yokulandwayo okuthile.

U-Sony Ericsson akazibophezeli olwazini olulahlekayo lwanoma yiluphi uhlobo futhi ngeke akuhlawulele ngokulahlekelwa kwakho. Kufanele njalo wenze amakhophi agade ingozi alo lonke ulwazi olugciniwe eMkhiziqweni wakho we-Sony Ericsson njengokulandwayo, ikhalenda noxhumene nabo ngaphambi kokuwuletha uMkhiziqo wakho we-Sony Ericsson ukuzokhanda nokushintshwa.

Imibandela

- 1 Isiqinisekiso sisebenza kuphela uma kukhishwe ubufakazi bokuthenga obanikwa umthengi enikwa ngumdayisi wakwa-Sony Ericsson, lobufakazi buchaza usuku okwathengwa ngalo nesirili namba**, konke akuvezwe noMkhiziqo lowo ofuna ukulungiswa noma ukushintshwa. U-Sony Ericsson uyaligodla ilungelo lokunganikezeli ngesevisi yesiqinisekiso uma le mininingwane isusive noma ishintshiwe emveni kokuba uMkhiziqo wathengwa okokuqala kumthengisi.
- 2 Uma u-Sony Ericsson elungisa noma eshintsha uMkhiziqo, lowo Mkhiziqo olungisiwe noma oshintshiwe usazoba nesiqiniseko esilingene isikhathi esisele sesiqiniseko, noma izinsuku ezingamamashumi ayisishiyagalolunye (90) emveni kokulungiswa noma kokushintshwa, kuye ngokuthi yisiphi isikhathi eside. Ukulungisa noma ukushintsha kungasho ukusetshenzisa izingxenye ezisebenza ngokufanayo kodwa esezilungiswe kabusha. Izingxenye ezikhishiwe kwafakwa ezinye esikhundleni sazo noma okuyakhile ifoni kuzoba imaphla ka-Sony Ericsson.
- 3 Lesi siqiniseko asifaki ukuhluleka kokusebenza koMkhiziqo ngenxa yokuguya, noma ukungasetshenziswa kahle kwawo, kubandakanya, kodwa hhayi kuphela, ukuwusebenzisa ngendlela engajwayelekile nengalungile futhi engahambisani nemithetho ka-Sony Ericsson yokusetshenziswa nokunakekelwa koMkhiziqo. Kanti futli lesi

siqiniseko asifaki ukuhluleka koMkhqiqo ukusebenza ngenxa yengozi, isofthiwe ukuguqulwa noma ukuhlulwa kabusha, ngokwenziwa nguMdali, ngokulimala okudalwa izinto ezizwuketshezi. Ibhethri elishajekayo lingashajwa futhi lingashajwa izikhathi ezingaphezu kwekhulu. Nokho, liyogcina ligugile – lokhu akukona ukwephuka kuti kuwukuguga okujwayelekile. Uma isikhathi sokukhuluma noma isikhathi esimiswe okwesikhasha sisifishane kakhulu, kusho ukuthi sekuyisikhathi sokuba ufake iinye ibhethri. U-Sony Ericsson uncoma ukuthi usebenzise kuphela amabhethri kanye namashaja agunyazwe ngu Sony Ericsson.

Izinguquko ezincane ekuboniseni kokugqama nombala kungenzeka phakathi kwamafoni. Kungenzeka kube namachashazi agqamile noma amnyama esibukweni. Abizwa ngam a-pixel aphundlekile futhi kungenzeka uma kunamachashazi angasebenzanga kahle futhi angalungiseki. Amachashazi amabili aphundlekile kuthiwa amukelekile.

Izinguquko ezincane ekubonakaleni komfanekiso wekhamera zingenza phakathi kwamafoni. Lokhu yinto ejwayelekile futhi akuthathwa njengemoduli yekhamera enenkinga.

- 4 Ngoba uhlelo lweselula lapho lo Mkhqiqo usebenza khona, lunikezelwa umnikezeli ongahlangene no-Sony Ericsson, u-Sony Ericsson ngeke athweswe cala ngokusebenza, ukubakhona, ukwembozeka kwamasevisi kanye nokuhleleka kwalolo luhlelo.
- 5 Lesi siqiniseko asibandakanyi ukwehuleka okudalwe ukufaka, ukuhlela kabusha, ukukhanda noma ukuvulwa koMkhqiqo ngumuntu ongagunyaziwe ngu-Sony Ericsson.
- 6 Lesi siqiniseko asikubandakanyi ukwehuleka koMkhqiqo okudalwe ukusebenza izisekeli noma ezinye izinto zokuxhuma ifoni okuyizisekeli okungesizo ezakhelwe u-Sony Ericsson ezihloselwe ukusetshenziswa noMkhqiqo.

- 7 Ukulimaza noma yisiphi isivalo (seal) salo Mkhqiqo kuyobanga ukuthi isiqiniseko singasebenzi.
- 8 AZIKHO EZINYE IZIQINISEKO EZISHIWO, KUNGABA EZIBHALWE NOMA ZOMLOMO, NGAPHANDLE KWALEZI EZINOMKHAWUKO EZIBHALWE LAPHA. ZONKE IZIQINISEKO EZICATSHANGELWAYO KUBANDAKANYA KODWA HHAYI KUPHELA IZIQINISEKO EZICATSHANGWAYO ZOKUFAKA IMPAHLA NOKULUNGELA KAHLE INHLOSO ETHILE, KONKE KUKALELWE ISIKHATHI SALESI SIQINISEKO ESINOMKHAWUKO. AKUKHO SIMO ESINGENZA U-SONY ERICSSON NOMA ABANIKEZELI BAKHE BELAYISENSE, UKUBA BAKHOKHISWE NGOKULIMALA OKUYINGONZI NOMA OKWAMABOMU KWANOMA YILUPHI UHLOBO, KUBANDAKANYA, KODWA HHAYI KUPHELA, UKULAHLEKA KWENZUZO NOMA KOKUTHENGISA, NGOKUGCWELE NJE LOKHO KULIMALA KUNGACHITHWA NGUMTHETHO.

Amanye amazwe/imibuso ayikuvumeli ukungabandakanywa noma ukunqunywa komonakalo wengozi noma wamabomu, noma umkhawukho wesikhathi esicatshangwayo, ngakho-ke lezi ziqiniseko ezibalwe ngenhla noma okungeke kwenziwa, kungenzeka kungakuthinti wena. Lesi siqiniseko asiwakhinyabezi amalungelo umthengi anawo ngaphansi komthetho osebenzayo njengamanje, futhi asiwakhinyabezi amalungelo umthengi anawo kumthengisi avela ekuthengiselaneni kwabo/isivumelwano sokuthenga.

* Ukusabalala kwamazwe kwewaranti

Uma uthenge uMkhqiqo wakho ezweni eliyilungu le-European Economic Area (EEA) noma eSwitzerland noma eRepublic of Turkey, futhi lowo mkhqiqo uma bekuhlose ukuba udayiswe kwi-EEA noma eSwitzerland noma eTurkey, uzokwazi ukusevisa umkhqiqo wakho kunoma yiliphi ezwe le-EEA country noma e-Switzerland noma eTurkey, ngaphansi kwemigomo ywaranti esebenza

ezweni lapho udinga khona ukuseviselwa, inqobo uma uMkhiqizo ofanayo udayiswa kulelo zwe ngumsabalalisi ogunyaziwe wakwa-Sony Ericsson. Uma ufuna ukuthola noma uMkhiqizo wakho uyadayiswa yini ezweni okulo, sicela ufonele i-Call Center yakwa-Sony Ericsson yangakini. Sicela wazi ukuthi amanye amasevisi ngeke enziwa noma yikuphi kuphela ezweni othenge kulo, isibonelo, ngenxa yokuthi uMkhiqizo wakho unengaphakathi noma ingaphandle elehlukile kule nhlobo edayiswa kwamanye amazwe. Ucelwa uqaphele futhi ukuthi kwesinye isikhathi ngeke kwenzake ukukhanda iMkhiqizo ene-SIM elokhiwe.

** Kwamanye amazwe/izifunda ulwazi olwengeziwe (njengekhadi lewaranti elisebenzayo) lungahle ludingeke.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



Declaration of Conformity

We, Sony Ericsson Mobile Communications AB of Nya Vattentornet

SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAD-3022101-BV

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards 3GPP TS 51.010-1, EN 301908-1, EN 301908-2, EN 301489-7, EN 301489-24, EN 300328, EN 301489-17 and EN 60950, following the provisions of, Radio Equipment and Telecommunication Terminal Equipment directive 99/5/EC with requirements covering EMC directive 89/336/EEC, and Low Voltage directive 73/23/EEC.

Lund, May 2007

CE 0682

A handwritten signature in black ink, appearing to read 'Shoji Nemoto', written over a horizontal line.

Shoji Nemoto,
Head of Product Business Group GSM/UMTS

Siyazifeza izidingo zeMiyalelo ye-R&TTE (99/5/EC).

Uhla lwezihloko

A	
Amafayela Ami	12
Ama-feed e-Web	37
amakhi	8
amamenyu	12
amamenyu amancane	12
amaqembu	19
amaringithoni	34
amaringithoni aqondene	
nomshayi lucingo	17
amaseethingi	
I-inthanethi	36
D	
declaration of conformity	54
I	
ibhethri	
ukufaka	5
ukusebenzisa nokunakekela	47
ukushaja	7
I-Bluetooth™ wireless technology	38
igama eliwumlingo	21
ihendisfri	20, 32
Ubuchwepheshe be-Bluetooth	38
i-imeyli	25
I-inthanethi	
amabhukumaka	37
amaseethingi	36
ikhamera	
amaseethingi	30
uhlolojikelele	29
imakhrofoni	15
i-master reset	41
imemori khadi	50
imeyili yezwi	20
imibiko	
i-imeyli	25
imihlahlandlela yezokuphepha	46
indlela yokudlulisa	
I-USB	39
Ubuchwepheshe be-Bluetooth	38
isevisi yokuphendula	20
isidlali sevidyo	33
isidlali somculo	32
isilawuli sezwi	20
I-SIM khadi	
kukopishelwa ku/kuvela ku	17, 18
isirekhodi somsindo	35

I-SMS	23	kuyathunyelwa	
I-T9™ Text Input	13	izithombe	31
ividyoyekhoda	29	umculo	33
ivolumu		kuyavulwa/kuyavalwa	
iringithoni	34	I-Bluetooth	38
Ispikha sasendlebeni	15		
Iwaranti Enomkhawuko	51	M	
izinga lememori	19	M2™	50
izingcingo			
eziphuthumayo	15	O	
ezomhlaba jikelele	14	okubekwe eceleni	6
ividyoye	16	oxhumene nabo	
kuyarekhodwa	35	amaqembu e	19
ukuphendula nokudikila	15	kwengezwa oxhumene	
ukushaya nokwamukela	14	nabo efonini	16
izithombe	31	oxhumene nabo bedifolthi	16
i-zoom	30		
		U	
K		uhla lwezingcingo	19
kudayelwa kabusha		uhlolojikelele lwemenyu	10
nge-othomathikhi	14	ukudayela okusheshayo	20
kuhanjwa kumamenyu	12	ukufaka umbhalo	13
kuyadluliswa		ukuhlanganisa	5
amafayela	39	ukuphendula ngezwi	22
izithombe zekhamera	30	ulimi	13
		usizo	7