


# SpotCell<sup>™</sup> Coverage Extension Kit Installation Guide




Spotwave Wireless Inc. 1 Hines Road, Ottawa ON K2K 3C7 Canada

www.spotwave.com

© 2003 Spotwave Wireless Inc. All rights reserved. Printed in Canada Spotwave and SpotCell are trademarks of Spotwave Wireless Inc. Patents pending.

780-00009-01-01


The SpotCell Coverage Extension kit extends SpotCell system coverage into hard to reach places that are blocked by obstructions such as dense walls or shadowed by elevator shafts or duct work.



#### 2. Coverage Extension antenna location



WARNING: The extended coverage antenna should be mounted in locations where people will not approach within 20 cm in front of the antenna.





The main CU and the auxillary antennas should never be co-located side by side and facing in the same direction. The two antennas must have a minimum of 10cm of separation when facing in opposite direction.

The SpotCell Coverage Extension should be connected to the Coverage Unit (CU) only after the SpotCell 100 or SpotCell 200 system has been properly installed.

### 4. Adapter cable to RG6


Join the other end of the adapter cable to one end of the provided RG6 cable with the supplied connector.






## 3. CU connection

Connect the Adapter cable to the Coverage Extension antenna (MCX) connector on the back of the CU. The CU can be powered and operational while connecting the Coverage Extension antenna.



**5. Connect RG6 to Coverage Extension Antenna** Connect the other end of the RG6 cable to the

F-connector on the Coverage Extension antenna.



Finally, mount the Coverage Extension antenna in a suitable location on the wall or ceiling.

#### LIMITED WARRANTY

Spotwave Wireless Inc. warrants to the original Purchaser that the Spotwave SpotCell Coverage Extension is free from defects in material and workmanship under normal use and service for a period of 12 months from the date of shipment from Spotwave (the "Limited Warranty Period").