USER MANUAL FOR THE TWO POSITION SWITCH (SSP17–2 POS)

Label

SSP17-2 POS
IC: 10245A-BSSPWZCR6
FCC ID: OV9BSSPWZCR6

Important Information

FCC Notice to Users

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
(2) Spyder Controls has not approved any changes or modification to this device by the user. Any changes or modification could void the user's authority to operate the equipment.
To comply with FCC exposure limits for general population / uncontrolled exposure, this device should be installed at a distance of 20 cm from all persons and must not be co-located or operating in conjunction with any other transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

Industry Canada Notice to Users

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the devices.
This device should be installed and operated with minimum distance 0.2 m from human body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage;
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
Cet appareil doit être installé et utilise à une distance minimale de 0.2 m du corps humain.

Operation

The SSP17 2-Position switch panel features an integrated 400 Mhz Transmitter that wirelessly sends messages to a receiver device. Each switch panel has a green “Transmit LED” located at the center of the switch panel. This LED should turn on whenever a button is being pressed or held, indicating that the switch panel is transmitting.

The messages sent out by each switch panel has a unique identifier which is used to distinguish them from one another. The message sent out when pressing a button also indicates which button is being pressed to allow the receiving device to perform a unique action for each button. The wireless receiver device only acknowledges messages from switch panels that are paired with it. To pair a SSP17 2-Position switch panel with the receiving device, put the receiving device into pairing mode (folowing the instructions for the receiver device), then press and hold both buttons on SSP17 2-Position switch panel to pair.

Transmitting



Not Transmitting



Troubleshooting

If the switch panel is not operating as expected, watch the Transmit LED and press one of the buttons to see if it comes on. If the LED does not come on, check the power source. Replace the CR2032 battery and try operating the switch panel again. If the Transmit LED still does not turn on when pressing a button after troubleshooting the power source, the switch panel has failed and needs to be replaced.

If the switch panel does not operate as expected, but the Transmit LED does come on when pressing the button there is likely a problem with the receiver device. If the transmit LED works but the icons on the receiving device do not change color when pressing a button, SSP17 2-Position switch panel need to be paired again to the device and repeat the procedure. If after re-pairing the SSP17 2-Position switch panel to the receiver, it still does not function correctly, the SSP17 2-Position switch panel is considered faulty and need to be replaced. If the icons on the receiving device turn red or alternate between red and green, the signal strength is not strong enough and the SSP17 2-Position switch panel is considered faulty and need to be replaced. Refer to the document of the receiver device being used for more detailed instructions on troubleshooting and pairing procedures.