

Keyboard

Model:ERK-321A 、 ERX-321A

User Manual

Important Information

For Windows® 8.1 operating system, you can use the keyboard immediately after plugging the dongle (receiver) into the USB port.

Hardware Installation

1. Plug in the dongle into your available USB port.
2. Make sure the batteries of the keyboard is installed correctly. **Please follow the polarity signs in the battery compartment.**

ID Pairing Procedure














Keyboard mouse and dongle has paired when ship out. If it can't work, please follow the steps to process the ID pairing procedure.

1. ID pairing/connect button location:
Keyboard ID pairing/connect button on the bottom of the keyboard.
2. After you plug the dongle into the USB port, please hold the keyboard close to the dongle within 0.1M and press the "Connect" button over 5 second.
3. If ID pairing is successful, the LED on the dongle will bright 2 seconds.
4. If ID pairing is fail, please follow the steps above to pair ID.

Note:

- Make sure your PC is ON and running when doing the pairing procedure.
- You don't have to pair ID again after changing batteries. If it can't work, please follow the steps above to pair ID.

Function

	Fn On	Fn Off
	F1	List of recent apps
	F2	Back
	F3	App bar
	F4	Show Desktop
	F5	Search Charm
	F6	Share Charm
	F7	Devices Charm
	F8	Setting Charm
	F9	Back
	F10	Play / Pause
	F11	Forward
	F12	Print
	Pause	R-Shift

Import Usage Information

◆ **Battery:**

1. We recommend using alkaline batteries for a longer battery life.
2. Don't mix different types of batteries or new and old batteries together. Always replaced old batteries with new and same type batteries.
3. Remove batteries after long periods of non-use. Battery leakage or corrosion may damage the device quality and cause danger.

◆ **Rating:**

Keyboard: 3VDC 20mA

Dongle: 5VDC 60mA

◆ **Max. operating temperature: 40° C**

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Caution

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'IndustrieCanadaapplicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.