


Radio Control Lil' Roadster



Battery Requirements

Requires 4 AA and 1 9-volt batteries (not included)


Battery Installation



For Remote Control:

Do not unscrew here Use a Phillips-head screwdriver to unscrew casing on controller and slide down as shown Replace 9-volt battery in controller

Controller



Helpful Hints (Maintenance and performance tips)

- · Check batteries frequently
- · Always replace with fresh alkaline batteries
- Check battery terminals for contact
- To save battery power, always turn switch off when not in operation
- Designed to run on most smooth surfaces

Warning : Change or modification to this unit not expressly approved by the party responsible for compliance could void the user(s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or televisin reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technican for help.