

USER GUIDE
Wireless Charger
MODEL: MC-007

APPEARANCE AND FUNCTION



- 1. Cover shell
- 2. Micro USB connection
- 3. Charge and discharge red/green indication light
- 4. Wireless charge zone
- 5. Anti-slip mat


SPECIFICATION

- Model: MC-007 ● Size: 95x95x10mm
- Input: 5V \approx 2.0A 9V \approx 1.5A
- Output: 5V \approx 1.0-1.5A 9V \approx 1.0A
- Power: 5W/7.5W/10W(Max)
- Working temperature: -5-45°C ● Weight: 82g


ITEM LIST

- Wireless charger X1
- Instruction X1
- Charge cable X1
- Specific accessories are based on real products

INSTRUCTION




- Charging cable interface: Micro USB



- Charging display: after turning on the power, the red/green light will be on for seven seconds, if no chargeable device is detected, the green light will go off.



- Charging method and requirement: the mobile phone should have wireless charge receiver. When the mobile phone comes with fast charge, the green light turns on after three seconds. When the mobile phone does not come with fast charge, the green light turns on after six seconds. The green light turns on for 20 seconds once fully charged. The red light turns on if low voltage occurs or the phone is being overheating.



- When using wireless charger, place it in the correct way as shown in Figure 4.

PRECAUTIONS

- Do not cruelty throw, carry, knock or drop the wireless charger. This may cause damage to the charger and its internal circuits.
- Do not put this product in water or fire, prevent the wireless charger exposure to sunlight or rain for long time.
- Do not store the wireless charger under environments with high temperature, flammable liquid, gas or other flammable and explosive objects.
- Place the wireless charger in a dry environment when not in use.
- Do not disassemble the product or use a product which is already damaged.
- Disconnect to the power after charging.
- Please read the instruction carefully before use.
- Digital devices charging mode: by wireless charge, with a distance between 2 to 12mm.



FCC CONTENT

- This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.