


User Manual

Remote Control

Model: T14

FCC ID: 2AM69T14



1 Pairing Procedure

Long press shutter button B to enter setup, press power button A to navigate. Press shutter button B to enter general setting, select RF CTRL. Turn on RF CTRL.

With camera RF CTRL on, press power Remote Control button and hold on for 3seconds to turn on the controller and pair . The LED Indicator will blink blue.

2 Using your remote

Photo Shot: Press the Photo button once to shoot a single picture, the LED indicator of remote flickers twice.


Video Record: Press the Video button once to start recording, the LED indicator flickers twice also, press the Video button again to stop.

Power Off button: Press the Power Off button and hold on for 3seconds to turn off the camera, the LED indicator turns off accordingly.

3 Replace the Battery

When the battery capacity is low, LED indicator flickers once per second. You need to replace with a new button battery.

How to replace a button battery?



1. Begin by purchasing a replacement battery for your remote. You need a button battery with model No. CR2032.
2. Screw the round cap at the bottom of remote. Please see above pictures.
3. Remove the old battery.
4. Insert the new battery into the slot where the old battery was, with the flat surface up.

Note:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This modular complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.