
Y860OA Case Quick Start

Getting to Know Your Case



- 1. Device holder
- 2. Product sticker
- 3. Protective folio
- 4. Magnetic stand
- 5. Power Key
- 6. OLED screen
- 7. SIM Card slot
- 8. SD Card slot
- 9. Reset hole

Set Up Your Case

- 1. Insert a SIM-Card into the SIM-Card slot
- 2. Press power key to power on the case;
- 3. Find out the SSID(network name) on product sticker; (Y860-XXXX)

On your device:

- 4. Select the network name on your device and enter password; (password is the same as last 8 digits of Device ID)
- 5. Start to access to internet

Expanded memory- Micro SD Card

You can insert a Micro SD card (up to 32GB) to the Micro SD card slot for expanded memory using.

Detaching your device

- 1. To detach your device from case, move back one of the holder
- 2. Your device is then released.

Storing your device for travel

- 1. Insert your device in the case holder
- 2. Close the folio.

OLED Screen



Network Indicators

Your case will display one of the following network indicators to let you know which networks you are connected to.



Connected to 4G LTE network



Connected to HSPA+ network

Battery status icon

lcon	Description
Animating	The battery is charging.
Solid display	The battery is fully charged (100%)
Quick blinking	Battery power is low (less than 15%). Recharge the battery.

Charging the battery

If the battery status icon is quick blinking, the case battery needs to be charged.

- 1. Plug the micro-USB cable into charging port, and the other end into a USB port of a 5V/2A charger. The status of battery icon changes to animating as the battery charges.
- 2. Charge the battery until the battery icon is solid display, then you can unplug the device and charger.

Note:

- A full charged battery working hours is around 10 hours
- Charge the battery if the battery icon is blinking.
- Turn off the case when it's not in use.

Battery take-back at product end of life

- 1. Pry off top cover with screwdriver.
- 2. Unscrew magnesium alloy with screwdriver.
- 3. Detach battery from circuit board.
- 4. Dispose of your product and battery according to local laws

CAUTION : RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Safety and Use

We recommend that you read this chapter carefully before using the case. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use of the case or of use contrary to the instructions contained herein.

Conditions of Use

- Switch the case off before boarding an aircraft.
- Switch the case off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, the case can interfere with other electrical or electronic devices, or equipment-using radio frequencies.
- Switch the case off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, chemical plant, or in any potentially explosive atmosphere.
- When the case is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc.
- Do not let children use the case without supervision.
- Always handle the case with care and keep it in a clean and dust-free place.
- Do not allow the case to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The recommended operating temperature range is 0°C to +45°C, humidity range is 10%-90%.
- Do not open, dismantle or attempt to repair the case yourself.
- Do not drop, throw or bend the case
- Do not paint it.

Federal Communications Commission (FCC) Declaration of

Conformity

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radio Waves Federal Communications Commission Notice (United States)

The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. The highest tested SAR value for this device compliance against the standard is 1.39 W/kg.

Although the SAR is determined at the highest certified power level, the actual SAR Level of the modem while operating can be well below the maximum value. This is because the modem is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the modem.

While there may be differences between SAR levels of various modems and at various positions, they all meet the government requirement for RF exposure. The modem meets FCC RF exposure guidelines provided that it is used with this device at least 0.5cm form the body.

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of modem. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of use to keep data card away from the head and body. (fact sheet n°193) Additional WHO information about electromagnetic fields and public health are available on the following website: http://www.who.int/peh-emf.

Note:

The modem has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

The modem generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning your modem off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

- Increase the separation between your modem and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Caution:

- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all WiFi product marketed in US must fixed to US operation channels only.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of <u>www.fcc.gov/oet/ea/fccid</u> after searching on FCC ID: 2ACCJB005.