

Quick Start Guide



This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on page 19 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.0 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

The mobile phone is in compliance with the requirement of EN 60950-1: 2006 amendment A12: 2011. There will appear a warning box when the volume level is over 4. If the user selects left soft key in the warning box, the volume can be increased and the phone will repeat the acknowledgement more than once every 20h of cumulative listening time.




PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.



ALCATEL
onetouch

Your mobile.....



- 1 Left soft key
- 2 Call logs (idle screen) Send call
- 3 Voice mail (long key-press)
- 4 Lock Key (long press *0# key)
- 5 Right soft key
- 6 Power on/Power off End call
- 7 Vibrate alert
- 8 Navigation key : Menu/Confirm an option
- Increase volume ▲
- Decrease volume ▼
- New SMS
- Profiles ▶

1.1 Keys

- Navigation key
Confirm an option (press the middle of the key)
- Send call
Access to call log (idle screen)
- Power on/off the handset (long press)
End call
Return to idle
- Left soft key
- Right soft key
- Dial the voice mail number (long press)
- From Idle screen
- Press: enter zero
- Press and hold: input +, "+" are used for dialing an international call.
- In Edit mode:
- Press: access the Symbols table
0 (add numbers)
- From Idle screen
- Press: input *
- Long press: lock keypad
In Edit mode:
- Press: change input methods
- From Idle screen
- Press: input #
- Press and hold: activate/deactivate the vibrator
In Edit mode:
- Press: input space

1.2 Idle screen icons

- Battery charge level.
- Meeting mode: your phone vibrates, but neither rings nor beeps.
- Silence mode: your phone neither rings, beeps nor vibrates.
- Flight mode.
- Headset connected.
- Alarm clock programmed.
- Missed calls.
- Roaming.
- Level of network reception.
- Unread SMS.
- Unread MMS.
- Message full.
- Call divert.

2 Getting started

2.1 Set-up

Removing and installing the back cover



Removing and installing the battery




Inserting and removing TF card



Inserting and removing SIM



Charging the battery



Connect the battery charger to your phone and outlet respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the idle screen.

3 Calls.....

3.1 Making a call

Dial the desired number, press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the key. To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your Voice mail⁽¹⁾

You can see SIM voice mail in this menu.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, your calendar, text messages, etc. without hanging up or dropping the call.

⁽¹⁾ Contact your network operator to check service availability.

4 Camera



This function enables you to take pictures. Press to take the picture.

5 Call history



You can access your call memory by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see all call history.

6 Audio player



Use this function to play audio files. Press to play/pause the audio player, short press or to last or next audio, in audio player interface, press and to tune volume.

7 Tools.....



7.1 Alarm

Your mobile phone has a built-in alarm clock with snooze feature.

7.2 Calculator

Press the up, down, left, right and OK key to select +, -, ., and = respectively.

Press to delete the figure.

7.3 Calendar

Once you enter this menu, there is a monthly-view calendar for you to view the date; you can go to any day you want.

7.4 Notes

You can create a note in text format by accessing "Notes" from the main menu.

7.5 Bluetooth

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

7.6 Unit conversion

Unit conversion support weight conversion and length conversion.

7.7 Fake Call

You can create fake call through this function.

7.8 Call filter

You can create blacklist through this function.

7.9 Torch

Turn on/off the torch as per your need. In idle screen, press and hold 5 key to activate/deactivate the torch light.

7.10 Internet service

This function enables you to surf the Internet using the mobile phone. Note: Consulting the local network operator for related fee and specific setup.

7.11 STK

STK service is the tool kit of SIM card. This phone supports the service function. The specific items depend on SIM card and network. Service menu will be automatically added to the phone menu when supported by network and SIM card.

8 Messages



8.1 Create SMS

From the main menu select "Message" to create text message. You can type a message send it to a recipient in the SIM card directory. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access all the messaging options.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

8.2 Create MMS

Select Options-Add subject, it will switch to MMS interface automatically.

9 Multimedia.....



9.1 Video player

Use this function to play video files. Press to play/pause the video player; short press up or down direction key to last or next video, press left and right direction key to tune volume.

9.2 FM radio

Your phone is equipped with a radio. You can use the application as a traditional radio with saved channels. In FM radio interface, press to play/pause the playing process of the current channel, press and to tune volume.

9.3 Image viewer

You can view images through this function.

9.4 Sound recorder

Use this function to record audio files. The phone support WAV and AMR. The recording file you stopped will be stored in audio file automatically.

10 File manager



The phone provides a certain space for users to manage files and support the memory card. The capacity of the memory card is selectable. You can use the file manager to conveniently manage various directories and files on the phone and the memory card.

11 Contacts



11.1 Consulting your contacts

You can access your call memory by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see all call history.

11.2 Adding a contact

Select the menu "New" then save it to "Phone", "SIM" as you like.

12 Settings.....



From the main menu, select the menu and select the function of your choice in order to customize your telephone: Profiles, Phone setting, Call settings, etc.

13 Input mode

This mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCL Communication Ltd.

© Copyright 2015 TCL Communication Ltd All rights reserved

TCL Communication Ltd reserves the right to alter material or technical specification without prior notice.

