

Quick Start Guide




www.sar-tick.com

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on page 19 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.0 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

The mobile phone is in compliance with the requirement of EN 60950-1: 2006 amendment A12: 2011. There will appear a warning box when the volume level is over 4. If the user selects left soft key in the warning box, the volume can be increased and the phone will repeat the acknowledgement more than once every 20h of cumulative listening time.



- 1 Left soft key
- 2 Call logs (idle screen) Send call
- 3 Voicemail (long key-press)
- 4 Lock Key (long press *0# key)
- 5 Right soft key
- 6 Power on/Power off End call
- 7 Silent mode
- 8 Navigation key: Music Increase volume Decrease volume New SMS Profiles

1.1 Keys

- Navigation key Confirm an option (press the middle of the key)
- Send call Access to call log (idle screen)
- Power on/off (long press) End call
- Return to idle
- Left soft key
- Right soft key
- Dial the voicemail number (long press)
- From Idle screen - Short key-press: enter zero - Long key-press: input +, "+" is used for dialling an international call.
- In Edit mode: - Short key-press: access the Symbols table 0 (add numbers)
- From Idle screen - Short key-press: input * - Long press: lock keypad In Edit mode: - Short key-press: change input methods
- From Idle screen - Short key-press: input # - Long key-press: activate/deactivate vibration mode In Edit mode: - Short key-press: input space

1.2 Idle screen icons

- Battery charge level
- Silence mode: your phone neither rings, beeps, nor vibrates
- Flight mode
- Headset connected
- Alarm clock programmed
- Missed calls
- Roaming
- Level of network reception
- Unread SMS
- Message full
- Call divert

2 Getting started

2.1 Setup

Removing and installing the back cover



Removing and installing the battery




Inserting and removing TF card



Inserting and removing SIM



Charging the battery



Connect the battery charger to your phone and outlet respectively.

- Charging may take about 20 minutes to start if the battery is completely drained.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The outlet must be near to the phone and easily accessible (avoid electric extension cables).
- When using your phone for the first time, you are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger; reduce the backlight time, etc.

The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the idle screen.

3 Calls.....

3.1 Making a call

Dial the desired number, press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the key. To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your Voicemail (1)

You can listen to your voicemail messages using this function.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, text messages, etc. without hanging up or dropping the call.

(1) Contact your network operator to check service availability.



ALCATEL onetouch

English - CJB1BK2ALAAA

4 Camera



This function enables you to take pictures. Press to take a picture.

5 Call logs



You can access your call memory by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see the entire call history.

6 Music



Use this function to play audio files. Press to play/pause the audio player, short press or to play the previous or next audio file. Using the audio player interface, press and to adjust the volume.

7 Tools



7.1 Alarm

Your mobile phone has a built-in alarm clock with snooze feature.

7.2 Calculator

Press the up, down, left, right and OK key to select +, -, x, ÷ and = respectively.

Press to delete the figure.

7.3 Calendar

Once you enter this menu, there is a monthly-view calendar for you to view the date; you can go to any day you want.

You can create a note in text format by selecting "Add new schedules" from the main menu.

7.4 Unit conversion

Unit conversion supports weight conversion and length conversion.

7.5 Fake Call

You can make a fake call using this function.

7.6 Call filter

You can create a blacklist & whitelist using this function.

7.7 Torch

Turn the torch on/off according to your preference. From the idle screen, long key press 5 key to activate/deactivate the torch light.

7.8 Browser

This function enables you to surf the Internet using your mobile phone. Note: Consult your local network operator for related fees and specific setup.

7.9 Service

STK service is the tool kit for your SIM card. This phone supports the service function. The specific items depend on SIM card and network. Service menu will be automatically added to the phone menu when supported by the network and SIM card.

8 Message.....



8.1 Create SMS

From the main menu, select "Message" to create a text message. You can type a message and send it to a recipient in the SIM card directory. You can also insert a pre-defined message from the "Templates" menu. While writing a message, select "Options" to access all of the messaging options.

Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

9 Media.....



9.1 Video

Use this function to play video files. Press to play/pause the video player, short press the up or down direction key to tune volume, press the left and right direction key to go to the previous or next video.

9.2 FM radio

Your phone is equipped with an FM radio. You can use the application as a traditional radio with saved channels. In FM radio interface, press to play/pause the playing process of the current channel, press and to tune volume.

9.3 Image

You can view images using this function.

9.4 Recorder

Use this function to record audio files. The phone supports WAV and AMR files. The recording file you stopped will be stored in the audio file folder automatically.

10 My files.....



The phone provides a certain amount of space for users to manage files and support the memory card. The capacity of the memory card is selectable. You can use the file manager to conveniently manage various directories and files on the phone and the memory card.

11 Contacts



11.1 Consulting your contacts

You can access your call memory by pressing from the idle screen, or press the key and select the icon from the menu. In this menu, you will see all contacts.

11.2 Adding a contact

Select "Add contact" from the menu, then save it to either "Phone" or "SIM".

12 Settings.....



From the main menu, select the menu icon and select the function of your choice in order to customize your telephone: Profiles, Phone settings, Call settings, etc.

13 Input mode

This mode allows you to insert a special character by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCL Communication Ltd.
© Copyright 2015 TCL Communication Ltd All rights reserved
TCL Communication Ltd reserves the right to alter material or technical specification without prior notice.

