
Your telephone 👛








WAP <

File manager >

- Sub-display (2) Volume un
- 4 Volume down A Left softkey
- Δnswer/Send call
- Voicemail
- Fnd call
- Display events (call, SMS, MMS, alarm...) or current status.







- Wibration alert Navigation key ⁽¹⁾ Menu/Confirm an option O Play/Pause key Messages A Directory V
- Call memory
- Right softkey Switch on/Switch off
- (1) Depending on your network operator.

Crystal A

Confirm an option (press the middle of the kev) Access slide show and music player (long keypress)

Send a call Access call memory (Redial) (short keypress)

Access events (long keypress)

Switch on/Switch off the telephone (long keypress) End call

Return to the main screen Left softkey

(R) Right softkey

Access your voicemail (long keypress)

In Edit mode-

Short keypress: change input methods Switch from T9 predictive mode to Normal mode

- Long keypress: access the Symbols table In Edit mode

Short keypress: access the language list

- Long keypress: enter zero

From main screen

Short keypress: # Long keypress: activate/deactivate the vibrator In edit mode

Short keypress: u (space)

Long keypress: add a word

Short keypress: Play/pause music, Radio off. Long keypress: Lock/Unlock the side keys (flip off).

Short keypress: Previous/next song (in the playing mode) Previous/next channel (Radio on) Long keypress: Volume up/down

least one message on your SIM card.

Getting started

Removing and installing the back cover





Inserting and



Place the SIM card with the chip facing downwards and slide it into During a call, you can use your directory, your diary, short message its housing. Make sure that it is correctly inserted. To remove the etc. without losing your correspondent by pressing the 🔸 key. Message list is full: your terminal cannot accept any new card, press it and slide it out. Please power off your phone before messages. You must access the message list and delete at you remove the SIM card.

2.2 Power on your phone

Hold down the O key until the telephone powers on.

2.3 Power off your phone

Hold down the O key from the main screen

Making a call

you make a mistake, you can delete the incorrect digits by pressing main screen. the right softkey.

To hang up the call, press the O key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail (1)

To access your voicemail, hold down the __ key.

3.3 Receiving a call

When you receive an incoming call, press the () key to talk and then hang up using the O key.

3.4 Available functions during the call

(1) Contact your network operator to check service availability.

Dial the desired number then press the O key to place the call. If You can access your call memory by pressing the O key from the

Call register

4 2 Events

By holding down he key from main screen or accessing from main menu, it allows you to view a list of your all latest 20 events (SMS, MMS, WAP Alerts, Voicemail and unanswered calls).

4.3 Billing

You can access different items with this option: Amount, Duration GPRS counter Been duration

4.4 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

Directory

5.1 Consulting your directory

To access the **directory** from the main screen, press the ▼ key or press the \(\) key and select the \(\overline{\overlin

5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

6.1 Create message

From the main menu select "Messages" to create text/multimedia message. You can type a message and you can also modify a Hold down the # wey to get the decimal point. Confirm with the predefined message in **Templates** or customize your message by key or the left softkey. adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select "Options" to access 8.5 Converter all the messaging options. You can save your messages that you Unit converter and Currency converter. send often to Drafts or Templates (MMS only).


6.2 Inbox

All received messages (read and unread) are stored in the same




My settings.....

From the main screen, select the icon menu and select the free on your phone and memory card (if any).







Rluetooth

Access this feature by selecting "Tools" from the main menu, then "Bluetooth"

8.2 Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments. etc. Days with events entered will be marked in color.

Your cellphone has a built-in alarm clock with a snooze feature.

8.4 Calculator

8 6 Voice memo

This feature enables you to record a call by selecting "Voice memo" or assign it to a contact in the directory. while communicating. To record a sound, select "Voice memo", then "New record"

8.7 Memory status

It will indicate how much space is used and how much is currently

It maintains copy of contacts between Phone Directory and memory 10.5 Unknown files card, in case of phone errors, theft or disasters.

8.9 My shortcuts

Access the shortcuts already programmed. To program new shortcuts: select "My shortcuts" if you want to create a quick access to a function, You will have access to all files stored in memory card here. Directory, or WAP Bookmarks, etc.







Access Wap options: Homepage, Bookmarks, Recent pages, Go to URL and Profiles.

File manager

You will have an access to all audio and visual files stored in phone or memory card in File manager.

10.1 My audios

Choose an audio for the ON/OFF screen, for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

10.2 My images

You can select an image or a photo as wallpaper, ON/OFF screen,

10.3 My videos

The "My videos" album contains all video clips embedded and downloaded in phone or memory card.

10.4 My creations

This feature stores all the photos captured by your cellphone.

Store files of unsupported format.

Memory card



slide it in the opposite direction to lock it.

10.7 Formats and compatibility

- Sounds: mp3, m4a, aac, midi, wav, amr
- Videos: 3gp, mjpg

Camera

shooting videos that you can use in different ways:

- store them in your "File manager"
- send them in a multimedia message (MMS) to a cellphone or an
- customize vour main screen
- select them as incoming call image to a contact in your directory.
- transfer them by data cable or microSD card to your computer.
- modify your photos through adding frames.

Access this feature from the main menu by selecting "Multimedia player". You will have full access to "Music player", "Video player", "Image viewer" and "FM radio"

🚺 Games & Applications 🔢





Making the most of your cellphone.....

You can download software upgrade for free from this website.

6 Latin input mode.....

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- Predictive with the T9 mode: this mode speeds up the writing of your text.
- key in edit mode:

Short keypress: Access the language list Long keypress: Enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved @ Copyright 2009 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.



11

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely Use only headphones recommended by TCT Mobile Limited and

Battery charge level Vibrate alert: your phone vibrates, but neither rings nor beeps except for the alarms Rivetonth status (Rive - Activated)

> Λ Bluetooth status (Connected to an audio device). Headset connected Call forwarding activated: your calls are forwarded.

W.

12

Alarm clock programmed Level of network recention Voicemail message arrived.

Main screen icons

Unanswered calls. WAP alerts (1 Reaming

Memory card scanning in progress Memory card scanning completed.

> Line switching (1): indicates the selected line. GPRS connection status (Blue - Activated). Shown only in no ciphering mode while calling, sending/

receiving SMS. Multimedia player active

USB cable connected Recention of a message in progress

Sending a message Silence mode: your phone neither rings, beeps nor vibrates except for the alarms.

Message unread

Antenna off mode A2DP connected.

(1) Contact your network operator to check service availability.



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and

- Images: jpg, gif, bmp



Your cellphone is fitted with a camera for taking photos and PC suite is provided on www.branddesignlab.com.

- email address.

2 Multimedia player.....

Your Alcatel phone may include (1) some Java™ applications and

Profiles

and environments.

Depending on your country or your operator.

English - CJB2111ALAAA

Thank you for buying Crystal mobile phone

masterniese of craftsmanship, designed to be the perfect gift for every occasion. It is a delicate product and should be treated as a jewel. It should be handled carefully scratching. Do not let your children play with it, it is not a toy.

In order to help maintain the beauty of your Crystal mobile phone over time, carefully polish it with a soft, lint-free cloth when necessary. Avoid contact with harsh cleansers. We wish you the most enjoyable experience with your new Crystal mobile phone. improper use or use contrary to the instructions contained herein.

• TRAFFIC SAFFTY-

risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to regulations for disposal of electronic products. refrain from using their cellohone when the vehicle is not parked. Check the laws and Remember to make back-up copies or keep a written record of all important information regulations on the use of wireless telephones and their accessories in the areas where stored in your cellphone. you drive. Always obey them. The use of these devices may be prohibited or restricted

When driving, do not use your cellphone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your cellphone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem

- do not place your cellphone on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from cellphone RF energy.

• CONDITIONS OF USE-

You are advised to switch off the cellphone from time to time to optimize its performance Switch the cellphone off before boarding an aircraft to avoid prosecution.

Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use cellphones can signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any notentially explosive atmosphere.

When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the cellphone you should hold it against the ear on the opposite side to the device, if any. To avoid hearing impairment, answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

Telephone warranty

Your cellphone is guaranteed against any deviation from technical

specifications for a period of twelve (12) months from the date

The warranty terms defined in the manual also apply to the battery

months (2) from the date of purchase shown on your original invoice.

Under the terms of this warranty, you must immediately inform

or its affiliates, which are listed on our website http://www.alcatel-

vendor or repair centre will decide whether to replace or repair, as

be defective; this warranty covers the cost of parts and labour but

modification or replacement of products, shall entitle to a ONE (1)

month warranty unless there are statutory provisions to the contrary.

1) not following the instructions for use or installation,

provisions are applicable in your jurisdiction.

and for approximately 200 more recharges.

using reconditioned components offering equivalent functionality.

Do not let small children use your cellphone without supervision

completely satisfied with it

and/or accessory caused by:

provisions (

When replacing the cover please note that your cellphone may contain substances that • PRIVACY:

Always handle your cellphone with care and keep it in a clean and dust-free place. Do not allow your cellphone to be exposed to adverse weather or environmental manufacturer's recommended operating temperature range is -10°C to +55°C (the max value depends on device, materials and housing paint/texture).

and out into a protective case when not used, in order to avoid any damage, such as

Over 55°C the legibility of the cellphone's display may be impaired, though this is

It is the user's sole responsibility to ensure that prior authorization be obtained. emporary and not serious.

> Do not open or attempt to repair your cellphone yourself. Do not drop, throw or try to bend your cellphone.

Do not paint it

We recommend that you read this chapter carefully before using your phone. The Use only batteries, battery chargers, and accessories which are recommended by TCT • BATTERY AND ACCESSORIES: manufacturer disclaims any liability for damage, which may result as a consequence of Mobile Limited and its affiliates and are compatible with your cellphone model.TCT Before removing the battery from your cellphone, please make sure that the Mobile Limited and its affiliates disclaim any liability for damage caused by the use of cellphone is switched off. other chargers or batteries.

Given that studies show that using a cellphone while driving a vehicle constitutes a real Your cellphone should not be disposed of in a municipal waste. Please check local

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights,

Batteries must be disposed of in accordance with locally applicable environmental or when playing video games. These seizures or blackouts may occur even if a person regulations. Only use the battery for the purpose for which it was designed. Never never had a previous seizure or blackout. If you have experienced seizures or blackouts, use damaged batteries or those not recommended by TCT Mobile Limited and/or or if you have a family history of such occurrences, please consult your doctor before its affiliates playing video games on your cellphone or enabling a flashing-lights feature on your cellphone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the cellphones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle. twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Plav in a well lit environment
- Play at the farthest distance possible from the screen.

When you play games on your cellphone, you may experience occasional discomfort These collection points are accessible free of charge. All products with this sign interfere with other electrical or electronic devices, or equipment using radio frequency, in your hands, arms, shoulders, neck, or other parts of your body. Follow these must be brought to these collection points. Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other In non European Union jurisdictions: musculoskeletal disorders:

Take a minimum of a 15-minute break every hour of game playing

- If your hands, wrists, or arms become tired or sore while playing, stop and rest for they are to be taken to collection points for them to be recycled. several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the recyclewirelessphones.com game and see a doctor



Prolonged exposure to music at full volume on the music player may cause the listener's hearing impairment. Adjust the volume before placing headphones on or in your ear. Only use headphones recommended by TCT Mobile Limited and its affiliates 14

13

2) not being compliant with technical and safety standards applicable Troubleshooting My cellphone has a low level or autonomy • Make sure you respected the complete charge timing (minimum) • Make sure you respected the complete charge timing (minimum)

- 3) improper maintenance of sources of energy, and of the overall Congratulations on choosing this cellphone - we hope that you will be electric installation
 - 4) accidents or consequences of theft of the vehicle in which follow the instructions below: the cellphone is transported, acts of vandalism, lightning, fire, • You are advised to switch off the telephone from time to time to humidity, infiltration of liquids, inclement weather,
 - not supplied or not recommended by TCT Mobile Limited or its affiliates, without their express written consent for such,
- and accessories sold with the cellphone but for a period of six (6) 6) any servicing, modification or repair performed by individuals not authorized by TCT Mobile Limited or its affiliates, the vendor or the approved maintenance centre.
- your vendor (or any repair centre approved by TCT Mobile Limited 7) use of the cellphone and/or its accessory for a purpose other My cellphone will not switch on than that for which it was designed,
- mobilephones.com) in case of a conformity defect on your cellphone, 8) normal wear,
- and present the invoice given to you at the time of purchase. The 9) malfunctions caused by external causes (e.g., radio interference Check the battery contacts, remove and reinstall your battery, from other equipment, power voltage fluctuations)
- appropriate, all or any part of the cellphone or accessory found to 10) modifications made to the equipment even if required by changes My phone has not responded for several minutes in regulations and/or modification of network parameters,
- excludes any other costs. Repair or replacement may be carried out 11) faulty connections resulting from unsatisfactory radio transmission Remove the battery and re-insert it, then switch the phone back on or caused by the absence of radio relay coverage.
- Servicing under the terms of this warranty, especially repair, 12) equipment on which markings or serial numbers have been removed or altered, and handsets on which labels have been removed or deteriorated shall be excluded from the warranty.

This warranty shall not apply to damage or defects to your cellphone In accordance with the applicable law, your product is warranted against hidden defects (defects inherent in the design, manufacture, My cellphone turns off by itself

There are no express warranties, whether written or oral, other The mandatory warranty period may vary if overriding statutory than this printed limited warranty, express or implied, of any nature • Check the battery charge level

The life of a rechargeable cellphone battery in terms of In no event shall TCT Mobile Limited or its affiliates be liable for conversation time, standby time, and total service life, will incidental or consequential damages of any nature whatsoever, depend on the conditions of use and network configuration. including but not limited to trading loss, commercial loss, to the full Batteries being considered expendable supplies, the extent those damages can be disclaimed by law. Some countries/states specifications state that you should obtain optimal performance do not allow the exclusion or limitation of incidental or consequential for your cellphone during the first six months after purchase damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

ase note that you must respect the laws and regulations in force in your iurisdiction or other jurisdiction(s) where you will use your cellphone regarding taking photographs and recording sounds with your cellphone. Pursuant to such Made with CRYSTALIZEDTM. Swarovski Elements, your Crystal mobile phone is a unique conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy.

if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your cellphone (including the operator) disclaim any liability which may result from the

- Observe the following precautions for battery use: Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in the garbage or store it at temperatures above 60°C.

This symbol on your cellphone, the battery and the accessories the power required to reach the network. In general, the closer you are to a wireless base means that these products must be taken to collection points at the station antenna, the lower the power output of the cellphone Before a cellphone model end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment

 Collection bins at points of sale. then be recycled, preventing substances being disposed of in the

environment, so that their components can be reused. In European Union countries:

Items of equipment with this symbol are not be thrown into ordinary bins if your time legit or using "hands-free" devices to keep cellphones away from the head jurisdiction or your region has suitable recycling and collection facilities; instead and body. (fact sheet n°193). Additional WHO information about electromagnetic fields In the United States you may learn more about CTIA's Recycling Program at www.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF LISED BATTERIES ACCORDING TO THE INSTRUCTIONS.

15

Before contacting the aftersales department, you are advised to • After a partial charge, the battery level indicator may not be exact. • Check your subscription status with your operator (credit, SIM • Try later if the network is busy

- ontimize its performance
- specified on your original invoice, subject to any other specific 5) connecting to or integrating into the cellphone any equipment You are advised to fully charge () the battery for optimal Make sure that your battery is not completely discharged; the The caller's name does not appear when a call is received
 - · Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

and carry out the following checks:

- Press 🔾 until the screen comes on
- · Check the battery charge level
- then turn your telephone back on

- Press the ○₀ key

My screen is difficult to read

- Clean vour screen
- Use your cellphone in accordance with the recommended

- Check that your keypad is locked when you are not using your Make sure the chip on your SIM card is not damaged or scratched

- 3 hours)
- Wait for at least 20 minutes after removing the charger to obtain card valid, etc.) an exact indication

The chargers designed for your cellphone meet with the standard for safety of information

technology equipment and office equipment use. Due to different applicable electrical

THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE

Your cellphone is a radio transmitter and receiver. It is designed and manufactured not

the general population. The guidelines are based on standards that were developed by

studies. These guidelines include a substantial safety margin designed to ensure the safety

The exposure standard for cellphones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the

Federal Communications Commission of the US Government (FCC), or by Industry

Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted

level of the cellinhone while operating can be well below the maximum value. This is

is available for sale to the public, compliance with national regulations and standards

The highest SAR value for this model cellphone when tested is 1.08 W/Kg for use at the

While there may be differences between the SAR levels of various cellphones and at

various positions, they all meet the government requirement for RF exposure. For body-

worn operation, the cellphone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 1.5 cm from the body. Use of other

accessories may not ensure compliance with FCC RF exposure guidelines.

The World Health Organization (WHO) considers that present scientific information does

not indicate the need for any special precautions for use of cellphones. If individuals are

concerned, they might choose to limit their own or their children's RF exposure by limiting

and public health are available on the following website: http://www.who.int/peh-emf.

Note: This equipment has been tested and found to comply with the limits for a Class B

digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

using standard operating positions with the cellphone transmitting at its highest certified

specifications, a charger you purchased in one jurisdiction may not work in another

urisdiction. They should be used for this purpose only.

Travel charger: Input: 100-240 V, 50/60 Hz, 0.15 A

Lithium 750 mAh

of all persons, regardless of age and health.

power level in all tested frequency bands.

ear and 1.09 W/Kg for use close to the body.

• RADIO WAVES-

TO RADIO WAVES

nust be shown

Output: 5 V 500 mA

Characteristics of nower sunnly (depending on the country)

My cellphone will not charge properly

- battery charge indicator can take several minutes and may be . Check that you have subscribed to this service with your operator accompanied by a quiet whistling sound
- . Make sure charging is carried out under normal conditions (0°C
- · Make sure your battery is inserted. It must be inserted before plugging in the charger
- · Make sure you are using an Alcatel battery and charger
- When abroad, check that the electrical current is compatible

My cellphone will not connect to a network

- · Try connecting in another location
- · Verify the network coverage with your operator
- . Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

SIM card error

- Make sure the SIM card has been correctly inserted
- . Verify with your operator that your SIM card is 3V compatible; the old 5V SIM cards cannot be used

Unable to make outgoing calls

- Make sure you have dialled a valid number and press the key · For international calls, check the country and area codes
- Make sure your cellphone is connected to a network, and that the network is not overloaded or unavailable
- · Check your subscription status with your operator (credit, SIM card valid etc.)
- · Make sure you have not barred outgoing calls

Regrient or relocate the receiving antenna.

- Increase the separation between the equipment and receive
- General information Connect the equipment into an outlet on a circuit different from that to which the
- receiver is connected.
- Website: www.alcatel-mobilephones.com Consult the dealer or an experienced radio/ TV technician for help. Changes or modifications not expressly approved by the party responsible for Hot Line Number: see "TCT Mobile Services" leaflet or go to our

compliance could void the user's authority to operate the equipment For the receiver devices associated with the operation of a licensed radio service

(e.g. FM broadcast), they bear the following statement: On our Internet site, you will find our FAQ (Frequently Asked This device complies with Part 15 of the FCC Rules. Operation is subject to the Questions) section. You can also contact us by e-mail to ask any condition that this device does not cause harmful interference.

For other devices, they bear the following statement questions you may have This device complies with Part 15 of the ECC Rules. Operation is subject to the

to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for (1) this device may not cause harmful interference

(2) this device must accept any interference received, including interference that independent scientific organizations through periodic and thorough evaluation of scientific may cause undesired operation

Your cellphone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As cellphone devices offer a range of functions, they can be used in positions 850 and 1900 MHz bands. other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset. If you are not using headset ensure that whatever product is used is free of any metal and that it positions the phone Protection against theft (1) at least 2 cm away from the body. Your cellphone is identified by an IMFI (cellphone serial number)

Although the SAR is determined at the highest certified power level, the actual SAR • LICENCES

pecause the cellphone is designed to operate at multiple power levels so as to use only Obigo®

is a registered trademark of Obigo AB

network (check for overloaded or unavailable network)

You can adjust the volume during a call by means of the key

Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not dialled

. Make sure that you have correctly recorded the number in your file

I am unable to use the features described in the manual

My callers are unable to leave messages on my voicemail

· Contact your network operator to check service availability

Make sure you have not forwarded incoming calls

. Make sure that you have not barred certain calls

· Your caller has concealed his/her number

The sound quality of the calls is not optimal

I am unable to create a file in my directory

professional or personal directories)

· Check the radio reception icon level

includes this service

a foreign country

microSD Logo is a trademark



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCT Mobile Limited person from using it, even with a different SIM card. and its affiliates is under license. Other trade marks and trade names are those of their respective owners.

CRYSTAL A Bluetooth QD ID B014211.



T9 Text Input is licensed under one or more of the following: description and the cellphone's operation, depending on the U.S. Pat. Nos. 5.187.480, 5.818.437, 5.945.928, 5.953.541 6.011.554.6.286.064.6.307.548.6.307.549. and 6.636.162. 6,646,573; European Pat. Nos. 0 842 463 (96927260.8), 010 057 (98903671.0), 1 018 069 (98950708.2); and additional patents are pending worldwide.

 $\mathsf{Java}^\mathsf{TM}$ and all $\mathsf{Java}^\mathsf{TM}$ based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Contact your network operator for service availability

17

 Make sure your operator's voicemail number is correctly entered in "My Numbers"

An electronic version of this user guide is available in English and

other languages according to availability on our server; www.alcatel-

Your cellphone is a transceiver that operates on GSM networks with

shown on the packaging label and in the product's memory. We

recommend that you note the number the first time you use your

cellphone by entering *#06# and keep it in a safe place. It may be

requested by the police or your operator if your cellphone is stolen.

This number allows your cellphone to be blocked preventing a third

There may be certain differences between the user manual

software release of your cellphone or specific operator services.

I cannot access my voicemail

Disclaimer

I am unable to send and receive messages MMS, Vox MMS

- Check your phone memory available as it might be full
- · Contact your network operator to check service availability and check MMS parameters
- Verify the server center number or your MMS profile with your
- . The server center may be saturated; try again later

The icon is displayed on my standby screen

· You have saved too many short messages on your SIM card; delete some of them or archive them in the product memory

. Check with your operator to make sure that your subscription "No service" is displayed

You are outside of the network coverage area.

I have already entered 3 incorrect PIN codes . Contact your network operator to obtain the PUK code (Personal

Unblocking Kev)

• Make sure that you have selected the country prefix when calling I am unable to connect my telephone to my computer

. Install first of all Alcatel's PC suite

- Use "Install the connection" and perform the installation
- · Make sure that your SIM card directory is not full; delete · Check that your computer meets the requirements for Alcatel's some files or save the files in the product directory (i.e. your PC Suite installation

I am unable to download new files

- · Check for free space
- Delete some files
- Select the MicroSD Card to store the files you downloaded

· Check your subscription status with your operator The phone can't be detected by others via Bluetooth

· Make sure that Bluetooth is turned on and your cellphone is visible to other users

22 23