


Operating Instructions For Bluetooth Speaker

There are two ways to play music through the blue tooth speaker – SD Card or through your portable device

1. To play through your SD Card

- 1) Make sure the bluetooth speaker is plugged and push mode button until a red light appears on top of the speaker.



- 2) SD Card – plug your SD card into the backside of the speaker.

**** note**** The SD Card must be pre-loaded with the music you desire to play.




**** Note****

Under SD mode, You can increase the volume FURTHER by using the volume buttons on the top of the speaker (as shown below). Make sure you hold down the volume button in order to adjust the volume setting (long press)



The music on the SD card can also be controlled through the buttons on top of the speaker as shown below. Use “short press” to activate this.



2. TO PLAY THROUGH YOUR WIRELESS DEVICE:

- 1) Make sure the bluetooth speaker is plugged in and push mode button until a blue light appears on top of the speaker.



- 2) Make sure the blue-tooth name “ Glo-TEC” is highlighted on your device.



- 3) Ensure the bluetooth setting is activated on your device and paired with the speaker before playing music.

- 4) After you select your music and it begins playing through the blue tooth speaker.

- 5) you can adjust the volume of the blue tooth speaker by increasing the volume on your wireless device. You can also increase the volume FURTHER by using the volume buttons on the top of the speaker. Make sure you hold down the volume button in order to adjust the volume setting (long press)



FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference; and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: “Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.