



Need some help?

Visit www.tp-link.com/support
for User Guides, FAQs, Warranty & more

Quick Start Guide

Kasa Smart Wi-Fi Outdoor Plug

Set Up Your Plug

STEP 1

INSTALL KASA APP

Get the **Kasa Smart** app from the Apple App Store or Google Play.



STEP 2

ADD TO KASA

Tap the ⊕ button in the Kasa Smart app and select **Smart Plugs > HomeKit Smart Plug, 2-Outlet**.



STEP 3

INSTALL AND POWER UP

Simply follow the instructions in the Kasa app to complete your Smart Outdoor Plug setup.

Note: Unused sockets should be firmly capped with the included weather-resistant cover.



Want to Add to Home?

This is a HomeKit-enabled device. You can also add it to the Home app for easy control from your iPhone or iPad.

Before You Start:

1. Your phone should be connected to a stable 2.4 GHz Wi-Fi network with internet access.
2. HomeKit will be disabled 10 minutes after the plug is powered on. You can unplug and plug it back in to restart the plug, and then try again.

Add to Home

Open the Home app and scan the HomeKit QR code on the plug, then you can add your plug to Home.

Failed to Add to Home?

- Press and hold the power button on your plug for at least 10 seconds to reset the plug, and restart your phone. Then try again.
- Refer to the troubleshooting guide for detailed instructions:

<https://www.tp-link.com/support/faq/3390/>



FCC compliance information statement

Product Name: Kasa Smart Wi-Fi Outdoor Plug

Model Number: EP40A

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

We, TP-Link USA Corporation, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.