Turbo Charger B25C1 User Manual

1. Product Overview



2. Operation Instruction

- Step 1: Insert the power supply
- Step 2: Open the power switch, the indicator of power lights red;
- Step 3: Insert the device(B2522) into the machine, the charger indicator lights red, the device enter charging stage;



Step 4: When the charger indicator lights green, charging finished.



Note: If the charger gets failure, the charger indicator will keep blinking.

3. Product Specification

Work Environment: 0° C---45 $^{\circ}$ C

Power supply: 24V/6A

Input Port: DC

Output Port: wireless charger

Output power: 5W*6

Output voltage: 5V

Output current: 1A

Physical Size: 220x145x315mm

Net Weight: 4.5kg

Quantity of simultaneous charging devices: 6 pcs



12404 Park Central Dr. Suite 350

Dallas, TX 75251

Email info@ziosk.com

Support (877) 585.4822

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 15cm between the radiator & body.