



OWNER'S MANUAL


Keep these instructions for future reference; they contain important information.

TRANSFORMER

CAUTION: Surfaces may become hot and cause burns if electronics get wet. Do not operate vehicle through water or snow.

TYCO R/C SUPPORT REGISTER YOUR VEHICLE 2 WAYS!
Online...or toll-free!
 tyco.com
 1-888-557-TYCO (8926)
 If you have questions or problems with your vehicle, **DON'T RETURN IT TO THE STORE...** get help from the EXPERTS! Just click or call.

I. CONTENTS




Vehicle




Transmitter

TOP VIEW



Note: The front wheels will make a "CLICKING" noise while spinning around. This is normal operation, designed to give a cool propeller sound effect to your vehicle.

BOTTOM VIEW




Refer to label on transmitter and vehicle for frequency. Do not race vehicles with the same frequency.

II. BATTERY INSTALLATION

VEHICLE

NOTE: Your vehicle requires a 6.0V Jet Turbo® NiCd battery pack (not included). For detailed information regarding NiCd vehicle battery charging and safety, please follow the specific instructions that came with your battery pack and charger.


1. Release battery compartment latch.
2. Insert battery pack into battery compartment.
3. Make sure battery pack snaps securely in place. Turn battery compartment latch to lock battery pack in place.
4. To remove battery pack: turn latch, slide battery pack to front of vehicle and lift out.



TRANSMITTER

TRANSMITTER


1. To install transmitter battery, open battery cover as shown.
2. Install one 9V battery with polarity (+/-) as shown inside battery compartment.
3. Replace battery cover.




NOTE: Your transmitter is equipped with a special automatic ON battery-saving feature. Just turn your vehicle ON. Then push either transmitter stick and you will be able to run and control your vehicle.

III. VEHICLE OPERATION


FORWARD




REVERSE




LEFT TURN




RIGHT TURN



"TURBO" TWIST LEFT




"TURBO" TWIST RIGHT



IV. COOL STUNTS


1. "TURBO" FLIPS

Push the left stick either up or down, while pushing the right stick either left or right. At the same time, push the red "turbo" button for wild twisting flips!




2. WHEELIE SPINS

Push the left stick down to drive in reverse. Then quickly push the left stick up while pushing the right stick either left or right, AND pushing the red "turbo" button. Your vehicle will jam up into a wheelie while the front wheels spin!





3. BACKFLIPS

Push the left stick down to drive in reverse. Once you hit full speed, quickly push the left stick up while pushing the right stick either left or right, AND pushing the red "turbo" button. Your vehicle will flip over onto its back!





To flip back right-side-up, push the right stick either left or right while pushing the red "turbo" button.




4. ROLLOVERS

Push the left stick up while quickly pushing the right stick either left or right AND pushing the red "turbo" button. Your vehicle will keep rolling over...and getting right back up again!




5. SKID-OUTS

Push the left stick up to drive forward. When you hit full speed, quickly push the red "turbo" button and push the right stick either left or right. Your vehicle will do an awesome skid-out!




6. SIDE-SPINS

Push the left stick down while quickly pushing the right stick left AND pushing the red "turbo" button. Your vehicle will flip onto its side and do an amazing 360° spin!



7. 360° SPINS

Push the right stick either left or right while pushing the red "turbo" button. Your vehicle will do a cool 360° spin!



This is a super stunt vehicle...challenging and fun to drive. You'll need to PRACTICE to perfect your stunt technique. Test your skill and challenge your friends!

V. CONSUMER INFORMATION

IMPORTANT:

Please read before operating your vehicle.

SAFETY INFORMATION

Note to Adults: To ensure that the child's play is both safe and fun, please review all operating instructions and safety rules with your child.

Safety Tips

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion.
- Keep fingers, hair and loose clothing away from the tires and the wheel hubs while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.

- To avoid accidental operation, remove all batteries when not in use.

BATTERY SAFETY INFORMATION


- ✓ Insure that battery polarity is correct.
- ✓ Use only batteries of the type recommended (or equivalent).
- ✓ Do not mix old and new batteries.
- ✓ Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- ✓ Remove used-up batteries immediately. Remove batteries if vehicle will not be used for a long period.
- ✓ Do not recharge non-rechargeable batteries.
- ✓ Do not short-circuit terminals.

- ✓ Remove rechargeable batteries before recharging (if the batteries are designed to be removable).
- ✓ Recharge batteries only under adult supervision (if the batteries are designed to be removable).
- ✓ Dispose of batteries safely. Do not dispose of batteries (or products containing non-replaceable batteries) in fire, as batteries may explode or leak.


Battery Performance Note:

For best performance use alkaline batteries (where disposable batteries are called for). If your vehicle is supplied with standard (carbon-zinc) batteries for initial use and/or demonstration purposes, we recommend replacing them with alkaline batteries when necessary. Battery life may vary depending on battery brand.


QUICK TIPS




1 When your vehicle starts to lose power, it may lose functions or performance. It's time for fresh batteries (or a recharge). Your vehicle's running time may change depending on your driving style.




2 Radio interference can make your vehicle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires; large buildings; or CB radios. Try to stay away from these!



3 Point your transmitter antenna up - not down toward your vehicle. If your vehicle gets too far away, it won't work properly.



4 Don't drive your vehicle in sand or through water or snow.



5 Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.

TROUBLESHOOTING

SYMPTOM	PROBABLE CAUSE	CORRECTION
Vehicle runs slowly or will not run.	<ul style="list-style-type: none"> • Loose battery connection or vehicle switch not ON. • Weak or uncharged rechargeable battery • Water in the electronics area. 	<ul style="list-style-type: none"> • Check battery connector and vehicle switch. • Charge battery or replace. • Vehicle will take several hours to dry. Allow to dry thoroughly overnight before trying again. Avoid driving in water or snow.
Erratic operation or only short range possible.	<ul style="list-style-type: none"> • Radio interference likely. 	<ul style="list-style-type: none"> • Change location - see Point 2, "Quick Tips." • Check connections and replace battery if required.
Short rechargeable battery life.	<ul style="list-style-type: none"> • Battery not fully charged 	<ul style="list-style-type: none"> • Recharge vehicle battery.

90-DAY LIMITED WARRANTY - TYCO® R/C PRODUCTS

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material and workmanship for ninety (90) days (unless specified in alternate warranties) from the date of purchase. Mattel will replace the product in the event of such a defect within the warranty period.

In the event of a defect covered under this warranty, first call the toll-free number listed below. Many problems can be solved in this manner. If necessary, you will be instructed to return the product, postage prepaid and insured, to the address below. Enclose your name, address, dated sales receipt, and a brief explanation of the defect. Replacement and return shipment will be free of charge.

This warranty does not cover damage resulting from unauthorized modification, accident, misuse or abuse. If the product is returned without a dated sales receipt the product may be excluded from coverage under this warranty.

Mattel's liability for defects in material and workmanship under this warranty shall be limited to replacement, and in no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). This warranty is exclusive, and is made in lieu of any express or implied warranty. Valid only in U.S.A. This warranty gives you specific legal rights and you may have other rights, which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

TOLL-FREE NUMBER: 1-888-557-TYCO (8926) (valid only in U.S.A.)

Hours: 8:00 A.M. - 5:00 P.M. Eastern Time; Monday - Friday. Expect some delay in January following the holiday season. Please be patient and keep trying the toll-free number.

ADDRESS FOR RETURNS: CONSUMER RELATIONS, 636 GIRARD AVENUE, EAST AURORA, NY 14052

© 2002 Mattel, Inc., Mt. Laurel, NJ 08054 U.S.A. PRINTED IN CHINA. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Retain this address for future reference: **Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB, Mattel Australia Pty., Ltd., Richmond, Victoria 3121 - Consumer Advisory Service: 1800 800 812 (valid only in Australia), Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Tsimshatsui, Harbour City, HK, China.**

COMPLIANCE WITH FCC REGULATIONS

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION OF THIS DEVICE IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

This device generates and uses radio frequency energy and if not used properly may cause interference to radio and

television reception. It has been tested and found to comply with the limits set by the FCC, which are designed to provide reasonable protection against such interference.



CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.