




RC 1:6 Vehicle ATV Water and Land

Thank you for purchasing your RC vehicle from **RadioShack**.



driving your vehicle

1. Slide **ON/OFF** on the vehicle to **ON**.
2. Use the transmitter's controls to steer your vehicle in the directions shown below.
3. Slide **ON/OFF** on the vehicle to **OFF** when you finish driving.



- To go straight, push both levers upwards/downwards simultaneously.
- To turn right or left, push one lever upwards and the other one downwards.
- To turn clockwise or counterclockwise, push either the right lever or left lever.

forward
↑
stop
↓
reverse



you will need...

One 9V battery (not included) for the transmitter.
One 6V battery pack (not included) for your vehicle.

in your transmitter


Turn your transmitter off. Slide open the battery cover. Insert one 9V battery, matching the polarity symbols (+ and -) marked inside. Replace when completed.



in your vehicle

Fully charge the 6V battery pack before use.

1. Turn your vehicle off.
2. Turn the latches to unlock and open.
3. Insert the 6V battery pack into the battery compartment with correct polarity.
4. Close and lock the battery cover.



Please read this user's guide before installing, setting up and using your new car
www.radioshack.com

important information

- This toy is recommended for children 8 years of age and older. To ensure that the child's play is both safe and fun, please review the operating instructions and these general safety rules with the child.
- Adult supervision is recommended when the vehicle is being operated.
- Keep fingers, hair and loose clothing away from the wheels while the vehicle is switched **ON**.
- To avoid accidental operation, remove the removable battery when not in use.
- If the vehicle and/or transmitter get wet, stop playing. Thoroughly wipe off all moisture and allow them to air-dry completely before use.
- **DO NOT** drive in the street! Make sure you have plenty of open space in all directions.
- Regularly inspect the antenna for cracks or breaks. **DO NOT** bend the transmitter antenna. **DO NOT** use the transmitter if the antenna is broken.
- The vehicle wire antenna is fragile. Never pull or tug

- on the antenna, as it may loosen or detach from the vehicle. Never coil or knot the antenna.
- Use and store your vehicle in room temperature environments only. Handle your vehicle carefully; do not drop it. Wipe your vehicle with a damp cloth occasionally to keep it looking new. Do not drive your vehicle through puddles or mud, in the rain, snow or sand.
- Modifying or tampering with the vehicle's internal components can cause a malfunction and might invalidate its warranty, and void your FCC authorization to operate it.
- If someone uses a CB nearby, it might interfere with the control of your car. If this happens, move the car away from the CB.
- You cannot operate your car near devices with transmitters that use the same frequency as your car (27 MHz or 49 MHz). Check the box to see which frequency you have.

installing batteries

- Do not use batteries of different types, capacities or chemistries.
- Never leave dead or weak batteries in your transmitter or vehicle.
- If you do not plan to use your vehicle or transmitter for several days, remove all batteries from them. Batteries can leak chemicals that may destroy electronic parts.
- If your vehicle runs slowly or does not move at all, replace or recharge the batteries.
- Dispose of old batteries promptly and properly. Do not burn or bury them.
- Driving your vehicle for long periods of time can generate a high heat level, which causes wear and tear on the motor. To help keep heat levels down, when your vehicle's battery power dies, let it cool for at least 10 minutes before installing new batteries.
- Do not touch the motor or batteries immediately after using the vehicle, as they may become hot during use.
- If your vehicle's motor runs, but does not respond to the transmitter, move closer to the vehicle and try again.

RF emissions information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult your local **RadioShack** store or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your product. Changes or modifications not expressly approved by **RadioShack** may cause interference and void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

what's included

RC 1:6 Vehicle ATV Water and Land
Transmitter
User's Guide

limited 90-day warranty

This product is warranted by **RadioShack** against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from **RadioShack** company-owned stores and authorized **RadioShack** franchisees and dealers. For complete warranty details and exclusions, check with your local **RadioShack** store.

RadioShack Customer Relations

300 RadioShack Circle, Fort Worth, TX 76102

04/04