# CUSTOMER SERVICE

1-800-531-0004 Monday - Friday • 8:00 am - 5:00 pm CT

or visit our website www.whistlergroup.com

Please keep the receipt in a safe place. You may register your product online at www.whistlergroup.com. For warranty verification purposes, a copy of your dated store receipt must still accompany any unit sent in for warranty work. If the unit is returned without a dated store receipt an out of warranty service charge applies. Note: Your warranty period begins at the time of purchase.

The warranty is validated only by the dated store receipt! Now is the time to record the serial number of the unit in the space provided in the warranty section of the manual.

\* Please note: This unit is a 1710A/1730A even though "A" is not indicated on the unit.

spend in your vehicle more productive, more fulfilling, safer, or just simply more fun. Our mission is to provide products that improve your driving experience. Your new Whistler 1710A/1730A/1733 laser/radar detector detects all radar, laser and safety radar systems. To fully acquaint yourself with the operation of the Whistler 1710A/1730A/1733 and to better understand the

INTRODUCTION

For many of us, a vehicle is more than just transportation.

It can be a mobile office, communications or entertainment

center, or simply an expression of our personality.

Whistler products are designed to make the time you

The Whistler Group, Inc.

differences between detecting radar, laser and safety radar signals, we recommend reading this entire manual or visit our FAQ page on our website www.whistlergroup.com Enjoy the Whistler 1710A/1730A/1733 and please drive Sincerely.

Dear Whistler Owner,

5. QUIET / Auto Quiet Button - Pressing QUIET

### Reset Features Care Maintenance

Operation
• Power On And Self-Test
• Self-Test Mute 11 - 12 Integrated Real Voice™
Feature Engaged Confirmation
Audio Level Adjustment Auto Quiet/Quiet Modes City Modes Dim/Dark Modes Engaging/Disengaging VG-2 Detection Option Select Mode Teach/Tutorial Mode Vehicle Battery Saver Mode Radar, Laser And VG-2 Alerts
 Radar Alerts
 Pulse Protection® 12 - 16

TABLE OF CONTENTS

Mounting Guidelines Visor/Windshield Mounting Power Connection And Fuse Replacement

1710A Features Summary

1730A Features Summary

1733 Features Summary

Installation

Page

4 - 5

5 -6 9 - 10

Safety Radar Audio/Visual Alerts Laser Audio/Visual Alerts VG-2 Audio/Visual Alerts Alert Priority

Troubleshooting Guide Are Detectors Legal? Speed Monitoring 18 19 - 21 Radar Facts Laser Facts
 Other Speed Detection Systems
Warranty Information 22 - 24 25 Specifications Accessories

INSTALLATION

· Mount the unit as low as possible near the center of the

### X ‰ H C I II III 兆

**1733/1734 FEATURES** 

16

# 10

13 14 12 Feature Listing of 1733/1734
Band • LED Display All Band City Mode LED Display Power Indicator City Mode
 Separate Radar Audio Alerts
 Alert Priority
 Auto Quiet
 Safety Warning
 System Alert Strength Indicators
• City Mode
Indicator 8 System Vehicle Battery

 Rear Laser Antenna – An integrated optical wave guide provides superior detection of laser signals transmitted from behind. 2. Bracket Release Button - Provides quick and easy release of the mounting bracket.

Whistler's ergonomic and user-friendly design provides

#### 3. Power / Volume Control - Turns unit on/off and adjusts audio level.

a new level of operating convenience.

Special Features Include:

- 4. City Button Reduces the annoyance of false alerts typically encountered in urban driving areas.

# 7

### keep you informed. Speaker – Provides distinct audio warnings for X, K, Ka band radar, safety radar, laser and the VG-2.

1733/1734 FEATURES

before a signal is detected engages Auto Quiet Mode. Pressing QUIET during a laser-radar encounter silences audio alerts, while allowing visual alerts to

- Power Jack Provides connection for the power cord. 8. Radar Antenna - Compact, high-efficiency antenna
- receives radar signals. 9. Laser Antenna (Front) - High gain optical lens
- provides increased sensitivity and field of view for leading-edge laser detection.
- Mounting Bracket Location Slot holds mounting bracket firmly. 11. X-band Indicator - Shows that unit is receiving an Xband signal.
- 12. K / Ka-band Indicator Shows that unit is receiving a K or Ka-band signal. 13. Highway Indicator - Shows that unit is operating in highway mode.
- 14.City Indicator Shows that unit is operating in city mode. Signal Strength Indicator - Shows the strength of the signal being detected. 16. VG-2 / Laser Indicator - Shows that unit is receiving
- VG-2 on laser signals
- 8

#### Do not mount your unit behind wipers, ornaments, mirrored sunscreens, etc. These obstructions have metal surfaces which can affect radar and laser signals and reduce critical warning time. (Regular tinted glass does not

Mounting Guidelines

windshield.

- Some windshields have an Instaclear™ or Electriclear™ type coating, which affect radar signals. Consult your dealer or the owner's manual supplied with your vehicle to determine if your windshield has this coating.
- · Avoid placing unit in direct contact with windshield. · To reduce the possibility of theft, conceal your unit when not in use.
- Windshield Mounting · Install the two suction cups and rubber bumper onto the

#### bracket by fitting them into their holes · Press the suction cups onto the windshield at the location you have chosen. IMPORTANT: Some newer cars have a plastic safety coating on the inside of the windshield. The windshield bracket may leave

### permanent marks on this type of surface. To find out if your vehicle has this type of windshield, check the owner's manual or ask your dealer. We recommend

that you do not leave the suction cup bracket on the window in direct sunlight. If the detector is removed, this may cause blistering of the dash in some vehicles.

**1710A FEATURES** 

5 000



before a signal is detected engages Auto Quiet Mode. Pressing QUIET during a laser-radar encounter silences audio alerts, while allowing visual alerts to keep vou informed. City Button – Reduces the annoyance of false alerts typically encountered in urban driving areas.

3. QUIET / Auto Quiet Button - Pressing QUIET

adjusts audio level.

- INSTALLATION Windshield Mounting (Continued)
- Slide the detector onto the bracket until it locks into place. · If necessary, the unit may be leveled by bending the windshield bracket. Press the bracket release button and remove the detector before bending. Visor Mounting (Optional Accessory) Slide the visor bracket into the bracket mounting slot. · Clip the visor bracket onto the visor making sure it is

relatively level and has a clear view of the road

• Plug the small end of the power cord into the unit's

Plug the large end into the vehicle's cigarette lighter.

The lighter socket plug is equipped with a replaceable

2 amp 3AG fuse located behind the silver tip. To replace

the fuse, carefully unscrew the tip of the plug.

-

Power Connection

Fuse Replacement

# 9.City Indicator - Shows that unit is operating in city

1710A FEATURES

Speaker – Provides distinct audio warnings for X, K, Ka band radar, safety radar, laser and the VG-2.

6. Power Jack - Provides connection for the power cord.

7. Power Indicator - Shows that unit is receiving power.

8. Signal Strength Indicator - Shows the strength of the

signal being detected.\*\*

\*\* Laser alert - Strength indicators chase right to left.

\*\* (SWS) 1st and 4th LEDs flash.

- 10. Radar Antenna Compact, high-efficiency antenna receives radar signals. Laser Antenna (Front) – High gain optical lens provides increased sensitivity and field of view for leading-edge laser detection.
  - bracket firmly.

12. Mounting Bracket Location - Slot holds mounting

4

**OPERATION** 

Each time a button is pressed one beep confirms feature

The QUIET Button accesses one of two muting options.

Pressing QUIET before a radar signal is detected provides

an alternate alert pattern, consisting of four beeps

(indicating X, K, Ka or Safety Radar) followed by clicking.

The clicking will continue for as long as the detected

signal is present or any new signal is detected within

20 seconds, becoming more rapid as the strength of the

If Auto Quiet is engaged, pressing QUIET while the unit

Feature Engaged Confirmation

"on", two beeps confirm feature "off"

Auto Quiet Mode

### 11

**1730A FEATURES** 

14 15

13

0000

16

Whistler 1730A

Feature Listing of 1730A

All Band
City Mode
Separate Radar
Audio Alerts
Alert Priority
Auto Quiet
Safety Warning
System
VG-2 Cloaking
VG-2 Cloaking 10 Whistler's ergonomic and user-friendly design provides a new level of operating convenience. Special Features Include: Rear Laser Antenna – An integrated optical wave guide provides superior detection of laser signals transmitted from behind.

4. QUIET / Auto Quiet Button – Pressing QUIET before a signal is detected engages Auto Quiet Mode. Pressing QUIET during a laser-radar encounter silences audio alerts, while allowing visual alerts to leave your information. keep you informed.

5

LASER/RADAR ALERTS

During this warning you can momentarily reset the unit

2. Bracket Release Button - Provides quick and easy

3. Power / Volume Control - Turns unit on/off and

release of the mounting bracket.

adjusts audio level.

by pressing any button. This will reset the timer. If the unit has automatically turned itself off, press any button to turn the unit back on. City Mode Whistler's City Mode is designed to reduce the annoyance

### of automatic door openers, intrusion alarms and other devices which share frequencies with police radar. • Press City to engage City. Press City a second time cancels City Mode. In City Mode, weak speed/safety radar signals give an initial alarm of two beeps, and then the unit remains quiet unless the signal strength increases, two additional beeps

IMPORTANT: Unscrew slowly. The tip contains a spring which may fly out when disassembling. Insert the new fuse with the spring and screw on the tip. With use, screw cap on plug may loosen. Retighten

- Unscrew the tip of the lighter socket plug carefully when
- replacing the 2 amp fuse.

**1730A FEATURES** 

5. VG-2 Button – Engages (one beep) or disengages (2 beeps) VG-2 Cloaking Technology for

**6. City Button** – Reduces the annoyance of false alerts typically encountered in urban driving areas.

Speaker – Provides distinct audio warnings for X, K, Ka band radar, safety radar, laser and the VG-2.

8. Power Jack - Provides connection for the power cord.

9. Radar Antenna – Compact, high-efficiency antenna

provides increased sensitivity and field of view for leading-edge laser detection.

10. Laser Antenna (Front) - High gain optical lens

non-detectability.

receives radar signals.

band signal.\*

#### is alarming will cancel the beeps or clicking. Pressing QUIET a second time when the unit is not

alarming will cancel Auto Quiet mode and restore the continuous audio alert pattern. Vehicle Battery Saver Mode

The Vehicle Battery Saver Mode automatically shuts off

your detector after 6 hours if you forget to turn it off. The timer is reset if the detector is turned off, unplugged or any button is pressed before the time has expired. The detector will alert you with an audible and visual warning

before it shuts off. 11

LASER/VG-2 ALERTS

When your detector detects a laser signal, the laser audio alert is sounded and the Laser indicator will illuminate for

as long as the signal is present, or for a minimum of three

When the laser signal is no longer detected, the audio

warning ends, but the indicator continues to flash slowly for

three seconds, indicating a laser encounter has just occurred.

If you are the targeted vehicle, a laser gun can often

determine your speed within a few seconds after you receive

an alert. In this situation there is generally no time to safely

adjust your speed. However, if you are traveling near or

The VG-2, also known as a "radar detector detector," is a

special receiver used by police to detect signals radiated by

a radar detector. See page 21 for more information on VG2. 1710A: Does not have VG-2 cloaking. 1730A: Press the VG-2 button once, unit beeps once 1733: Press and hold the quiet button, unit beeps once.

When a VG-2 signal is detected the VG-2 alert is sounded. After 3 seconds the audio is cancelled and the VG-2 indicator flashes at a slower rate. This cycle is repeated if the

seconds

VG-2 Detection Mode

VG-2 signal is again detected.

Radar Detector Detectors (VG-2)

is known as a "radar detector detector"

are provided. **Highway Mode** 

Highway mode provides full audio warnings any time radar (X, K, Ka, Safety Radar) or laser signals are detected,

and is recommended for open road driving.

12

VG2/SAFETY RADAR ALERTS

During the period a VG-2 signal is detected, a radar signal

cannot be detected. However, because the VG-2 alert has

confirmed that a patrol car is nearby, you are already aware

of the potential for speed monitoring and can adjust your

speed accordingly. Laser detection is not affected while a

Note: VG-2 must be turned on each time the unit is turned

Your Whistler detector detects the new Safety Warning

System<sup>™</sup>. In communities where transmitters are located,

NOTE: You will not be able to receive SWS alerts if transmit-

ters are not located in your area. For a current list of trans-

#### 11. Mounting Bracket Location - Slot holds mounting bracket firmly. X-band Indicator Shows that unit is receiving an Xband signal.\*

13. K-band Indicator - Shows that unit is receiving a K-

- \* X and K both lit when unit detects Ka-band signals 14.Power / VG-2 Indicator - Shows that unit is receiving power, and flashes when VG2 is detected.
- 16.City Indicator Shows that unit is operating in city 6
- LASER/RADAR ALERTS

When your Whistler detector encounters traffic radar, it

provides a distinctive audio tone for the specific radar

The audio alerts are continuous, but have a Geiger counter-

like pattern to help you determine your distance from the

radar source; the faster the beeping, the stronger the sig-

Pulse Protection® Pulse (or instant-on) radar is more difficult to detect than conventional radar because it remains "off" until activated to measure the speed of a targeted vehicle.

When a pulse type transmission is detected, your Whistler

detector sounds an urgent 3-second audio warning and

flashes the Alert strength indicators at their fastest rate.

After the 3-second pulse alert, the standard alert pattern

continues for as long as the signal is present.

# warning time may be minimal

band detected: X, K, or Ka.

nal strength will be.

13

# Radar Audio Alerts

#### behind the targeted vehicle and receive an alert, response this provides advanced warning of various road hazards time should be sufficient. Any laser alert, regardless of duaincluding accident sites, highway construction, emergency tion, requires immediat action! vehicles, etc. and enables you to respond more appropriately to potentially dangerous conditions.

VG-2 signal is detected.

on to receive VG-2 Alerts.

Safety Radar Audio/Visual Alerts

mitters please visit www.safetyradar.com

15. Signal Strength Indicator - Shows the strength of the signal being detected.\*\*

\*\* Laser alert - Strength indicators chase right to left.

\*\* (SWS) 1st and 4th LEDs flash.

> 14 SPEED MONITORING

The Interceptor VG-2, or simply VG-2, is a microwave

receiver used by police to detect signals radiated by the

local oscillator of a radar detector. Because its purpose is to identify persons driving with radar detectors, the VG-2

The VG-2 is the primary tool used by the police to

identify radar detector equipped vehicles. If caught, in a

state where detectors are illegal, (see page 18), drivers risk losing their radar detector and receiving a fine. In

addition, instant-on radar is almost always used in combination with a VG-2, leaving unsuspecting motorists vulnerable to receiving two tickets - one potentially for speeding, the other for possession of a detector. Having a radar detector capable of detecting the VG-2 may alert you to the presence of a speed trap.

For more information on speed monitoring technologies,

www.whistlergroup.com

It is the responsibility of the individual radar detector

please visit our FAQ page on our website:

owner to know and understand the laws in your area regarding the legality of the use of radar detectors. 21

TROUBLESHOOTING GUIDE

Your Whistler detector is expertly engineered and

designed to exacting quality standards to provide you with reliable, trouble-free operation. If your unit has been

correctly installed following the guidelines in this manual, but is not operating optimally, please refer to the troubleshooting guide below.

PROBLEM: No display or audio.

Check fuse in Whistler plug; replace if necessary with a 2 amp 3AG type.

Check fuse for lighter socket; replace if necessary.

Check for loose lighter socket; tighten and clean.
Check connections at both ends of power cord. Substitute another cord to determine if cord is defective. Return defective cord to the factory.

PROBLEM: Unit alarms when using vehicle electrical accessories (brakes, power mirrors/windows, directionals,

Norn, etc.).
Vehicle's electrical system, including battery and alternator, may have electrical noise. Install a filter capacitor (470mfd. 25 volt or larger capacitance value) on the back of the lighter socket.

PROBLEM: Unit gives laser alert when accelerating.

• Possible bad or low quality distributor cap. Replace with high quality cap

If difficulties occur which cannot be solved by information in this Troubleshooting Guide, please call Whistler Customer Service at 1-800-531-0004 or visit our FAQ page at

www.whistlergroup.com/faq-detectors.asp, before return-

17

**WARRANTY INFORMATION** 

Units will be repaired at "out of warranty" service rates when:

PROBLEM: Audio alerts are not loud enough.

Cancel Auto Quiet Mode or City Mode.

Check audio level setting (see page 10 & 11).

PROBLEM: Unit alarms when vehicle hits bumps.

Make sure lighter socket is clean.

ing your unit for service.

Service Out of Warranty

15 WARRANTY INFORMATION

Consumer Warranty
This Whistler Laser/Radar detector is warranted to the

original purchaser for a period of one year from the date of original purchase against all defects in materials and workmanship. This limited warranty is void if the unit is abused, modified, installed improperly, if the housing has been removed, or if the serial number is missing. There

are no express warranties covering this product other than those set forth in this warranty. All express or implied warranties for this product are limited to one year. Whistler is not liable for damages arising from the use, misuse, or operation of this product. Service Under Warranty During the warranty period, defective units will be repaired without charge to the purchaser when returned with a dated store receipt to the address below. Units

returned without dated store receipt will be handled as described in section "Service Out Of Warranty." Due to the

specialized equipment necessary for testing a laser/radar receiver, there are no authorized service stations for

Whistler brand detectors other than Whistler.

please follow these instructions:

When returning a unit for service under warranty,

# It is important to respond promptly to a pulse alert, since

### 1. Ship the unit in the original carton or in a suitable sturdy equivalent, fully insured, with return receipt requested to: Whistler Repair Dept. 1201 North Dixieland Rd Rogers, AR. 72756 22

In Most States YES!

26,000 lbs.

IMPORTANT

ARE DETECTORS LEGAL?

Laser detectors are completely legal in every state when

used in automobiles or light trucks (under 10,000 lbs.).

Similarly, when used in automobiles or light trucks, radar

detectors are legal in almost every state. Exceptions

are Virginia and Washington, D.C., which have local

regulations restricting the use of radar receivers in any

vehicle. Concerning trucks over 10,000 lbs., the Federal Highway Administration (FHwA) issued a regulation,

effective January, 1994 which prohibits radar and laser

Prior to the FHwA regulation, laws existed in the state of

New York restricting the use of radar detectors in trucks

over 18,000 lbs. and in the state of Illinois in trucks over

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)

This device many not cause harmful interference, and (2) this device must accept any interference received,

including interference that may cause undesired operation.

FCC requirements state that changes or modifications not

18

**SPECIFICATIONS** 

expressly approved by Whistler could void the use

1710A Dimensions: 1.2"H x 2.72"W x 3.9"L

Weight: 5.5 oz. 1730A Dimensions: 1.3"H x 2.9"W x 3.9"L

Weight: 5.5 oz. Dimensions: 1.3"H x 2.9"W x 3.9"L

detector use in these types of vehicles nationally.

FCC ID HSXWH01 - 1710/1730/1733 FCC ID HSXWH10 - 1730/1733

authority to operate the equipment.

Weight: 5.5 oz.

One or more U.S. patents apply:

905 ± 50 nanometers (nm)

Laser Wavelength:

16

**WARRANTY INFORMATION** 

IMPORTANT: Whistler will not assume responsibility

for loss or damage incurred in shipping. Therefore, please ship your unit insured with return receipt requested. CODs

2. Include with your unit the following information,

Your name and street address (for shipping via

UPS), a daytime telephone number and email

**CARE & MAINTENANCE** 

During the summer months, avoid prolonged exposure to

direct sunlight by removing your unit from the dash when

your vehicle is parked for an extended period of time. Do not

spray water, cleaners, or polishes directly onto the unit. The

spray may penetrate through the openings and damage the

unit. Also, do not use any abrasive cleaners on the units exte-

Be sure to check out all of the other Whistler products at our

website. Whistler carries a wide range of quality products.

You can also find answers to your questions in our FAQ's, and

be one of the first to see our new products offerings as they

become available. Get connected with Whistler today!!

Care And Maintenance

Check out our website!!!

www.whistlergroup.com

will not be accepted!

clearly printed:

address, if applicable.

• A detailed description of the problem (e.g., "Unit performs self-test but does not respond to radar"). A copy of your dated store receipt or bill of sale. Be certain your unit is returned with its serial number. For reference, please write your units serial number in the following space: s/n Units without serial numbers are not covered under warranty. IMPORTANT: To validate that your unit is within the warranty period, make sure you keep a copy of your dated

store receipt. You may register your warranty online at www.whistlergroup.com, however, for warranty

verification purposes, a copy of your dated store receipt must accompany any unit sent in for warranty work.

23

radar gun's receiving section. When a radar beam reflects off a moving target, a measurable frequency shift occurs. The radar unit converts this shift into miles per hour to determine your vehicle's speed. Currently, the FCC (Federal Communications Commission) permits operation of traffic radar guns at X Band (10.500 - 10.550 GHz), K Band (24.050 - 24.250 GHz), and Ka Band

(33.400 - 36.000 GHz).

Laser Facts

any one of the above radar bands.

SPEED MONITORING

A radar gun operates by transmitting radio waves at certain fre-

quencies which reflect off objects and are then picked up by the

Note: A radar detector will not alarm if an officer is not transmitting on

It's well documented that many radar guns cannot reliably

provide the speed of a targeted vehicle that is traveling in a

group of vehicles. In contrast, a laser gun can target a specific vehicle out of a line of traffic and determine its speed.

The advantage of laser over radar in terms of target

identification is the result of the laser gun's narrow beam. A

radar transmission can cover more than a four-lane highway at

a distance of 1,000 feet, compared with a laser transmission which covers about 3 feet at the same distance. For best protection, keep these points in mind: 19 The following accessories can be ordered directly from Whistler by calling 1-800-531-0004 or visit our online store at www.whistlergroup.com

Order

Code 202138

202140

206552

# The units original warranty has expired. Dated store receipt is not supplied. The unit has been returned without its serial number. The unit has been returned without its serial number, or had its housing removed. The minimum out of warranty service fee for your Whistler detector is \$35.00 (U.S.). If you require out of warranty service, please return your unit as outlined in the section "Service Under Warranty" along with a certified check or money order for \$35.00. Payment may also be made by MasterCard, VISA or American Express; personal checks are not accepted. In the event repairs cannot be covered by the minimum \$35.00 service fee, you will be contacted by a Whistler technical service specialist who will outline options available to you. If you elect not to have your unit repaired.

**IMPORTANT:** When returning your unit for service, be certain to include a daytime telephone number, and email address (if applicable). Customer Service If you have questions concerning the operation of your Whistler detector, or require service during or after the warranty period, please call Customer Service at:

1-800-531-0004.

Representatives are available to answer your questions Monday - Friday from 8:00 a.m. to 5:00 p.m. (CT). 24

### **Radar Frequencies:** 10.500 - 10.550 GHz (*X Band*) 24.050 - 24.250 GHz (*K Band*) 33.400 - 36.000 GHz (*Ka Superwideband*) Operating Temperature Range: $-20^{\circ}$ C to $+80^{\circ}$ C $(-4^{\circ}$ F to $+176^{\circ}$ F) available to you. If you elect not to have your unit repaired, it will be returned to you along with your certified check or Power Requirements: Operational 12 to 15 volts DC, 250mA nominal Vehicle Battery Saver, 30mA nominal.

#4,315,261 #5,146,227

#5,379,456

#5,990,821

 Do not follow closely behind any vehicle you cannot see through. If you can't see past a vehicle ahead of you, chances are your detector won't either. The receiving range of your laser detector will not be the same as a radar detector. Laser guns are most often used

at short range

Pro Laser™ I II III

• LT1 20-20

Ultra Lyte

 Vascar/Aircraft - The time it takes a vehicle to travel a known distance is measured.

20

Whistler Laser/Radar detectors receive all current laser guns which operate at a laser wavelength of 905 +/- 10mm.

### ACCESSORIES OWNER'S MANUAL

Coiled Power Cord (7') 206553 206880 Hardwire Kit (10') (for wiring to fuse box) Modular Cord Package (includes coiled and straight cords, 206666 and power adapter) 159032 Package of 8 Suction Cups \$ 2.95 402081 Dash Pad 6.95 Straight Modular Cord and 206660 Socket Multiplier \$ 11.95 Coiled Modular Cord and 206661 \$ 12.95 Socket Multiplier

Description

Visor Bracket

Windshield Bracket Kit

Straight Power Cord (5')

Other Speed Detection Systems Several techniques other than radar or laser are used to measure vehicle speeds. When these methods are being used, no detector can provide a warning. These techniques include:

SPEED MONITORING Because you vehicle's license plate or headlights are the laser gun's primary targets, mounting your Whistler detector on the dashboard can improve laser detection at

1733 LASER-RADAR

Specifications are subject to change without notice.

25

 Pacing - A patrol car drives behind you and matches your driving speed.

WHISTLER

1710A/1730A

The Whistler Group Corporate Headquarters 13016 N. Walton Blvd. • Bentonville, AR 72712 Tel (479) 273-6012 • Fax (479) 273-2927 Customer Return Center 1201 N. Dixieland Rd. • Rogers, AR 72756 Consumer Relations Tel (800) 531-0004 P/N 1710A/1730A/1733/REV1, © Whistler 2003

\*Modular: Interconnecting pieces cord and plug. Shipping and handling (per order) \$5.00 Prices are subject to change without notice.

26

Price \$ 6.95 9.95 \$ 14.95 \$ 15.95 \$ 9.95 \$ 17.95