#### TRANSFERRING CALLER ID RECORDS IN MEMORY

- 1. Make sure the phone is OFF (in standby mode).
- 2. Press the CALLER ID/VOL (- or +) button to scroll to the desired caller ID.
- 3. Press the MEM button.
- Press a number key (0 9) to store the number in that memory location. You will hear a confirmation tone.

**NOTE:** It is important that you format the caller ID records correctly before storing in memory. It is not possible to re-format caller ID records stored in memory.

# TO REPLACE AN OLD MEMORY WITH A NEW CID RECORD

- 1. Repeat steps 1 through 4 in Transferring Caller ID Records in Memory. After you enter the memory location, *REPLACE MEMO?* shows in the display.
- 2. Press the MEM button again, and the new CID record replaces the old memory in that location. You will hear a confirmation tone.

#### DELETING THE CURRENT CID RECORD

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the CALLER ID/VOL (- or +) button to scroll to the desired record.
- 3. Press DEL/CHAN. The display shows DELETE CALL ID?
- Press DEL/CHAN again to erase the record and the next Caller ID record shows in the display. You will hear a confirmation tone.

#### **DELETING ALL CID RECORDS**

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the CALLER ID/VOL (- or +) button to display any Caller ID record.
- 3. Press and hold the DEL/CHAN button until DELETE ALL? shows in the display.
- Press DEL/CHAN again to erase all records. You will hear a confirmation tone. The display shows NO CALLS.

## DIALING A CALLER ID NUMBER

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Use the CALLER ID/VOL (- or +) button to display the desired record.
- 3. Press TALK/END/CALLBACK. The number dials automatically.

## CHANGING THE TELEPHONE NUMBER FORMAT

The FORMAT button lets you change the format of the displayed telephone number. The available formats are as follows.

- **7-digit** 7-digit telephone number.
- **10-digit** 3-digit area code + 7-digit telephone number.
- **11-digit** long distance code "1" + 3-digit area code + 7-digit telephone number.
- Use the CALLER ID/VOL (- or +) button to scroll to the number you want to call back.
  Press TALK/END/CALLBACK. The number dials automatically.
  - **NOTE:** If the telephone number cannot be dialed, press the format button to adjust the number, and try again.

# Memory

Store up to ten 24-digit 15-character numbers in memory for quick dialing. This memory feature is in addition to the CID memory log, which stores up to 40 CID records.

## STORING A NAME AND NUMBER IN MEMORY

- 1. Make sure the phone is **OFF** (not in TALK mode).
- 2. Press the MEM button.
- 3. Press the desired memory location (0 through 9) or use CALLER ID/VOL (+ or -) to scroll to the desired memory location.

**NOTE:** If the memory location is occupied, the memory location number and its contents show in the display.

#### 4. Press the MEM button again. The display shows ENTER NAME.

NOTE: If you don't want to enter the name, skip step 5.