


Wyze Sense Starter Kit

QUICK START GUIDE

IN THE BOX


Wyze Contact Sensor (battery pre-installed)	x2
Wyze Motion Sensor (battery pre-installed)	x1
Wyze Sensor Bridge	x1
Quick Start Guide	x1
Pin	x1

Wyze Contact Sensor (WHCS1)




- 1 Reset button
- 2 Status Light

Wyze Motion Sensor (WHMS1)



- 1 Status Light
- 2 Reset button


Wyze Sensor Bridge (WHSB1)



- 1 Status Light
- 2 USB

SETUP

- 1 Insert the Sensor Bridge into the USB port of a Wyze Cam or Wyze Cam Pan.




- 2 Log into your Wyze account and add a new device from the Home page. Follow the instructions in the Wyze app to finish setup.



- 3 Repeat Step 2 for each Contact and Motion Sensor.




CONTACT SENSOR PLACEMENT



Ensure the two sections of the Contact Sensor are at most 2 cm apart when closed.

MOTION SENSOR PLACEMENT



Place Sensor approximately 6 feet high and ensure the Wyze Logo is in the top left corner.

STATUS LIGHT



Solid yellow light
The device is powered on, but not connected



Flashing yellow/blue light
The bridge is connecting



Solid blue light
The device is working properly



Flashing blue light
The device is ready to pair with a sensor

Sensors



FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful

interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

NEED HELP?

Resources & Support
www.wyze.com/support
Community
www.wyze.com/forums