


EN

What's in the box

1 TomTom GO




- (A) On/Off button
- (B) Microphone
- (C) Light sensor
- (D) Speaker
- (E) Memory card (micro SD card) slot


2 PowerDock




3 USB car charger




4 Home Dock



5 Documentation pack





Before you start

Switching on and off

Install your TomTom GO in your car following the instructions on the installation poster at the start of this book.

To switch on your TomTom GO, press and hold the On/Off button until you see the start-up screen. The first time you switch on your device, it may take a short while to start.

You have to answer a few questions to set up your device.

Having problems?

In rare cases, your TomTom GO may not start correctly or may stop responding to your taps.

First, check that the battery is properly charged. To charge the battery, connect your device to the TomTom Home charger, the TomTom Car charger or to your computer. It can take up to 2 hours to fully charge the battery.

If this does not solve the problem, you can reset the device. To do this, press and hold the On/Off button for fifteen seconds and release the button when your GO begins to restart.




Battery notes

The battery in your TomTom GO charges when you connect it to the car charger or to your computer.

The light next to the On/Off button is orange while the battery is charging and is green when the battery is fully charged.

When you connect your GO to a computer using the home dock, you are asked if you want to connect to the computer. If you select **No and do not tap the screen within three minutes, the device will automatically switch off**. This happens so that the battery can charge faster.

Important: You should plug the USB connector directly into a USB port on your computer and not into a USB hub or USB port on a keyboard or monitor.



EN

Before you start

PowerDock

Use the PowerDock to install your TomTom GO inside your car.

Make sure that both the PowerDock and your windshield are clean and dry before you attach the holder. Place the PowerDock so that it does not interfere with your view of the road or of any of the controls in your car.

To attach the PowerDock, press the suction cup firmly against the windscreen on an area where the glass is flat. Then twist the rubber grip near the base of the PowerDock in a clockwise direction until you hear a click.

GPS reception

When you first start your TomTom GO, the device may need a few minutes to determine your GPS position and show your current location on the map. In the future, your position will be found much faster, usually within a few seconds.

To ensure reception of a strong GPS signal, your GO should be used outdoors. Large objects such as tall buildings can sometimes interfere with reception.

Safety Notice

Your TomTom GO contains a GSM/GPRS module which can interfere with electrical devices such as cardiac pacemakers, hearing aids and aviation equipment.

Interference with these devices may endanger the health or life of others.

Do not use near unprotected electrical units nor in areas where the use of mobile telephones is prohibited, such as hospitals and airplanes.

Take care of your TomTom GO

Never leave your TomTom GO or accessories in view when you leave the car or they may become an easy target for thieves.

You can set a password for your TomTom GO which must be entered every time you start your GO.

It is important to take care of your GO.

- Your GO is not designed for use in extreme temperatures and any such exposure may cause permanent damage.
- Do not open the casing of your GO under any circumstances. Doing so may be dangerous and will invalidate the warranty.
- Wipe or dry the screen of your GO using a soft cloth. Do not use any liquid cleaners.


Safety

Choosing where to attach the PowerDock

Consider carefully where you place the PowerDock in your car. The PowerDock should not block or interfere in any way with the following:

- Your view of the road
- Any of the controls in your car
- Any of your mirrors
- The airbag

You should be able to reach your GO easily when it is in the PowerDock without leaning or stretching. The diagram shows where you can safely attach the PowerDock.



You can attach the PowerDock to the windshield, side window or use a Dashboard Mount Disk to attach the PowerDock to your dashboard. TomTom also offers alternative mounting solutions for your TomTom device. For more information about Dashboard Mount Disks and alternative mounting solutions, go to www.tomtom.com/accessories.

Installing the PowerDock

Make sure that both the Powerdock and your window are clean and dry.

1. Press the suction cup firmly against the window on an area where the glass is flat.
2. Twist the rubber grip near the base of the Powerdock in a clockwise direction until you hear a click.

The PowerDock is now installed.

Safety preferences



We recommend using the safety preferences to make your driving as safe as possible.


The safety preferences include, for example, the following options:

- Hide most menu options when driving
- Show safety reminders
- Warn when driving faster than allowed

You can also drive more safely by using voice commands to control your TomTom GO.

EN

Making your first trip




Planning a route with your TomTom GO is easy. To plan your first route, follow the steps below.

Important: For safety reasons, you should always plan a route before you start your trip and not when you are driving.

1. Tap the screen to bring up the main menu.

Note: The buttons on your GO are shown in full color unless a button is currently unavailable. For example, the button named **Find alternative...** in the Main Menu is not available until you have planned a route.




2. Tap **Navigate to...**

3. Tap **Address**.

In this example, we will enter an exact address.

4. Tap **Street and house number**.

Note: When planning a trip for the first time your GO asks you to choose a state or country. Your choice is saved and used for all routes you plan.



You can change this setting at any time by tapping the state symbol or country flag.

EN


Making your first trip

5. Start to type the name of the town where you want to go. Tap the name when it is shown in the list.



Tip: Instead of typing the name, tap this button to say the address by speaking to your GO.

6. Start to type the name of the street and select it when it is shown.
7. Now enter the house number of your destination and then tap **Done**.
8. Your GO asks if you need to arrive at a particular time. For this exercise, tap **NO**. The route is calculated by your GO using IQ Routes™. IQ Routes™ is used to plan the best possible route - taking into account the real average speeds measured on the roads.
9. When the route has been calculated, tap **Done**.



EN

Voice control

Instead of tapping the screen to control your TomTom GO, you can now give instructions to your GO using your voice.

For example, to increase the volume on your GO, you can say, "Increase volume."

Important: To use voice control, you must have a computer voice installed on your TomTom GO. If you don't have a computer voice installed, use TomTom HOME to install one.

To view the list of available commands, tap voice control preferences in the Preferences menu and then tap **What can I say?**

Using voice control

To control your TomTom GO using your voice, follow the steps below.

In this example, you will use voice control to plan a trip to your home address.

1. Tap the voice control button in the Driving View.



Note: To add or remove this button from the Driving View, tap **Voice control** in the Preferences menu and then tap **Enable voice control** or **Disable voice control**.

The voice control monitor is shown in color, unless voice control is busy with another task.

Voice control

EN

2. When you hear a beep, say, "Navigate to Home."

When you speak, the voice control monitor shows if you are talking too loudly or quietly:



A green bar means your voice is at the right level for your GO to hear your commands.



A red bar means your voice is too loud.



A grey bar means your voice is too quiet.

For some phrases, your GO will always repeat the command and then ask you if the command has been correctly recognized.

3. If the command is correct, say, "Yes."

If the command is incorrect, say, "No" and when prompted, say the command again after the beep .

Your GO plans a route from your current position to your Home address.

Tips

- Voice control switches off after a few seconds if you don't say anything. For example, if your GO asks you to confirm the last command you gave and you don't say anything, voice control switches off after a few seconds.
 - You can stop your GO from listening for commands either by tapping the screen or by saying any of the following commands: Back, Cancel, Quit.
 - To select an item from a list, tap the screen to select the item. Voice control cannot be used to select items from a list.
-


EN

Driving View


When your TomTom GO starts, you are shown the Driving View along with detailed information about your current location.

Tap the center of the screen at any time to open the Main Menu.

Note: The Driving View is shown in black and white until your GO locates your current position.



- Ⓐ Tap + and - to zoom in and out.
- Ⓑ Quick menu - switch this on in the Preferences menu.
- Ⓒ Your current position.
- Ⓓ The name of the next major road or road sign information, if applicable.
- Ⓔ Traffic sidebar.
- Ⓕ Voice command button
- Ⓖ Navigation instruction for the road ahead.
Tap this area to repeat the last spoken instruction and to change the volume.
- Ⓗ The name of the street you are on.
- Ⓘ Information about your trip such as trip time, remaining distance and arrival time.
To change the information shown, tap **Status bar preferences** in the **Preferences** menu.
- Ⓙ GPS signal strength.



Advanced Lane Guidance




Your TomTom GO helps you prepare for highway exits and intersections by showing you which lane you should be in.

Note: This information is not available for all intersections or in all countries.

For some exits and intersections, an image shows the turning and the lane you should take.

To turn the images off, tap **Hide lane images** in the Preferences menu.

For other exits and intersections, your GO shows the lane you should take in the Status bar. To turn this guidance off, tap **Change preferences** in the Main Menu, then tap **Status bar preferences**. Clear the checkbox for **Show lane guidance**.



EN

LIVE Services

Regional availability

Note: LIVE services are only available in supported countries. For more information on available services in your country, go to tomtom.com.

Safety Notice

Your TomTom GO contains a GSM/GPRS module which can interfere with electrical devices such as cardiac pacemakers, hearing aids and aviation equipment.

Interference with these devices may endanger the health or life of others.

Do not use near unprotected electrical units nor in areas where the use of mobile telephones is prohibited, such as hospitals and airplanes.

TomTom Traffic

TomTom Traffic is a unique TomTom service for receiving up-to-date traffic information. For more information about services and subscriptions, go to tomtom.com/services.



In combination with IQ Routes, Traffic helps you plan the quickest possible route to your destination taking into account the latest traffic information.

Using TomTom Traffic

The Traffic bar is shown on the right side of the Driving View. It warns you about traffic incidents on your planned route.



The top of the Traffic bar represents your destination and shows the total delay time for any incidents on your route.

The central section of the Traffic bar shows individual traffic incidents in the order they occur on your route.


The bottom of the Traffic bar represents your current position and shows the distance to the next incident.

To find the quickest route to your destination taking into account the latest traffic information, do the following:

1. Tap the sidebar.
2. Tap **Minimize traffic delays**.

Your device looks for the quickest route to your destination.

It is possible that the new route may also include traffic delays, or may even be the same route as before. You can re-plan the route to avoid all delays, but this new route



EN

LIVE Services

will take longer than the quickest route already shown.

3. Tap **Done**.

Fuel Prices

The Fuel Prices service sends up-to-date information about fuel prices directly to your TomTom GO or via TomTom HOME when your GO is connected to your computer.



Search for the best fuel prices

To search for the cheapest fuel prices, do the following. In this example, you will plan a route to the cheapest nearby fuel station.

1. Tap the screen to bring up the Main Menu, then tap **TomTom Services**.

2. Tap **Fuel Prices**.

3. Tap **Cheapest nearby**, tap the name at the top of the list.

The fuel station location is shown on the map.

4. Tap **Select**.

You are asked if you want to navigate to the fuel station.

5. Tap **Yes**.




You are asked if you need to arrive at a particular time.

6. Tap **No**.

The route is planned and a summary of the route is shown on the map.

7. Tap **Done**.

The Driving View is shown and your GO directs you to the fuel station.



EN

LIVE Services

TomTom local search with Google



Using local search, you can search the Google listings to find shops and businesses near you, or any another location, and navigate there.

Using local search

To find a destination using local search and plan a route to that location, follow the steps below. In this example, you will search for a supermarket near your current location.

1. Tap the screen to bring up the Main Menu, then tap **Navigate to**.
2. Tap the **Google** button.
3. Tap **Search near you**.
4. Type 'supermarket' then tap **OK**.

The locations that match your search are shown in a list.

5. Tap one of the locations in the list.

The location is shown on the map.

Tap **Details** to see more information about this location.

6. Tap **Select** to plan a route to the location.

Your TomTom GO plans a route to the location you selected.

TomTom Safety Alerts


The TomTom Safety Alerts service warns you about safety camera locations.



Important: Regularly connect your navigation device to TomTom HOME and update the list of locations for all Safety Alerts except mobile safety camera locations, which are sent to your device using a wireless connection.

When a safety camera location is shown on the map, a warning sound is played to warn you that you are approaching an area where a safety camera is located.

If you discover a location that has a safety camera but you receive no warning, you can report the new location to TomTom using your GO.



LIVE Services

Other services

The following services are also available on your TomTom GO:



TomTom Weather

TomTom Weather gives you five day weather reports for any location on your map.



QuickGPSfix

QuickGPSfix contains information about GPS satellite positions which helps your TomTom GO find your position faster.



TomTom Buddies

With Buddies, you can see where your friends are and let them see your location. You can also send messages and locations to your friends.






My services

To check your subscription, tap **TomTom Services** in the Main Menu and then tap **My Services**.

Your TomTom GO informs you when your LIVE Services subscription is due for renewal. You can use your GO to inform TomTom that you wish to renew your current subscription. You then have two weeks to complete the payment online.

For more information about LIVE Services subscription and payment terms, go to tomtom.com/services.



EN

Maps

Latest Map Guarantee

TomTom regularly releases new map versions. When you buy a new navigation device which comes with a preloaded map, it may be possible that a newer map version is available.

TomTom HOME automatically checks for a newer version of your map each time you connect your device to your computer.

If a newer version of your map is available during the period immediately after you purchased your TomTom navigation device, then you are entitled to download the latest version of the map.

Downloading the latest version of your map

To check for the latest version of your map using TomTom HOME, do the following:

1. Start TomTom HOME.

If TomTom HOME is not installed on your computer, install it from the CD included with your TomTom GO or download it from **tomtom.com/home**.

2. Connect your TomTom GO to your computer.
3. Click **Use Latest Map Guarantee** in the **Tools** menu in TomTom HOME.

***Note:** This option is not shown if your device already has the latest version of the map.*

4. Select the map you want to download and click Done.


The latest version of your map is downloaded to your GO.

Maps

EN

TomTom Map Share™

With TomTom Map Share, you can correct errors on your map and share those corrections with other people in the TomTom Map Share community as well as receive corrections made by others.



You choose the type of corrections you want and each time you connect your TomTom GO to TomTom HOME, the map will be updated automatically.

Note: TomTom Map Share is not available in all regions. For more information, go to tomtom.com/mapshare

TomTom Map Share community

To join the Map Share community, do the following:

1. Tap **Map corrections** in the Main Menu.

Tip: If you cannot see the **Map corrections** button in the Main Menu, tap **Show ALL menu options** in the Preferences menu.

2. Tap **Download corrections made by others**.
3. Tap **Join**.

When you connect your GO to your computer, TomTom HOME downloads new corrections and sends your corrections to the Map Share community.


Important: TomTom Map Share corrections are not sent to your navigation device using a wireless connection. You should regularly connect your device to your computer and use TomTom HOME to check for new updates.

EN

Maps


Trust slider

Use the Trust level slider to set the type of map corrections you want added to your map. To do this, tap **Correction preferences** in the Map corrections menu.



There are four levels of trust that you can choose:

- Strict - accept changes made by TomTom.
- High - accept changes made by trusted users who are verified by TomTom as well as changes made by TomTom.
- Medium - accept changes made by a high number of Map Share community members as well as changes made by TomTom and by trusted users.
- Low - accept changes made by just a few members of the Map Share community as well as changes made by TomTom, by trusted users, and by a high number of community members.



Introducing TomTom HOME

TomTom HOME is a free application for your computer that helps you manage the contents of your TomTom navigation device. It is a good idea to frequently connect to TomTom HOME, to ensure you always have the latest updates on your device.

Tip: We recommend using a broadband internet connection whenever you connect to TomTom HOME.

Installing TomTom HOME

To install TomTom HOME on your computer, do the following:

1. Connect your computer to the internet.
2. Connect the home dock to your computer.

Important: You should plug the USB connector directly into a USB port on your computer and not into a USB hub or USB port on a keyboard or monitor.

3. Place your TomTom navigation device in the home dock and switch it on.

HOME starts to install.




Note: If HOME does not install automatically, you can also download it from tomtom.com/home and run the installation from your computer.

You can also install TomTom HOME from the supplied CD.

TomTom HOME automatically starts whenever the navigation device is switched on and you connect the device to your computer.

MyTomTom Account

In order to buy content and services through TomTom HOME you will have to set up a MyTomTom account for the device you want to buy the content for. You will be asked to create an account when you start using TomTom HOME.



EN

Discover more

Help me!

Help me! provides an easy way for you to find and contact emergency service centers and other special services.




Help me! also includes a selection of useful documents covering topics such as First Aid and car maintenance.

Safety preferences

Take a look at the safety preferences. These will help you enjoy using your GO while you concentrate on driving safely.



We strongly recommend that you consider using the **Safety preferences** which can be found in the Preferences menu.



Discover more

EN


Hands-free calling

If you have a cell phone with Bluetooth, you can use your GO to make phone calls and send and receive messages.



To establish a connection between your mobile phone and your GO, tap **Mobile phone** in the Main Menu, then follow the instructions on the screen.

Important: To find out even more about your TomTom GO, use the CD included or TomTom HOME to read the Reference Guide. Alternatively you can download the Reference Guide from tomtom.com/downloads.



For a list of supported phones, go to tomtom.com/phones.

Addendum

Important Safety Notices and Warnings

Global Positioning System

The Global Positioning System (GPS) is a satellite-based system that provides location and timing information around the globe. GPS is operated and controlled under the sole responsibility of the Government of the United States of America, which is responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your TomTom device. TomTom does not accept any liability for the availability and accuracy of GPS.

Use with Care

Use of a TomTom device for navigation still means that you need to drive with due care and attention.

Aircraft and Hospitals

Use of devices with an antenna is prohibited on most aircraft, in many hospitals and in many other locations. A TomTom device must not be used in these environments.

Battery

This product uses a Lithium-Polymer battery. Do not use it in a humid, wet and/or corrosive environment. Do not put, store or leave your product in or near a heat source, in a high temperature location, in strong direct sunlight, in a microwave oven or in a pressurized container, and do not expose it to temperatures over 60 C (140 F). Failure to follow these guidelines may cause the Lithium-Polymer battery to leak acid, become hot, explode or ignite and cause injury and/or damage. Do not pierce, open or disassemble the battery. If the battery leaks and you come into contact with the leaked fluids, rinse thoroughly with water and seek medical attention immediately. For safety reasons, and to prolong the lifetime of the battery, charging will not occur at low (below 0 C/ 32 F) or high (over 45 C/113 F) temperatures.

Temperatures: Standard operation: -10 C (14 F) to +55 C (131 F); short period storage: -20 C (-4 F) to + 60 C (140 F); long period storage: -20 C (-4 F) to +25 C (77 F).



THE LITHIUM-POLYMER BATTERY CONTAINED IN THE PRODUCT MUST BE RECYCLED OR DISPOSED OF PROPERLY. USE YOUR TomTom ONLY WITH THE SUPPLIED DC POWER CABLE (CAR CHARGER/ BATTERY CABLE) AND AC ADAPTER (HOME CHARGER) FOR BATTERY CHARGING.

To recycle your TomTom unit please see your local approved TomTom service center.

SPECIAL NOTE REGARDING DRIVING IN CALIFORNIA AND MINNESOTA

California Vehicle Code Section 26708 (a) (1) provides that "No persons shall drive any motor vehicle with an object or material placed, displayed, installed, affixed or applied upon the windshield or side or rear windows." Drivers in California should not use a suction mount on their windshield, side or rear windows.

Note: this section of the California Vehicle Code applies to anyone driving in California, not just California residents.

Minnesota State Legislature Statutes Section 169.71, subdivision 1, section 2 provides that "A person shall not drive or operate with any objects suspended between the driver and the windshield other than sun visors and rearview mirrors and electronic toll collection devices."

Note: this Minnesota Statute applies to anyone driving in Minnesota, not just Minnesota residents.

TomTom Inc. bears no responsibility for any fines, penalties or damage that may be incurred by disregarding this notice. While driving in any state with windshield mounting restrictions, TomTom recommends the use of the supplied Adhesive Mounting Disk or its Alternative Mounting Kit, which includes multiple options for mounting TomTom devices on the dashboard and using the air vents. See www.tomtom.com for more information about this mounting option.

FCC Information for the User



This product contains a transmitter which must not be co-located or simultaneously operated in conjunction with any other transmitter.

Exposure to Radio Frequency Radiation

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 8 inches (20 cm) during normal operation.

Radio and Television Interference

This equipment radiates radio frequency energy and if not used properly - that is, in strict accordance with the instructions in this manual - may cause interference to radio communications and television reception.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation distance between the equipment and the receiver.



Addendum

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Important

This equipment was tested for FCC compliance under conditions that included the use of shielded cables and connectors between it and the peripherals. It is important that you use shielded cables and connectors to reduce the possibility of causing radio and television interference. Shielded cables suitable for the product range can be obtained from an authorised dealer. If the user modifies the equipment or its peripherals in any way, and these modifications are not approved by TomTom, the FCC may withdraw the user's right to operate the equipment. For customers in the USA, the following booklet prepared by the Federal Communications Commission may be of help: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the US Government Printing Office, Washington, DC 20402. Stock No 004-000-00345-4.

FCC Declaration of Conformity

Tested to comply with FCC Standards for Home or Office Use

FCC ID: S4L4CF7
IC ID: 5767A-4CF7

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Responsible party in North America

TomTom, Inc., 150 Baker Avenue Extension, Concord, MA 01742
Tel: 866 486-6866 option 1 (1-866-4-TomTom)

Emissions information for Canada

This Class B digital apparatus complies with Canadian ICES-003.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This category II radio communication device complies with Industry Canada Standard RSS-310.

Connected networks

This device is intended for connection to the following networks:
GSM/GPRS 850/1800/1900

This Document

Great care was taken in preparing this manual. Constant product development may mean that some information is not entirely up-to-date. The information in this document is subject to change without notice.

TomTom shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the performance or use of this material. This document contains information protected by copyright. No part of this document may be photocopied or reproduced in any form without prior written consent from TomTom International B.V.

