

The RF Flex Pointer is a FSK (Frequency Shift Key) Transmitter for the frequency band 433-434 MHz. The Flex Pointer offers a full-integrated PLL synthesizer and a high efficiency power amplifier to drive a loop antenna, A special circuit design and an unique power amplifier design are used to save current consumption and to save battery life.


This RF Flex Pointer is a best companion of Microsoft Power Point designed, lets you Slide Forward, Slide Back , Blank functions , F5 and Esc as desired, when browsing the Internet or scrolling through any Windows documents gives reliable control and accuracy. Flex Pointer RF's radio frequency wireless technology solves all of your presentation input needs.

For the RF Receiver use with USB 1.1 compliant can be easily actuated without affecting the position of the Flex Pointer.



The Radio Frequency designed in this Version of RF Flex Pointer is FSK 433.92MHz and can be use in a range of up to 10 Meter from the Receiver at any directions. The Flex Pointer can operate for 6 months with CR2032 DC 3V Lithium batteries.

Physical Description and Specification:



Dimensions


The approximate dimensions of the remote's transmitter is as follows:





Length	90mm
Width	40mm
Height	22mmB

Weight




The approximate weight of the remote's transmitter is as follows:

Weight of the RF Flex Pointer not to exceed 40 grams (with batteries)



Symbol		Key definition
	Black	Display a black screen or return to the slide show from a black screen
	Slide Forward	Perform the next animation or advance to the next slide
	Slide Back	Perform the previous animation or return to the previous
F5/ESC	F5/ESC	F5: Running your slide show in full screen mode ESC:End a Slide show
		Laser pointer on/offBB

Notice:

- 1.ID Change : Press Both "F5/ESC " and " " buttons simultaneously more than 3 seconds will change the current ID . **(Green LED flashed)**
2. Remote **Power On/Off** : In the remote **ON** mode , press and hold the "F5/ESC " key and press " " buttons more than 3 seconds the remote will be Power Off (Laser Off). Green LED from on to off.
In the remote **Off** mode , press and hold the "F5/ESC " key and press " " buttons more than 3 seconds the remote will be Power On (Laser On). Green LED from off to on.

FCC Warning Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.