

# OWNER'S MANUAL

**CAUTION-ELECTRICALLY OPERATED PRODUCT:**  
NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE, AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK. INPUT: 120V AC 60Hz 300mA, OUTPUT: 7.5V DC 1000mA.



# VAPORIZR™ 2

CONTROLLER



BATTERIES INCLUDED

VEHICLE



BATTERY INCLUDED

8+  
#94155



**Important! Carefully read the Owners Manual before play!**



## CAUTION

---



### **WARNING! CHOKING HAZARD**

Small parts. Not for Children under 3 years.



Only operate the product and its accessories when fully assembled and in accordance with this manual!

- This product and its accessories are not suitable for children under the age of 36 months, because of small parts that can be swallowed.
- Intended for children age 8 and older.
- Adult supervision strongly recommended.
- Drive your vehicle in a safe area away from people, pets, cars, etc.
- Do not drive on streets or after dark.
- Do not touch or try to pick up the vehicle when it is in motion. Wait until it has stopped completely.
- Keep hair, fingers, face and loose clothing away from front and rear wheels while the vehicle is switched on or while the transmitter is operating.
- Do not drive the vehicle toward walls or other hard objects.
- Be a responsible operator!
- Do not drop or give impact to the product and its accessories.
- Check if a near transmitter produces interference or signals with the same frequency. In such a case, move to another location or try again after a while.
- Never attempt to disassemble or modify the product or its accessories.
- Regularly inspect the antennas for cracks or breaks. Do not bend the transmitter antenna. Do not use the transmitter if the antenna is broken.
- The vehicle wire antenna is fragile. Never pull or tug on the antenna, as it may loosen or detach from the vehicle.
- Use extra caution when playing near water or ice.
- Intended to be used on land and in water.
- Do not use the product in salt water or water with strong currents.

## BATTERIES AND CHARGER

---

Included: 6.0V Rechargeable NiMH Battery Pack and Battery Charger for NiMH Battery Pack and AAA/LR03 battery x3.



### **IMPORTANT BATTERY SAFETY INFORMATION**

**CAUTION: TO AVOID BATTERY LEAKAGE (AAA/LR03 and the 6.0V NiMH RECHARGEABLE BATTERY PACK):**

- Make sure the batteries are inserted with correct polarity and follow the toy and battery manufacturer's instructions.
- Use only battery type(s) recommended.
- Do not attempt to short-circuit, charge, disassemble or heat batteries.
- Do not dispose of batteries in fire or make them wet.
- Do not mix or use new and old batteries together.
- Do not mix or use different types of batteries together.
- Non-rechargeable batteries are not to be recharged because of the danger of eruption.
- Remove rechargeable batteries from the product before charging.
- Recharge batteries only under adult supervision and follow the battery and charger manufacturer's instructions.
- Only children of age 8+ are allowed to use the charger and only if used under adult supervision.
- Battery replacement should be done in presence of an adult.
- Never pull a battery pack out of the vehicle by the wire of the plug.
- Remove batteries from the product for storage. Battery may be hot.
- After use, be sure to turn the switch off. Failure to do so may adversely affect batteries, resulting in disabled charged.
- Remove weak or exhausted batteries from the product.
- Dispose batteries safely and properly, according to your local requirements.

---

## BATTERY CHARGING AND CARE

---



**NOTE: NICKEL-METAL HYDRIDE BATTERIES MUST BE RECYCLED OR DISPOSED PROPERLY.** Contact your local area office of solid waste management or other appropriate local agency for information.



**WARNING: The transformer/ charger is not a toy.**

- Regularly examine charger and battery pack for leaking, corrosion, damage, including plugs, casings and all other parts. If damaged, do not use.
- Do not short-circuit the charger.
- Do not charge batteries with a charger other than the included one.
- Do not charge batteries other than the included NiMH battery pack with the charger and do not use the charger as the power source for other equipment.
- Do not charge batteries in a place within the reach of small children.
- Do not short-circuit battery terminals, otherwise the battery may swell and get hot, leading to a dangerous situation.
- Do not use, store or charge batteries in a place near a heater or in high temperature or in humid or damp situations.
- Vehicle will not run without a 6.0V rechargeable NiMH battery pack and matching charger, commonly available for R/C vehicles at many toy and hobby dealers. Always follow the instructions that come with your battery pack and charger.
- Toy must only be used with recommended transformer/ charger.

---

## RUNNING AND CHARGING TIME

---

- NiMH battery packs are not like alkaline batteries. They lose all their power suddenly, not gradually, and the vehicle will stop very soon after slowing down becomes noticeable, with little warning. This is normal, but keep it in mind, since you need to get the vehicle back before the battery power runs out.
- Battery pack running times depend on the conditions you operate in. Running time may vary over the life of the battery pack, with the first few charge cycles yielding shorter run times than later charges.

---

## BATTERY CHARGING INSTRUCTIONS

---



**NOTE: "CONDITION" BATTERY PACK FOR BEST RESULTS BY CHARGING ACCORDING TO THESE INSTRUCTIONS ON EVERY CHARGE. ON THE FIRST CHARGE, EXPECT A SHORTER RUN TIME. RUN TIMES WILL INCREASE OVER THE NEXT 6 CHARGES.**

### **Drain Down-Cool Down-Charge Up**

1. After the first charge, for best performance always run the battery pack fully empty before recharging. Run until vehicle wheels/rotors/propellers/motors slow to stop.
2. Allow the battery pack to cool before recharging.

### **Battery Pack Heat**

1. Battery pack gets hot after use! This is normal, but be careful. Wait until battery pack is cool (20 minutes or more if needed) before charging. Charging battery packs when they are hot will severely reduce the number of times they can be recharged.
2. After charging, battery pack will be warm. This is normal.

---

## RECHARGING INSTRUCTIONS

---

1. Plug the battery pack charger into a standard household outlet.
2. Connect the battery pack to the charger as show in page 5.
3. Red light on the charger to show that the charger is operating. Normal charging time is 60–80 minutes.
4. Red light will blink continuously when the battery pack is fully charged.
5. Unplug the charger from the standard household outlet after 60–80 minutes of charging.
6. After charging, the battery pack will feel warm, this is normal.

---

## NIMH RECHARGEABLE BATTERY PACK TIPS

---

- Don't overcharge the battery pack, unplug the charger from the household outlet at the end of the recommended charging time (Approximately 60–80 minutes).
- Store your battery pack discharged.
- Your battery pack will hold a charge for a shorter time in hot weather.
- The charging time is 60–80 minutes. Make sure the charging time will not be longer or shorter then the advised charging time as that will effect the quality of the battery.
- When the use time of this battery pack becomes shorter and shorter, it is most likely time to replace the battery pack.
- If driving time becomes shorter or wheels do not turn with full power, the capacity of the 1.5V battery or 6.0V battery pack are insufficient. This is the sign indicating that you need to replace the 1.5V battery or recharge the 6.0V battery pack.
- Be sure to recharge the battery pack before driving it. If you do not play with the vehicle immediately after recharging, the charge is drained and the vehicle cannot drive.
- When the battery temperature gets too high, the circuit shuts off automatically to protect the receiver circuit and the battery in the vehicle. In such a case, wait until the battery cools down before recharging or playing with the vehicle.
- If the rechargeable battery is repeatedly charged without being sufficiently discharged first, the capacity will gradually decrease (memory effect of battery). This is a characteristic of rechargeable batteries. Be sure to start recharging after operating the vehicle until they nearly stop.

---

## CAUTION DURING PLAYING WITH VEHICLE

---

- Do not drive your vehicle on streets or in a crowded place.
- When the battery pack gets wet, dry completely before storing it.
- Do not store the vehicle in a place near a heater or where temperature rises. After use, remove the batteries from the transmitter and vehicle to store.
- This vehicle can run on land and in water but it is not fully water–proof! Immersing it into water may lead to a malfunction. Dry vehicle well after operating in water.
- Adult supervision is strongly recommended when playing near water. Do not drive your vehicle in the sea and wavy water surface, or where a rapid current flows. Stay away from areas where waves rise due to a strong wind. Also avoid driving on dirty water surface or where waterweed grows dense, this can cause a malfunction.
- Operate your vehicle in water with due care to the distance and battery life, since you need to get the vehicle back before the battery power runs out.


---

## SAFETY CIRCUIT


---

During use, the internal power in the electric circuit can get quite high (for example during a 360 spin). In such a case a safety circuit will shut down the vehicle for approximately 10–15 seconds. During this period the car will not respond to signals from the transmitter. This is not a defect but a safety measure to protect the electronic circuits. After this period, the car will resume normal operation.


## CONTENTS & FEATURES




## ANTENNA ASSEMBLY




Insert antenna wire from product into tube.




Slide tube down antenna wire and into hole in product.



Tie knot with any remaining antenna wire (Do not pull wire tight).



## TRANSMITTER BATTERY INSTALLATION




1. To remove battery lid, loosen screw to open.
2. Slide open the battery lid in the direction as shown in the figure, while lightly pressing its center.
3. Insert 1.5V (AAA/LR03) batteries x3 with the polarity (+/-) as shown on the bottom of battery compartment.  
Replace the battery lid, following the removal procedure in reverse.

**NOTE:** For best performance, always use alkaline batteries only. To remove the batteries, reverse the installation procedure.

- There is no on/off switch on the Transmitter. Moving the sticks turns it on automatically.

## VEHICLE BATTERY INSTALLATION





1. Fully charge 6.0V NiMH battery pack in advance of your use.
2. Turning off vehicle.
3. Turn the latches located underneath of vehicle to unlock battery lid as shown in the figure with arrows.
4. Loosen screw to open battery lid.
5. Remove battery lid.
6. Insert 6.0V battery pack into battery compartment with correct polarity (+/-). Place battery lid back in position and lock properly




**THIS PRODUCT SHOULD BE USED WITH ADULT SUPERVISION.**

**NOTE:** To remove the batteries, reverse the installation procedure.


## OPERATING R/C VEHICLE




**FORWARD** (Push both sticks forward)



**BACKWARDS** (Pull both sticks backwards)




**LEFT TURN (FORWARD)** (Push right stick forward)




**RIGHT TURN (FORWARD)** (Push left stick forward)

**RIGHT TURN (BACKWARDS)** (Pull right stick backwards)

**LEFT TURN (BACKWARDS)** (Pull left stick backwards)



**LEFT SPIN** (At the same time, pull left stick back and push right stick forward)




**RIGHT SPIN** (At the same time, pull right stick back and push left stick forward)

**NOTE:** After play, always turn vehicle off. Remove batteries from controller and R/C vehicle when not in use or when storing. Leakage may occur and cause damage if left for a long period of time.




## TROUBLESHOOTING AND CARE FOR R/C VEHICLE



### LIMITED RADIO CONTROL RANGE

While R/C vehicle may be visible at a distance, full operational control may be lost. Hold controller high in the air and direct vehicle back.




### INTERFERENCE

Other radio signals may cause loss of control. Remove vehicle from an area of interference.


<p><b>R/C VEHICLE DOES NOT MOVE</b></p>	<ul style="list-style-type: none"> <li>• Are the + and - contacts correctly matched in the controller?</li> <li>• Are the metal contact tabs touching, rusty or dirty in controller?</li> <li>• Are there batteries in the vehicle and controller?</li> <li>• Is the power switch turned to play?</li> <li>• Are the batteries weak or out of power?</li> </ul>
<p><b>R/C VEHICLE MOVES BY ITSELF</b></p>	<ul style="list-style-type: none"> <li>• There is radio interference in the area.</li> <li>• Another R/C vehicle with the same frequency is close by.</li> </ul>
<p><b>R/C VEHICLE RUNS SLOWLY</b></p>	<ul style="list-style-type: none"> <li>• There is radio interference in the area.</li> <li>• Another R/C vehicle with the same frequency is close by.</li> <li>• Are the batteries weak or out of power?</li> </ul>
<p><b>PERFORMANCE DROP, INCONSISTENT MOVEMENT OR FAILS TO RUN</b></p>	<p>Check batteries. If necessary, recharge battery pack and/or replace the batteries in the R/C vehicle and controller with new alkaline batteries.</p>

## TREAT YOUR R/C VEHICLE WELL


Radio waves control the R/C vehicle. Care for your vehicle and it will provide hours of fun!  
Avoid heat, sand and high impact crashes!




Store in safe place.




No direct sunlight.




No sand or dust.



No Collisions.




R/C vehicle may get stuck on carpet or grass.




Avoid running 2 vehicles with the same radio control frequencies.

## CLEANING AND MAINTAINING



Brush areas where dirt and dust get trapped.



Wipe body off with a soft rag or tact cloth.



Do not clean vehicle with chemicals.

## FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE

### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device must not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## MANUFACTURER'S NOTE

"Modifications not authorized by the manufacturer may void users authority to operate the device."

## ATTENTION PARENTS

This toy and all accessories need to be periodically examined for potential hazards and any potentially hazardous parts be repaired or replaced.

[www.toystate.com](http://www.toystate.com)  
[www.NikkoRC.com](http://www.NikkoRC.com)

For questions, e-mail our Consumer Service Dept.at  
[consumerservice@toystate.com](mailto:consumerservice@toystate.com)  
 Or Call 1-877-473-8015



### WARNING:

Not suitable for children under 36 months due to small parts. Choking hazard.



**MADE IN SHENZHEN, CHINA**  
**TOY STATE INTERNATIONAL LIMITED**  
 66 MODY ROAD, KOWLOON, HONG KONG

IN THE INTEREST OF BETTER QUALITY AND VALUE, WE ARE CONSTANTLY IMPROVING AND UPDATING OUR PRODUCTS. CONSEQUENTLY, PICTURES IN THIS INSTRUCTION SHEET MAY SOMETIMES DIFFER FROM THE MODEL ENCLOSED.





[www.toystate.com](http://www.toystate.com)