



For the complete User  
Guide, How-To Videos  
and more visit:


[www.nickwatch.com](http://www.nickwatch.com)

© 2022 VIACOM INTERNATIONAL INC. ALL RIGHTS RESERVED.  
NICKELODEON, NICKWATCH, NICKELODEON SLIME,  
SPONGEBOB SQUAREPANTS, THE LOUD HOUSE, TMNT  
AND ALL RELATED TITLES, LOGOS AND CHARACTERS ARE  
TRADEMARKS OF VIACOM INTERNATIONAL INC.

## WHAT'S IN THE BOX?




NickWatch



Connect-o Cable



Power Station



Simple Strap & Snazzy Strap

**nickWATCH**  
BY: nickelodeon.  
**QUICK START GUIDE**







Kid's 4G watch with WiFi/Bluetooth/  
GPS tracking, camera, and  
Emergency button.

#### 1. Camera

#### 2. Display screen & touch panel

#### 3. Button

- Press once for back button
- Long press for turn on/off
- Very long press to activate SOS

#### 4. Speaker

#### 5. Microphone

#### 6. Charging port

#### 7. Strap holsters



### APP INSTALLATION

Find the free Nickwatch app on Google Play or App Store.

Or scan QR code to go to the app in the Google Play or App Store.



### CREATE THE ACCOUNT

Launch the mobile app, tap "Create Account", and follow the on-screen prompts. You will need to enter a valid email address.

Verify your email address (on your phone) and accept the Privacy Policy and Terms of Service to create the account.

Tap "Add Watch"

Scan the QR code displayed on the watch display with the phone's camera.

If purchased via [nickwatch.com](http://nickwatch.com), Enter the subscription activation code that was sent to you.

Enter your child's information

### CHARGING THE WATCH

Charge the watch by connecting it to the Connect-o Cable OR the Power Station.

Connect the USB to a power source (not included) and ensure that the contacts on the back of the watch engage the port on the charging dock. When the watch is fully charged, remove it from the charging dock.



### SPLASH RESISTANCE

The watch is rated IP68 for dust and splash resistance. You CANNOT immerse the watch in water (for swimming or other sports), and it should not be worn during showering or bathing.

Care should be taken to avoid exposure from moisture due to rain, hand washing or perspiration.







For the complete User  
Guide, How-To Videos  
and more visit:

[www.nickwatch.com](http://www.nickwatch.com)


## WHAT'S IN THE BOX?



NickWatch



Connect-o Cable



Simple Strap & Snazzy Strap



© 2022 VIACOM INTERNATIONAL INC. ALL RIGHTS RESERVED.  
NICKELODEON, NICKWATCH, NICKELODEON SLIME,  
SPONGEBOB SQUAREPANTS, THE LOUD HOUSE, TMNT  
AND ALL RELATED TITLES, LOGOS AND CHARACTERS ARE  
TRADEMARKS OF VIACOM INTERNATIONAL INC.





Kid's 4G watch with WiFi/Bluetooth/  
GPS tracking, camera, and  
Emergency button.

**1. Camera**

**2. Display screen  
& touch panel**

**3. Button**

- Press once for back button
- Long press for turn on/off
- Very long press to activate SOS

**4. Speaker**

**5. Microphone**

**6. Charging port**


**7. Strap holsters**



## APP INSTALLATION

Find the free Nickwatch app on Google Play or App Store.

Or scan QR code to go to the app in the Google Play or App Store.



## CREATE THE ACCOUNT

Launch the mobile app, tap "Create Account", and follow the on-screen prompts. You will need to enter a valid email address.

Verify your email address (on your phone) and accept the Privacy Policy and Terms of Service to create the account.

Tap "Add Watch"

Scan the QR code displayed on the watch display with the phone's camera.

If purchased via [nickwatch.com](http://nickwatch.com), Enter the subscription activation code that was sent to you.

Enter your child's information

## CHARGING THE WATCH

Charge the watch by connecting it to the Connect-o Cable.

Connect the USB to a power source (not included) and ensure that the contacts on the back of the watch engage the port on the charging dock.

When the watch is fully charged, remove it from the charging dock.




## SPLASH RESISTANCE

The watch is rated IP68 for dust and splash resistance. You CANNOT immerse the watch in water (for swimming or other sports), and it should not be worn during showering or bathing.

Care should be taken to avoid exposure from moisture due to rain, hand washing or perspiration.







COLOR:

<p>their children's RF exposure by limiting the length of calls or using 'hands-free' devices to keep mobile devices away from the head and body.</p> <p>Further information on exposure to radio waves can be obtained from the WHO <a href="http://www.who.int/mediacentre/factsheets/fs193/en/">http://www.who.int/mediacentre/factsheets/fs193/en/</a></p>	<p>with care and keep it in a clean and dust-free place.</p> <ul style="list-style-type: none"> <li>Do not expose your device or its accessories to open flames or lit tobacco products.</li> <li>Do not expose your device or its accessories to liquid, moisture or high humidity.</li> <li>Do not drop, throw or try to bend your device or its accessories.</li> <li>Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.</li> <li>Do not paint your device or its accessories.</li> <li>Do not attempt to disassemble your device or its accessories, only authorised personnel must do so.</li> <li>Do not expose your device or its accessories to extreme temperatures, minimum -20 °C and maximum +40 °C. Any temperatures below -20 °C the display/battery may have reduced function due to freezing. After recovering to room temperature full function will be regained. Do not leave the device in your car along, because temperatures in parked cars can exceed this range.</li> <li>Please check local regulations for disposal of electronic products.</li> <li>Do not carry your device in your back pocket as it could break when you sit down.</li> </ul>	<p>They could hurt themselves or others or may accidentally damage the device. Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.</p>	<p><b>ELECTRICAL SAFETY</b></p> <p>Use only approved accessories and chargers. Do not connect with incompatible products or accessories.</p> <p>Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the battery terminals, charger, and device charging point or any electrical contacts on accessories.</p> <p>Do not touch your charger with wet hands. Doing so may cause an electric shock.</p> <p>Do not touch the power cord with wet hands or disconnect the charger by pulling the cord. Doing so may result in electrocution.</p>	<p>Only use the charger supplied, or manufacturer approved replacements intended for use with your device. Using other chargers could be dangerous.</p> <p>Improper use of your device may result in fire, explosion or other hazards.</p> <p>If you believe the battery has been damaged, do not use or re-charge the device and take it to a authorised service centre for testing.</p> <p>Do not puncture or crush the device or allow it to be subjected to any external pressure or force.</p>	<p>ence. You may also consult your hearing aid manufacturer to discuss alternatives.</p>	<p>areas where the air contains chemicals or particles, such as grain, dust, or metal powders.</p>
<p><b>REGULATORY INFORMATION</b></p> <p>The following safety approvals and notices apply in specific regions as noted.</p> <p>The manufacture, hereby, declares that this product is in compliance with the essential requirements and other relevant provisions of Directive (RED) 2014/53/EU.</p> <p>A full copy of the Declaration of Conformity can be found at</p> <p><a href="https://www.nickwatch.com/conformity">https://www.nickwatch.com/conformity</a></p>	<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>POWER SUPPLY</b></p> <p>Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.</p>	<p><b>DEMAGNETISATION</b></p> <p>To avoid the risk of demagnetisation, do not allow electronic devices or magnetic media close to your device for a long time.</p> <p>Avoid other magnetic sources as these may cause the internal magnetometer or other sensors to malfunction and provide incorrect data.</p> <p>Glass Display</p> <p>LCD and window of the product's front panel are made of glass. Be careful since the product may be damaged by severe impact. If damaged, be careful not to get hurt by pieces of broken glass. If the product's window is damaged, immediately cease product use and contact Customer Service for repair.</p>	<p><b>INTERFERENCE</b></p> <p>Care must be taken when using the device near personal medical devices, such as pacemakers and hearing aids.</p>	<p><b>MEDICAL DEVICES</b></p> <p>Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the operation of your medical device.</p>	<p><b>BLASTING CAPS AND AREAS</b></p> <p>Turn off your mobile device or wireless device when in a blasting area or in areas posted turn off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.</p>
<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>POWER SUPPLY</b></p> <p>Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.</p>	<p><b>FAULTY AND DAMAGED PRODUCTS</b></p> <p>Do not attempt to disassemble the device or its accessory.</p> <p>Only qualified personnel should service or repair the device or its accessory.</p> <p>If your device or its accessory has been submerged in water or other liquid, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorised service centre.</p>	<p><b>PACEMAKERS</b></p> <p>Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker.</p>	<p><b>HOSPITALS</b></p> <p>Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.</p>	<p><b>DISPOSAL AND RECYCLING</b></p> <p>This symbol on your device, battery and accessories means that these products must be taken to collection points at the end of their life:</p> <ul style="list-style-type: none"> <li>Municipal waste disposal centers with specific bins for these items of equipment.</li> <li>Collection bins at points of sale</li> </ul> <p>They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.</p>
<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>POWER SUPPLY</b></p> <p>Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.</p>	<p><b>FAULTY AND DAMAGED PRODUCTS</b></p> <p>Do not attempt to disassemble the device or its accessory.</p> <p>Only qualified personnel should service or repair the device or its accessory.</p> <p>If your device or its accessory has been submerged in water or other liquid, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorised service centre.</p>	<p><b>PACEMAKERS</b></p> <p>Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker.</p>	<p><b>HOSPITALS</b></p> <p>Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.</p>	<p><b>DISPOSAL AND RECYCLING</b></p> <p>This symbol on your device, battery and accessories means that these products must be taken to collection points at the end of their life:</p> <ul style="list-style-type: none"> <li>Municipal waste disposal centers with specific bins for these items of equipment.</li> <li>Collection bins at points of sale</li> </ul> <p>They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.</p>
<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>PRODUCT HANDLING</b></p> <p>You alone are responsible for how you use your device and any consequences of its use.</p> <p>You must always switch off your device whenever the use of a device is prohibited. Use of your device is subject to safety measures designed to protect users and their environment.</p> <ul style="list-style-type: none"> <li>Your device has an IP68 water and dust resistance rating. However, the watch is not designed for swimming, diving, or prolonged submersion in water.</li> <li>Do not charge your watch while it is wet.</li> <li>Always treat your device and its accessories</li> </ul>	<p><b>POWER SUPPLY</b></p> <p>Do not connect your device to the power supply or switch it on until instructed to do so in the installation instructions.</p>	<p><b>FAULTY AND DAMAGED PRODUCTS</b></p> <p>Do not attempt to disassemble the device or its accessory.</p> <p>Only qualified personnel should service or repair the device or its accessory.</p> <p>If your device or its accessory has been submerged in water or other liquid, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorised service centre.</p>	<p><b>PACEMAKERS</b></p> <p>Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker.</p>	<p><b>HOSPITALS</b></p> <p>Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.</p>	<p><b>DISPOSAL AND RECYCLING</b></p> <p>This symbol on your device, battery and accessories means that these products must be taken to collection points at the end of their life:</p> <ul style="list-style-type: none"> <li>Municipal waste disposal centers with specific bins for these items of equipment.</li> <li>Collection bins at points of</li></ul>

