

COMPLIANCE INFORMATION

UL Listed
C-UL Listed (Canada)
CISPR22/EN55022 Class A + EN55024
CE Mark

FCC Regulations

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at the user's own expense.

Canadian Regulations

This digital apparatus does not exceed the Class A limits for radio noise for digital apparatus set out on the radio interference regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

European Regulations

Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Achtung !

Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in weichen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention !

Ceci est un produit de Classe A. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées



CAUTION: RJ connectors are NOT INTENDED FOR CONNECTION TO THE PUBLIC TELEPHONE NETWORK. Failure to observe this caution could result in damage to the public telephone network.

Der Anschluss dieses Gerätes an ein öffentliches Telekommunikationsnetz in den EG-Mitgliedstaaten verstösst gegen die jeweiligen einzelstaatlichen Gesetze zur Anwendung der Richtlinie 91/263/EWG zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über Telekommunikationsendeinrichtungen einschliesslich der gegenseitigen Anerkennung ihrer Konformität.

Trademark Notice

All registered trademarks and trademarks are the property of their respective owners.


Copyright Restrictions

© 2001, 2002 TRANSITION Networks.

All rights reserved. No part of this work may be reproduced or used in any form or by any means – graphic, electronic, or mechanical – without written permission from TRANSITION Networks.

Printed in the U.S.A.

33202.C



T1/E1 Twisted-Pair Copper to Fiber

Media Converters

SSDTF10xx*-100

USER'S GUIDE

TRANSITION Networks SSDTF10xx-100 series media converters encode and decode T1 or E1 twisted-pair copper signals over duplex fiber-optic cable to extend the distance and transmission reliability of high speed T1 or E1 data traffic.

SSDTF1011-100

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and a set of RX/TX **ST** connectors to **850 nm multimode** duplex fiber-optic cable.

SSDTF1012-100

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and an RX/TX **ST** connector to **1300 nm singlemode** duplex fiber-optic cable.

SSDTF1013-100

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and an RX/TX **SC** connector to **850 nm multimode** duplex fiber-optic cable.

SSDTF1014-100

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and an RX/TX **SC-SM** connector to **1300 nm singlemode** duplex fiber-optic cable.



SSDTF1015-100 (long haul)

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and an RX/TX **SC-LH** connector to **1300 nm singlemode** duplex fiber-optic cable.

SSDTF1022-100 (long haul)

Provides an RJ-45 twisted pair copper connector for T1 or E1 signals and an RX/TX **ST** connector to **1300 nm singlemode** duplex fiber-optic cable.

SSDTF10xx in the Network	2
Installation	3
Operation	7
Fault Isolation and Correction	8
Cable Specifications	9
Technical Specifications	11
Compliance Information	12

*In SSDTF10xx model designation, **10** represents the T1 or E1 RJ-45 connector; **xx** represents the selectable fiber connector installed on the media converter.

CABLE SPECIFICATIONS (continued)

Twisted-Pair Copper Cable

Twisted pair connection requires two active pairs. The two active pairs in a T1/E1 network are pins 1 & 2 and pins 4 & 5. Use only dedicated wire pairs (such as blue/white & white/blue, orange/white & white/orange) for the active pins.

Category 3 or better twisted-pair copper wire is required. Either shielded twisted-pair (STP) or unshielded twisted-pair (UTP) can be used.

T1:

Gauge	24 to 22 AWG
Attenuation	2.6 dB/100 meters @ 1.0 MHz
Differential Characteristic Impedance	100 Ω \pm 10%


E1:

Gauge	24 to 22 AWG
Attenuation	2.6 dB/100 meters @ 1.0 MHz
Differential Characteristic Impedance	120 Ω \pm 10%

Dry-Contact Relay

RJ-45 dry-contact relay opens if power, signal detect/copper or signal detect/fiber are lost.

Operational rating on pins 3 and 6: 0-30VDC maximum 1A



Switch-Selectable Configurations

T1 COPPER RJ-45

Configured as either "long haul" or "short haul" on 100 ohm cable, with a variety of selectable distance settings.

E1 COPPER RJ-45

Configured as either "long haul" or "short haul" on 120 ohm cable.


STRAIGHT-THROUGH/CROSSOVER RJ-45

Allows straight-through cable to be used where crossover-configuration cable is required.

Switch-Selectable Functions

LOOPBACK TEST FUNCTION

A loopback switch facilitates installation and network debug procedures. The path for the SSDF10xx loopback is shown:



TRANSMIT ALL ONES FUNCTION

A selectable Transmit All Ones switch on the fiber interface and on the twisted-pair interface allows for insertion of an "all ones" pattern on that interface when *signal detect* is lost, which creates an alarm condition at the equipment connected to the interface.

INSTALLATION

CAUTION: Wear a grounding device and observe electrostatic discharge precautions when setting switch and when installing Media Converter Slide-in-Module in the Media Conversion Center. Failure to observe this caution could result in damage to, and subsequent failure of, the Media Converter Slide-in-Module.

Set Loopback Test Switch

NOTE: The Loopback Test switch, located on Media Converter Slide-in-Module front panel, allows the network administrator to enable a loopback test for installation and network debug procedures.




Use small flatblade screwdriver or similar device to set recessed switches. Refer to drawing for switch locations.

Set MDI/MDI-X Switch

NOTE: The MDI/MDI-X switch allows the network administrator to use straight-through cable in installations where crossover-configuration cable is required.

Use small flatblade screwdriver or similar device to set recessed switches. Refer to drawing for switch settings.



Set 8-Position Switch

NOTE: An eight-position switch allows the network administrator to configure the media converter for network conditions.

Use small flatblade screwdriver or similar device to set recessed switches for site installation. Refer to drawings at right for eight-position switch settings.

CABLE SPECIFICATIONS

Fiber Cable

Bit error rate: $\leq 10^{-9}$

MULTIMODE

Fiber Optic Cable Recommended: 62.5 / 125 μm multimode fiber
Optional: 100 / 140 μm multimode fiber
85 / 125 μm multimode fiber
50 / 125 μm multimode fiber

SSDTF1011-100

Fiber Optic Transmitter Power: min: -14.0 dBm max: -12.0 dBm
Fiber Optic Receiver Sensitivity: min: -25.0 dBm max: -12.0 dBm

Typical Maximum Cable Distance*: 2 kilometers

SSDTF1013-100

850 nM
Fiber-optic Transmitter Power: min: -14.0 dBm max: -12.0 dBm
Fiber-optic Receiver Sensitivity: min: -25.0 dBm max: -12.0 dBm

Typical Maximum Cable Distance*: 2 kilometers

SINGLEMODE

Fiber Optic Cable Recommended: 9 μm singlemode fiber

SSDTF1012-100

1300 nM
Fiber-optic Transmitter Power: min: -21.0 dBm max: -14.0 dBm
Fiber-optic Receiver Sensitivity: min: -25.0 dBm max: -14.0 dBm

Typical Maximum Cable Distance*: 8 kilometers

SCSDTF1014-100

1300 nM
Fiber-optic Transmitter Power: min: -21.0 dBm max: -14.0 dBm
Fiber-optic Receiver Sensitivity: min: -27.0 dBm max: -14.0 dBm

Typical Maximum Cable Distance*: 8 kilometers

SSDTF1015-100 (long haul)

1300 nM
Fiber-optic Transmitter Power: min: -15.0 dBm max: -5.0 dBm
Fiber-optic Receiver Sensitivity: min: -27.0 dBm max: -14.0 dBm

Typical Maximum Cable Distance*: 15 kilometers

SSDTF1022-100 (long haul)

1300 nM
Fiber-optic Transmitter Power: min: -15.0 dBm max: -5.0 dBm
Fiber-optic Receiver Sensitivity: min: -25.0 dBm max: -14.0 dBm

Typical Maximum Cable Distance*: 15 kilometers

*Actual distance dependent upon physical characteristics of network installation.

FAULT ISOLATION and CORRECTION

If the media converter fails, isolate and correct the failure by determining the answers to the following questions and then taking the indicated action:

1. Is the P(o)W(e)R LED on the media converter illuminated?

NO

- Is the power adapter the proper voltage and cycle frequency for the AC outlet?
- NOTE: Refer to the "Power Supply Requirements" on page 7.
- Is the power adapter properly installed in the media converter and in the outlet?
- Contact Technical Support: (800) 260-1312/(800) LAN-WANS.

YES

- Proceed to step 2.

2. Is the SDF (Signal Detect/Fiber) LED illuminated?

NO

- Check fiber cables for proper connection.
- Verify that TX and RX cables on media converter are connected to RX and TX ports, respectively, on other media converter.
- Contact Technical Support: (800) 260-1312/(800) LAN-WANS.

YES

- Proceed to step 3.

3. Is the SDC (Signal Detect/Copper) LED illuminated?

NO

- Check twisted pair cables for proper connection.
- Check RJ-45 Pinning Switch for correct twisted pair cable configuration.
- Check integrity of device attached to media converter by twisted-pair cable.
- Contact Technical Support: (800) 260-1312/(800) LAN-WANS.

YES

- Contact Technical Support: (800) 260-1312/(800) LAN-WANS.


NOTE:

T1 must be selected (LEFT SWITCH SET #4 UP) for RIGHT SWITCH SET to have any effect.


If E1 is selected (LEFT SWITCH SET #4 DOWN), RIGHT SWITCH SET is ignored and the default is E1 3.0V 120Ω cable.

If T1 and short haul are selected (LEFT SWITCH SET #3 UP, #4 UP), but RIGHT SWITCH SET is not set to a valid short haul value, the short haul default is DSX-1 0'-133' cable.

If T1 and long haul are selected (LEFT SWITCH SET #3 DOWN, #4 UP), but RIGHT SWITCH SET is not set to a valid long haul value, the long haul default is 0db 100Ω cable.




LEFT SWITCH SET




toward chassis toward network connectors

NETWORK Switch Settings

1 2 3 4



Transmit All Ones onto Fiber on loss of TP Carrier Detect
UP= Enabled



Transmit All Ones onto TP on loss of FiberCarrier Detect
UP= Enabled




Long Haul/Short Haul (T1 only)
UP= Short Haul



T1/E1 Selection
UP= T1

RIGHT SWITCH SET



toward chassis toward network connectors

LONG HAUL Switch Settings*

1 2 3 4



-22.5db
100 ohm cable



-15db
100 ohm cable



-7.5db
100 ohm cable



0db
100 ohm cable

SHORT HAUL Switch Settings*


1 2 3 4




DSX-1 533'-655'
100 ohm cable




DSX-1 399'-533'
100 ohm cable




DSX-1 266'-399'
100 ohm cable



DSX-1 133'-266'
100 ohm cable



DSX-1 1 0'-133'
and ANSI T1.403
100 ohm cable



DSX-1 6.0V
100 ohm cable

*Right switch set #4 not used

*Right switch set #4 not used

INSTALLATION (continued)

Install Cable


COPPER

T1 100 OHM (RJ-45 CONNECTOR)

1. Locate or build twisted-pair cables that are compliant with specifications on page 10, with RJ-45 plug connectors at both ends.
2. Ensure that MDI/MDI-X switch is set according to network conditions.
3. Connect RJ-45 plug connector at one end of cable to media converter RJ-45 jack connector.
4. Connect RJ-45 plug connector at other end of cable to network equipment.

FIBER

1. Locate or build fiber cables that are compliant with specifications on page 9, with male two-stranded TX to RX connectors installed at both ends.
2. Connect cable with connector installed at TX location on media converter to RX location on attached device.



3. Connect cable with connector installed at RX location on media converter to TX location on attached device.

Power the Media Converter

1. Install power adapter cord at back of media converter.
2. Connect power adapter plug to AC power.
3. Verify that media converter is powered by observing illuminated LED(s).

OPERATION


After installation, the media converter should function without operator intervention.

Status LEDs

Use the status LEDs to monitor media converter operation in the network.

SDC

Signal Detect/Copper - Steady LED indicates twisted-pair copper link is up.
Flashing LED (once/second) indicates transmitting on link if other link is down.
Flashing LED (5 times/second) indicates All Ones detected on Link.



SDF

Signal Detect/Fiber - Steady LED indicates fiber link is up.
Flashing LED (once/second) indicates transmitting on link if other link is down.
Flashing LED (5 times/second) indicates All Ones detected on Link.

P(o)W(e)R

Steady green LED indicates connection to external AC power.