


# User Manual

Kitchen Scale

GKS-1136-BT



- Thank you very much for selecting the Transtek Kitchen Scale GKS-1136-BT.
- Please do read the user manual carefully and thoroughly so as to ensure the safe usage of this product, and keep the manual well for further reference in case you have problems.






TRANSTEK

## Table of Contents

Symbol Meaning .....	2
Initial Setup .....	2
Pairing with the App .....	2
Weight Measurements .....	3
Tare (Add & Weigh) .....	3
Kitchen Timer .....	4
Bluetooth Smart .....	4
Touch Sensitive Controls .....	4
Automatic Shut-off .....	4
Blue Backlight Display .....	5
Sounds .....	5
Proper Use & Care .....	5
Warning Messages .....	6
Product Specifications .....	6
Maintenance .....	7
Warranty .....	7

## ♥ Symbol Meaning



The warning signs and symbols are essential to ensure your correct and safe use of this product and protect you and others from injury. Please kindly find the meanings of the warning signs and symbols, which you may encounter in the label and user manual, as follows:

	Symbol for "THE OPERATION GUIDE MUST BE READ"		Symbol for "COMPLIES WITH MDD 93/42/ECC REQUIREMENTS"
	The Bluetooth Combination Mark		Symbol for "ENVIRONMENT PROTECTION – Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice"
<b>SN</b>	Symbol for "SERIAL NUMBER"		

## ♥ Initial Setup

1. Remove batteries from plastic wrap and insert them into the battery compartment located beneath the scale.
2. Download the free Escali SmartConnect app from the Apple App Store.
3. Remove the app reminder cling from the scale & wipe clean.

## ♥ Pairing with the App

1. Turn on bluetooth for your iPhone or iPad.
2. Install and open the App.
3. Create a profile (optional ) or select "USE AS A GUEST".
4. Navigate to the KITCHEN screen.
5. Press the Bluetooth button  and the symbol will turn blue.
6. Turn on the Kitchen Scale. 

Hardware requirements:

iPhone 4s (or newer), iPad 3rd generation (or newer), iPad Mini (or newer), iPod Touch 5th generation(or newer)

Software requirements:



iOS 6.0 (or newer)



Attention!

Open the app before turning on the kitchen scale for successful pairing. If you have troubles pairing the scale with the app turn off the scale, completely close the app and start over at step 1.


## ♥ Weight Measurements

1. Press the power  to turn the scale on.
2. Press UNIT  to change units(pounds, ounces, grams.)
3. Place an item on the scale in the center of the platform.


## ♥ Tare (Add & Weigh)

Ignore the weight of a container:


1. Place a container on the platform before turning the scale on.
- OR-

1. Turn the scale on, add the container and press TARE 
2. Wait 3 seconds and zero weight will display.
3. Add items into the container to be weighed.

Find the individual weight of multiple items in one container:

1. Press TARE  to reset the scale back to zero weight.
2. Add additional items to be weighed.
3. Repeat steps 1-2 for each additional item.

Reset the scale back to zero weight:









1. If nothing is on the scale and it does not read zero weight, press TARE  to reset the scale back to zero weight.



Attention!

The scale will tare any amount of weight. Once the total weight actually on the scale reaches the maximum capacity of 11 pounds( 5000 g.) the overload warning code (EEEE) will display.

## ♥ Kitchen Timer

1. Press the timer symbol  to enter into the timer feature.
2. Press UNIT  to change numbers. Press  to confirm.
3. After selecting the last number, press  to start the timer.
4. Press  to switch back into scale mode. The timer will continue to run. Press  to switch back into timer mode.
5. To reset the timer, press and hold  while in timer mode.
6. Press  to turn off the alarm.

## ♥ Bluetooth® Smart

Bluetooth® Smart wireless technology allows for the Transtek Kitchen Scale to automatically send weight measurements to your iPhone or iPad for enhance functionality. Download the app from the APP Store.

## ♥ Touch Sensitive Controls

- \* The controls are touch sensitive.
- \* Light contact with the surface of the controls will activate them.
- \* Pressing hard on the controls will cause the scale to malfunction.
- \* You must operate the controls with bare hands.



## ♥ Automatic Shut-off

The scale will turn off after 5 minutes of inactivity to save battery.

## ♥ Blue Backlight Display

- \* The backlight will turn on when adding items onto the scale.
- \* The backlight turns off automatically after 18 seconds of inactivity.


## ♥ Sounds

- \* To silence the confirmation beeps press and hold UNIT .
- \* The kitchen timer alarm will not be silenced.
- \* To reactive the confirmation beeps press and hold UNIT .

## ♥ Proper Use & Care

- \* Use and stow the scale at room temperature.
- \* Use on a flat, level and stable surface.
- \* The scale is an instrument of precision. Do not submit the scale to shaking, excessive vibration or other rough treatment.
- \* The display may be affected by electromagnetic disturbances such as radios, microwaves or cell phones. If such disturbances occur, remove the source of the disturbance and restart the scale.
- \* Disassembling or tampering with the scale will void the warranty.
- \* Clean the scale with dish soap and a damp cloth.
- \* Do not submerge in liquid. The scale is not waterproof.

## ♥ Warning Messages

EEEE	Overload warning.
unSt	Unstable surface warning.
out2	Load cell is permanently damaged.
	Low battery warning.

## ♥ Product Specifications

Model: GKS-1136-BT  
Capacity: 11 lb.(5000 g)  
Graduation: 0.1oz. (1g.)  
Dimensions: 10 inches x 6 inches x 3/4 inch (Approx. 251.2 mm x 151.2 x 18.5 mm)  
Power Source: 3 x AAA size batteries (included)  
Automatic off : 5 minutes  
LCD Display: 56 x 45 mm  
Working Environment: Temperature: 0 °C to 40 °C Humidity: ≤90% RH  
Storage Environment: Temperature: -20 °C to 60 °C Humidity: 10%RH to 93% RH

### Caution

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## ♥ Maintenance

When carrying out usual maintenance, please ensure practice of the following Do's and Don'ts:

- DO use a dry soft cloth to wipe the dust.
- DO use a wet soft cloth, dipped into water and wrung out, to wipe the dirt. Then use a dry soft cloth to dry up the device.
- DON'T wash the device with water or immerse it in water.
- DON'T use propellant, abrasive or other chemicals to wipe the dirt in avoidance of discolor or malfunction.
- DON'T disassemble this device. If you have any problems, please contact Transtek.  
(Please refer to Warranty for contact information)

## ♥ Warranty

- Transtek warrants its products free of defects in materials and workmanship in normal use for a period of TWO years from the date of retail purchase.
- This warranty does NOT cover damages caused by misuse or abuse, including but not limited to:
  - Failure caused by unauthorized repairs or modifications;
  - Damage caused by shock or drop during transportation;
  - Failure caused by improper operation inconsistent with the instructions stated in this user manual;
  - Malfunction or damage from failure to provide the recommended maintenance;
  - Damage caused by improper use of power supply.
- Should this device require maintenance (or replacement at our option) under warranty, please deliver the original package to GUANGDONG TRANSTEK MEDICAL ELECTRONICS CO., LTD prepaid. Please return the store receipt (with the retail purchase date) and a note with reasons to return on it as well.

GUANGDONG TRANSTEK MEDICAL ELECTRONICS CO., LTD  
Zone A, 5/F., Investment Building, No. 12 Huizhan East Rd., Torch Development District,  
Zhongshan, 528437, Guangdong, China  
Tel: 86-760-88282982  
Website: <http://www.transtek.cn>

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.