

WLS919

Wireless Key


Available Model: WLS919-433




OPERATING INSTRUCTIONS

The WLS919 wireless key allows you to arm and disarm your alarm system, as well as perform other keypad functions, from a unit small enough to keep in your pocket. Together with your installer, you can decide which functions you wish to have accessible from your portable key.

To activate any one of the four selected functions, press and hold the appropriate button for two seconds. The functions will be etched on each button. These can be changed by the installer by placing labels on the button that needs to be changed.



False Alarm Prevention

The WLS919 has a slide cover, used to cover 2 or all of the buttons, to prevent accidental activation. The WLS919 is shipped with a red panic button (). The color difference will make this button easy to identify to ensure the correct key is pressed in a panic situation.

! Signals will not be received if the key is not within the range of the wireless receiver.

The default functions are as follows:



Stay Arming

Press this button to arm your system in the Stay mode. All perimeter zones will be armed, such as all window and door contacts, but the interior zones will remain inactive, allowing you to stay on the premises without setting off an alarm.



Away Arming

Press this button to arm your system in the Away mode. Both the interior and exterior zones will be armed, allowing you to exit the premises.



Disarm

Press this button to disarm your system. You do not have to enter your access code when you use the key to disarm the system.



Panic

Press this button to notify your central monitoring station of a situation requiring the police, such as a break-in.

Other available functions (to be programmed by the installer):



Fire

Press this button to notify your central monitoring station of a fire condition.



Auxiliary

Press this button to notify your monitoring station of a non-medical emergency.



Quick Exit

Press this button to allow 2 minutes to exit the premises while the system is armed, without sounding the alarm.



System Test

Press this button to activate a system test. The alarm will sound for 2 seconds and a communication will be sent to the central monitoring station, if programmed to do so.

Please discuss all WLS919 options with your installer in order to program the best possible combination to suit your needs.


Testing the WLS919 Key

When any key is pressed on the WLS919 to perform a function, its battery status is sent to the receiver. If the batteries are low, the Trouble light on your system's keypads will turn ON. If this occurs, the key's batteries must be replaced.

! *Do not use a Fire, Auxiliary or Panic key to test your WLS919 unit as pressing these buttons will always notify your monitoring station of a non-medical emergency.*

Replacing the Batteries

The WLS919 Wireless Key requires two lithium CR2032 batteries. To replace the batteries, open the key's plastic housing by inserting a flathead screwdriver along the side of the unit and carefully twist the screwdriver to separate the top and bottom plastic. Once separated the batteries will be visible, simply remove the old batteries and insert the new ones.



! *The polarity of the batteries must be observed, as shown in the diagram above.*

LIMITED WARRANTY

Digital Security Controls Ltd. warrants that for a period of twelve months from the date of purchase, the product shall be free of defect in materials and workmanship under normal use and that in fulfillment of any breach of such warranty, Digital Security Controls Ltd. shall, at its option, repair or replace the defective equipment upon return of the equipment to its repair depot. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of Digital Security Controls Ltd. such as lightning, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or liabilities on the part of Digital Security Controls Ltd. This warranty contains the entire warranty. Digital Security Controls Ltd. neither assumes, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

In no event shall Digital Security Controls Ltd. be liable for any direct, indirect or consequential damages, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

WARNING: Digital Security Controls Ltd. recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

FCC COMPLIANCE STATEMENT

CAUTION: Changes or modifications not expressly approved by Digital Security Controls Ltd. could void your authority to use this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

The user may find the following booklet prepared by the FCC useful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402, Stock # 004-000-00345-4.

Digital Security Controls Ltd. 160 Washburn St., Lockport, NY 14094

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Ce dispositif satisfait aux exigences d'Industrie Canada, prescrites dans le document CNR-210. son utilisation est autorisée seulement aux conditions suivantes: (1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.



©2000 Digital Security Controls Ltd.

www.dsc.com

Printed in Canada 29005248 R001