
Mini Wireless Keyboard

instructions





Introduction:

- PC Keyboard for Home entertainment, multi-media Education, Training, Conference, presentation controlled with computer.
- Perfect for Pad, Andriod TV Box, Google TV Box, Xbox360,PS3, HTPC/IPTV

Package:

- Mini Keyboard
- User manual
- USB cable

Feature:

- Portable and handheld size
- Full QWERTY keyboard
- Ultra-sensitive mouse touchpad
- Supports multi-touch gesture and Scrolling bar
- Supports multi language (need to be customized)

Specifications:


- Wireless connection
- Max Distance:10 m
- Size:147X99.5X21.6mm
- Weight:110g
- Transmit power: +5db Max
- Operation voltage: 3.3V
- Power Supply: Two version for choosing
 - a.1.5V 3A Battery x2
 - b. Rechargeable Li-ion battery

System Requirement:

- Windows
- Mac OS
- Linux
- Android/Google/Smart TV

6.How to use

6.1.Start up





2.Plug USB dongle into any USB port of your device (Raspberry Pi/Smart TV /PC)



1. Open the battery cover, take USB dongle out



Power Switch

3. Turn the unit on by switching the power switch to on (the LED would be flashing then go out)

4. The connection is successful

(slide your finger on touchpad you can see the cursor moving on the screen)

- 6.2. Pair:in case of lose connection between USB dongle and keyboard, please follow below steps to do re-pair procedure:
- 6.2.1. Press button "Fn" and "" at the same time till LED flash;
- 6.2.2. Plug USB dongle into any USB port of your computer;
- 6.2.3. Approach mini keyboard to the USB dongle and LED off means re-pair is successful.

6.3. Recharge your keyboard: when your keyboard I flashing without any operation that means your keyboard is in low charge, and need to recharge Connect your keyboard to your computer with mini end of USB cable to your keyboard and another end to computer, then A will light up with steady on, and go out when it is fully recharged.



6.4. To avoid the RF-signal blocked by TV metal case Please use the supplied extend USB cable

Note: Work with Raspberry Pi/Smart TV:

1.How to use:

- 1.1. Open the battery cover, take out the USB dongle
- 1.2 .Plug USB dongle into device USB port.
- 1.3. Before connection established ,it will take seconds to install driver by USB dongle itself.

2. If still can't work or lost connection in using, Please do re-pair procedure as following

2.1. Charge battery for one hour and press FN+ r simultaneously till LED flash

2.2. Plug the USB dongle into device USB port and put the keyboard closer to the USB dongle

2.3. LED off means re-pair procedure is completed successfully.

Multi-touch application:

the touchpad supports various gesture, the related gesture and function is described below:

Touchpad Function	Mouse Function	Finger Gesture	Finger Action	Remark
Moving	Move Cursor		Slide one finger on the touchpad	
Middle botton click	Middle botton click		Tap the touchpad with two finger simultaneously	Scroll upward scroll downward Scroll pages quicky when browse website
Vertical two finger scroll	Scroll middle key	NT T	Slide two finger vertically	Zoom in or out the picture when view pictures
Right click	Right button click		Tap the touchpad with three fingers simultaneously	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.