



Manual

DSP-A45

Distributed media player

v1.01-090519-152900

DSP-A45 MANUAL



DSP-A45 MANUAL

Introduction

DSP-A45 distributed media player is designed for information distribution system with high display resolution. DSP-A45 is perfect for all kinds of multimedia signage application or videowall display. With its advanced integration, DSP-A45 provides functions of video stream decoding, audio frequency transmission and videowall display and more. DSP-A45 is designed with ZX2800M A17 quad-core processor which brings an efficient experience in building distributed videowall display system or digital signage system.

1.1 Feature

- ◎ **Server-less architecture / Power-on and play**
DSP-A45 is designed in server-less architecture. With its easy installation, Power-on DSP-A45 and it plays the content immediately.
- ◎ **Support Mobile APP**
VIA provides mobile control App to ease user's manipulating experience
- ◎ **Support various types of display unit**
Support to numerous splicing videowall and not limited to portrait or landscape display
- ◎ **Support 4K video playback and video switch**

①



DSP-A45 MANUAL



DSP-A45 MANUAL

1.2 Specification

CPU

ZX-2800M Cortex-A17 quad-core processor

Memory

2GB

Storage

16GB eMMC

Graphics Unit

Highly integrated Elite2000S1 2D/3D graphics processor
Support DX11 Level 9.3
Support H.265(4K@60fps) or H.264(4K@30fps) video decoding
Support AAC/PCM audio decoding

Front I/O

1 x power indicator

Back I/O

1 x DC-in jack
1 x Ethernet Lan port
2 x USB 3.0 port
1 x HDMI 2.0 port
1 x RS232

1 x Line Out

1 x Micro SD slot

1 x WIFI antenna

Power supply

12V DC-in

Working environment

-20°C ~ 45°C

Chassis

Aluminum alloy chassis

Dimension

152(L) x 29(H) x 112.5(W) mm

Weight

290 g

Accessory

2 x brackets

②

③



1.3 I/O Interface




Figure 1: Front




Figure :: Dimension (Front)

④




Activate the system

Click **MagicView®** mobile APP to search the players in the intranet. Choose “Search the monitor” and it will auto-search all DSP-A45. This will take a few minutes, please be patient until the process is done. Next step, is to activate the system. Please input the activation code from your vendor.

Note: While activating the system, please be aware that your device must be accessed to the Internet.

After activation is done, user may start to publish the content to a signage or in videowall.

For more information , please check **VIA MagicView®** manual.



⑥



Ready to use DSP-A45

Please insert a SD card (with at least 32G Capacity) into one of DSP-A45, and then connect all players to the screens and Intranet router. Scan the QR code on the screen to download **MagicView®** mobile APP first. Then activate your phone WiFi and connect to the same Intranet with all players.



Scan the QR code and download
MagicView® mobile APP

VIA TECHNOLOGIES (SHENZHEN) CO., LTD

VIA Building 4F, NO. 9966, Shennan Avenue, Nanshan District, Shenzhen, PR China, Shenzhen, 518057
Contact number: 400-818-5166

Mailbox: embedded@viatech.com.cn

⑤

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

⑥