



P² Page&Point

- GB** Instruction Manual
- F** Manuel d'utilisation
- D** Bedienungsanleitung
- I** Manuale d'istruzioni
- E** Manual de instrucciones
- NL** Gebruiksaanwijzing
- S** Bruksanvisning
- P** Manual de Instruções
- PL** Instrukcja obsługi
- RUS** Руководство по эксплуатации
- CZ** Návod k obsluze
- H** Használati útmutató

Specifications

	Nobo P ² Page & Point
Range	Up to 8m
Frequency	2.4 GHz Wireless Technology
Radio Classification	Class 1 Radio Equipment
RF Maximum Output	1 mW
Wavelength	650nm
Power Level	Less than 1 mW
Laser Classification	Class II Laser Product in compliance with EN60825-1
Laser Distance	Up to 200m
System Requirement	PC running Windows® 98 SE or later or Macintosh® computer with USB port running Mac® OS 9 or later.
Material	Painted ABS Plastic
Colour	Dark Blue

Special notice


Congratulations on your purchase of a Nobo P² Page & Point, a Wireless Presenter with built-in laser pointer which will enable you to control your presentation from up to 8m.

Caution



Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous exposure.

Warning



- Do not stare into the laser beam or direct it into another person's eyes.
- Keep your laser pointer out of children's reach.
- Do not disassemble the laser pointer.
- Avoid dropping on hard surfaces.

Replacing the Batteries



Unscrew the bottom of the Nobo P² Page & Point, where the three buttons are situated, and remove the used battery. Insert one AAA battery. Screw back in the bottom of the Wireless Presenter.

Features

Your new Nobo P² Page & Point contains many features:

- Page Up Page Down buttons, enabling you to move forwards and backwards in your presentation.
- A high quality laser pointer incorporating advanced laser optics and microelectronics.
- A USB receiver which slots conveniently into the end of the Wireless Presenter for safe-keeping.
- Up to 8m of wireless range.
- Simple and easy to use – just Plug & Play.
- Compatible with most presentation applications including Microsoft® PowerPoint.
- No software required.

Connecting your P² Page & Point

Plug the USB receiver into your computer's USB port. You do not need to turn off your computer before connecting or disconnecting the USB receiver.

Operating your P² Page & Point

- Press the button to activate the laser pointer and release to deactivate (★).
- Press the Page Down button (▼) to move **forward** one slide in your presentation.
- Press the Page Up button (▲) to move **back** one slide in your presentation.

Tips

- First point the laser pointer at the desired information you wish to highlight. Then switch on the laser pointer and align.
- Do not keep the laser pointer switched on for more than a few seconds in order to keep your audience's attention.

Warranty

The Nobo P² Page & Point is guaranteed from defect for a period of one year from date of purchase against faulty workmanship and materials.

Comforms with FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Nobo® is a registered trademark of Acco Brands Corporation. Microsoft Office® and Windows® are registered trademarks of Microsoft Corporation. Apple®, Macintosh® and Mac® are registered trademarks of Apple Corporation.



Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

