

# **Bluetooth Optical Mouse VM-1350**

## **Quick Start**

### **1. Power On/Off**

Sliding power switch at bottom of mouse to turn on/off VM-1350.

### **2. Pairing**

Press Connect button, and then Blue LED flash at mouse wheel. Now, VM-1350 is under pairing mode.

Step 1. Set VM-1350 under pairing mode

Step 2. Follow the pairing process of PC to search & pair with VM-1350

Step 3. After pairing is complete, VM-1350 will connect automatically. When VM-1350 is connected, Blue LED will off.

### **3. Connect**

To press any key or move mouse to connect to the paired PC when Bluetooth link is disconnect.

### **4. Sleep/Auto Disconnect**

VM-1350 will auto disconnect with PC, if no any action for a while.

### **5. LED indicator**

There is Blue LED under the mouse wheel. The LED will flash when pairing and low battery.

### **6. Low Battery**

If the Blue LED flash, it means low battery. Please prepare new battery.

## **Bluetooth Optical Mouse VM-1350**

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation of the device.

### **FCC RF Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.