



**VENCER Co., Ltd. 晶綸股份有限公司**

## Quick Guide of VR-2100

### **FCC Statement:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



***VENCER Co., Ltd.* 晶綸股份有限公司**

## **Quick Guide of VR-2100**

### **To turn the Plant on**

Press the button 3 seconds when power off. The Plant will power on and enter advertising mode automatically. Green LED will slow flash with 10 seconds.

### **To turn the Plant off**

Press the button 3 seconds when power on. The Plant will power off and stop advertising mode automatically. Green LED will fast flash 3 times.

### **Plant Low battery warning**

If battery voltage lower than 1.2 volts, the Red LED will slow flash around 10 seconds.

### **Data Storage**

VR-2100 provide temperature, humidity and sunshine data store, under normal operating the Plant lose connection with the APP, Plant will automatically record data per two hours, but at most retain 90 days data

When VR-2100 connection with APP, it will send stored data to APP, the APP received all data from Plant completed, the Plant stored data will be deleted.