

Wireless Optical Mouse User Manual


ped wireless RF mice in our company, and it uses the global-used frequency of 27MHz. The comfortable and e bondage of wires and enjoy your beautiful life from the high technology.



many mice being used at the same time.
and scientific.

charge for the mouse. Even if there is no battery in the mouse, you can use the mouse directly, thus it resolve

matically, at this time, mouse begin to work. If you push the receiver back to the transmitter, power will be cut




The Steps of Install Battery

- 1, Please prepare for two PCS new AAA alkaline batteries
- 2, Press the button of the mouse upper cover and pull the battery cover rearward (Please see the referenc
- 3, Please insert the batteries correctly according to the polarity marks of the battery grooves.
- 4, Pull the battery covers forward, when you hear "crack" sound which shows the battery cover is locked s

Receiver Installation

- 1, please use extended cable, and put the receiver and transmitter on one desktop, in this way, you may ha
- 2, If you use PS/2 connector, please use the USB to PS/2 adaptor and connect with the connector before yo
- 3, For laptop, you may connect the receiver directly with the USB connector.



ID Setup

- 1, Please move the mouse near to the receiver
- 2, Press the ID button of the mouse bottom with some hard and acuate object within 10 seconds, the rec
successfully to finish the digital transmission between the mouse and the receiver. You may start to use
- 3, Working distance: within 0.6-1.5 m

please change batteries or charge them. The mouse can use USB line to charge, connect one side of USB to the mouse, thus it can successfully charge the battery. It can charge while you use the mouse. It is full within 2 hours. The time of charge may vary when the degree of discharge is different.

more smoothly.
can be used longer time. Please remove the batteries if the mouse will not be used for a long time or if you travel

scroll the wheel to wake up the mouse when it is sleeping.
press the ID switch of the mouse bottom over 3 seconds. If you want to take on the power, please click the ID switch once again.
on a non-slip, textured surface, 3D mouse pad.
LED indicator flashes, which shows that the power is nearly finished. Please change the proper-sized new battery or charge it.
press the ID switch on business, and press the switch of ID for a long time so as to switch off the power.

Any changes or modifications not expressly approved by the party responsible for compliance could void the warranty.

Note

Note: This equipment has been tested and found to comply with the limits for a Class B digital device. It provides reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the interference can be eliminated by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.